

Bosch Dishwasher Quick Tips and Tricks



1

Use the 3rd rack for silverware, large utensils or other hard-to-place items.

2

Rackmatic® system lets you adjust rack height to accommodate taller items in the lower and middle racks. Simply pull out the middle rack, press the side levers, and adjust each side up or down.

3

Face dishes inward. Use angled tines to help with loading. Use fold down flip tines to help fit bulkier items like large pots.

4

Clean the dishwasher filter bi-monthly with normal use. Simply unscrew the knob and lift the filter out. Wash the filter by rinsing it with warm water and dishwashing soap.

5

Bosch recommends using Finish® detergent tabs and Jet-Dry® Rinse Aid for best results.



Other useful tips to get the most from your Bosch dishwasher:

- **With Bosch PrecisionWash®**, there is no need to pre-rinse—simply scrape food off and place dishes in the dishwasher.
- **Set your water heater temperature** between 120 and 125 degrees F. If too high, the soap will not activate and perform properly.
- **Start your dishwasher** by pressing the “On/Off” button and selecting a cycle and option if desired, and then press “Start”. Always ensure nothing is blocking the spray arms before starting a wash cycle.
- **All Bosch dishwashers use PureDry®**, with no exposed heating element for energy-efficient drying that is safe on plastics. PureDry® whisks moisture away from dishes as they cool, so you may see condensation on the tub walls, which is normal.
- **Clean dishwasher surfaces** with a damp cloth and mild soap. Do not use abrasives or bleach-based cleaners.

For complete product information, refer to the Use and Care Manual available online at: www.bosch-home.com/us/owner-support