

Your washing machine

Congratulations - You have opted for a modern, high-quality domestic appliance manufactured by Bosch. This washing machine is distinguished by its economical water and energy consumption. Each machine that leaves our factory has been inspected thoroughly to ensure that it functions properly and is in perfect condition.

Further information: www.bosch-home.com
You can find the contact details for your nearest after-sales service here or in the after-sales service directory (depending on model).
GB 0844 8928979
Calls from a BT landline will be charged at up to 3 pence per minute. A call set-up fee of up to 6 pence may apply.
IE 01450 2655
0.03 € per minute at peak. Off peak 0.0088 € per minute.

Environmentally friendly waste disposal

Dispose of packaging in an environmentally-responsible manner. This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Contents

Intended use	1
Programmes	1
Setting and adjusting the programme	3
Washing	3/4
After washing	4
Individual settings	5
Important information	6
Overview of programmes	7
Safety instructions	8
Consumption values	8
Care	9
Information on the display panel	9
Maintenance	10
What to do if ...	11

Protection of the environment/Conservation tips

- Always fill the washing machine with a maximum amount of laundry for the relevant programme.
- Wash normally soiled laundry without a pre-wash.
- The selectable temperatures apply to the care labels on the textiles. The temperatures in the machine may deviate from this so that you get the optimum mix of energy-saving and washing results.
- Measure the detergent according to the manufacturer's instructions and water hardness.
- If the laundry is then dried in the tumble dryer, select the spin speed according to the instructions of the dryer manufacturer.

Intended use

- for domestic use only,
- for washing machine-washable fabrics and hand-washable wool in detergent solution,
- to be operated with cold drinking water and commercially available detergents and care products which are suitable for use in washing machines.

- Do not leave children unattended near the washing machine.
- The washing machine is not to be used by children or persons not familiar with the operating instructions.
- Keep pets away from the washing machine.

Read these instructions and the separate installation instructions before operating the washing machine.

Programmes	
Detailed overview of programmes → page 7. Temperature and spin speed can be selected individually, irrespective of the selected programme and programme progress.	
Cottons	
Cottons Eco	hard-wearing fabrics
Delicate/Silk	delicate washable fabrics
Wool	hand/machine-washable wool
Easy-Care	easy-care fabrics
Dark Load	dark textiles
Rinse/Freshen Up	with subsequent spin cycle; for hand-washed items, starching or freshen up items → page 6.
Spin	laundry washed by hand
Gentle Spin	laundry washed by hand with a reduced spin speed
Drain	the rinsing water if (without final spin) occurs
Mixed Load	different types of laundry
Super 15	short programme
Sportswear	fabrics made from microfibre
Allergy Plus	hard-wearing fabrics

Preparation

Correct installation according to the separate Installation instructions.

Checking the machine

- Never use a damaged machine.
- Inform customer service.

Connecting the mains plug

- Make sure your hands are dry. Take hold of the plug only.

Turning the tap on

Sorting and loading laundry

Follow the manufacturer's care information. According to the information on the care labels. According to type, colour, soiling and temperature. Do not exceed the maximum load → page 7.

Observe the important information → page 6. Insert large and small items of laundry. Take care not to trap items of laundry between the washing machine door and the rubber seal.

Add detergent and care products

Measure accordingly: Amount of laundry, soiling, water hardness (ask your water supply company) and manufacturer's instructions. Pour liquid detergent into the appropriate dispenser and place in the drum.

Dilute viscous fabric softener and fabric conditioner with water. This prevents blockages.

Compartment II: Detergent for the main wash, water softener, bleach, stain remover

Compartment : Fabric softener, starch

Compartment I: Detergent for pre-wash

Additional functions

Display panel / options buttons

Start/Pause

Programme selector

**Additional functions and options buttons → Individual settings, page 5.

All buttons are sensitive and need only to be touched lightly. If the buttons are held for longer, the appliance automatically runs through the setting options.

Programme selector for switching the machine on and off and for selecting the programme. Can be turned in either direction.

Press **Start/Pause**

- 90 °C	Temp. °C	Select the temperature (= cold)
1 - 24h	Ready in	Programme end after
- 1100*	rpm	Select the spin speed (*depending on the model) or (with no final spin, laundry soaks in the last rinsing water, display panel - --)
Status displays		
Wash, rinse, spin, programme duration or end (-0-)		

Washing



Removing the washing

Open the washing machine door and remove the washing. If (without final spin) is active: Turn programme selector to **Drain** or select the spin speed. Choose **Start/Pause**.

- Remove any foreign objects - risk of rusting.
- Leave the washing machine door and detergent drawer open so that any residual water can evaporate.

Turning the tap off

Switching off

Turn the programme selector to **Off**.

End of programme when ...

... **Start/Pause** flashes and **-0-** appears on the display panel.

Interrupting the programme

Programmes at high temperatures:
– Cool washing: Select **Rinse/Freshen Up**. Washing machine door remains locked.
– Select **Off**.
– Select **Spin** or **Drain**.
– Select **Start/Pause**.

Changing the programme, if ...

... you have selected the wrong programme by mistake:
– Reselect the programme.
– Press **Start/Pause**. The new programme starts from the beginning.

Individual settings

Options buttons

You can change the spin speed and the temperature before the selected programme starts and while it is running. The effects depend on the programme progress.

Temp. °C (Temperature)

You can change the displayed washing temperature. The maximum selectable temperature depends on the current programme.

Ready in

When you select the programme, the relevant programme duration is displayed. You can delay the start of the programme before it begins. The Ready in-time can be set in increments of one hour up to a maximum of 24 hours. Press the **Ready in** button repeatedly until the required number of hours is displayed (h = hour). Choose **Start/Pause**.

rpm (spin speed in rpm / no final spin)

You can change the displayed spin speed. The maximum selectable spin speed depends on the model and on which programme is currently selected.

Additional functions → and overview of programmes, see page 7.

Intensive

Extension of the washing time for a more intensive washing of highly soiled washing or 7 kg of cottons and coloureds.

Prewash

For heavily soiled, hard-wearing washing, e.g. made of cotton or linen. Prewash at 30 °C.

Start/Pause

To start the programme or to subsequently load additional laundry, and to activate/deactivate the childproof lock.

Signal

1. Activating the mode for setting the signal volume

2. Setting the volume for ...

Important information

Protecting the laundry and the machine

- When determining the dosage of all washing powders, additives and cleaning agents, you must follow the manufacturer's instructions.
- Empty pockets.
- Look out for metal items (paperclips, etc.).
- Wash delicates in a laundry bag (tights, curtains, underwired bras).
- Fasten zips, do up any buttons.
- Brush sand out of pockets and collars.
- Remove curtain fittings or place in the laundry bag.

Laundry with varying degrees of soiling

Wash new items of clothing separately.

light		Do not pre-wash. If required, choose the additional function Intensive .
		Pre-treat any stains as necessary.
intense		Do not load as much laundry. Choose the Prewash additional function.

Soaking

Load laundry of the same colour.

Pour soaking agent/detergent into compartment **II** in accordance with the manufacturer's instructions. Turn the programme selector to **Cottons 30 °C** and press **Start/Pause**. After approx. 10 minutes, press **Start/Pause** to pause the programme. Once the required soaking time has elapsed, press **Start/Pause** again to continue the programme, or select a different programme.

Starch

Laundry should not be treated with fabric softener.

Starching is possible in all wash programmes if liquid starch is used. Pour the starch in accordance with the manufacturer's instructions into fabric softener compartment (rinse first if necessary).

Dye / Bleach

Dye should only be used in normal household quantities. Salt may damage stainless steel. Always follow the dye manufacturer's instructions! Do **not** use the washing machine for bleaching clothes!

Freshen Up

Use programme **Rinse/Freshen Up**.

For items, that have been tucked away or stored for a period of time, to remove creases caused by folding and storage and to eliminate odours. Use fabric conditioner for 'fresh' smell.

Programmes	°C	max.	Type of laundry	Additional functions; information
Cottons	* - 90 °C		Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen	
Cottons Stains	* - 60 °C			
Cottons Eco**	* - 60 °C	7 kg*		
Allergy Plus	* - 60 °C		Hard-wearing fabrics made of cotton or linen	
Easy-Care	* - 60 °C		Easy-care fabrics made of cotton, linen, synthetic fibres or blended fabrics	
Mixed Load	* - 40 °C	3 kg*	Fabrics made of cotton or easy-care fabrics	
Dark Load	* - 40 °C		Dark-coloured fabrics made of cotton and dark easy-care fabrics	
Delicate/Silk	* - 40 °C		For delicate, washable fabrics, e.g. made of silk, synthetic fibres or blended fabrics (e.g. curtains)	
Wool	* - 40 °C	2 kg	Hand- or machine-washable fabrics made of wool or containing wool	
Super 15*	* - 40 °C		Easy-care fabrics made of cotton, linen, synthetic fibres or blended fabrics	
Sportswear	* - 40 °C		Fabrics made from microfibre	
Additional programmes				
1	The programmes are time-controlled for lightly soiled textiles. If textiles are heavily soiled, reduce the load or select additional functions, e.g. Intensive . Programmes without Prewash - add detergent to compartment II , programmes with Prewash - distribute the detergent between compartments I and II . * When washing the maximum load for programmes marked with *, always select the Intensive additional function. Regardless of the type of washing, Easy-Care 40 °C with maximum spin speed is the best short programme for the job. ** The Cottons 40 °C Intensive , 1100 rpm programme is recommended for normal use.			

Robert Bosch Hausgeräte GmbH
Carl-Wery-Str. 34
81739 München / Germany

WAE22464AU ...



9407 / 9000904994

Safety instructions

- Read the instruction manual and installation instructions and all other information enclosed with the washing machine and act accordingly.
- Retain the documents for subsequent use.

Risk of electric shock

- Never pull the cable to disconnect the mains plug.
- Never insert/disconnect the mains plug with damp hands.

Danger to life

For worn-out appliances:

- Disconnect the mains plug.
- Sever the mains cable and discard along with the plug.
- Destroy the lock on the washing machine door. This will prevent children from locking themselves in and risking their lives.

Danger of suffocation

Risk of poisoning

Risk of explosion

- Keep packaging, film and packaging parts out of the reach of children.
- Keep detergents and care products out of the reach of children.
- Items of laundry pretreated with cleaning agents containing solvents, e.g. stain remover / cleaning solvent may lead to an explosion after being loaded into the washing machine. Rinse items of laundry thoroughly by hand beforehand.

Risk of injury

- The washing machine door can become very hot.
- Be careful when draining hot detergent solution.
- Do not climb onto the washing machine.
- Do not lean on the open washing machine door.
- Do not reach into the drum if it is still rotating.
- Be careful when opening the detergent drawer while the machine is in operation.

Programme	Additional function	Load	Electricity consumption**	Water**	Programme duration**
Cottons 40 °C	-	7 kg	0,48 kWh	68 l	2 h
Cottons 40 °C*	Intensive*	7 kg	0,73 kWh	72 l	4 h
Cottons 60 °C	-	7 kg	0,98 kWh	73 l	1 ¾ h
Cottons 60 °C	Intensive	7 kg	1,14 kWh	73 l	2 ½ h
Cottons 90 °C	-	7 kg	2,02 kWh	79 l	2 h
Cottons 90 °C	Intensive	7 kg	2,13 kWh	79 l	2 ¾ h
Easy-Care 40 °C	-	3 kg	0,54 kWh	40 l	1 h
Mixed Load 30 °C	-	3 kg	0,32 kWh	35 l	¾ h
Delicate/Silk 30 °C	-	2 kg	0,25 kWh	38 l	¾ h
Wool 30 °C	-	2 kg	0,15 kWh	34 l	¾ h

* Programme setting with maximum spin speed for testing according to or in accordance with AS/NZS 2040.2 and AS/NZS 6400.
Note on comparative tests: test the test programme with maximum load, **Intensive** additional function selected, maximum spin speed.
A **short programme** which can be used for coloured items is **Easy-Care 40 °C**, without the **Intensive** additional function selected and set to maximum spin speed.
** The values deviate from the indicated values depending on water pressure, hardness, and inlet temperature, ambient temperature, type, amount and soiling of the laundry, detergent used, fluctuations in the power supply and selected additional functions.

Care

Before washing for the first time

Do not load any laundry into the machine. Turn on the tap. Add the following to compartment **II**:

- approx. 1 litre water
- detergent (dosage according to the manufacturer's instructions for light soiling and the appropriate degree of water hardness)

Set the programme selector to **Easy-Care 60 °C** and select **Start/Pause**. At the end of the programme, turn the programme selector to **Off**.

Machine housing, control panel

- Wipe with a soft, damp cloth.
- Do not use any abrasive cloths, scourers or cleaning agents (stainless steel cleaners).
- Remove detergent and cleaning agent residue immediately.
- Do not clean with a jet of water.

Cleaning the detergent drawer and housing...

... if it contains detergent or fabric softener residues.

- Pull the drawer out, press down the insert and fully remove the drawer from the housing.
- To remove the insert: press the insert upwards from below with your finger.
- Clean the detergent dispenser tray and insert with water and a brush and dry it. Also remove any detergent or fabric softener residues in the housing.
- Attach the insert and engage (connect the cylinder to the guide pin).
- Push in the detergent drawer.

Leave the detergent drawer open so that any residual water can evaporate.

Washing drum and rubber seal

Wipe the inside of the rubber seal dry with a cloth. Leave the washing machine door open so that the drum can dry out. Rust stains - use chlorine-free cleaning agent, not steel wool.

Descaling *Ensure there is no laundry in the machine*

Descal the appliance according to the descaler manufacturer's instructions. This should not be necessary if the correct dosage of detergent is used.

Information on the display panel *depending on model*

F: 16 Close the washing machine door properly; laundry may be caught.

F: 17 Open the tap completely, supply hose kinked or trapped; Clean the filter → *page 10*, Water pressure too low.

F: 18 Detergent solution pump blocked; Clean the detergent solution pump → *page 10*. Drainage hose / waste pipe blocked; Clean the drainage hose at the siphon → *page 10*.

F: 21 Motor fault. Call customer services.

F: 23 Water in the base tub, appliance leaking. Call customer services.

Maintenance

Detergent solution pump

Turn the programme selector to **Off** and disconnect the mains plug.

- Open and remove the service flap.
- For models with a drainage hose:** Remove the drainage hose from the retainer and pull it from the housing. Remove the container. Remove the sealing cap, allow the detergent solution to flow out. Replace the sealing cap and place the drainage hose in the retainer.
- For models without a drainage hose:** Carefully unscrew the pump cover until the detergent solution begins to flow out. When the service flap is half full, close the pump cover and empty the service flap. Repeat the above steps until all the detergent solution has completely drained out.
- Carefully unscrew the pump cover (residual water).
- Clean the interior, pump cover thread and pump housing (the impeller in the detergent solution pump must rotate).
- Replace the pump cover and screw it tightly.
- Place the service flap back on and close.

To prevent unused detergent from flowing straight into the drain during the next wash: Pour 1 litre of water into compartment **II** and start the **Drain** programme.

Drainage hose at the siphon

Turn the programme selector to **Off** and disconnect the mains plug.

- Loosen the hose clamp, carefully remove the drainage hose (residual water).
- Clean the drainage hose and siphon connecting piece.
- Reattach the drainage hose and secure the connection with the hose clamp.

Filter in the water supply

Reduce the water pressure in the supply hose:

- Turn off the tap.
- Select any programme (apart from **Spin** / **Drain**).
- Choose **Start/Pause**. Let the programme run for approximately 40 seconds.
- Turn the programme selector to **Off**. Disconnect the mains plug.

Clean the filter:

- Depending on model:

Disconnect the hose from the tap. Clean the filter using a small brush.

and/or for Standard and Aqua-Secure models:

- Remove the hose on the rear of the appliance. Remove the filter with pliers and clean.
- Connect the hose and check for leaks.

What to do if ...

- Water is leaking out.
- No water supply. Detergent not dispensed.
- Washing machine door cannot be opened.
- Programme does not start.
- Detergent solution is not drained.
- Water not visible in the drum.
- Unsatisfactory spin result. Laundry wet/too damp.
- The programme duration changes during the wash cycle.
- Spin cycle performed several times.
- Residual water in the compartment for care products.
- Odour formation in the washing machine.
- Status display (Wash) flashes. Foam may be coming out of the detergent drawer.
- Intense noise formation, vibrations and "wandering" during the spin cycle.
- Noises during spin and drain cycles.
- Display panel/indicator lamps do not function during operation.
- Programme sequence longer than usual.
- Detergent residues on the laundry.

- Attach/replace the drainage hose correctly. Tighten the screw connection of the supply hose.
- Start/Pause** not selected? Tap not turned on? Filter blocked? Clean the filter → *page 10*. Supply hose kinked or trapped?
- Safety function active. Programme stopped? → *page 4*. (without final spin) selected? → *page 3, 4*. Can be opened by emergency release only? → *page 9*.
- Start/Pause** or **Ready** in time selected? Washing machine door closed? Childproof lock active? Deactivate → *page 5*.
- (without final spin) selected? → *page 3, 4*. Clean the detergent solution pump → *page 10*. Clean the waste pipe and/or drainage hose.
- Not a fault - water below the visible area.
- Not a fault - the unbalanced-load detection system has cancelled the spin cycle because of uneven distribution of the laundry. Distribute small and large items of laundry evenly inside the drum. Selected speed too low? → *page 5*.
- Not a fault - the programme sequence is optimised for the particular wash process. This may result in changes to the programme duration in the display field.
- Not a fault - unbalanced load detection system adjusts the imbalance.
- Not a fault - the action of the care product is not affected. Clean the insert if necessary → *page 9*.
- Run programme **Cottons 90 °C** without laundry. Use standard detergent.
- Too much detergent used? Mix 1 tablespoon of fabric softener with ½ litre of water and pour into dispenser **II** (not for outdoor and down-filled textiles!). Reduce the detergent dosage for the next wash cycle.
- Are the appliance feet fixed? Secure the appliance feet → *Installation instructions*. Transportation safety devices removed? Remove the transportation safety devices → *Installation instructions*.
- Clean detergent-solution pump → *page 10*.
- Power cut? Fuses triggered? Reset/change the fuse. If the fault occurs repeatedly, call customer services.
- Not a fault - unbalanced load detection system adjusts imbalance by repeatedly distributing the laundry. Not a fault - foam detection system active - adds an additional rinse cycle.
- Occasionally, phosphate-free detergents contain water-insoluble residues. Use the **Rinse/Freshen Up** or brush out the laundry after washing.

If you cannot correct a fault yourself (switching on/off) or a repair is required:

- Turn the programme selector to **Off** and remove the mains plug from the socket.
- Turn off the water supply and call customer services → *Installation instructions*.

Register your new Bosch now:
www.bosch-home.com/welcome

Washing machine
WAE22464AU ...

en operating instructions

Your washing machine

Congratulations - You have opted for a modern, high-quality domestic appliance manufactured by Bosch. This washing machine is distinguished by its economical water and energy consumption. Each machine that leaves our factory has been inspected thoroughly to ensure that it functions properly and is in perfect condition.

Further information: www.bosch-home.com
You can find the contact details for your nearest after-sales service here or in the after-sales service directory (depending on model).
GB 0844 8928979


Calls from a BT landline will be charged at up to 3 pence per minute. A call set-up fee of up to 6 pence may apply.
IE 01450 2655
0.03 € per minute at peak. Off peak 0.0088 € per minute.

Environmentally friendly waste disposal

Dispose of packaging in an environmentally-responsible manner.
This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE).
The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Contents


	Page
Intended use	1
Programmes	1
Setting and adjusting the programme	3
Washing	3/4
After washing	4
Individual settings	5
Important information	6
Overview of programmes	7
Safety instructions	8
Consumption values	8
Care	9
Information on the display panel	9
Maintenance	10
What to do if	11



Protection of the environment/Conservation tips

- Always fill the washing machine with a maximum amount of laundry for the relevant programme.
- Wash normally soiled laundry without a pre-wash.
- The selectable temperatures apply to the care labels on the textiles. The temperatures in the machine may deviate from this so that you get the optimum mix of energy-saving and washing results.
- Measure the detergent according to the manufacturer's instructions and water hardness.
- If the laundry is then dried in the tumble dryer, select the spin speed according to the instructions of the dryer manufacturer.

Intended use

- for domestic use only,
 - for washing machine-washable fabrics and hand-washable wool in detergent solution,
 - to be operated with cold drinking water and commercially available detergents and care products which are suitable for use in washing machines.
- 
 - Do not leave children unattended near the washing machine.
 - The washing machine is not to be used by children or persons not familiar with the operating instructions.
 - Keep pets away from the washing machine.



Read these instructions and the separate installation instructions before operating the washing machine.

Programmes

Detailed overview of programmes → page 7.
Temperature and spin speed can be selected individually, irrespective of the selected programme and programme progress.


	Cottons	
	Cottons Stains	hard-wearing fabrics
	Cottons Eco	
	Delicate/Silk	delicate washable fabrics
	Wool	hand/machine-washable wool
	Easy-Care	easy-care fabrics
	Dark Load	dark textiles
	Rinse/Freshen Up	with subsequent spin cycle; for hand-washed items, starching or freshen up items → page 6.
	Spin	laundry washed by hand
	Gentle Spin	laundry washed by hand with a reduced spin speed
	Drain	the rinsing water if (without final spin) occurs
	Mixed Load	different types of laundry
	Super 15'	short programme
	Sportswear	fabrics made from microfibre
	Allergy Plus	hard-wearing fabrics

Preparation

- 

Correct installation according to the separate Installation instructions.
- 

Checking the machine


 - Never use a damaged machine.
 - Inform customer service.
- 

Connecting the mains plug





Make sure your hands are dry. Take hold of the plug only.
- 

Turning the tap on




Compartment II: Detergent for the main wash, water softener, bleach, stain remover
Compartment ⌘: Fabric softener, starch
Compartment I: Detergent for pre-wash


Additional functions










Display panel / options buttons






Start/Pause



Programme sequence displays:



❄ - 90 °C	Temp. °C	Select the temperature (❄ = cold)
1 - 24h	Ready in	Programme end after
▽ - 1100*	rpm	Select the spin speed (*depending on the laundry soaks in the last rinsing water, c
Status displays		Programme sequence displays:
  		Wash, rinse, spin, programme duration

Before washing for the first time
Wash once without any laundry → page 9.

Sorting and loading laundry

Follow the manufacturer's care information. According to the information on the care labels. According to type, colour, soiling and temperature. Do not exceed the maximum load → page 7.

Observe the important information → page 6.

Insert large and small items of laundry.

Close the washing machine door. Take care not to trap items of laundry between the washing machine door and the rubber seal.

Add detergent and care products


Measure accordingly:

Amount of laundry, soiling, water hardness (ask your water supply company) and manufacturer's instructions. Pour liquid detergent into the appropriate dispenser and place in the drum.

i Dilute viscous fabric softener and fabric conditioner with water. This prevents blockages.

Setting** and adjusting programmes

Programme selector



i **Additional functions and options buttons → Individual settings, page 5.

i All buttons are sensitive and need only to be touched lightly. If the buttons are held for longer, the appliance automatically runs through the setting options.

Press **Start/Pause**

i Programme selector for switching the machine on and off and for selecting the programme. Can be turned in either direction.

Washing

Detergent drawer with compartments I, II, ♂

Drum

Control panel

Washing machine door

Service flap

Removing the washing

Open the washing machine door and remove the washing. If **Drain** (without final spin) is active: Turn programme selector to **Drain** or select the spin speed. Choose **Start/Pause**.

i – Remove any foreign objects - risk of rusting.
– Leave the washing machine door and detergent drawer open so that any residual water can evaporate.

Turning the tap off

Switching off

Turn the programme selector to **Off**.

End of programme when ...

... **Start/Pause** flashes and **-0-** appears on the display panel.

Interrupting the programme

Programmes at high temperatures:

- Cool washing: Select **Rinse/Freshen Up**. Washing machine door remains locked.
- Select **Off**.
- Select **Spin** or **Drain**.
- Select **Start/Pause**.

Changing the programme, if ...

... you have selected the wrong programme by mistake:

- Reselect the programme.
- Press **Start/Pause**. The new programme starts from the beginning.

Individual settings

Options buttons

You can change the spin speed and the temperature before the selected programme starts and while it is running. The effects depend on the programme progress.

Temp. °C (Temperature)

You can change the displayed washing temperature. The maximum selectable temperature depends on the current programme.

Ready in

When you select the programme, the relevant programme duration is displayed. You can delay the start of the programme before it begins. The Ready in-time can be set in increments of one hour up to a maximum of 24 hours. Press the **Ready in** button repeatedly until the required number of hours is displayed (h = hour). Choose **Start/Pause**.

rpm (spin speed in rpm / no final spin)

You can change the displayed spin speed. The maximum selectable spin speed depends on the model and on which programme is currently selected.

Additional functions → and overview of programmes, see page 7.

Intensive Extension of the washing time for a more intensive washing of highly soiled washing or 7 kg of cottons and coloureds.


Prewash For heavily soiled, hard-wearing washing, e.g. made of cotton or linen. Prewash at 30 °C.

Start/Pause

To start the programme or to subsequently load additional laundry, and to activate/deactivate the childproof lock.

Signal


1. Activating the mode for setting the signal volume



2. Setting the volume for ...



* you may need to select the function several times.



Important information



Protecting the laundry and the machine

- When determining the dosage of all washing powders, additives and cleaning agents, you must follow the manufacturer's instructions.
- Empty pockets.
- Look out for metal items (paperclips, etc.).
- Wash delicates in a laundry bag (tights, curtains, underwired bras).
- Fasten zips, do up any buttons.
- Brush sand out of pockets and collars.
- Remove curtain fittings or place in the laundry bag.



Laundry with varying degrees of soiling

light	Wash new items of clothing separately.
	Do not pre-wash. If required, choose the additional function Intensive .
	Pre-treat any stains as necessary.
intense	Do not load as much laundry. Choose the Prewash additional function.



Soaking

Load laundry of the same colour.

Pour soaking agent/detergent into compartment **II** in accordance with the manufacturer's instructions. Turn the programme selector to **Cottons 30 °C** and press **Start/Pause**. After approx. 10 minutes, press **Start/Pause** to pause the programme. Once the required soaking time has elapsed, press **Start/Pause** again to continue the programme, or select a different programme.



Starch

Laundry should not be treated with fabric softener.

Starching is possible in all wash programmes if liquid starch is used. Pour the starch in accordance with the manufacturer's instructions into fabric softener compartment **✳** (rinse first if necessary).



Dye / Bleach

Dye should only be used in normal household quantities. Salt may damage stainless steel. Always follow the dye manufacturer's instructions! Do **not** use the washing machine for bleaching clothes!



Freshen Up

Use programme **Rinse/Freshen Up**.

For items, that have been tucked away or stored for a period of time, to remove creases caused by folding and storage and to eliminate odours. Use fabric conditioner for 'fresh' smell.

	Cottons	- 90 °C		Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen	Intensive, Prewash
	Cottons Stains	- 60 °C			
	Cottons Eco**	- 60 °C	7 kg*	Hard-wearing fabrics made of cotton or linen	Intensive, Prewash;
	Allergy Plus	- 60 °C		Easy-care fabrics made of cotton, linen, synthetic fibres or blended fabrics	Intensive, Prewash;
	Easy-Care	- 60 °C			Intensive, Prewash
	Mixed Load	- 40 °C	3 kg*	Fabrics made of cotton or easy-care fabrics	Intensive, Prewash;
	Dark Load	- 40 °C		Dark-coloured fabrics made of cotton and dark easy-care fabrics	different types of laundry can be washed together
	Delicate/Silk	- 40 °C		For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. curtains)	Intensive, Prewash;
	Wool	- 40 °C	2 kg	Hand- or machine-washable fabrics made of wool or containing wool	Reduced rinse and final spin cycle
	Super 15'	- 40 °C		Easy-care fabrics made of cotton, linen, synthetic fibres or blended fabrics	Intensive, Prewash;
	Sportswear	- 40 °C		Fabrics made from microfibre	No spin between rinse cycles

Additional programmes

- i The programmes are time-controlled for lightly soiled textiles. If textiles are heavily soiled, reduce the load or select additional functions, e.g. **Intensive**.
Programmes without Prewash - add detergent to compartment **II**, programmes with Prewash - distribute the detergent between compartments **I** and **II**.
* When washing the maximum load for programmes marked with *, always select the **Intensive** additional function.
Regardless of the type of washing, **Easy-Care 40 °C** with maximum spin speed is the best short programme for the job.
** The **Cottons 40 °C** **Intensive**, **1100 rpm** programme is recommended for normal use.

9407 / 9000904994



WAE22464AU ...

Robert Bosch Hausgeräte GmbH
Carl-Wery-Str. 34
81739 München / Germany



Safety instructions

- Read the instruction manual and installation instructions and all other information enclosed with the washing machine and act accordingly.
- Retain the documents for subsequent use.

Risk of electric shock

- Never pull the cable to disconnect the mains plug.
- Never insert/disconnect the mains plug with damp hands.

Danger to life

For worn-out appliances:

- Disconnect the mains plug.
- Sever the mains cable and discard along with the plug.
- Destroy the lock on the washing machine door. This will prevent children from locking themselves in and risking their lives.

Danger of suffocation

Risk of poisoning

Risk of explosion

- Keep packaging, film and packaging parts out of the reach of children.
- Keep detergents and care products out of the reach of children.
- Items of laundry pretreated with cleaning agents containing solvents, e.g. stain remover / cleaning solvent may lead to an explosion after being loaded into the washing machine.
Rinse items of laundry thoroughly by hand beforehand.

Risk of injury

- The washing machine door can become very hot.
- Be careful when draining hot detergent solution.
- Do not climb onto the washing machine.
- Do not lean on the open washing machine door.
- Do not reach into the drum if it is still rotating.
- Be careful when opening the detergent drawer while the machine is in operation.

Consumption values

Programme	Additional function	Load	Electricity consumption**	Water**	Programme duration**
Cottons 40 °C	-	7 kg	0,48 kWh	68 l	2 h
Cottons 40 °C*	Intensive*	7 kg	0,73 kWh	72 l	4 h
Cottons 60 °C	-	7 kg	0,98 kWh	73 l	1 ¾ h
Cottons 60 °C	Intensive	7 kg	1,14 kWh	73 l	2 ½ h
Cottons 90 °C	-	7 kg	2,02 kWh	79 l	2 h
Cottons 90 °C	Intensive	7 kg	2,13 kWh	79 l	2 ¾ h
Easy-Care 40 °C	-	3 kg	0,54 kWh	40 l	1 h
Mixed Load 30 °C	-	3 kg	0,32 kWh	35 l	¾ h
Delicate/Silk 30 °C	-	2 kg	0,25 kWh	38 l	¾ h
Wool 30 °C	-	2 kg	0,15 kWh	34 l	¾ h

- * Programme setting with maximum spin speed for testing according to or in accordance with AS/NZS 2040.2 and AS/NZS 6400.
Note on comparative tests: test the test programme with maximum load, **Intensive** additional function selected, maximum spin speed.
A **short programme** which can be used for coloured items is **Easy-Care 40 °C**, without the **Intensive** additional function selected and set to maximum spin speed.
- ** The values deviate from the indicated values depending on water pressure, hardness, and inlet temperature, ambient temperature, type, amount and soiling of the laundry, detergent used, fluctuations in the power supply and selected additional functions.

Care



Before washing for the first time

Do not load any laundry into the machine. Turn on the tap.

Add the following to compartment **II**:

- approx. 1 litre water
- detergent (dosage according to the manufacturer's instructions for light soiling and the appropriate degree of water hardness)

Set the programme selector to **Easy-Care 60 °C** and select **Start/Pause**. At the end of the programme, turn the programme selector to **Off**.



Machine housing, control panel



- Wipe with a soft, damp cloth.
- Do not use any abrasive cloths, scourers or cleaning agents (stainless steel cleaners).
- Remove detergent and cleaning agent residue immediately.
- Do not clean with a jet of water.



Cleaning the detergent drawer and housing...

... if it contains detergent or fabric softener residues.

1. Pull the drawer out, press down the insert and fully remove the drawer from the housing.
2. To remove the insert: press the insert upwards from below with your finger.
3. Clean the detergent dispenser tray and insert with water and a brush and dry it. Also remove any detergent or fabric softener residues in the housing.
4. Attach the insert and engage (connect the cylinder to the guide pin).
5. Push in the detergent drawer.



Leave the detergent drawer open so that any residual water can evaporate.



Washing drum and rubber seal

Wipe the inside of the rubber seal dry with a cloth. Leave the washing machine door open so that the drum can dry out. Rust stains - use chlorine-free cleaning agent, not steel wool.



Descaling

Ensure there is no laundry in the machine

Descal the appliance according to the descaler manufacturer's instructions. This should not be necessary if the correct dosage of detergent is used.



- **Risk of electric shock.** Disconnect the mains plug.
- **Risk of explosion.** No solvents.

Maintenance






- **Risk of scalding.** Allow the detergent solution to cool down.
- Turn off the tap.



Detergent solution pump

Turn the programme selector to **Off** and disconnect the mains plug.

1. Open and remove the service flap.
2. **For models with a drainage hose:** Remove the drainage hose from the retainer and pull it from the housing. Remove the container. Remove the sealing cap, allow the detergent solution to flow out. Replace the sealing cap and place the drainage hose in the retainer.
- 2* **For models without a drainage hose:** Carefully unscrew the pump cover until the detergent solution begins to flow out. When the service flap is half full, close the pump cover and empty the service flap. Repeat the above steps until all the detergent solution has completely drained out.
3. Carefully unscrew the pump cover (residual water).
4. Clean the interior, pump cover thread and pump housing (the impeller in the detergent solution pump must rotate).
5. Replace the pump cover and screw it tightly.
6. Place the service flap back on and close.



To prevent unused detergent from flowing straight into the drain during the next wash: Pour 1 litre of water into compartment **II** and start the **Drain** programme.



Drainage hose at the siphon

Turn the programme selector to **Off** and disconnect the mains plug.


1. Loosen the hose clamp, carefully remove the drainage hose (residual water).
2. Clean the drainage hose and siphon connecting piece.
3. Reattach the drainage hose and secure the connection with the hose clamp.



Filter in the water supply

Reduce the water pressure in the supply hose:

1. Turn off the tap.
2. Select any programme (apart from **Spin** / **Drain**).
3. Choose **Start/Pause**. Let the programme run for approximately 40 seconds.
4. Turn the programme selector to **Off**. Disconnect the mains plug.




Clean the filter:

1. Depending on model:

Disconnect the hose from the tap.
Clean the filter using a small brush.

and/or for Standard and Aqua-Secure models:

- Remove the hose on the rear of the appliance, Remove the filter with pliers and clean.
2. Connect the hose and check for leaks.



Information on the display panel depending on model

F: 16	Close the washing machine door properly; laundry may be caught.
F: 17	Open the tap completely, supply hose kinked or trapped; Clean the filter → <i>page 10</i> , Water pressure too low.
F: 18	Detergent solution pump blocked; Clean the detergent solution pump → <i>page 10</i> . Drainage hose / waste pipe blocked; Clean the drainage hose at the siphon → <i>page 10</i> .
F: 21	Motor fault. Call customer services.
F: 23	Water in the base tub, appliance leaking. Call customer services.

What to do if ...

Water is leaking out.	<ul style="list-style-type: none"> – Attach/replace the drainage hose correctly. – Tighten the screw connection of the supply hose.
No water supply. Detergent not dispensed.	<ul style="list-style-type: none"> – Start/Pause not selected? – Tap not turned on? – Filter blocked? Clean the filter → <i>page 10</i>. – Supply hose kinked or trapped?
Washing machine door cannot be opened.	<ul style="list-style-type: none"> – Safety function active. Programme stopped? → <i>page 4</i>. – Start (without final spin) selected? → <i>page 3, 4</i>. – Can be opened by emergency release only? → <i>page 9</i>.
Programme does not start.	<ul style="list-style-type: none"> – Start/Pause or Ready in time selected? – Washing machine door closed? – Childproof lock active? Deactivate → <i>page 5</i>.
Detergent solution is not drained.	<ul style="list-style-type: none"> – Start (without final spin) selected? → <i>page 3, 4</i>. – Clean the detergent solution pump → <i>page 10</i>. – Clean the waste pipe and/or drainage hose.
Water not visible in the drum.	<ul style="list-style-type: none"> – Not a fault - water below the visible area.
Unsatisfactory spin result. Laundry wet/too damp.	<ul style="list-style-type: none"> – Not a fault - the unbalanced-load detection system has cancelled the spin cycle because of uneven distribution of the laundry. Distribute small and large items of laundry evenly inside the drum. – Selected speed too low? → <i>page 5</i>.
The programme duration changes during the wash cycle.	<ul style="list-style-type: none"> – Not a fault - the programme sequence is optimised for the particular wash process. This may result in changes to the programme duration in the display field.
Spin cycle performed several times.	<ul style="list-style-type: none"> – Not a fault - unbalanced load detection system adjusts the imbalance.
Residual water in the compartment for care products.	<ul style="list-style-type: none"> – Not a fault - the action of the care product is not affected. – Clean the insert if necessary → <i>page 9</i>.
Odour formation in the washing machine.	<ul style="list-style-type: none"> – Run programme Cottons 90 °C without laundry. Use standard detergent.
Status display Wash flashes. Foam may be coming out of the detergent drawer.	<ul style="list-style-type: none"> – Too much detergent used? Mix 1 tablespoon of fabric softener with ½ litre of water and pour into dispenser II (not for outdoor and down-filled textiles!). – Reduce the detergent dosage for the next wash cycle.
Intense noise formation, vibrations and “wandering” during the spin cycle.	<ul style="list-style-type: none"> – Are the appliance feet fixed? Secure the appliance feet → <i>Installation instructions</i>. – Transportation safety devices removed? Remove the transportation safety devices → <i>Installation instructions</i>.
Noises during spin and drain cycles.	<ul style="list-style-type: none"> – Clean detergent-solution pump → <i>page 10</i>.
Display panel/indicator lamps do not function during operation.	<ul style="list-style-type: none"> – Power cut? – Fuses triggered? Reset/change the fuse. – If the fault occurs repeatedly, call customer services.
Programme sequence longer than usual.	<ul style="list-style-type: none"> – Not a fault - unbalanced load detection system adjusts imbalance by repeatedly distributing the laundry. – Not a fault - foam detection system active - adds an additional rinse cycle.
Detergent residues on the laundry.	<ul style="list-style-type: none"> – Occasionally, phosphate-free detergents contain water-insoluble residues. – Use the Rinse/Freshen Up or brush out the laundry after washing.

If you cannot correct a fault yourself (switching on/off) or a repair is required:

- Turn the programme selector to **Off** and remove the mains plug from the socket.
- Turn off the water supply and call customer services → *Installation instructions*.



Register your new Bosch now:
www.bosch-home.com/welcome



**Washing machine
WAE22464AU ...**



en operating instructions