



Register your new Bosch now:
www.bosch-home.com/welcome



Microwave
HBC84H501B



BOSCH

[en] Instruction manual

en Table of contents

Important safety information	4	Tips for roasting and grilling.....	24
Causes of damage.....	6	Bakes, gratins, toast with toppings.....	24
Installation and connection	7	Convenience products, frozen.....	25
Your new appliance	7	Test dishes	25
Control panel.....	7		
Buttons.....	7		
Function selector.....	7		
Temperature selector.....	7		
Cooling fan.....	8		
Accessories.....	8		
Before using the appliance for the first time	8		
Setting the clock.....	8		
Heating up the oven.....	8		
Cleaning the accessories.....	8		
Setting the oven	9		
Setting the type of heating and temperature.....	9		
Rapid heating.....	9		
Automatic safety switch-off.....	9		
The microwave	9		
Notes regarding ovenware.....	9		
Microwave power settings.....	10		
Setting the microwave.....	10		
Combined oven and microwave operation	10		
Setting MicroCombi operation.....	10		
Automatic programmes	11		
Setting a programme.....	11		
Defrosting programmes.....	11		
Cooking programmes.....	12		
Combi cooking programmes.....	12		
Setting the time-setting options	12		
Setting the timer.....	12		
Setting the cooking time.....	13		
Setting the clock.....	13		
Childproof lock	14		
Switching on the childproof lock.....	14		
Switching off the childproof lock.....	14		
Childproof lock with automatic programmes.....	14		
Changing the basic settings	14		
Basic settings.....	14		
Care and cleaning	14		
Cleaning agents.....	15		
Malfunction table	15		
Malfunction table.....	15		
After-sales service	16		
E number and FD number.....	16		
Technical data.....	16		
Acrylamide in foodstuffs	17		
Energy and environment tips	17		
Saving energy.....	17		
Environmentally-friendly disposal.....	17		
Tested for you in our cooking studio	17		
Defrosting, heating up and cooking with the microwave.....	17		
Microwave tips.....	20		
Cakes and pastries.....	20		
Baking tips.....	21		
Roasting and grilling.....	22		

Additional information on products, accessories, replacement parts and services can be found at www.bosch-home.com and in the online shop www.bosch-eshop.com

Important safety information

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual for future use or for subsequent owners.

This appliance is only intended to be fully fitted in a kitchen. Observe the special installation instructions.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The appliance must be supervised during operation. Only use this appliance indoors.

This appliance is intended for use up to a maximum height of 4000 metres above sea level.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 8 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always insert the accessories into the cooking compartment correctly. See "*Description of accessories*" in the instruction manual.

Risk of fire!

- The appliance becomes very hot. If the appliance is installed in a fitted unit with a decorative door, heat will accumulate when the decorative door is closed. Only operate the appliance when the decorative door is open.
- Combustible items stored in the cooking compartment may catch fire. Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance and unplug it from the mains or switch off the circuit breaker in the fuse box.
- Using the appliance for anything other than its intended purpose is dangerous and may cause damage. The following is not permitted: drying out food or clothing, heating slippers, grain or cereal pillows, sponges, damp cleaning cloths or similar. For example, heated slippers and grain or cereal pillows may catch fire, even several hours after they have been heated. The appliance must only be used for the preparation of food and drinks.
- Food may catch fire. Never heat food in heat-retaining packages. Do not leave food heating unattended in containers made of plastic, paper or other combustible materials. Do not select a microwave power or time setting that is higher than necessary. Follow the information provided in this instruction manual. Never use the microwave to dry food. Never defrost or heat food with a low water content, e.g. bread, at too high a microwave power or for too long.
- Cooking oil may catch fire. Never use the microwave to heat cooking oil on its own.

Risk of explosion!

Liquids and other food may explode when in containers that have been tightly sealed. Never heat liquids or other food in containers that have been tightly sealed.

Risk of serious damage to health!

- The surface of the appliance may become damaged if it is not cleaned properly. Microwave energy may escape. Clean the appliance on a regular basis, and remove

any food residue immediately. Always keep the cooking compartment, door seal, door and door stop clean; see also section *Care and cleaning*.

- Microwave energy may escape if the cooking compartment door or the door seal is damaged. Never use the appliance if the cooking compartment door or the door seal is damaged. Contact the after-sales service.
- Microwave energy will escape from appliances that do not have any casing. Never remove the casing. For any maintenance or repair work, contact the after-sales service.

Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- Penetrating moisture may cause electric shock. Never subject the appliance to intense heat or humidity. Only use this appliance indoors.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.
- The appliance is a high-voltage appliance. Never remove the casing.

Risk of burns!

- The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.
- Accessories and ovenware become very hot. Always use oven gloves to remove

accessories or ovenware from the cooking compartment.

- Alcoholic vapours may catch fire in the hot cooking compartment. Never prepare food containing large quantities of drinks with a high alcohol content. Only use small quantities of drinks with a high alcohol content. Open the appliance door with care.
- Foods with peel or skin may burst or explode during, or even after, heating. Never cook eggs in their shells or reheat hard-boiled eggs. Never cook shellfish or crustaceans. Always prick the yolk when baking or poaching eggs. The skin of foods that have a peel or skin, such as apples, tomatoes, potatoes and sausages, may burst. Before heating, prick the peel or skin.
- Heat is not distributed evenly through baby food. Never heat baby food in closed containers. Always remove the lid or teat. Stir or shake well after the food has been heated. Check the temperature of the food before it is given to the child.
- Heated food gives off heat. The ovenware may become hot. Always use oven gloves to remove ovenware or accessories from the cooking compartment.
- Airtight packaging may burst when food is heated. Always observe the instructions on the packaging. Always use oven gloves to remove dishes from the cooking compartment.

Risk of scalding!

- When you open the appliance door, hot steam may escape. Open the appliance door with care. Keep children at a safe distance.
- Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.
- There is a possibility of delayed boiling when a liquid is heated. This means that the liquid reaches boiling temperature without the usual steam bubbles rising to the surface. Even if the container only vibrates a little, the hot liquid may suddenly boil over and spatter. When heating, always place a spoon in the container. This will prevent delayed boiling.

Risk of injury!

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- Unsuitable ovenware may crack. Porcelain or ceramic ovenware can have small perforations in the handles or lids. These perforations conceal a cavity below. Any moisture that penetrates this cavity could cause the ovenware to crack. Only use microwave-safe ovenware.
- If using the appliance in microwave mode only, placing cookware and containers made of metal inside the appliance may cause sparks when the appliance is operating. This will damage the appliance. Never use metal containers when using the appliance in microwave mode only. Use only microwave-safe cookware or, alternatively, the microwave in combination with a type of heating.

Causes of damage

Caution!

- Creation of sparks: Metal - e.g. a spoon in a glass - must be kept at least 2 cm from the oven walls and the inside of the door. Sparks could irreparably damage the glass on the inside of the door.
- Water in the hot cooking compartment: Never pour water into the hot cooking compartment. This will cause steam. The temperature change can cause damage.
- Moist food: Do not store moist food in the closed cooking compartment for long periods. Do not use the appliance to store food. This can lead to corrosion.
- Cooling with the appliance door open: Only leave the cooking compartment to cool with the door closed. Do not trap anything in the appliance door. Even if the door is only slightly ajar, the fronts of adjacent units may be damaged over time.
- Heavily soiled seal: If the seal is very dirty, the appliance door will no longer close properly during operation. The fronts of adjacent units could be damaged. Always keep the seal clean.
- Operating the microwave without food: Operating the appliance without food in the cooking compartment may lead to overloading. Never switch on the appliance unless there is food in the cooking compartment. An exception to this rule is a short crockery test (see the section "Microwave, suitable crockery").
- Using the appliance door for standing on or placing objects on: Do not stand or place anything on the open appliance door. Do not place ovenware or accessories on the appliance door.
- Transporting the appliance: Do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.
- Microwave popcorn: Never set the microwave power too high. Use a power setting no higher than 600 watts. Always place the popcorn bag on a glass plate. The disc may jump if overloaded.
- Liquid that has boiled over must not be allowed to run through the turntable drive into the interior of the appliance. Monitor the cooking process. Choose a shorter cooking time initially, and increase the cooking time as required.
- Never use the microwave oven without the turntable.

Installation and connection

Please observe the special installation instructions.

The appliance is fitted with a plug and must only be connected to a properly-installed earthed socket. The fuse protection must be rated at 16 amperes (L or B circuit breakers). The mains voltage must correspond to the voltage specified on the rating plate.

The socket must be installed and the power cable replaced by a qualified electrician only. If the plug is no longer accessible following installation, an all-pin disconnecting device must be present on the installation side, with a contact gap of at least 3 mm.

Multiple plugs, plug bars and extension leads must not be used. Overloading can result in a risk of fire.

Your new appliance

Use this section to familiarise yourself with your new appliance. The control panel and the individual operating controls are explained. You will find information on the cooking compartment and the accessories.

Control panel



Buttons

You can use the buttons to set various functions. On the display, you can read the values that you have set.

Symbol	Button function
90	Selects 90 watt microwave power
180	Selects 180 watt microwave power
360	Selects 360 watt microwave power
600	Selects 600 watt microwave power
900	Selects 900 watt microwave power
>>>>	Selects rapid heating
kg	Selects the weight
⌚	Opens and closes the time-setting options menu
🔑	Selects childproof lock
-Minus	Decreases the adjustment values
+Plus	Increases the adjustment values
▶	Press briefly: starts/stops operation Press and hold: cancels operation

Function selector

Use the function selector to set the type of heating.

Setting	Use
0	Off position The oven is switched off.
🔥	Microwave Selects microwave operation.
🍷	Hot air For baking sponge cakes in baking tins, flans and cheesecakes as well as cakes, pizza and small baked items on the baking tray.

Setting	Use
🍷	Hot air grilling Poultry goes brown and crispy. Baked casseroles and grilled dishes work out best using this setting.
🍷	Pizza setting For frozen convenience products and dishes which require a lot of heat from underneath.
🔥	Grill Select between the levels high, medium or low. This is ideal if you wish to grill several steaks, sausages, pieces of fish or slices of bread.
P	Programmes 4 defrosting programmes 11 cooking programmes The type of heating and cooking time are set by weight.

Notes

- When you make settings, the indicator lamp above the function selector lights up.
- When you press the ▶|| button, the oven light switches on in the cooking compartment.

Temperature selector

The temperature selector is used to set the temperature or grill setting.

Setting	Use
●	Off position The oven does not heat up.
50, 100-230	Temperature range Temperature in °C
1, 2, 3	Grill settings 1 = low 2 = medium 3 = high

Cooling fan

Your appliance has a cooling fan. The cooling fan switches on during operation. The hot air escapes above the door.




The cooling fan continues to run for a certain time after operation.

Caution!

Do not cover the ventilation slots. Otherwise, the appliance will overheat.

Notes

- The appliance remains cool during microwave operation. The cooling fan will still switch on. The fan may run on even when microwave operation has ended.



- Condensation may appear on the door window, interior walls and floor. This is normal and does not adversely affect microwave operation. Wipe away the condensation after cooking.

Accessories

Caution!

When removing dishes, make sure that the turntable does not move. Make sure that the turntable is properly locked. The turntable can turn left or right.

Turntable

As a surface for the wire rack.

Food which particularly requires a lot of heat from underneath can be prepared directly on the turntable.

The turntable can turn clockwise or anti-clockwise, and is cut resistant. You can cut pizza into slices on the turntable itself.

- Never use the microwave without the turntable.
- The turntable can withstand max. 5 kg.
- The turntable must turn when using all types of heating.

Lower wire rack

For the microwave and for baking and roasting in the oven.

Higher wire rack

For grilling, e.g. steaks, sausages and for toasting bread.

As a support for shallow dishes.

Fitting the turntable

As shown in the figure, place the turntable with rollers "A", onto the turntable drive coupling "B" in the centre of the cooking compartment floor.

The turntable must sit straight on the driver.

Before using the appliance for the first time

Here you will find everything you need to do before using your oven to prepare food for the first time. First read the section on *Safety information*.

Setting the clock

Once the appliance is connected, three zeros and the ► ⌚ symbols light up in the display. Set the clock.

1. Press the + or - button.
Default value +: 12:00
Default value -: 23:59
2. Use the + or - button to set the clock.
3. Press the ⌚ button.
The time is set.

Note: In order to reduce the energy consumption of your appliance in standby, you can hide the clock. Read about this in the *Changing basic settings* section.

Heating up the oven

To remove the new cooker smell, heat up the oven when it is empty and closed. One hour with Hot air at 180 °C is ideal. Ensure that no packaging remnants have been left in the cooking compartment.

1. Use the function selector to set Hot air.
2. Set the temperature to 180 °C using the temperature selector.
3. Press the button.
The oven begins to heat up.

After an hour, switch off the oven. To switch off, turn the function selector to the off position.


Cleaning the accessories

Before you use the accessories for the first time, clean them thoroughly with hot soapy water and a soft dish cloth.


Setting the oven

There are various ways in which you can set your oven. Here we will explain how you can select the desired type of heating and temperature or grill setting. You can also select the oven cooking time for your dish. Please refer to the section on *Setting the time-setting options*.


Setting the type of heating and temperature

Example in diagram:  Hot air at 200 °C.

1. Use the function selector to set the type of heating.




2. Use the temperature selector to set the temperature or grill setting.





3. Press the  button.

The oven begins to heat up.

Opening the oven door during operation

Operation is suspended. After closing the door, press the  button. Operation will then continue.

Pausing operation

Press the  button to pause operation. Press the  button to continue operation.

Switching off the oven

Turn the function selector to the off position.




Changing the settings

The type of heating and temperature or grill setting can be changed at any time using their respective selectors.

Rapid heating


With rapid heating, your oven reaches the set temperature particularly quickly.

Use the rapid heating function when temperatures above 100 °C are set. Rapid heating is available for the following types of heating:

-  Hot air
-  Pizza setting
-  Hot air grilling

To ensure an even cooking result, only put your food in the cooking compartment when the rapid heating phase is complete.

1. Setting the type of heating and temperature.


2. Press the  button.

The  symbol lights up in the display.



3. Press the  button.

The oven begins to heat up.

The rapid heating process is complete

A signal sounds. The  symbol in the display goes out. Put your dish in the oven.


Cancelling rapid heating

Press the  button. The  symbol in the display goes out.

Automatic safety switch-off

The automatic safety switch-off is activated if your appliance is operating for a long time with no cooking time having been set. The time at which your appliance switches itself off depends on the set operating mode and temperature.

Example: If your oven is operating with Hot air at 160 °C, it will automatically switch off after approx. 5 hours.

 appears in the display panel. The appliance switches off. To acknowledge, press the  button.

The microwave

Microwaves are converted to heat in foodstuffs. The microwave can be used solo, i.e. on its own, or in combination with a different type of heating. You will find information about ovenware and how to set the microwave.

Note:

In the *Tested for you in our cooking studio* section, you will find examples for defrosting, heating and cooking with the microwave oven.

Notes regarding ovenware

Suitable ovenware

Suitable dishes are heat-resistant ovenware made of glass, glass ceramic, porcelain, ceramic or heat-resistant plastic. These materials allow microwaves to pass through.

You can also use serving dishes. This saves you having to transfer food from one dish to another. You should only use ovenware with decorative gold or silver trim if the manufacturer guarantees that they are suitable for use in microwaves.

Unsuitable ovenware

Metal ovenware is unsuitable. Metal does not allow microwaves to pass through. Food in covered metal containers will remain cold.

Caution!

Creation of sparks: metal – e.g. a spoon in a glass – must be kept at least 2 cm from the oven walls and the inside of the door. Sparks could destroy the glass on the inside of the door.

Ovenware test

Do not switch on the microwave unless there is food inside. The following ovenware test is the only exception to this rule.

Perform the following test if you are unsure whether your ovenware is suitable for use in the microwave:

1. Heat the empty ovenware at maximum power for ½ to 1 minute.

2. Check the temperature occasionally during that time.

The ovenware should still be cold or warm to the touch.

The ovenware is unsuitable if it becomes hot or sparks are generated.

Microwave power settings

Use the button to set the desired microwave power.


90 W	for defrosting delicate foods
180 W	for defrosting and continued cooking
360 W	for cooking meat and heating delicate foods
600 W	for heating and cooking food
900 watts	for heating liquids

Notes

- When you press a button, the selected power lights up.
- The microwave power can be set to 900 watts for a maximum of 30 minutes. With all other power settings a maximum cooking time of 1 hour 30 minutes is possible.

Setting the microwave

Example: Microwave power 600W, cooking time 17 minutes.


1. Set the function selector to .
2. Press the button for the microwave power setting you require. The 600 W power level lights up and a suggested cooking time is displayed.

3. Use the + or – button to set the cooking time.


4. Press the  button.

Operation begins. The cooking time starts counting down.

The cooking time has elapsed

A signal sounds. Microwave operation has finished. Turn the function selector to the zero position. You can stop the audible signal by pressing the .

Opening the oven door during cooking

Operation is suspended. After closing the door, press the  button briefly. The programme will then continue.



Changing the cooking time

This can be done at any time. Use the + or – button to change the cooking time.


Changing the microwave power setting

Press the button for the new microwave power setting. Use the + or – button to set the cooking time and restart the microwave.


Pausing operation

Press the  button to pause operation. Press the  button to continue operation.

Cancelling operation

Press and hold the  button for approximately 4 seconds and turn the function selector to the off position.

Notes

- When you set the function selector to , the highest microwave power setting always lights up as the suggested setting.
- If you open the appliance door during cooking, the fan may continue to run.


Combined oven and microwave operation


Use the microwave at the same time as an oven operating mode. The food becomes crispy and brown just as in the oven, but more quickly.

You can combine all microwave power settings up to 600 W with the oven operating modes.

Observe the instructions on ovenware in the *Microwave* section.


Setting MicroCombi operation

Example: Microwave 360 W, 17 minutes and  Hot air 190 °C.


1. Set the type of heating using the function selector, and the temperature using the temperature selector.
2. Press the button for the microwave power setting you require. A suggested cooking time appears.
3. Use the + or – button to set the cooking time.
4. Press the  button.

Operation begins. The cooking time starts counting down in the display.



The cooking time has elapsed

A signal sounds. Combination mode has finished. You can stop the audible signal by pressing the .

Opening the oven door during cooking

Operation is suspended. After closing the door, press the  button briefly. The programme will then continue.

Pausing operation

Press the  button briefly. The oven is paused. Press the  button again to continue operation.


Changing the cooking time

This can be done at any time. Use the + or – button to change the cooking time.

Changing the microwave power setting

Press the button for the new microwave power setting. Use the + or – button to set the cooking time and restart the microwave.

Cancelling operation

Press and hold the  button for approximately 4 seconds and turn the function selector back to the off position.

Automatic programmes


The automatic programmes enable you to prepare food very easily. You select the programme and enter the weight of your food. The automatic programme makes the optimum setting. You can choose from 15 programmes.


Always place the food in the cold cooking compartment.

Setting a programme

When you have selected a programme, set the oven. The temperature selector must be in the off position.

Example in diagram: Programme 2 with a weight of 1 kilogramme.

1. Set the function selector to automatic programmes . The first programme number appears in the display.




2. Use the **+** or **-** button to select the programme number.






3. Press the **kg** button. The weight suggestion 0.50 kg appears in the display.




4. Use the **+** or **-** button to set the weight.



5. Press the  button. The programme starts. You can see the cooking time counting down and the  and  symbols appear.

The programme has finished


An audible signal sounds. The programme has finished and the oven stops heating.

Press the  button and turn the function selector to the off position.


Changing the programme

Once you have started the programme, the programme number and weight cannot be changed.



Switching off the signal early

Press the  button.


Opening the oven door during cooking

Operation is suspended. After closing the door, press the  button briefly. The programme will then continue.

Pausing operation

Press the  button briefly. The oven is paused. Press the  button again to continue operation.

Cancelling the programme

Press and hold the  button for approximately 4 seconds and turn the function selector to the zero position. The oven switches off.

Changing the cooking time and end time

If using automatic programmes, you cannot change the cooking time or end time.

Defrosting programmes

You can use the 4 defrosting programmes to defrost meat, poultry and bread.

Notes

■ Preparing food

Use food that has been frozen at $-18\text{ }^{\circ}\text{C}$ and stored in portion-sized quantities that are as thin as possible.

Take the food to be defrosted out of all packaging and weigh it. You need to know the weight to set the programme.

- Liquid will be produced when defrosting meat or poultry. Drain off this liquid when turning meat and poultry and under no circumstances use it for other purposes or allow it to come into contact with other foods.

■ Ovenware

Place the food in a microwaveable shallow dish, e.g. a china or glass plate, but do not cover.

- When defrosting chicken and chicken portions (P03), an audible signal will sound on two occasions to indicate that the food should be turned.

■ Resting time

The defrosted food should be left to stand for an additional 10 to 30 minutes until it reaches an even temperature. Large pieces of meat require a longer standing time than smaller pieces. Flat pieces of meat and items made from minced meat should be separated from each other before leaving to stand.

After this time, you can continue to prepare the food, even though thick pieces of meat may still be frozen in the middle. The giblets can be removed from poultry at this point.

Programme no.	Weight range in kg	
Defrost		
P 01	Minced meat	0.20 - 1.00
P 02	Pieces of meat	0.20 - 1.00
P 03	Chicken, chicken pieces	0.40 - 1.80
P 04	Bread	0.20 - 1.00

Cooking programmes

With the 3 cooking programmes, you can cook rice, potatoes or vegetables.

Notes

■ Preparing food

Weigh out the food. You need to know the weight to set the programme.

■ Ovenware

Generally, the food must be cooked in microwaveable ovenware with a lid. For rice, you should use a large, deep dish. Place the ovenware on the lower wire rack.

Rice (P05)

Note: Do not use boil-in-the-bag rice. Rice foams a lot during cooking. Enter the uncooked weight (without liquid). Add two to two and a half times the amount of liquid to the rice.

Potatoes (P06)

Note: Boiled potatoes:

Cut into pieces of equal size. Add a little salt and 1 tablespoon of water for every 100 g of potatoes.

Vegetables (P07)

Notes

■ Fresh vegetables:

Cut into pieces of equal size. Add 1 tablespoon of water for every 100 g of vegetables.

■ Resting time

Once the programme has finished, stir the food again. You should leave it to stand for another 5-10 minutes until it reaches an even temperature.

The cooking result will depend on the quality and consistency of the food.

Programme no.	Weight range in kg	
Cooking		
05	Rice	0.05 - 0.20
06	Potato	0.15 - 1.00
07	Vegetables	0.15 - 1.00

Combi cooking programmes

Notes

■ Take the food out of its packaging and weigh it. If it is not possible to enter the exact weight, you should round it up or down.

■ Ovenware

Cook the food in ovenware which is not too big, and is heat-resistant and microwaveable. Place the ovenware on the lower wire rack.

Lamb, medium (P12)

Ideal for a shoulder joint or boned leg of lamb.

Meat loaf (P13)

The programme is suitable for meat loaves not more than 7 cm in height.

Fish, whole (P14)

Scale the fish beforehand. Place the fish in the ovenware in its swimming position.

Rice stew (P15)

Only enter the weight of the rice. Ideal for rice stews with vegetables, fish or poultry. Only use fresh ingredients. Use a high-sided dish with a lid.






Resting time

Once the programme has finished, the food should be allowed to rest for another approx. 5-10 minutes so it reaches an even temperature.

Programme no.	Weight range in kg	
Combi-cooking		
08	Bake, frozen* (up to 3 cm in height)	0.40 - 1.20
09	Chicken, whole*	0.50 - 2.00
10	Sirloin, medium*	0.50 - 1.50
11	Pork neck joint	0.50 - 2.00
12	Lamb, medium	0.80 - 2.00
13	Meat loaf*	0.50 - 1.50
14	Fish, whole	0.30 - 1.00
15	Rice stew using fresh ingredients	0.05 - 0.20

* Use ovenware without a lid



Setting the time-setting options



Your oven has various time-setting options. You can use the  button to call up the menu and switch between the individual functions. As long as the symbols are lit, you can make settings. The  arrow shows you the time-setting option that is active. A time-setting option that has already been set can be changed directly with the  or  button when the  arrow is next to the relevant time symbol.

Setting the timer


You can use the timer as a kitchen timer. It runs independently of the oven. The timer has its own audible signal. In this way, you can tell whether it is the timer or a cooking time which has elapsed.



1. Press the  button once.

The time symbols light up in the display and the  arrow is next to .


2. Use the  or  button to set the timer duration.

Default value for  button = 10 minutes

Default value for  button = 5 minutes

After a few seconds, the time setting is adopted. The timer starts. The   symbol lights up in the display and the timer duration counts down. The other time symbols go out.

The timer duration has elapsed

A signal sounds. 0:00 is shown in the display. Use the  button to switch off the timer.



Changing the timer duration





Use the **+** or **-** button to change the timer duration. After a few seconds, the change is adopted.

Cancelling the timer duration

Use the **-** button to reset the timer duration to 0:00. The change will be adopted after a few seconds. The timer is switched off.

Checking the time settings




If several time-setting options are set, the corresponding symbols are illuminated on the display. The timer counts down in the foreground. The  symbol is preceded by the  arrow and the timer can be seen counting down.

To check the ,  cooking time or  clock, press the  button repeatedly until the arrow points to the appropriate symbol. The value is shown for a few seconds on the display.

Setting the cooking time

The cooking time for your meal can be set on the oven. When the cooking time has elapsed, the oven switches itself off automatically. This means that you do not have to interrupt other work to switch off the oven. The cooking time cannot be accidentally exceeded.

Example in the diagram: Cooking time 45 minutes.


1. Use the function selector to set the type of heating.
2. The temperature selector is used to set the temperature or grill setting.
3. Press the  button twice.
20:00 is shown in the display. The time symbols light up and the arrow  is next to .




4. Use the **+** or **-** button to set the cooking time.




5. Press the  button.

The oven starts. The cooking time counts down in the display and the  symbol lights up. The other time symbols go out.


The cooking time has elapsed

An audible signal sounds. The oven stops heating. 0:00 is shown in the display. Press the  button. The audible signal stops. Turn the function selector to the off position. The oven is switched off.


Changing the cooking time






Use the **+** or **-** button to change the cooking time. After a few seconds, the change is adopted. If the timer has been set, press the  button beforehand.

Cancelling the cooking time



Use the **-** button to reset the cooking time to 0:00. After a few seconds, the change is adopted. The cooking time is cancelled. If the timer has been set, press the  button beforehand.


Checking the time settings

If several time-setting options are set, the corresponding symbols are illuminated on the display. The  arrow is next to the symbol for time function which is currently visible on the display.

To check the ,  cooking time or  clock, press the  button repeatedly until the  arrow points to the appropriate symbol. The display shows the value for a few seconds.




Setting the clock

When the appliance has been connected to the power supply, or after a power cut, the   symbols and three zeros light up in the display. Set the clock.

1. Press the **+** or **-** button.
Default value **+**: 12:00
Default value **-**: 23:59
2. Use the **+** or **-** button to set the clock.
3. Press the  button. The time is set.

Changing the clock

Prerequisite: your appliance must be switched off.

1. Press the  button twice.
The time symbols light up in the display, the  arrow is next to the  symbol.
2. Use the **+** or **-** button to change the clock.
After a few seconds, the time that has been set is adopted.

Hiding the clock

You can hide the clock. For more information, please refer to the section *Changing the basic settings*.

Childproof lock


The oven has a childproof lock to prevent children switching it on accidentally.

The oven will not react to any settings. The timer and clock can also be set when the childproof lock has been switched on.

Switching on the childproof lock


Requirement: No cooking time should be set and the function selector is in the off position.

Press and hold the  button for approx. four seconds.

The  symbol appears in the display. The childproof lock is activated.

Switching off the childproof lock

Press and hold the  button for approx. four seconds.

The  symbol on the display goes out. The childproof lock is deactivated.

Childproof lock with automatic programmes




















When automatic programmes have been set, the childproof lock is not operational.

Changing the basic settings




Your appliance has various basic settings which you can change at any time.






Basic settings

In the table, you will find all the basic settings and options for changing them.

Basic setting	Options	Explanation
  Clock display  = on	Clock display  = off	Displays the clock
  Signal duration  = medium = 2 minutes	 = short = 10 seconds  = long = 5 minutes	Audible signal after the cooking time has elapsed
  Signal volume  = medium	 = low  = high	Volume of the signal
  Waiting time  = medium = 5 seconds	 = short = 2 seconds  = long = 10 seconds	Waiting time between two separate steps, after setting

Requirement: Your appliance is switched off.

1. Press and hold the  button for several seconds.
The first basic setting appears in the display.
2. Use the  or  button to change the basic setting.

3. Confirm by pressing the  button.
The next basic setting appears in the display. You can go through all of the basic settings using the  button and make changes using the  or  button.
4. When finished, press and hold the  button for several seconds.
All settings are applied.

You can change the settings at any time.

Care and cleaning

With careful care and cleaning your microwave oven will retain its looks and remain good order. We will explain here how you should care for and clean your appliance correctly.

Risk of electric shock!

Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.

Risk of burns!

Never clean the appliance immediately after switching off. Let the appliance cool down.

Risk of serious damage to health!

Microwave energy may escape if the cooking compartment door or the door seal is damaged. Never use the appliance if

the cooking compartment door or the door seal is damaged. Contact the after-sales service.

Notes

- Slight differences in colour on the front of the appliance are caused by the use of different materials, such as glass, plastic and metal.
- Shadows on the door panel which look like streaks, are caused by reflections made by the oven light.
- Unpleasant odours, e.g. after fish has been prepared, can be removed very easily. Add a few drops of lemon juice to a cup of water. Place a spoon into the container as well, to prevent delayed boiling. Heat the water for 1 to 2 minutes at maximum microwave power.

Cleaning agents

To ensure that the different surfaces are not damaged by using the wrong cleaning agent, observe the information in the table. Do not use:

- Harsh or abrasive cleaning agents.
- Metal or glass scrapers to clean the glass in the appliance door.
- Metal or glass scrapers to clean the door seal.
- Hard scouring pads or sponges.
- Cleaning agents with a high alcohol content.

Wash new sponge cloths thoroughly before use.

Allow surfaces to dry thoroughly before operating the appliance again.

Area	Cleaning agents
Appliance front	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Do not use glass cleaners or metal or glass scrapers for cleaning.
Appliance front with stainless steel	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under such flecks. Special stainless-steel cleaning agents are available from the after-sales service or from specialist retailers. Do not use glass cleaners or metal or glass scrapers for cleaning.

Area	Cleaning agents
Cooking compartment	Hot soapy water or a vinegar solution: Clean with a dish cloth and then dry with a soft cloth. For stubborn dirt: Do not use oven spray or any other aggressive oven cleaners or abrasive materials. Scouring pads, rough sponges and pan cleaners are also unsuitable. These items scratch the surface. Allow the interior surfaces to dry thoroughly.
Cleaning aids for the cooking compartment	Cup filled with washing-up liquid solution: Add a few drops of washing-up liquid to a cup of water. Place a spoon into the container as well to prevent delayed boiling. Heat the water for 2 minutes at maximum microwave output. Switch off the appliance and leave the container to stand in the cooking compartment with the door closed for another 5 minutes. Then wipe around the cooking compartment using a soft cloth and allow it to dry thoroughly.
Indentation in the cooking compartment	Damp cloth: Water must not penetrate the appliance through the turntable drive.
Wire racks	Hot soapy water: Clean using stainless-steel cleaner or clean in the dishwasher.
Door panels	Glass cleaner: Clean with a dish cloth. Do not use a glass scraper.
Seal	Hot soapy water: Clean with a dish cloth and do not scour. Do not use metal or glass scrapers for cleaning.

Malfunction table




Malfunctions often have simple explanations. Please refer to the malfunction table before calling the after-sales service.




If a meal does not turn out exactly as you wanted, refer to the *Tested for you in our cooking studio* section, where you will find plenty of cooking tips and tricks.

Risk of electric shock!

Incorrect repairs are dangerous. Repairs may only be carried out by one of our trained after-sales engineers.

Malfunction table

Problem	Possible cause	Remedy/information
The appliance does not work.	Faulty circuit breaker.	Look in the fuse box and check that the circuit breaker for the appliance is in working order.
	Plug not plugged in.	Plug in the plug.
	Power cut	Check whether the kitchen light works.
The appliance does not work.  appears in the display panel.	Childproof lock is active.	Deactivate the childproof lock (see section: Childproof lock).
 and  are in the display panel.	Power cut	Reset the clock.
The microwave does not switch on.	Door not fully closed.	Check whether food residue or debris is trapped in the door.

Problem	Possible cause	Remedy/information
It takes longer than before for the food to heat up in the microwave	The selected microwave power level is too low.	Select a higher power level.
	A larger amount than usual has been placed in the appliance.	Double the amount = almost double the cooking time.
	The food was colder than usual.	Stir or turn the food during cooking.
Turntable grates or grinds.	Dirt or debris in the area around the turntable drive.	Clean the rollers under the turntable and the recess in the oven floor thoroughly.
A particular operating mode or power level cannot be set.	The temperature, power level or combined setting is not possible for this operating mode.	Choose permitted settings.
E 1 appears in the display panel.	The thermal safety switch-off function has been activated.	Call the after-sales service.
E 2 appears in the display panel.	The automatic safety switch-off function has been activated.	Touch any button or turn the rotary selector.
E 3 appears in the display panel.	The oven is malfunctioning.	Call the after-sales service.
E 4 appears in the display panel.	The thermal safety switch-off function has been activated.	Call the after-sales service.
E 11 appears in the display panel.	Moisture in the control panel.	Allow the control panel to dry.
E 17 appears in the display panel.	Rapid heating has failed.	Call the after-sales service.
The appliance can be set, but does not heat up. The colon is flashing.	The demo mode has been activated.	Disconnect the appliance from the mains power supply, then reconnect it. Press and hold the  button until the  symbol appears in the display and the colon stops flashing. Confirm within 4 seconds using the  button.

After-sales service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find the right solution in order to avoid unnecessary visits from a service technician.

E number and FD number

When calling us, please give the product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate containing these numbers is found on the side of the oven door. You can make a note of the number of your appliance and the telephone number of the after-sales service in the space below to save time should it be required.

E no.	FD no.

After-sales service

Please note that there will be a fee for a visit by a service technician in the event of a malfunction, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

To book an engineer visit and product advice

GB 0344 892 8979
Calls charged at local or mobile rate.

IE 01450 2655
0.03 € per minute at peak. Off peak 0.0088 € per minute.

Rely on the professionalism of the manufacturer. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your appliances.

Technical data

Power supply	220-230 V, 50 Hz
Microwave power setting	900 W
Microwave frequency	2,450 MHz
Fuse	16 A
VDE approved	Yes
CE mark	Yes

This appliance corresponds to the standards EN 55011 and CISPR 11. It is a Group 2, Class B product.

Group 2 means that microwaves are produced for the purpose of heating food. Class B states that the appliance is suitable for private households.

Acrylamide in foodstuffs

Which foods are affected?

Acrylamide is mainly produced in grain and potato products that are heated to high temperatures, such as potato crisps,

chips, toast, bread rolls, bread, fine baked goods (biscuits, gingerbread, cookies).

Tips for keeping acrylamide to a minimum when preparing food	
General	Keep cooking times to a minimum. Cook meals until they are golden brown, but not too dark. Large, thick pieces of food contain less acrylamide.
Baking biscuits	Max. 200 °C in Top/bottom heating or max. 180 °C in 3D hot air or hot air mode. Max. 190° C in Top/bottom heating or max. 170 °C in 3D hot air or hot air mode. Egg white and egg yolk reduce the formation of acrylamide.
Oven chips	Distribute thinly and evenly over the baking tray. Cook at least 400 g at once on a baking tray so that the chips do not dry out.

Energy and environment tips

Here you can find tips on how to save energy when baking and roasting and how to dispose of your appliance properly.

Saving energy

- Only preheat the oven if this is specified in the recipe or in the operating instruction tables.
- Use dark, black lacquered or enamelled baking tins. They absorb the heat particularly well.
- Open the oven door as infrequently as possible while you are cooking, baking or roasting.
- It is best to bake several cakes one after the other. The oven is still warm. This reduces the baking time for the second cake. You can also place two loaf tins next to each other.

- For longer cooking times, you can switch the oven off 10 minutes before the end of the cooking time and use the residual heat to finish cooking.

Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Tested for you in our cooking studio

Here you will find a selection of recipes and the ideal settings for them. We will show you which type of heating and which temperature or microwave power setting is best for your meal. You can find information about suitable accessories and the height at which they should be inserted. There are also tips about ovenware and preparation methods.

Notes

- The values in the table always apply to food placed into the cooking compartment when it is cold and empty. Only preheat the appliance if the table specifies that you should do so. Before using the appliance, remove all accessories from the cooking compartment that you will not be using.
- Do not line the accessories with greaseproof paper until after they have been preheated.
- The times specified in the tables are only guidelines. They will depend on the quality and composition of the food.
- Use the accessories supplied. Additional accessories may be obtained from specialist retailers or from the after-sales service.
- Always use an oven cloth or oven gloves when taking accessories or ovenware out of the cooking compartment.

Defrosting, heating up and cooking with the microwave

The following tables provide you with numerous options and settings for the microwave.

The times specified in the tables are only guidelines. They may vary according to the ovenware used, the quality, temperature and consistency of the food.

Time ranges are often specified in the tables. Set the shortest time first and then extend the time if necessary.

It may be that you have different quantities from those specified in the tables. A rule of thumb can be applied: Double amount - just under double the cooking time, half amount - half the cooking time.

Place the ovenware in the centre of the lower wire rack. The food will then absorb the microwaves from all sides.

Defrosting

Notes

- Place the frozen food in an open container on the wire rack.
- Delicate parts such as the legs and wings of chicken or fatty outer layers of roasts can be covered with small pieces of aluminium foil. The foil must not touch the cooking compartment walls. You can remove the foil half way through the defrosting time.
- Turn or stir the food once or twice during the defrosting time. Large pieces of food should be turned several times. When turning, remove any liquid that has resulted from defrosting.
- Leave defrosted items to stand at room temperature for a further 10 to 60 minutes so that the temperature can stabilise. The giblets can be removed from poultry at this point.

Defrost	Weight	Microwave power setting in watts, cooking time in minutes	Notes
Whole pieces of meat (beef, veal or pork - on the bone or boned)	800 g	180 W, 15 mins + 90 W, 10-20 mins	Turn several times
	1 kg	180 W, 20 mins + 90 W, 15-25 mins	
	1.5 kg	180 W, 30 mins + 90 W, 20-30 mins	
Meat in pieces or slices of beef, veal or pork	200 g	180 W, 3 mins + 90 W, 10-15 mins	Separate any defrosted parts when turning
	500 g	180 W, 5 mins + 90 W, 15-20 mins	
	800 g	180 W, 8 mins + 90 W, 15-20 mins	
Minced meat, mixed	200 g	90 W, 10-15 mins	Freeze food flat if possible Turn several times, remove any defrosted meat
	500 g	180 W, 5 mins + 90 W, 10-15 mins	
	800 g	180 W, 8 mins + 90 W, 15-20 mins	
Poultry or poultry portions	600 g	180 W, 8 mins + 90 W, 10-15 mins	Turn during cooking.
	1.2 kg	180 W, 15 mins + 90 W, 25-30 mins	
Duck	2 kg	180 W, 20 mins + 90 W, 30-40 mins	Turn several times
Fish fillet, fish steak or slices	400 g	180 W, 5 mins + 90 W, 10-15 mins	Separate any defrosted parts
Whole fish	300 g	180 W, 3 mins + 90 W, 10-15 mins	-
	600 g	180 W, 8 mins + 90 W, 10-15 mins	
Vegetables, e.g. peas	300 g	180 W, 10-15 mins	Stir carefully during defrosting.
	600 g	180 W, 10 mins + 90 W, 10-15 mins	
Fruit, e.g. raspberries	300 g	180 W, 7-10 mins	Stir carefully during defrosting and separate any defrosted parts
	500 g	180 W, 8 mins + 90 W, 5-10 mins	
Butter, defrosting	125 g	180 W, 1 mins + 90 W, 2-4 mins	Remove all packaging
	250 g	360 W, 1 min + 90 W, 2-4 mins	
Loaf of bread	500 g	180 W, 6 mins + 90 W, 5-10 mins	Turn during cooking.
	1 kg	180 W, 12 mins + 90 W, 15-25 mins	
Cakes, dry, e.g. sponge cake	500 g	90 W, 15-20 mins	Only for cakes without icing, cream or crème pâtissière, separate the pieces of cake.
	750 g	180 W, 5 mins + 90 W, 10-15 mins	
Cakes, moist, e.g. fruit flan, cheese-cake	500 g	180 W, 5 mins + 90 W, 10-15 mins	Only for cakes without icing, cream or gelatine
	750 g	180 W, 7 mins + 90 W, 10-15 mins	

Defrosting, heating up or cooking frozen food

Notes

- Take ready meals out of the packaging. They will heat up more quickly and evenly in microwaveable ovenware. The different components of the meal may not require the same amount of time to heat up .
- Food which lies flat will cook more quickly than food which is piled high. You should therefore distribute the food so that it is as flat as possible in the ovenware. Different foodstuffs should not be placed in layers on top of one another.


- Always cover the food. If you do not have a suitable cover for your ovenware, use a plate or special microwave foil.
- Stir or turn the food 2 or 3 times during cooking.
- After heating, allow the food to stand for a further 2 to 5 minutes so that it can achieve an even temperature.
- Always use an oven cloth or oven gloves when removing plates from the oven.
- This will help the food retain its own distinct taste, so it will require less seasoning.

Defrosting, heating up or cooking frozen food	Weight	Microwave power setting in watts, cooking time in minutes	Notes
Menu, plated meal, ready meal	300-400 g	600 W, 10-15 mins	Take meal out of packaging; cover food to heat
Soup	400-500 g	600 W, 8-10 mins	Ovenware with lid
Stews	500 g	600 W, 10-15 mins	Ovenware with lid
	1 kg	600 W, 20-25 mins	
Slices or pieces of meat in sauce, e.g. goulash	500 g	600 W, 15-20 mins	Ovenware with lid
	1 kg	600 W, 25-30 mins	
Fish, e.g. fillet steaks	400 g	600 W, 10-15 mins	Covered
	800 g	600 W, 18-20 mins	
Side dishes, e.g. rice, pasta	250 g	600 W, 2-5 mins	Ovenware with lid; add liquid
	500 g	600 W, 8-10 mins	
Vegetables, e.g. peas, broccoli, carrots	300 g	600 W, 8-10 mins	Ovenware with lid; add 1 tbsp of water
	600 g	600 W, 15-20 mins	
Creamed spinach	450 g	600 W, 11-16 mins	Cook without additional water

Heating food

Risk of scalding!

There is a possibility of delayed boiling when a liquid is heated. This means that the liquid reaches boiling temperature without the usual steam bubbles rising to the surface. Even if the container only moves a little, the hot liquid can suddenly boil over and spatter. When heating liquids, always place a spoon in the container. This will prevent delayed boiling.



Caution!

Metal - e.g. a spoon in a glass - must be kept at least 2 cm from the oven walls and the inside of the door. Sparks could irreparably damage the glass on the inside of the door.

Notes

- Take ready meals out of the packaging. They will heat up more quickly and evenly in microwaveable ovenware. The different components of the meal may not require the same amount of time to heat up .
- Always cover the food. If you do not have a suitable cover for your container, use a plate or special microwave foil.
- Stir or turn the food several times during the heating time. Check the temperature.
- After heating, allow the food to stand for a further 2 to 5 minutes so that it can achieve an even temperature.
- Always use an oven cloth or oven gloves when removing plates from the oven.

Heating food	Weight	Microwave power setting in watts, cooking time in minutes	Notes
Menu, plated meal, ready meal	350-500 g	600 W, 5-10 mins	Take meal out of packaging, cover food to heat
Drinks	150 ml	900 W, 1-2 mins	Caution! Place a spoon in the glass. Do not over-heat alcoholic drinks. Check during heating
	300 ml	900 W, 2-3 mins	
	500 ml	900 W, 3-4 mins	
Baby food, e.g. baby bottle	50 ml	360 W, approx. 1 min	Place baby bottles on the cooking compartment floor without the teat or lid. Shake or stir well after heating. You must check the temperature
	100 ml	360 W, 1-2 mins	
	200 ml	360 W, 2-3 mins	
Soup			-
1 cup	175 g	900 W, 2-3 mins	
2 cups	175 g each	900 W, 4-5 mins	
4 cups	175 g each	900 W, 5-6 mins	
Slices or pieces of meat in sauce, e.g. goulash	500 g	600 W, 10-15 mins	Covered
Stew	400 g	600 W, 5-10 mins	Ovenware with lid
	800 g	600 W, 10-15 mins	
Vegetables	150 g	600 W, 2-3 mins	Add a little liquid
	300 g	600 W, 3-5 mins	

Cooking food

Notes

- Food which lies flat will cook more quickly than food which is piled high. You should therefore distribute the food so that it is as flat as possible in the ovenware. Different foodstuffs should not be placed in layers on top of one another.
- Cook the food in ovenware with a lid. If you do not have a suitable lid for your ovenware, use a plate or special microwave foil.

- This will help the food retain its own distinct taste, so it will require less seasoning.
- After cooking, allow the food to stand for a further 2 to 5 minutes so that it can achieve an even temperature.
- Always use an oven cloth or oven gloves when removing plates from the oven.

Cooking food	Weight	Microwave power in watts, Cooking time in minutes	Notes
Whole chicken, fresh, no giblets	1.5 kg	600 W, 30-35 mins	Turn halfway through the cooking time
Fish fillet, fresh	400 g	600 W, 5-10 mins	-
Fresh vegetables	250 g	600 W, 5-10 mins	Cut into equal-sized pieces; add 1 to 2 tbsp water per 100 g; stir during cooking
	500 g	600 W, 10-15 mins	
Potatoes	250 g	600 W, 8-10 mins	Cut into equal-sized pieces; add 1 to 2 tbsp water per 100 g; stir during cooking
	500 g	600 W, 11-14 mins	
	750 g	600 W, 15-22 mins	

Cooking food	Weight	Microwave power in watts, Cooking time in minutes	Notes
Rice	125 g	600 W, 7-9 mins+ 180 W, 15-20 mins	Add double the quantity of liquid and use deep ovenware with a lid
	250 g	600 W, 10-12 mins + 180 W, 20-25 mins	
Sweet foods, e.g. blancmange (instant)	500 ml	600 W, 7-9 mins	Stir 2 to 3 times with an egg whisk while heating
Fruit, compote	500 g	600 W, 9-12 mins	-

Popcorn for the microwave

Notes

- Use heat-resistant, flat glass ovenware, e.g. the lid of an ovenproof dish, a glass plate or a glass tray (Pyrex)
- Always place the ovenware on the wire rack.
- Do not use porcelain or overly curved plates.
- Make the settings as described in the table. You can adjust the timings according to product and amount.

- So that the popcorn doesn't burn, briefly take the popcorn bag out of the oven after 1 minute and 30 seconds and shake it. Take care as the bag will be hot!

Risk of scalding!

- Open the popcorn bag carefully as hot steam may be released.
- Never set the microwave to full power.

	Weight	Accessories	Microwave power in watts, Cooking time in minutes
Popcorn for the microwave	1 bag, 100 g	Ovenware, wire rack	600 W, 3-5 mins

Microwave tips

You cannot find any information about the settings for the quantity of food you have prepared.

Increase or reduce the cooking times using the following rule of thumb:

Double the amount = almost double the cooking time

Half the amount = half the cooking time

The food has become too dry.

Next time, set a shorter cooking time or select a lower microwave power setting. Cover the food and add more liquid.

When the time has elapsed, the food is not defrosted, hot or cooked.

Set a longer time. Large quantities and food which is piled high require longer times.

When the time has elapsed, the food is overheated at the edge but not done in the middle.

Stir it during the cooking time and next time, select a lower microwave power setting and a longer cooking time.

After defrosting, the poultry or meat is defrosted on the outside but not defrosted in the middle.

Next time, select a lower microwave power setting. If you are defrosting a large quantity, turn it several times.

Cakes and pastries

About the tables

Notes










- The times given apply to food placed in a cold oven.
- The temperature and baking time depend on the consistency and amount of the mixture. This is why temperature ranges are given in the tables. Begin with the lower temperature and,

if necessary, use a higher setting the next time, since a lower temperature results in more even browning.

- Additional information can be found in the *Baking tips* section following the tables.
- Always place the cake tin in the centre of the lower wire rack.










Baking tins

Note: It is best to use dark-coloured metal baking tins.

Baking in tins	Accessories	Type of heating	Temperature °C	Microwave power in watts	Cooking time in minutes
Sponge cake, simple	Ring tin/cake tin		170-180	90	40-50
Sponge cake, delicate (e.g. sandcake)*	Ring tin/cake tin		150-170	-	70-90
Sponge flan base	Flan-base cake tin		160-180	-	30-40
Delicate fruit flan, sponge	Springform/ring tin		170-180	90	35-45
Sponge base, 2 eggs	Flan-base cake tin		160-170	-	20-25
Sponge flan, 6 eggs	Dark springform cake tin		170-180	-	35-45
Shortcrust pastry base with crust	Dark springform cake tin		170-190	-	30-40
Fruit tart/cheesecake with pastry base*	Dark springform cake tin		170-190	180	35-45
Swiss flan**	Dark springform cake tin		190-200	-	45-55








* Allow cake to cool in the oven for approx. 20 minutes.





** Place the tin directly on the turntable.

Baking in tins	Accessories	Type of heating	Temperature °C	Microwave power in watts	Cooking time in minutes
Ring cake	Ring cake tin		170-180		40-50
Pizza, thin base, light topping**	Round pizza tray		220-230	-	15-25
Savoury cakes**	Dark springform cake tin		200-220	-	50-60
Nut cake	Dark springform cake tin		170-180	90	35-45
Yeast dough with dry topping	Round pizza tray		160-180	-	50-60
Yeast dough with moist topping	Round pizza tray		170-190	-	55-65
Plaited loaf with 500 g flour	Round pizza tray		170-190	-	35-45
Stollen with 500 g flour	Round pizza tray		160-180	-	60-70
Strudel, sweet	Round pizza tray		190-210	180	35-45

* Allow cake to cool in the oven for approx. 20 minutes.

** Place the tin directly on the turntable.

Small baked items	Accessories	Type of heating	Temperature in °C	Cooking time in minutes
Biscuits	Round pizza tray		150-170	25-35
Macaroons	Round pizza tray		110-130	35-45
Meringue	Round pizza tray		100	80-100
Muffins	Muffin tray on wire rack		160-180	35-40
Choux pastry	Round pizza tray		200-220	35-45
Puff pastry	Round pizza tray		190-200	35-45
Leavened cake	Round pizza tray		200-220	25-35

Bread and bread rolls	Accessories	Type of heating	Temperature in °C	Cooking time in minutes
Sourdough bread with 1.2 kg flour	Round pizza tray		210-230	50-60
Flatbread*	Round pizza tray		220-230	25-35
Bread rolls	Round pizza tray		210-230	25-35
Rolls made with sweet yeast dough	Round pizza tray		200-220	15-25

* Place the tin directly on the turntable.

Baking tips

You want to bake according to your own recipe.	Use similar items in the baking tables as a guide.
Use baking tins made of silicone, glass, plastic or ceramic materials.	The baking tin must be heat-resistant up to 250 °C. Cakes in these baking tins will be less brown. When using the microwave, the cooking time will be shorter than the time shown in the table.
How to establish whether sponge cake is baked through.	Approximately 10 minutes before the end of the baking time specified in the recipe, poke the cake with a cocktail stick at its highest point. If the cocktail stick comes out clean, the cake is ready.
The cake collapses.	Use less liquid next time or set the oven temperature 10 degrees lower and extend the baking time. Observe the specified mixing times in the recipe.
The cake has risen in the middle but is lower around the edge.	Only grease the base of the springform cake tin. After baking, loosen the cake carefully with a knife.
The cake is too dark.	Select a lower temperature and bake the cake for a little longer.
The cake is too dry.	When it is done, make small holes in the cake using a toothpick. Then drizzle fruit juice or an alcoholic beverage over it. Next time, select a temperature 10 degrees higher and reduce the baking time.
The bread or cake (e.g. cheesecake) looks good, but is soggy on the inside (sticky, streaked with water).	Use slightly less fluid next time and bake for slightly longer at a lower temperature. When baking cakes with a moist topping, bake the base first, cover with almonds or bread crumbs and then add the topping. Please follow the recipe and follow the baking times.
The cake cannot be turned out of the dish when it is turned upside down.	After baking, allow the cake to cool for a further 5 to 10 minutes, then it will be easier to turn out of the tin. If it still sticks, carefully loosen the cake around the edges using a knife. Turn the cake tin upside down again and cover it several times with a cold, wet cloth. Next time, grease the tin well and sprinkle some bread crumbs into it.

You have measured the temperature of the oven using your own meat thermometer and found there is a discrepancy.	The oven temperature is measured by the manufacturer after a specified period of time using a test rack in the centre of the cooking compartment. Ovenware and accessories affect the temperature measurement, so there will always be some discrepancy when you measure the temperature yourself.
Sparks are generated between the tin and the wire rack.	Check that the tin is clean on the outside. Change the position of the tin in the cooking compartment. If this does not help, continue baking but without the microwave. The baking time will then be longer.

Roasting and grilling

About the tables

The temperature and roasting time depend on the type and amount of food being cooked. This is why temperature ranges are given in the tables. Begin with the lower temperature and, if necessary, use a higher setting the next time,

For more information, see the section entitled *Tips for grilling and roasting* which follows the tables.

Ovenware

You may use any heat-resistant ovenware which is suitable for use in a microwave. Metal roasting dishes are not suitable for roasting with microwaves.

The ovenware can become very hot. Use oven gloves to take the ovenware out of the oven.

Place hot glass ovenware on a dry kitchen towel after they have been removed from the oven. The glass could crack if placed on a cold or wet surface.

Tips for roasting





Notes

- Use a deep roasting dish for roasting meat and poultry.
- Check that your ovenware fits in the cooking compartment. It should not be too big.
- Meat:
Cover approx. two thirds of the ovenware base with liquid.

Beef



Notes

- Turn pot-roasted beef after $\frac{1}{3}$ and $\frac{2}{3}$ of the cooking time. Finally, allow to stand for approx. a further 10 minutes.

Beef	Accessories	Type of heating	Temperature in °C, grill setting	Microwave power in watts	Cooking time in minutes
Pot-roasted beef, approx. 1 kg	Ovenware with lid		180-200	-	120-143
Fillet of beef, medium, approx. 1 kg	Ovenware without lid		180-200	90	30-40
Sirloin, medium, approx. 1 kg	Ovenware without lid		210-230	180	30-40
Steak, medium, 3 cm thick	Higher wire rack		3	-	each side: 10-15

Veal

Note: Turn joints and knuckle of veal halfway through the cooking time. Finally, allow to stand for approx. a further 10 minutes.

Veal	Accessories	Type of heating	Temperature °C	Microwave power in watts	Cooking time in minutes
Joint of veal, approx. 1 kg	Ovenware with lid		180-200	-	110-130
Knuckle of veal, approx. 1.5 kg	Ovenware with lid		200-220	-	120-130

Add slightly more liquid for pot roasts. Turn pieces of meat halfway through the cooking time. When the roast is ready, turn off the oven and allow it to rest for an additional 10 minutes. This allows better distribution of the meat juices.

- Poultry:
Turn the pieces of meat after $\frac{2}{3}$ of the cooking time has elapsed.

Tips for grilling

Notes






- Always keep the oven door closed when grilling and do not preheat.
- As far as possible, the pieces of food you are grilling should be of equal thickness. Steaks should be at least 2 to 3 cm thick. This will allow them to brown evenly and remain succulent and juicy. Do not add salt to steaks until they have been grilled.
- Use tongs to turn the pieces of food you are grilling. If you pierce the meat with a fork, the juices will run out and it will become dry.
- Dark meat, e.g. beef, browns more quickly than lighter-coloured meat such as veal or pork. When grilling light-coloured meat or fish, these often only brown slightly on the surface, although they are cooked and juicy on the inside.
- The grill element switches off and on again automatically. This is normal. The grill setting determines how frequently this will happen.
- Turn tenderloins and sirloins halfway through the cooking time. Finally, allow to stand for approx. a further 10 minutes.
- Turn steaks after $\frac{2}{3}$ of the cooking time.

Pork

Notes

- Turn lean joints of pork and rindless joints halfway through the cooking time. Finally, allow to stand for approx. a further 10 minutes.

- Place the joint in the ovenware rind-side up. Score the rind. Do not turn the joint. Finally, allow to stand for approx. a further 10 minutes.
- Do not turn pork fillets or pork chops. Finally, allow to stand for approx. a further 5 minutes.
- Turn the neck of pork after $\frac{2}{3}$ of the cooking time.



Pork	Accessories	Type of heating	Temperature in °C, grill setting	Microwave power in watts	Cooking time in minutes
Joint without rind (e.g. neck), approx. 750 g*	Ovenware with lid		220-230	180	40-50
Joint with rind (e.g. shoulder) approx. 1.5 kg*	Ovenware without lid		190-210	-	130-150
Fillet of pork, approx. 500 g*	Ovenware with lid		220-230	90	25-30
Joint of pork, lean, approx. 1 kg*	Ovenware with lid		210-230	90	60-80
Smoked pork on the bone, approx. 1 kg*	Ovenware without lid	-	-	360	45-45
Neck of pork, 2 cm thick**			3	-	1st side: approx. 15-20 2nd side: approx. 10-15

* Lower wire rack

** Higher wire rack

Lamb



Note: Turn the leg of lamb halfway through the cooking time.

Lamb	Accessories	Type of heating	Temperature °C	Microwave power in watts	Cooking time in minutes
Saddle of lamb on the bone, approx. 1 kg	Ovenware without lid		210-230	-	40-50
Leg of lamb, boned, medium, approx. 1.5 kg	Ovenware with lid		190-210	-	90-95

Miscellaneous

Notes

- Finally, allow the meat loaf to stand for approx. a further 10 minutes.
- Turn the sausages after $\frac{2}{3}$ of the cooking time.

Miscellaneous	Accessories	Type of heating	Temperature in °C, grill setting	Microwave power in watts	Cooking time in minutes
Meat loaf, approx. 1 kg*	Ovenware without lid		180-200	600 W + 180 W	-
4 to 6 sausages for grilling approx. 150 g each**	-		3	-	each side: 10-15



* lower wire rack **
higher wire rack

Poultry

Notes

- Place whole chickens and chicken breasts breast-side down. Turn after $\frac{2}{3}$ of the cooking time.
- Place poulard breast-side down. Turn after 30 minutes and set the microwave power to 180 watts.

- Place half chickens and chicken portions skin-side up. Do not turn.
- Turn the duck and goose breast skin-side up. Do not turn.
- Turn goose thighs halfway through the cooking time. Prick the skin.
- Place turkey breast and thighs skin-side down. Turn after $\frac{2}{3}$ of the cooking time.

Poultry	Accessories	Type of heating	Temperature in °C, grill setting	Microwave power in watts	Cooking time in minutes
Chicken, whole, approx. 1.2 kg	Ovenware with lid		220-230	360	35-45
Poulard, whole, approx. 1.6 kg	Ovenware with lid		220-230	360 180	30 20-30

Poultry	Accessories	Type of heating	Temperature in °C, grill setting	Microwave power in watts	Cooking time in minutes
Chicken, halves, 500 g each	Ovenware without lid		180-200	360	30-35
Chicken portions, approx. 800 g	Ovenware without lid		210-230	360	20-30
Chicken breast with skin and bones, 2 pieces, approx. 350-450 g	Ovenware without lid		190-210	180	30-40
Duck breast with skin, 2 pieces, 300-400 g each	Ovenware without lid		3	90	20-30
Goose breast, 2 pieces, 500 g each	Ovenware without lid		210-230	90	25-30
Goose legs, 4 pieces, approx. 1.5 kg	Ovenware without lid		210-230	180	30-40
Turkey breast, approx. 1 kg	Ovenware with lid		200-220	-	90-100
Turkey drumsticks, approx. 1.3 kg	Ovenware with lid		200-220	180	50-60

Fish

Notes

- For grilling, place the whole fish, e.g. trout, onto the middle of the higher wire rack.
- Grease the wire rack with oil beforehand.

Fish	Accessories	Type of heating	Temperature °C	Cooking time in minutes
Fish steak, e.g. salmon, 3 cm thick, grilled	Higher wire rack		3	20-25
Whole fish, 2-3 pieces, 300 g each, grilled	Higher wire rack		3	20-30

Tips for roasting and grilling

The table does not contain information for the weight of the joint.	For small roasts, select a higher temperature and a shorter cooking time. For larger roasts, select a lower temperature and a longer cooking time.
How to tell when the roast is ready.	Use a meat thermometer (available from specialist shops) or carry out a "spoon test". Press down on the roast with a spoon. If it feels firm, it is ready. If the spoon can be pressed in, it needs to be cooked for a little longer.
The roast looks good but the juices are burnt.	Next time, use a smaller roasting dish or add more liquid.
The roast looks good but the juices are too clear and watery.	Next time, use a larger roasting dish and add less liquid.
The roast is not well-done enough.	Carve the roast. Prepare the gravy in the roasting dish and place the slices of roast meat in the gravy. Finish cooking the meat using the microwave only.

Bakes, gratins, toast with toppings

Notes

- The values in the table apply to food placed in a cold oven.
- For bakes, potato gratins and lasagne, use a microwaveable, heat-resistant ovenproof dish 4 to 5 cm deep.
- Place the bake on the lower wire rack.
- Leave bakes and gratins to cook in the oven for a further 5 minutes after switching off.
- Cheese on toast:
Pre-toast slices of bread.

Bakes, gratins, toasts	Accessories	Type of heating	Temperature in °C, grill setting	Microwave power in watts	Cooking time in minutes
Bake, sweet, approx. 1.5 kg	Ovenware without lid		140-160	360	25-35
Savoury bake, made with cooked ingredients, approx. 1 kg	Ovenware without lid		150-170	600	20-25
Lasagne, fresh	Ovenware without lid		200-220	360	25-35
Potato gratin made from raw ingredients, approx. 1.1 kg	Ovenware without lid		180-200	600	25-30
Toast with topping, 4 slices*			3	-	8-10















* higher wire rack

Convenience products, frozen

Notes

- Observe the instructions on the packaging.

- The values in the table apply to food placed in a cold oven.
- Do not lay chips, croquettes or potato rösti on top of each other. Turn half way through the cooking time.
- Place the food directly on the turntable.

Convenience products	Accessories	Type of heating	Temperature °C	Microwave power in watts	Cooking time in minutes
Pizza with thin base*	Turntable		220-230	-	10-15
Pizza with deep-pan base	Turntable		-	600	3
			220-230	-	13-18
Mini pizza*	Turntable		220-230	-	10-15
Pizza baguette*	Turntable		-	600	2
			220-230	-	13-18
Chips	Turntable		220-230	-	8-13
Croquettes*	Turntable		210-220	-	13-18
Rösti, stuffed potato pockets	Turntable		200-220	-	25-30
Part-cooked rolls or baguette	Lower wire rack		170-180	-	13-18
Fish fingers	Turntable		210-230	-	10-20
Chicken goujons, nuggets	Turntable		200-220	-	15-20
Strudel	Turntable		210-220	180	20-30
Lasagne, approx. 400 g**	Lower wire rack		220-230	600	12-17

* Preheat the cooking compartment for 5 minutes, then place the food on the hot turntable.

** Place the food in suitable, heat-resistant ovenware.

Test dishes

The quality and function of microwave combination appliances are tested by testing institutes using the following dishes.

In accordance with the standards EN 60705, IEC 60705 or DIN 44547 and EN 60350 (2009)




Defrosting with the microwave

Dish	Microwave power setting in watts, cooking time in minutes	Note
Meat	180 W, 5 mins + 90 W, 10-15 mins	Place the Pyrex dish with a 22 cm diameter on the lower wire rack. After approx. 13 minutes, remove the defrosted meat.



Microwave cooking

Dish	Microwave power setting in watts, cooking time in minutes	Note
Custard	600 W, 10-13 mins + 180 W, 25-30 mins	Place the Pyrex dish with dimensions 24 x 19 cm on the lower wire rack.
Sponge flan	600 W, 9-10 mins	Place the Pyrex dish with a 22 cm diameter on the lower wire rack.
Meat loaf	600 W, 18-23 mins	Place the 28 cm Pyrex dish on the lower wire rack.



Combined microwave cooking


Dish	Microwave power setting in watts, cooking time in minutes	Type of heating	Temperature °C	Note
Potato gratin	600 W, 25-30 mins		210-220	Place the Pyrex dish with a 22 cm diameter on the lower wire rack.
Cake	180 W, 15-20 mins		180-200	Place the Pyrex dish with a 22 cm diameter on the lower wire rack.
Chicken	360 W, 35-40 mins		200-220	Turn after 2/3 of the cooking time.

Baking**Note:** The values in the table apply to food placed in a cold oven.

Dish	Ovenware	Type of heating	Temperature °C	Baking time in minutes
Hot water sponge cake	Springform cake tin, dia. 26 cm, lower wire rack		160-180	30-40
German apple pie	Springform cake tin, dia. 20 cm, lower wire rack		190-210	50-60

Grilling

Dish	Accessories	Type of heating	Grill setting	Cooking time in minutes
Browning toast	Higher wire rack		3	4-5
Beefburgers, x 9	Higher wire rack		3	30-35



Robert Bosch Hausgeräte GmbH

Carl-Wery-Straße 34

81739 München

Germany

www.bosch-home.com



9001121666

961210