



Brief and handy:
everything your dishwasher
needs ...

**Before using for the first time,
read the Installation instructions
and Operating instructions!**

1


Adjusting the water softening system *

Ask your water supply
company what
the water hardness
is and enter ...



* only before the first
wash or if the
water hardness
has been changed

Water hardness value °Clarke	Hardness range	mmol/l	Factory setting
0-8	soft	0-1.1	H:00
9-10	soft	1.2-1.4	H:01
11-12	medium	1.5-1.8	H:02
13-15	medium	1.9-2.1	H:03
16-20	medium	2.2-2.9	H:04
21-26	hard	3.0-3.7	H:05
27-38	hard	3.8-5.4	H:06
39-62	hard	5.5-8.9	H:07




Quickly sorted ...

How to adjust

- Switch on ON/OFF switch.
- Hold down programme button A and press START button until H:0... is indicated on the digital display.
- Release both buttons.
The LED for button A flashes and the factory set value of H:04 is indicated on the digital display.
- Press programme button C.
Each time the button is pressed the set value increases by one setting; when the value reaches H:07, the display jumps back to H:00 (off).
- Press START button. The chosen setting has now been stored.


Filling the salt dispenser Dissolves limescale (not necessary for set value 0!) ...




Unscrew
cover.



Fill the salt
dispenser with
water before
the first wash only.




Add special **salt**
(never add
detergent!).




Screw on
the cover.
Wash
immediately.


Adding rinse aid



Press
mark 1,
lift up
cover 2.




Fill in
rinse aid.





Screw on
the cover.
CLICK!

Adding detergent




If required,
open the cover
(press button).

Attention:
Combination
products
are not suitable
for all programmes,
follow
manufacturer's
instructions.



Pour detergent
into the dry
detergent
dispenser only.



Slide cover
shut, press.
PLOP!

Select programme

Quick, economical or intensive ...

Overview of programmes

The max. possible number of programmes is illustrated in this overview.
The corresponding programmes for your appliance can be found on the fascia.

The programme data has been measured in the
laboratory according to European standard EN 50242.
Deviations are possible in practice.

* The programme consists of a one-off heating up
phase (approx. 25 min.) and several possible rinsing
phases (20 min. each).
Please refer to operation in the instructions for use!

Intensive 70°	Auto 45°/65°	Eco 50°	Gentle 40°	Turbo Speed 20 min. *	Prerinse
Duration: hs : mins	3:00 - 1:10	0:25 + 0:20	0:15	0:15	0:15
Energy consumption in kWh	1,40 - 0,75	0,95	0,05	0,05	0,05
Water consumption in litres	17 - 6	8	4	4	4

Additional options **



**Express Wash/
Speed Perfect
(VarioSpeed)**

... is obtained by increased
energy consumption
at a constant cleaning
performance.



Half load

... for a few items,
saves water, energy
and time.



Intensive zone

... perfect for
a mixed load.
Washing pressure
and washing temperature
are increased slightly.



Hygiene

... the temperature
is increased during
the final rinse process.
This increases
the hygiene status.



Extra drying

... improves the drying
result by increased
temperature
in the final rinse.
(Please take care
with delicate dishes.)

** depending on model

Switching on the appliance

Start programme Here we go ...


Switch off the appliance Everything o.k. ...

Maintenance and care

For perfect rinsing results ...

Cleaning waste water pump


Filters
... check,
if required,
clean.




Rotate
filter cylinder,
remove filter
system ...



rinse
under
running
water ...




insert ...




Screw on
filter system
**NOTE
MARK!**


Spray arms
... Remove
blockages/
deposits.



pull lower arm
upwards ...




unscrew
upper arm ...





clean spray nozzles
under running water
(if required
use toothpicks) ...

insert
lower arm ...



screw on upper
arm tightly

– Pull out the mains plug.
– Remove filters and scoop out water.
– Lever off cover (A).
– Check area around the fan impeller
for foreign objects.
– Click cover shut (B).
– Insert filters.



Rectifying minor faults yourself ...

... as it is worth doing it yourself!

More information can be found in the operating instructions

Fault	Possible causes	Remedial action
Display “  ” is lit	Supply fitting jammed or calcified	Open supply fitting. 1. Unscrew water connection. 2. Clean filter in the water connection. 3. Flow rate must be min. 10 l/min., when water supply is open. If the flow rate is less, replace the supply fitting. Install supply hose without kinks.
Display “E:22”	Filters are soiled or blocked	Clean the filters (see above).
Display “E:24” and “  ” are lit	Waste water hose is blocked or kinked	Install waste water hose without kinks.
	Cover not attached to waste water pump	Attach cover (see above).
Display “E:25” and “  ” are lit	Waste water pump blocked	Clean waste-water pump (see above).
Other fault display “E:XX” is lit	Appliance has technical defect	Call factory customer service (state fault display). Unplug appliance.
Residual water in the appliance	The programme has not yet ended	Close the appliance and switch it on or terminate the programme (see Terminating the programme).
Rust on the cutlery	Cutlery not rust-resistant Hard knife blades are more susceptible	Use dishwasher-proof cutlery.
	Extraneous rust	Never wash rusting parts in the appliance.

Fault	Possible causes	Remedial action
Utensils are not clean	Utensils are situated close together or one above the other	Separate the utensils, prevent contact points.
Sand or gritty residue on the utensils	Too little detergent	Follow manufacturer's instructions (detergent).
	Unsuitable programme selected	Select a more intensive programme.
	Spray arm nozzles blocked	Clean the spray arms (see above).
	Filters dirty, not seated firmly	Clean the filters (see above).
	Spray arms blocked	Arrange the utensils so that the spray arms can rotate freely.
Stains and streaks	Rinse aid dosage too high/too low	Streaks: reduce dosage. Water or limescale stains: increase dosage.
Utensils not dry	Rinse aid	Increase dosage. Change the product.
	The combined detergent used has a poor drying performance	Use rinse aid.
	Appliance setting	Activate intensive drying (depending on model).
Milky deposits on the utensils (can be removed)	Water softening system incorrectly set	Correctly set water softening system.
	No salt	Refill with special salt.
Milky deposits, glasses cloudy/tarnished (cannot be removed)	Glasses not dishwasher-proof	Use dishwasher-proof glasses.
		Use a detergent suitable for glasses.
Plastic/utensils discoloured	Too little detergent	Follow manufacturer's instructions (detergent).
	Discoloration caused by food colourings (tomato sauce)	Discoloration is harmless; subsequent rinse cycles will cause it to fade.

Terminating the programme ...

Loading the dishwasher correctly ...

While the programme is running,
press the START button
for approx. 3 sec. (Reset).



The numerical display
indicates “0:01”;
approx. 1 minute after
the programme ends,
“0:00” is indicated.



Switch off the appliance.

Dishwasher-proof utensils (not soiled with ash, wax, lubricating grease, ink or adhesive labels; remove large remnants of jam, milk products and food according to the operating instructions and check that the spray arms can rotate freely.