

Programmes	°C	max.	Type of laundry	Additional functions; information
Resistentes/Algod. (Cottons)	frio (cold), 40, 60, 90 °C			
Resistentes/Algod. intensivo (Cottons Intensive)		7 kg	Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen	
Resistentes/Algod. + Prelava. (Cottons + Prewash)	60 °C			
Sintéticos (Easy-Care)	frio (cold), 40, 60 °C	3 kg	Easy-care fabrics made of cotton, linen, synthetic fibres or blended fabrics	
Delicado (Delicates)	frio (cold)	2 kg	For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. curtains)	No spin between rinse cycles
Lana/Lã (Wool)	frio (cold), 30 °C		Hand- or machine-washable fabrics made of wool or containing wool	Particularly gentle wash programme to prevent shrinkage of laundry. Longer programme breaks (fabrics rest in the detergent solution)
Additional programmes				
i Programmes without prewash - add detergent to compartment II, programmes with prewash - distribute the detergent between compartments I and II (model-dependent).				

0311 / 9000632659

Robert Bosch Hausgeräte GmbH
Carl-Wery-Str. 34
81739 München / Deutschland

WAE20061EP ...

 **Safety instructions**

- Read the instruction manual and installation instructions and all other information enclosed with the washing machine and act accordingly.
- Retain the documents for subsequent use.

Risk of electric shock

- Never pull the cable to disconnect the mains plug.
- Never insert/disconnect the mains plug with damp hands.

Danger to life

For worn-out appliances:

- Disconnect the mains plug.
- Sever the mains cable and discard along with the plug.
- Destroy the lock on the washing machine door. This will prevent children from locking themselves in and risking their lives.

Danger of suffocation

- Keep packaging, film and packaging parts out of the reach of children.

Risk of poisoning

Risk of explosion

- Keep detergents and care products out of the reach of children.
- Items of laundry pretreated with cleaning agents containing solvents, e.g. stain remover/cleaning solvent may cause an explosion after being loaded into the washing machine. Rinse items of laundry thoroughly by hand beforehand.

Risk of injury

- The washing machine door can become very hot.
- Be careful when draining hot detergent solution.
- Do not climb onto the washing machine.
- Do not lean on the open washing machine door.
- Do not reach into the drum if it is still rotating.
- Be careful when opening the detergent drawer while the machine is in operation.

Programme	Load	Electricity consumption**	Water**	Programme duration**
Resistentes/Algod (Cottons) 40 °C *	7 kg	0.85 kWh	65 l	02:25 h
Resistentes/Algod (Cottons) 60 °C *	7 kg	1.40 kWh	65 l	02:40 h
Resistentes/Algod intensivo (Cottons Intensive) 60 °C *	7 kg	1.19 kWh	49 l	02:35 h
Resistentes/Algod (Cottons) 90 °C	7 kg	2.10 kWh	70 l	02:40 h
Sintéticos (Easy-Care) 40 °C *	3 kg	0.55 kWh	48 l	01:15 h
Delicado (Delicates) frio (cold)	2 kg	0.28 kWh	48 l	00:44 h
Lana/Lã (Wool) 30 °C	2 kg	0.20 kWh	32 l	00:53 h

* Programme setting for testing in accordance with valid standard EN60456.
Note on comparative tests: Try out the test programme by washing the specified load using the maximum spin speed.

** The values deviate from the indicated values depending on water pressure, hardness, and inlet temperature, ambient temperature, type, amount and soiling of the laundry, detergent used, fluctuations in the power supply and selected additional functions.

Care



- Risk of electric shock. Disconnect the mains plug.
- Risk of explosion. No solvents.

Before washing for the first time

Do not load any laundry into the machine. Turn on the tap. Add the following to compartment II:

- approx. 1 litre water
- detergent (dosage according to the manufacturer's instructions for light soiling and the appropriate degree of water hardness)

Set the programme selector to **Sintéticos (Easy-Care) 60 °C** and select **Inicio (Start)**. At the end of the programme, turn the programme selector to **Off (Stop)**.

Machine housing, control panel

- Wipe with a soft, damp cloth.
- Do not use any abrasive cloths, scourers or cleaning agents (stainless steel cleaners).
- Remove detergent and cleaning agent residue immediately.
- Do not clean with a jet of water.

Cleaning the detergent drawer ...

... if it contains detergent or fabric softener residues.

1. Pull out, press insert down, remove draw completely.
2. To remove the insert: press the insert upwards from below with your finger.
3. Clean the detergent dispenser tray and insert with water and a brush and dry it.
4. Attach the insert and engage (connect the cylinder to the guide pin).
5. Push in the detergent drawer.

Leave the detergent drawer open so that any residual water can evaporate.

Drum

Leave the washing machine door open so that the drum can dry out. Rust stains - use chlorine-free cleaning agent, not steel wool.

Descaling *Ensure there is no laundry in the machine*

Descale the appliance according to the descaler manufacturer's instructions. This should not be necessary if the correct dosage of detergent is used.

Information to indicator lights	
Indicator lights	Close the washing machine door properly; laundry may be caught.
Indicator lights	Open the tap completely, supply hose kinked or trapped; Clean the filter → page 10, Water pressure too low.
Indicator lights	Detergent solution pump blocked; Clean the detergent solution pump → page 10. Drainage hose/waste pipe blocked; Clean the drainage hose at the siphon → page 10.
Indicator light	Motor fault. Call the after-sales service.
All indicator lights flash	Turn off the tap and call the after-sales service.

9

Maintenance



- Risk of scalding. Allow the detergent solution to cool down.
- Turn off the tap.

Detergent solution pump

Turn the programme selector to **Stop (Off)** and disconnect the mains plug.

1. Open and remove the service flap.
2. **For models with a drainage hose:** Remove the drainage hose from the retainer and pull it from the housing. Remove the container. Remove the sealing cap, allow the detergent solution to flow out. Replace the sealing cap and place the drainage hose in the retainer.
- 2* **For models without a drainage hose:** Carefully unscrew the pump cover until the detergent solution begins to flow out. When the service flap is half full, close the pump cover and empty the service flap. Repeat the above steps until all the detergent solution has completely drained out.
3. Carefully unscrew the pump cover (residual water).
4. Clean the interior, pump cover thread and pump housing (the impeller in the detergent solution pump must rotate).
5. Replace the pump cover and screw it tightly in place.
6. Place the service flap back on and close.

To prevent unused detergent from flowing straight into the drain during the next wash: pour 1 litre of water into compartment II and start the **☞ (Empty)** programme.

Drainage hose at the siphon

Turn the programme selector to **Stop (Off)** and disconnect the mains plug.

1. Loosen the hose clamp, carefully remove the drainage hose (residual water).
2. Clean the drainage hose and siphon connecting piece.
3. Reattach the drainage hose and secure the connection with the hose clamp.

Filter in the water supply

Reduce the water pressure in the supply hose:

1. Turn off the tap.
2. Select any programme (except for **☞ Centrifug. adicional (Spin)**, **☞ (Empty)**).
3. Select **Inicio (Start)**. Let the programme run for approximately 40 seconds.
4. Turn the programme selector to **Stop (Off)**. Disconnect the mains plug.

Clean the filter:

1. Depending on model: Disconnect the hose from the tap. Clean the filter using a small brush.

and/or for Standard and Aqua-Secure models:

1. Remove the hose on the rear of the appliance. Remove the filter with pliers and clean.
2. Connect the hose and check for leaks.

10

What to do if ...

- Water is leaking out.
- No water supply. Detergent not dispensed.
- Washing machine door cannot be opened.
- Programme does not start.
- Detergent solution is not drained.
- Water not visible in the drum.
- Unsatisfactory spin result. Laundry wet/too damp.
- Spin cycle performed several times.
- Residual water in the compartment for care products.
- Odour formation in the washing machine.
- Foam escaping from the detergent drawer.
- Intense noise formation, vibrations and "walking" during the spin cycle.
- Noises during spin and drain cycles.
- The indicator lights do not function during operation.
- Programme sequence longer than usual.
- Detergent residues on the laundry.

- Attach/replace the drainage hose correctly.
- Tighten the screw connection of the supply hose.
- **Inicio (Start)** not selected?
- Tap not turned on?
- Filter blocked? Clean the filter → page 10.
- Supply hose kinked or trapped?
- Safety function active. Wait approx. 2 minutes.
- ☞ (without final spin) selected? → page 3, 4.
- **Inicio (Start)** selected?
- Washing machine door closed?
- ☞ (without final spin) selected? → page 3, 4.
- Clean the detergent solution pump → page 10.
- Clean the waste pipe and/or drainage hose.
- Not a fault - water below the visible area.
- Not a fault - the unbalanced-load detection system has cancelled the spin cycle because of uneven distribution of the laundry. Distribute small and large items of laundry evenly inside the drum.
- Too low a speed selected? → page 5.
- Not a fault - unbalanced load detection system adjusts the imbalance.
- Not a fault - the action of the care product is not affected.
- Clean the insert if necessary → page 9.
- Run programme **Resistentes/Algod. (Cottons) 90 °C** without laundry. Use standard detergent.
- Too much detergent used?
- If foam is escaping from the detergent drawer: Mix 1 tablespoon of fabric softener with ½ litre of water and pour into compartment II (not with outdoor or down fabrics).
- Reduce the detergent dosage for the next wash cycle.
- Are the appliance feet fixed?
- Secure the appliance feet → Installation instructions.
- Transportation safety devices removed?
- Remove the transportation safety devices → Installation instructions.
- Clean detergent-solution pump → page 10
- Power cut?
- Fuses tripped? Reset/change the fuse.
- If the fault occurs repeatedly, call the after-sales service.
- Not a fault - unbalanced load detection system adjusts imbalance by repeatedly distributing the laundry.
- Not a fault - foam detection system active - adds an additional rinse cycle.
- Occasionally, phosphate-free detergents contain water-insoluble residues.
- Select **☞ (Rinse)** or brush out the laundry after washing.

If you cannot correct a fault yourself (switching on/off) or a repair is required:

- Turn the programme selector to **Stop (Off)** and remove the mains plug from the socket.
- Turn off the water supply and call the after-sales service → Installation instructions.

Washing machine

en Instruction manual

11

Your washing machine

Congratulations - You have opted for a modern, high-quality domestic appliance manufactured by Bosch. This washing machine is distinguished by its economical water and energy consumption. Each machine that leaves our factory has been inspected thoroughly to ensure that it functions properly and is in perfect condition.

For further information and a selection of our products go to our web site: www.bosch-home.com

Environmentally friendly waste disposal

All packaging must be disposed of in accordance with environmental guidelines. This appliance is certified in accordance with European Directive 2002/96/EC on waste electrical and electronic equipment (WEEE). This directive provides the framework for the EU-wide collection and reuse of used appliances.



Observe the safety instructions on page 8.

Read these instructions and the separate installation instructions before operating the washing machine.

Contents

	Page
Intended use	1
Programmes	1
Setting and adjusting the programme	3
Washing	3/4
After washing	4
Individual settings	5
Important information	6
Overview of programmes	7
Safety instructions	8
Consumption values	8
Care	9
Information to indicator lights	9
Maintenance	10
What to do if...	11



Environmental protection/Conservation tips

- Always fill the washing machine with a maximum amount of laundry for the relevant programme.
- Wash normally soiled washing without a pre-wash (*model-dependent*).
- Instead of **Resistentes/Algod. (Cottons) 90 °C**, choose the programme **Resistentes/Algod. intensivo (Cottons Intensive) 60 °C**. Comparable cleaning result with significantly lower energy consumption.
- Measure the detergent according to the manufacturer's instructions and water hardness.
- If the laundry is then dried in the tumble dryer, select the spin speed according to the instructions of the dryer manufacturer (*model-dependent*).

Intended use

- for use in the household only,
- for machine-washable fabrics and hand-washable wool in detergent solution,
- to be operated with cold drinking water and commercially available detergents and care products which are suitable for use in washing machines.



- Do not leave children unattended near the washing machine.
- The washing machine is not to be used by children or persons not familiar with the operating instructions.
- Keep pets away from the washing machine.

Preparation



Correct installation according to the separate *Installation instructions*.



Checking the machine

- Never use a damaged machine.
- Inform the after-sales service.




Connecting the mains plug



Make sure your hands are dry. Take hold of the plug only.



Turning the tap on




Compartment II: Detergent for the main wash, water softener, bleach, stain remover

Compartment ⌘: Fabric softener, starch

Compartment I: Detergent for pre-wash (*model-dependent*)

(*spin speed depending on model)



Pro
swi
and
the
turn

Programmes

Detailed overview of programmes → page 7.

Resistentes/Algod. (Cottons)	hard-wearing fabrics
Resistentes/Algod.intensivo (Cottons Intensive)	hard-wearing fabrics
Resistentes/Algod. +Prelava. (Cottons + Prewash)	hard-wearing fabrics, prewash at 30 °C
🌀 (Rinse)	with subsequent spin cycle
🌀 Centrifug. adicional (Spin)	laundry washed by hand
🌀 (Empty)	the rinsing water
🌀 Lana/Lã (Wool)	hand/machine-washable textiles
Delicado (Delicates)	delicate washable fabrics
Sintéticos (Easy-Care)	easy-care fabrics

Before washing for the first time
Wash once without any laundry → page 9.

Sorting and loading laundry

Follow the manufacturer's care information.
According to the information on the care labels.
According to type, colour, soiling and temperature.
Do not exceed the maximum load → page 7.

Observe the important information → page 6.

Insert large and small items of laundry.

Close the washing machine door. Take care not to trap items of laundry between the washing machine door and the rubber seal.

Add detergent and care products

Measure accordingly:

Amount of laundry, soiling, water hardness (ask your water supply company) and manufacturer's instructions.
Put liquid detergent into the appropriate dispenser and place in the drum.

i Dilute thick fabric softener and fabric conditioner with water.
This prevents blockages.

Setting and adjusting programmes

Programme selector



Additional function → Individual settings, page 5.

Select Inicio (Start)

Programme selector for switching the machine on and off and for selecting a programme. Can be turned in either direction.

Washing

Detergent drawer with compartments I, II, ⌀

Drum

Control panel

Washing machine door

Service flap for detergent solution pump

Removing the washing

Open the washing machine door and remove the washing.
If (without final spin) is active: Turn the programme selector to (**Empty**) or select the spin speed (model-dependent).
Select **Inicio (Start)**.



- Remove any foreign objects - risk of rusting.
- Leave the washing machine door and detergent drawer open so that any residual water can evaporate.

Turning the tap off

Switching off

Turn the programme selector to **Stop (Off)**.

End of programme when ...

... the status indicator **centrifugar (spin) - terminado (end)** flashes.

Interrupting the programme

Programmes at high temperatures:

- Cool washing: Select (**Rinse**).
- Select **Inicio (Start)**.

Programmes at lower temperatures:

- Select **Centrifug. adicional (Spin)** or (**Empty**).
- Select **Inicio (Start)**.

Changing the programme, if ...

... you have selected the wrong programme by mistake:

- Reselect the programme.
- Select **Inicio (Start)**. The new programme starts from the beginning.

Individual settings

● **Additional functions** → and overview of programmes, see page 7.

☒ Clothing remains immersed in the last rinse water.

1000 | 600 ↓ Reduce spin speed (*values depending on model*).

● **Start**

For starting or interrupting the programme.



Important information



Protecting the washing and the machine

- When determining the dosage of all washing powders, additives and cleaning agents, you must follow the manufacturer's instructions.
- Empty pockets.
- Look out for metal items (paperclips, etc.).
- Wash delicates in a laundry bag (tights, curtains, underwired bras).
- Fasten zips, do up any buttons.
- Brush sand out of pockets and collars.
- Remove curtain fittings or place in the laundry bag.



Washing with varying degrees of soiling

		Wash new items of clothing separately.
light		Do not pre-wash.
		If required, pretreat stains. Select programme Resistentes/Algod. intensivo (Cottons Intensive) 60 °C.
heavy		Load less washing. Select programme Resistentes/Algod. + Prelava. (Cottons + Prewash) 60°C.



Soaking Load laundry of the same colour

Pour soaking agent/detergent into compartment **II** in accordance with the manufacturer's instructions. Turn the programme selector to **Resistentes/Algod. (Cottons) 30° C** and select **Inicio (Start)**. After approx. 10 minutes, press **Inicio (Start)**, to pause the programme. Once the required soaking time has elapsed, press **Inicio (Start)**, again to continue the programme, or select a different programme.



Starching

Washing must not be treated with fabric softener

Starching is possible in all wash programmes if liquid starch is used. Pour the starch in accordance with the manufacturer's instructions into fabric softener compartment ☼ (rinse first if necessary).



Dyeing / Bleaching

Dye should only be used in normal household quantities. Salt may damage stainless steel. Always follow the dye manufacturer's instructions! Do **not** use the washing machine for bleaching clothes!

Overview of programmes

→ refer to the table of consumption values on page 8 and notes on page 6.

Programmes	°C	max.	Type of laundry	Additional functions: information
Resistentes/Algod. (Cottons)	frio (cold), 40, 60, 90 °C			
Resistentes/Algod. intensivo (Cottons Intensive)	60 °C	7 kg	Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen	1000 600 , ▢
Resistentes/Algod. + Prelava. (Cottons + Prewash)				
Sintéticos (Easy-Care)	frio (cold), 40, 60 °C	3 kg	Easy-care fabrics made of cotton, linen, synthetic fibres or blended fabrics	1000 600 , ▢
Delicado (Delicates)	frio (cold)	2 kg	For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. curtains)	1000 600 , ▢ ; No spin between rinse cycles
Lana/Lã (Wool)	frio (cold), 30 °C		Hand- or machine-washable fabrics made of wool or containing wool	Particularly gentle wash programme to prevent shrinkage of laundry. Longer programme breaks (fabrics rest in the detergent solution)
Additional programmes				
i Programmes without prewash - add detergent to compartment II, programmes with prewash - distribute the detergent between compartments I and II (model-dependent).				

0311 / 9000632659



Robert Bosch Hausgeräte GmbH
Carl-Wery-Str. 34
81739 München / Deutschland

WAE20061EP ...



Safety instructions

- Read the instruction manual and installation instructions and all other information enclosed with the washing machine and act accordingly.
- Retain the documents for subsequent use.

- Risk of electric shock**
- Never pull the cable to disconnect the mains plug.
 - Never insert/disconnect the mains plug with damp hands.
- Danger to life**
- For worn-out appliances:
- Disconnect the mains plug.
 - Sever the mains cable and discard along with the plug.
 - Destroy the lock on the washing machine door. This will prevent children from locking themselves in and risking their lives.
- Danger of suffocation**
- Keep packaging, film and packaging parts out of the reach of children.
- Risk of poisoning**
- Risk of explosion**
- Keep detergents and care products out of the reach of children.
 - Items of laundry pretreated with cleaning agents containing solvents, e.g. stain remover/cleaning solvent may cause an explosion after being loaded into the washing machine. Rinse items of laundry thoroughly by hand beforehand.
- Risk of injury**
- The washing machine door can become very hot.
 - Be careful when draining hot detergent solution.
 - Do not climb onto the washing machine.
 - Do not lean on the open washing machine door.
 - Do not reach into the drum if it is still rotating.
 - Be careful when opening the detergent drawer while the machine is in operation.

Consumption values

Programme	Load	Electricity consumption**	Water**	Programme duration**
Resistentes/Algod (Cottons) 40 °C *	7 kg	0.85 kWh	65 l	02:25 h
Resistentes/Algod (Cottons) 60 °C *	7 kg	1.40 kWh	65 l	02:40 h
Resistentes/Algod intensivo (Cottons Intensive) 60 °C *	7 kg	1.19 kWh	49 l	02:35 h
Resistentes/Algod (Cottons) 90 °C	7 kg	2.10 kWh	70 l	02:40 h
Sintéticos (Easy-Care) 40 °C *	3 kg	0.55 kWh	48 l	01:15 h
Delicado (Delicates) frio (cold)	2 kg	0.28 kWh	48 l	00:44 h
Lana/Lã (Wool) 30 °C	2 kg	0.20 kWh	32 l	00:53 h

* Programme setting for testing in accordance with valid standard EN60456.
Note on comparative tests: Try out the test programme by washing the specified load using the maximum spin speed.

** The values deviate from the indicated values depending on water pressure, hardness, and inlet temperature, ambient temperature, type, amount and soiling of the laundry, detergent used, fluctuations in the power supply and selected additional functions.

Care



- Risk of electric shock. Disconnect the mains plug.
- Risk of explosion. No solvents.



Before washing for the first time

Do not load any laundry into the machine. Turn on the tap.

Add the following to compartment **II**:

- approx. 1 litre water
- detergent (dosage according to the manufacturer's instructions for light soiling and the appropriate degree of water hardness)

Set the programme selector to **Sintéticos (Easy-Care) 60 °C** and select **Inicio (Start)**. At the end of the programme, turn the programme selector to **Off (Stop)**.



Machine housing, control panel



- Wipe with a soft, damp cloth.
- Do not use any abrasive cloths, scourers or cleaning agents (stainless steel cleaners).
- Remove detergent and cleaning agent residue immediately.
- Do not clean with a jet of water.



Cleaning the detergent drawer ...

... if it contains detergent or fabric softener residues.

1. Pull out, press insert down, remove draw completely.
2. To remove the insert: press the insert upwards from below with your finger.
3. Clean the detergent dispenser tray and insert with water and a brush and dry it.
4. Attach the insert and engage (connect the cylinder to the guide pin).
5. Push in the detergent drawer.



Leave the detergent drawer open so that any residual water can evaporate.



Drum

Leave the washing machine door open so that the drum can dry out.
Rust stains - use chlorine-free cleaning agent, not steel wool.



Descaling

Ensure there is no laundry in the machine

Descal the appliance according to the descaler manufacturer's instructions. This should not be necessary if the correct dosage of detergent is used.

Information to indicator lights

Indicator lights for status displays and/or buttons flash:

Indicator lights aclar/enx. (rinse) and lavar (wash) flash	Close the washing machine door properly; laundry may be caught.
Indicator lights centrifugar (spin) and lavar (wash) flash	Open the tap completely, supply hose kinked or trapped; Clean the filter → page 10, Water pressure too low.
Indicator lights centrifugar (spin) and aclar/enx. (rinse) flash	Detergent solution pump blocked; Clean the detergent solution pump → page 10. Drainage hose/waste pipe blocked; Clean the drainage hose at the siphon → page 10.
Indicator light aclar/enx. (rinse) flashes	Motor fault. Call the after-sales service.
All indicator lights flash	Turn off the tap and call the after-sales service.

Maintenance






- Risk of scalding.
Allow the detergent solution to cool down.
- Turn off the tap.



Detergent solution pump

Turn the programme selector to **Stop (Off)** and disconnect the mains plug.

1. Open and remove the service flap.
2. **For models with a drainage hose:** Remove the drainage hose from the retainer and pull it from the housing. Remove the container. Remove the sealing cap, allow the detergent solution to flow out. Replace the sealing cap and place the drainage hose in the retainer.
- 2* **For models without a drainage hose:** Carefully unscrew the pump cover until the detergent solution begins to flow out. When the service flap is half full, close the pump cover and empty the service flap. Repeat the above steps until all the detergent solution has completely drained out.
3. Carefully unscrew the pump cover (residual water).
4. Clean the interior, pump cover thread and pump housing (the impeller in the detergent solution pump must rotate).
5. Replace the pump cover and screw it tightly in place.
6. Place the service flap back on and close.




To prevent unused detergent from flowing straight into the drain during the next wash: pour 1 litre of water into compartment **II** and start the **Empty** programme.



Drainage hose at the siphon

Turn the programme selector to **Stop (Off)** and disconnect the mains plug.


1. Loosen the hose clamp, carefully remove the drainage hose (residual water).
2. Clean the drainage hose and siphon connecting piece.
3. Reattach the drainage hose and secure the connection with the hose clamp.



Filter in the water supply

Reduce the water pressure in the supply hose:

1. Turn off the tap.
2. Select any programme (except for **Centrifug. adicional (Spin)**, **Empty**).
3. Select **Inicio (Start)**. Let the programme run for approximately 40 seconds.
4. Turn the programme selector to **Stop (Off)**. Disconnect the mains plug.





Clean the filter:

1. Depending on model:
Disconnect the hose from the tap.
Clean the filter using a small brush.

and/or for Standard and Aqua-Secure models:

1. Remove the hose on the rear of the appliance.
Remove the filter with pliers and clean.
2. Connect the hose and check for leaks.



What to do if ...

Water is leaking out.	– Attach/replace the drainage hose correctly. – Tighten the screw connection of the supply hose.
No water supply. Detergent not dispensed.	– Inicio (Start) not selected? – Tap not turned on? – Filter blocked? Clean the filter → <i>page 10</i>. – Supply hose kinked or trapped?
Washing machine door cannot be opened.	– Safety function active. Wait approx. 2 minutes. –  (without final spin) selected? → <i>page 3, 4</i>.
Programme does not start.	– Inicio (Start) selected? – Washing machine door closed?
Detergent solution is not drained.	–  (without final spin) selected? → <i>page 3, 4</i>. – Clean the detergent solution pump → <i>page 10</i>. – Clean the waste pipe and/or drainage hose.
Water not visible in the drum.	– Not a fault - water below the visible area.
Unsatisfactory spin result. Laundry wet/too damp.	– Not a fault - the unbalanced-load detection system has cancelled the spin cycle because of uneven distribution of the laundry. Distribute small and large items of laundry evenly inside the drum. – Too low a speed selected? → <i>page 5</i>.
Spin cycle performed several times.	– Not a fault - unbalanced load detection system adjusts the imbalance.
Residual water in the compartment for care products.	– Not a fault - the action of the care product is not affected. – Clean the insert if necessary → <i>page 9</i>.
Odour formation in the washing machine.	– Run programme Resistentes/Algod. (Cottons) 90 °C without laundry. Use standard detergent.
Foam escaping from the detergent drawer.	– Too much detergent used? – If foam is escaping from the detergent drawer: Mix 1 tablespoon of fabric softener with ½ litre of water and pour into compartment II (<i>not with outdoor or down fabrics</i>). – Reduce the detergent dosage for the next wash cycle.
Intense noise formation, vibrations and “walking” during the spin cycle.	– Are the appliance feet fixed? – Secure the appliance feet → <i>Installation instructions</i>. – Transportation safety devices removed? – Remove the transportation safety devices → <i>Installation instructions</i>.
Noises during spin and drain cycles.	– Clean detergent-solution pump → <i>page 10</i>
The indicator lights do not function during operation.	– Power cut? – Fuses tripped? Reset/change the fuse. – If the fault occurs repeatedly, call the after-sales service.
Programme sequence longer than usual.	– Not a fault - unbalanced load detection system adjusts imbalance by repeatedly distributing the laundry. – Not a fault - foam detection system active - adds an additional rinse cycle.
Detergent residues on the laundry.	– Occasionally, phosphate-free detergents contain water-insoluble residues. – Select  (Rinse) or brush out the laundry after washing.

If you cannot correct a fault yourself (switching on/off) or a repair is required:

- Turn the programme selector to **Stop (Off)** and remove the mains plug from the socket.
- Turn off the water supply and call the after-sales service → *Installation instructions*.



Washing machine

en Instruction manual