





























Overview of programmes → Refer to the table of consumption values on page 8 and notes on page 6.				
Programmes	°C	max.	Type of laundry	Additional functions, information
Cottons	30, 40, 60, 90 °C			
Intensive Stains	60 °C	5.5 kg	Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen	Express Wash
+Prewash	60 °C			
Easy-Care	30, 40, 60 °C	2.5 kg	Easy-care fabrics made of cotton, linen, synthetic fibres or blended fabrics	Express Wash
Delicates	30 °C		For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. curtains)	Express Wash No spin between rinse cycles
Wool 	cold, 30 °C	2 kg	Hand- or machine-washable fabrics made of wool or containing wool	Particularly gentle wash programme to prevent shrinkage of laundry. Longer programme breaks (fabrics rest in the detergent solution)
Additional programmes				
1 Programmes without prewash - add detergent to compartment II ; programmes with prewash - distribute the detergent between compartments I and II .				
0811 / 9000640405		WAA28168GB		Robert Bosch Hausgeräte GmbH Carl-Wery-Str. 34 81739 München / Germany

Consumption values				
Programme	Load	Electricity***	Water***	Programme duration***
Cottons 30 °C*	5.5 kg	0.32 kWh	57 l	1:40 min
Cottons 40 °C*	5.5 kg	0.60 kWh	57 l	1:45 min
Cottons 60 °C*	5.5 kg	0.87 kWh	57 l	1:55 min
Cottons 90 °C	5.5 kg	2.00 kWh	64 l	1:50 min
Easy-Care 40 °C*	2.5 kg	0.45 kWh	50 l	1:15 min
Delicates 30 °C	2 kg	0.30 kWh	55 l	0:50 min
Wool  30 °C	2 kg	0.20 kWh	35 l	0:55 min
* Programme setting for testing in accordance with valid standard EN60456. Note on comparative tests: For testing the test programmes, wash the specified load using the maximum spin speed.				
Programme	Load	Annual energy consumption	Annual water consumption	
Cottons 40°C** / Cottons Intensive Stains 60°C**	5,5/2,75 kg	175 kWh	9400 l	
** Programme setting for testing and energy labelling in accordance with EU directive 2010/30/EU with cold water (15 °C). ***The values deviate from the indicated values depending on water pressure, hardness, and inlet temperature, ambient temperature, type, amount and soiling of the laundry, detergent used, fluctuations in the power supply and selected additional functions.				

Before washing for the first time	
 II:	Do not load any laundry into the machine. Turn on the tap. Add the following to compartment II : <ul style="list-style-type: none">– approx. 1 litre water– detergent (dosage according to the manufacturer's instructions for light soiling and the appropriate degree of water hardness) Set the programme selector to Easy-Care 60 °C and select Start . At the end of the programme, turn the programme selector to Off .
	<ul style="list-style-type: none">– Risk of electric shock. <i>Disconnect the mains plug.</i>– Risk of explosion. <i>No solvents.</i>
Care	
	Machine housing, control panel <ul style="list-style-type: none">– Wipe with a soft, damp cloth.– Do not use any abrasive cloths, scourers or cleaning agents (stainless steel cleaners).– Remove detergent and cleaning agent residue immediately.– Do not clean with a jet of water.
	Cleaning the detergent drawer if it contains detergent or fabric softener residues. <ol style="list-style-type: none">1. Pull out, press insert down, remove drawer completely.2. To remove the insert: press the insert upwards from below with your finger.3. Clean the detergent dispenser tray and insert with water and a brush and dry it.4. Attach the insert and engage (connect the cylinder to the guide pin).5. Push in the detergent drawer.
	Leave the detergent drawer open so that any residual water can evaporate.
	Drum Leave the washing machine door open so that the drum can dry out. Rust stains - use chlorine-free cleaning agent, not steel wool.
	Descaling <i>Ensure there is no laundry in the machine</i> Descale the appliance according to the descaler manufacturer's instructions. This should not be necessary if the correct dosage of detergent is used.
Information to indicator lights	
Indicator lights for status displays flash:	
Wash and Rinse	Close the washing machine door properly; laundry may be caught.
Wash and Spin	<ul style="list-style-type: none">– Open the tap completely.– Supply hose kinked or trapped.– Clean the filter → <i>page 10</i>, Water pressure too low.
Rinse and Spin	Detergent solution pump blocked; Clean the detergent solution pump → <i>page 10</i> . Drainage hose/waste pipe blocked; Clean the drainage hose at the siphon → <i>page 10</i> .

Maintenance	
	Detergent solution pump Turn the programme selector to Off and disconnect the mains plug. <ol style="list-style-type: none">1. Remove the service flap for detergent solution pump.2. Carefully unscrew the pump cover (residual water).3. Clean the interior, pump cover thread and pump housing (the impeller in the detergent solution pump must rotate).4. Replace the pump cover and screw it tightly.5. Place the service flap back. <p>To prevent unused detergent from flowing straight into the drain during the next wash: Pour 1 litre of water into compartment II and start the Drain programme.</p>
	Drainage hose at the siphon Turn the programme selector to Off and disconnect the mains plug. <ol style="list-style-type: none">1. Loosen the hose clamp, carefully remove the drainage hose (residual water).2. Clean the drainage hose and siphon connecting piece.3. Reattach the drainage hose and secure the connection with the hose clamp.
	Filter in the water supply  Risk of electric shock <i>Do not immerse the HydroSafe safety device in water (contains an electric valve).</i> Reduce the water pressure in the supply hose: <ol style="list-style-type: none">1. Turn off the tap.2. Select any programme (except Spin/Drain).3. Select Start. Let the programme run for approximately 40 seconds.4. Turn the programme selector to Off. Disconnect the mains plug. and/or for Standard and Aqua-Secure models: Remove the hose on the rear of the appliance, Remove the filter with pliers and clean. <ol style="list-style-type: none">6. Connect the hose and check the leak tightness of the connection points.

What to do if ...	
	Water is leaking out. <ul style="list-style-type: none">– Attach/replace the drainage hose correctly.– Tighten the screw connection of the supply hose.
	No water supply. Detergent not dispensed. <ul style="list-style-type: none">– Start not selected?– Tap not turned on?– Filter blocked? Clean the filter → <i>page 10</i>.– Supply hose kinked or trapped?
	Washing machine door cannot be opened. <ul style="list-style-type: none">– Safety function active. Wait approx. 2 minutes.
	Programme does not start. <ul style="list-style-type: none">– Start selected?– Washing machine door closed?
	Detergent solution is not drained. <ul style="list-style-type: none">– Clean the detergent solution pump → <i>page 10</i>.– Clean the waste pipe and/or drainage hose.
	Water not visible in the drum. <ul style="list-style-type: none">– Not a fault - water below the visible area.
	Unsatisfactory spin result. Laundry wet/too damp. <ul style="list-style-type: none">– Not a fault - the unbalanced-load detection system has cancelled the spin cycle because of uneven distribution of the laundry. Distribute small and large items of laundry evenly inside the drum.– Selected speed too low? → <i>page 5</i>.
	Spin cycle performed several times. <ul style="list-style-type: none">– Not a fault - unbalanced load detection system adjusts the imbalance.
	Residual water in the compartment for care products. <ul style="list-style-type: none">– Not a fault - the action of the care product is not affected.– Clean the insert if necessary → <i>page 9</i>.
	Odour formation in the washing machine. <ul style="list-style-type: none">– Run programme Cottons 90 °C without laundry. Use standard detergent.
	Foam escaping from the detergent drawer. <ul style="list-style-type: none">– Too much detergent used?– If foam is escaping from the detergent drawer: Mix 1 tablespoon of fabric softener with ½ litre of water and pour into compartment II (<i>not with outdoor or down fabrics</i>).– Reduce the detergent dosage for the next wash cycle.
	Intense noise formation, vibrations and “wandering” during the spin cycle. <ul style="list-style-type: none">– Are the appliance feet fixed? Secure the appliance feet → <i>Installation instructions</i>.– Transportation safety devices removed? Remove the transportation safety devices → <i>Installation instructions</i>.
	Indicator lamps do not function during operation. <ul style="list-style-type: none">– Power cut?– Fuses triggered? Reset/change the fuses.– If the fault occurs repeatedly, call the after-sales service.
	Programme sequence longer than usual. <ul style="list-style-type: none">– Not a fault - unbalanced load detection system adjusts imbalance by repeatedly distributing the laundry.– Not a fault - foam detection system active - adds an additional rinse cycle.
	Detergent residues on the laundry. <ul style="list-style-type: none">– Occasionally, phosphate-free detergents contain water-insoluble residues.– Select Rinse or brush the laundry after washing.

	
Washing machine	
en Instruction manual	

Your washing machine

Congratulations - You have opted for a modern, high-quality domestic appliance manufactured by Bosch. This washing machine is distinguished by its economical water and energy consumption. Each machine that leaves our factory has been inspected thoroughly to ensure that it functions properly and is in perfect condition.

For further information and a selection of our products go to our web site: www.bosch-home.com

You can find the contact details for your nearest after-sales service here or in the after-sales service directory (*depending on model*), see also Installation Instructions, *page 7*.

- **GB** 0844 8928979 Calls from a BT landline will be charged at up to 3 pence per minute. A call set-up fee of up to 6 pence may apply.
- **IE** 01450 2655

Environmentally friendly waste disposal

All packaging must be disposed of in accordance with environmental guidelines. This appliance is certified in accordance with European Directive 2002/96/EC on waste electrical and electronic equipment (WEEE). This directive provides the framework for the EU-wide collection and reuse of used appliances.

Contents

	Page
Intended use	1
Programmes	1
Setting and adjusting the programme	3
Washing	3/4
After washing	4
Individual settings	5
Important information	6
Overview of programmes	7
Safety instructions	8
Consumption values	8
Before washing for the first time/Care	9
Information to indicator lights	9
Maintenance	10
What to do if... ..	11



Environmental protection/Conservation tips

- Always fill the washing machine with a maximum amount of laundry for the relevant programme.
- Wash normally soiled washing without a pre-wash.
- Instead of **Cottons 90 °C**, choose the programme **Cottons 60 °C Intensive Stains**. Comparable cleaning result with significantly lower energy consumption.
- Measure the detergent according to the manufacturer's instructions and water hardness.
- If the laundry is then dried in the tumble dryer, select the spin speed according to the instructions of the dryer manufacturer.

Intended use

- for use in the household only,
- for machine-washable fabrics and hand-washable wool in detergent solution,
- to be operated with cold drinking water and commercially available detergents and care products which are suitable for use in washing machines.

- Observe the safety instructions on page 8.
 - Do not leave children unattended near the washing machine.
 - The washing machine is not to be used by children or persons not familiar with the operating instructions.
 - Keep pets away from the washing machine.
- Read these instructions and the separate installation instructions before operating the washing machine.



Preparation



Correct installation according to the separate Installation instructions.



Checking the machine

- Never use a damaged machine.
- Inform the after-sales service.




Connecting the mains plug



Make sure your hands are dry. Take hold of the plug only.



Turning the tap on



Compartment II: Detergent for the main wash, water softener, bleach, stain remover

Compartment : Fabric softener, starch


Compartment I: Detergent for pre-wash

(*spin speed depending on model)

Programmes

Detailed overview of programmes → *page 7*.

Cottons	hard-wearing fabrics
Cottons Intensive Stains	hard-wearing fabrics
Cottons + Prewash	hard-wearing fabrics, prewash at 30 °C
Rinse	with subsequent spin cycle
Spin	laundry washed by hand
Drain	the rinsing water
Wool	hand/machine-washable textiles
Delicates	delicate washable fabrics
Easy-Care	easy-care fabrics



Pr
sw
an
th
tu

Before washing for the first time
Wash once without any laundry → page 9.

Sorting and loading laundry

Follow the manufacturer's care information. According to the information on the care labels. According to type, colour, soiling and temperature. Do not exceed the maximum load → page 7.

Observe the important information → page 6.

Insert large and small items of laundry.

Close the washing machine door. Take care not to trap items of laundry between the washing machine door and the rubber seal.

Add detergent and care products


Measure accordingly:

Amount of laundry, soiling, water hardness (ask your water supply company) and manufacturer's instructions. Pour liquid detergent into the appropriate dispenser and place in the drum.

i Dilute thick fabric softener and fabric conditioner with water. This prevents blockages.

Setting and adjusting programmes

Programme selector



Additional function → Individual settings, page 5.

Select Start ▷

Programme selector for switching the machine on and off and for selecting the programme. Can be turned in either direction.

Washing

Detergent drawer with compartments I, II, ⌘

Drum

Control panel

Washing machine door

Service flap for detergent solution pump

Removing the washing

Open the washing machine door and remove the washing.



- Remove any foreign objects - risk of rusting.
- Leave the washing machine door and detergent drawer open so that any residual water can evaporate.

Turning the tap off

Not required for AquaStop models → Hinweise Installation Instructions, page 7.

Switching off

Turn the programme selector to **Off**.

End of programme when ...

... the status indicator **Spin - End** flashes.

Interrupting the programme

Programmes at high temperatures:

- Cool washing: Select **Rinse**.
- Select **Start**.

Programmes at lower temperatures:

- Select **Spin** or **Drain**.
- Select **Start**.

Changing the programme, if ...

... you have selected the wrong programme by mistake:

- Reselect the programme.
- Select **Start**. The new programme starts from the beginning.

Individual settings

- Additional functions** → and overview of programmes, see page 7.

1400 ↓
600 ↓

Express Wash

Reduce spin speed (*values depending on model*).
Reduced wash time - only 2 rinse cycles.Suited for slightly soiled washing. Recommended load: up to a maximum of 3 kg.
- Start** ▶

For starting the programme.



Important information



Protecting the washing and the machine

- Empty pockets.
- Look out for metal items (paperclips, etc.).
- Wash delicates in a laundry bag (tights, curtains, underwired bras).
- Fasten zips, do up any buttons.
- Brush sand out of pockets and collars.
- Remove curtain fittings or place in the laundry bag.



Washing with varying degrees of soiling

		Wash new items of clothing separately.
light		Do not pre-wash.
		If required, pretreat stains. Select programme Cottons 60°C Intensive Stains .
heavy		Load less washing. Select programme Cottons 60°C + Prewash .



Starching

Washing must not be treated with fabric softener

Starching is possible in all wash programmes if liquid starch is used. Pour the starch in accordance with the manufacturer's instructions into fabric softener compartment ⌘ (rinse first if necessary).




Dyeing/bleaching

Dye should only be used in normal household quantities. Salt may damage stainless steel. Always follow the dye manufacturer's instructions! Do **not** use the washing machine for bleaching clothes!

Overview of programmes

→ Refer to the table of consumption values on page 8 and notes on page 6.

Programmes	°C	max.	Type of laundry	Additional functions; information
Cottons	30, 40, 60, 90 °C			
Intensive Stains	60 °C	5.5 kg	Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen	1400 l, Express Wash
+Prewash	60 °C			
Easy-Care	30, 40, 60 °C	2.5 kg	Easy-care fabrics made of cotton, linen, synthetic fibres or blended fabrics	1400 l, Express Wash
Delicates	30 °C	2 kg	For delicate, washable fabrics; e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. curtains)	1400 l, Express Wash No spin between rinse cycles
Wool 	cold, 30 °C		Hand- or machine-washable fabrics made of wool or containing wool	Particularly gentle wash programme to prevent shrinkage of laundry. Longer programme breaks (fabrics rest in the detergent solution)
Additional programmes				
i Programmes without prewash - add detergent to compartment II , programmes with prewash - distribute the detergent between compartments I and II .				

0811 / 9000640405

WAA28168GB

Robert Bosch Hausgeräte GmbH
Carl-Wery-Str. 34
81739 München / Germany

Safety instructions

- Read the instruction manual and installation instructions and all other information enclosed with the washing machine and act accordingly.
- Retain the documents for subsequent use.

Risk of electric shock

Danger to life

Danger of suffocation

Risk of poisoning
Risk of explosion

Risk of injury

- Never pull the cable to disconnect the mains plug.
- Never insert/disconnect the mains plug with damp hands.

For worn-out appliances:

- Disconnect the mains plug.
- Sever the mains cable and discard along with the plug.
- Destroy the lock on the washing machine door. This will prevent children from locking themselves in and risking their lives.


- Keep packaging, film and packaging parts out of the reach of children.

- Keep detergents and care products out of the reach of children.

- Items of laundry pretreated with cleaning agents containing solvents, e.g. stain remover/cleaning solvent may cause an explosion after being loaded into the washing machine. Rinse items of laundry thoroughly by hand beforehand.

- The washing machine door can become very hot.
- Be careful when draining hot detergent solution.
- Do not climb onto the washing machine.
- Do not lean on the open washing machine door.
- Do not reach into the drum if it is still rotating.
- Be careful when opening the detergent drawer while the machine is in operation.

Consumption values

Programme	Load	Electricity***	Water***	Programme duration***
Cottons 30 °C*	5.5 kg	0.32 kWh	57 l	1:40 min
Cottons 40 °C*	5.5 kg	0.60 kWh	57 l	1:45 min
Cottons 60 °C*	5.5 kg	0.87 kWh	57 l	1:55 min
Cottons 90 °C	5.5 kg	2.00 kWh	64 l	1:50 min
Easy-Care 40 °C*	2.5 kg	0.45 kWh	50 l	1:15 min
Delicates 30 °C	2 kg	0.30 kWh	55 l	0:50 min
Wool  30 °C	2 kg	0.20 kWh	35 l	0:55 min

* Programme setting for testing in accordance with valid standard EN60456.
Note on comparative tests: For testing the test programmes, wash the specified load using the maximum spin speed.

Programme	Load	Annual energy consumption	Annual water consumption
Cottons 40°C** / Cottons Intensive Stains 60°C**	5,5/2,75 kg	175 kWh	9400 l

** Programme setting for testing and energy labelling in accordance with EU directive 2010/30/EU with cold water (15 °C).
*** The values deviate from the indicated values depending on water pressure, hardness, and inlet temperature, ambient temperature, type, amount and soiling of the laundry, detergent used, fluctuations in the power supply and selected additional functions.

Before washing for the first time

i Do not load any laundry into the machine. Turn on the tap. Add the following to compartment **II**:

- approx. 1 litre water
- detergent (dosage according to the manufacturer's instructions for light soiling and the appropriate degree of water hardness)

Set the programme selector to **Easy-Care 60 °C** and select **Start**. At the end of the programme, turn the programme selector to **Off**.

Care



! Risk of electric shock. Disconnect the mains plug.
! Risk of explosion. No solvents.

i **Machine housing, control panel**

- Wipe with a soft, damp cloth.
- Do not use any abrasive cloths, scourers or cleaning agents (stainless steel cleaners).
- Remove detergent and cleaning agent residue immediately.
- Do not clean with a jet of water.

! Cleaning the detergent drawer ...
... if it contains detergent or fabric softener residues.

1. Pull out, press insert down, remove drawer completely.
2. To remove the insert: press the insert upwards from below with your finger.
3. Clean the detergent dispenser tray and insert with water and a brush and dry it.
4. Attach the insert and engage (connect the cylinder to the guide pin).
5. Push in the detergent drawer.



i Leave the detergent drawer open so that any residual water can evaporate.

i **Drum**

Leave the washing machine door open so that the drum can dry out. Rust stains - use chlorine-free cleaning agent, not steel wool.

i **Descaling** *Ensure there is no laundry in the machine*

Descale the appliance according to the descaler manufacturer's instructions. This should not be necessary if the correct dosage of detergent is used.

Information to indicator lights

Indicator lights for status displays flash:	
Wash and Rinse	Close the washing machine door properly; laundry may be caught.
Wash and Spin	<ul style="list-style-type: none">- Open the tap completely.- Supply hose kinked or trapped.- Clean the filter → <i>page 10</i>, Water pressure too low.
Rinse and Spin	Detergent solution pump blocked; Clean the detergent solution pump → <i>page 10</i> . Drainage hose/waste pipe blocked; Clean the drainage hose at the siphon → <i>page 10</i> .


Maintenance

! Risk of scalding. Allow the detergent solution to cool down.
! Turn off the tap.

! Detergent solution pump

Turn the programme selector to **Off** and disconnect the mains plug.

1. Remove the service flap for detergent solution pump.
2. Carefully unscrew the pump cover (residual water).
3. Clean the interior, pump cover thread and pump housing (the impeller in the detergent solution pump must rotate).
4. Replace the pump cover and screw it tightly.
5. Place the service flap back.




To prevent unused detergent from flowing straight into the drain during the next wash: Pour 1 litre of water into compartment **II** and start the **Drain** programme.

! Drainage hose at the siphon

Turn the programme selector to **Off** and disconnect the mains plug.

1. Loosen the hose clamp, carefully remove the drainage hose (residual water).
2. Clean the drainage hose and siphon connecting piece.
3. Reattach the drainage hose and secure the connection with the hose clamp.




! Filter in the water supply

! Risk of electric shock
Do not immerse the HydroSafe safety device in water (contains an electric valve).

Reduce the water pressure in the supply hose:

1. Turn off the tap.
2. Select any programme (except **Spin/Drain**).
3. Select **Start**. Let the programme run for approximately 40 seconds.
4. Turn the programme selector to **Off**. Disconnect the mains plug.




5. Clean the filter:
Disconnect the hose from the tap.
Clean the filter using a small brush.

and/or for Standard and Aqua-Secure models:

Remove the hose on the rear of the appliance, Remove the filter with pliers and clean.

6. Connect the hose and check the leak tightness of the connection points.



What to do if ...

● Water is leaking out.	<ul style="list-style-type: none"> – Attach/replace the drainage hose correctly. – Tighten the screw connection of the supply hose.
● No water supply. Detergent not dispensed.	<ul style="list-style-type: none"> – Start not selected? – Tap not turned on? – Filter blocked? Clean the filter → <i>page 10</i>. – Supply hose kinked or trapped?
● Washing machine door cannot be opened.	<ul style="list-style-type: none"> – Safety function active. Wait approx. 2 minutes.
● Programme does not start.	<ul style="list-style-type: none"> – Start selected? – Washing machine door closed?
● Detergent solution is not drained.	<ul style="list-style-type: none"> – Clean the detergent solution pump → <i>page 10</i>. – Clean the waste pipe and/or drainage hose.
● Water not visible in the drum.	<ul style="list-style-type: none"> – Not a fault - water below the visible area.
● Unsatisfactory spin result. Laundry wet/too damp.	<ul style="list-style-type: none"> – Not a fault - the unbalanced-load detection system has cancelled the spin cycle because of uneven distribution of the laundry. Distribute small and large items of laundry evenly inside the drum. – Selected speed too low? → <i>page 5</i>.
● Spin cycle performed several times.	<ul style="list-style-type: none"> – Not a fault - unbalanced load detection system adjusts the imbalance.
● Residual water in the compartment for care products.	<ul style="list-style-type: none"> – Not a fault - the action of the care product is not affected. – Clean the insert if necessary → <i>page 9</i>.
● Odour formation in the washing machine.	<ul style="list-style-type: none"> – Run programme Cottons 90 °C without laundry. Use standard detergent.
● Foam escaping from the detergent drawer.	<ul style="list-style-type: none"> – Too much detergent used? – If foam is escaping from the detergent drawer: Mix 1 tablespoon of fabric softener with ½ litre of water and pour into compartment II (<i>not with outdoor or down fabrics</i>). – Reduce the detergent dosage for the next wash cycle.
● Intense noise formation, vibrations and “wandering” during the spin cycle.	<ul style="list-style-type: none"> – Are the appliance feet fixed? Secure the appliance feet → <i>Installation instructions</i>. – Transportation safety devices removed? Remove the transportation safety devices → <i>Installation instructions</i>.
● Indicator lamps do not function during operation.	<ul style="list-style-type: none"> – Power cut? – Fuses triggered? Reset/change the fuses. – If the fault occurs repeatedly, call the after-sales service.
● Programme sequence longer than usual.	<ul style="list-style-type: none"> – Not a fault - unbalanced load detection system adjusts imbalance by repeatedly distributing the laundry. – Not a fault - foam detection system active - adds an additional rinse cycle.
● Detergent residues on the laundry.	<ul style="list-style-type: none"> – Occasionally, phosphate-free detergents contain water-insoluble residues. – Select Rinse or brush the laundry after washing.

If you cannot correct a fault yourself or a repair is required:

- Turn the programme selector to **Off** and remove the mains plug from the socket.
- Turn off the water supply and call the after-sales service → *Installation instructions*.



Washing machine

en Instruction manual