



Brief and handy:  
everything your dishwasher  
needs ...


 Before using for the first time,  
read the Installation instructions  
and Operating instructions!




## 2 Filling the salt dispenser



## 3 Adding rinse aid



## 4 Adding detergent



## 5 Switch on the device.



## 6 Select programme




The programme data has been measured in the laboratory according to European standard EN 50242. Deviations are possible in practice.  
\* half normal load

Duration: hs/mins	3:15 - 1:30	0:29 *	0:15
Energy consumption in kWh	1,30 - 0,70	0,80	0,05
Water consumption in litres	18 - 7	10	4

## 7 Start programme Here we go ...

## 8 Additional options \*\*



## 9 Switch off the appliance Everything o.k. ...

\*\* depending on model


Quickly sorted ...

## How to adjust


- Switch on ON/OFF switch.
- Hold down programme button A and press START button until H:0 ... is indicated on the digital display.
- Release both buttons. The LED for button A flashes and the factory set value of H:04 is indicated on the digital display.
- Press programme button C. Each time the button is pressed the set value increases by one setting; when the value reaches H:07, the display jumps back to H:00 (off).
- Press START button. The chosen setting has now been stored.

## Maintenance and care


Filters  
... check,  
if required,  
clean.




Rotate  
filter cylinder,  
remove filter  
system ...



rinse  
under  
running  
water ...




insert ...




Screw on  
filter system  
NOTE  
MARK!

- Pull out the mains plug.
- Remove filters and scoop out water.
- Lever off cover (A).
- Check area around the fan impeller for foreign objects.
- Click cover shut (B).
- Insert filters.


Spray arms  
... Remove  
blockages/  
deposits.




pull lower arm  
upwards ...




unscrew  
upper arm ...




clean spray nozzles  
under running water  
(if required  
use toothpicks) ...



insert  
lower arm ...



screw on upper  
arm tightly



**A**

**B**

**CLICK!**

## Rectifying minor faults yourself ...

... as it is worth doing it yourself!

More information can be found in the operating instructions


### Fault

### Possible causes

### Remedial action

Display "█" is lit

Supply fitting jammed  
or calcified



- Open supply fitting.
- 1. Unscrew water connection.  
2. Clean filter in the water connection.  
3. Flow rate must be min. 10 l/min.,  
when water supply is open.  
If the flow rate is less,  
replace the supply fitting.
- Install supply hose without kinks.

Display "E:22"

Filters are soiled or blocked

- Clean the filters (see above).

Display "E:24"  
and "█" are lit

Waste water hose is blocked  
or kinked  
Cover not attached to waste  
water pump

- Install waste water hose without kinks.
- Attach cover (see above).

Display "E:25"  
and "█" are lit

Waste water pump blocked

- Clean waste-water pump (see above).

Other fault display  
"E:XX" is lit

Appliance has technical defect

- Call factory customer service (state fault display).
- Unplug appliance.

Residual water  
in the appliance

The programme has not yet ended

- Switch on and close the appliance  
or terminate the programme  
(see Terminating the programme).

Rust on the cutlery

Cutlery not rust-resistant  
Hard knife blades are more susceptible  
Extraneous rust

- Use dishwasher-proof cutlery.
- Never wash rusting parts in the appliance.


### Fault

### Possible causes

### Remedial action

Utensils are not clean

Sand or gritty residue  
on the utensils



Utensils are situated close together  
or one above the other

Too little detergent  
Unsuitable programme selected

Spray arm nozzles blocked  
Filters dirty, not seated firmly  
Spray arms blocked

- Separate the utensils, prevent contact points.

- Follow manufacturer's instructions (detergent).
- Select a more intensive programme.

- Clean the spray arms (see above).
- Clean the filters (see above).
- Arrange the utensils so that the spray arms can rotate freely.

Stains and streaks

Rinse aid dosage too high/  
too low

- Streaks: reduce dosage.
- Water or limescale stains: increase dosage.

Utensils not dry

Rinse aid

- Increase dosage.
- Change the product.
- Use rinse aid.

Milky deposits  
on the utensils  
(can be removed)

The combined detergent used  
has a poor drying performance  
Appliance setting

- Activate intensive drying (depending on model).
- Correctly set water softening system.

Water softening system incorrectly set

No salt

- Refill with special salt.

Milky deposits, glasses  
cloudy/tarnished  
(cannot be removed)

Glasses not dishwasher-proof

- Use dishwasher-proof glasses.
- Use a detergent suitable for glasses.

Plastic/utensils  
discoloured

Too little detergent

Discoloration caused by food colourings  
(tomato sauce)

- Follow manufacturer's instructions (detergent).
- Discoloration is harmless; subsequent rinse cycles will cause it to fade.

## Terminating the programme ...

While the programme is running,  
press the START button  
for approx. 3 sec. (Reset).



The numerical display  
indicates "0:01";  
approx. 1 minute after  
the programme ends,  
"0:00" is indicated.



Switch off the appliance.

## Loading the dishwasher correctly ...

Dishwasher-proof utensils (not soiled with ash, wax, lubricating grease, ink or adhesive labels; remove large remnants of jam, milk products and food according to the operating instructions and check that the spray arms can rotate freely).