





Dishwasher SM... SB...



en Instruction manual





#### **Table of contents**

S Intended use5	Water softening system /
Safety instructions. 5  Before you switch ON the appliance 5 Delivery. 5 Installation. 6 In daily use 7 Damage 7 Disposal 7	special salt
Door lock	Rinse aid
Old appliances       10         Getting to know your appliance       10         Control panel       10         Appliance interior       11         Info button       11         Time setting       11         Initial start-up       12         Settings       13         Home Connect       15         Info button       15         Setting up the App       15         Setting up Home Connect       16         Wi-Fi       16	Not suitable
Network login	Adding detergent

#### en

D+ Additional functions	2.4
P+ Additional functions	34
Save time (VarioSpeedPlus) 3	34
Half load	34
hygienePlus (HygienePlus)	34
intensiveZone	
extraDry	
Shine and Dry	
Energy Save	)
Operating the appliance	35
Programme data	
Changing the settings	
AquaSensor	
Zeolith drying	
Time display	
Sensor setting	37
extraDry	
Eco forecast	
Auto Power Off	
emotionLight	
Front display	
timeLight	
infoLight	
Changing start programme	
Tone volume	
Child-proof lock	
Greeting	
Factory setting	
Switching the appliance on	
Time preselection	
Programme end	
Switching off the appliance	
Interrupting the programme	10
Terminating the programme	
Changing the programme	11

54	
Cleaning and maintenance	41
Overall status of the dishwasher	41
Machine Care	42
Special salt and rinse aid	
Spray arms	
Fault, what to do?	44
Error message	44
Waste water pump	
Fault table	46
Customer service	55
Installation and connection	55
Contents of package	55
Safety instructions	
Delivery	56
Technical specifications	
Drainage connection	
Drinking water connection	
Warm water connection	
Electrical connection	
Removal	58
TransportingProtection against frost	59
(Emptying the appliance)	59

#### S Intended use

- This appliance is intended for use in the home and domestic environments
- Use the dishwasher only in the home and only for its designated purpose: for washing domestic dishes.
- This appliance is intended for use up to a maximum altitude of 2500 metres above sea level.

## **⚠** Safety instructions

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 8 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

#### Before you switch ON the appliance

Please read the instructions for use and installation carefully. They contain important information on how to install. use and maintain the appliance.

Retain all documents for later use or for the subsequent owner.

You can download the instructions for use from our website free of charge. The relevant Internet address can be found overleaf on these instructions for use.

#### **Delivery**

- Check the packaging and dishwasher immediately for damage caused in transit. Do not switch on a damaged appliance, but contact your supplier.
- 2. Please dispose of the packaging material in an environmentally friendly manner.
- 3. Do not let children play with packaging and its parts. There is a risk of suffocation from collapsible boxes and film.

#### Installation

- Following installation, ensure that the back of the dishwasher is not freely accessible (protection against contact due to hot surface).
- Install and connect the appliance according to the installation and assembly instructions.
- Prior to installation, disconnect the dishwasher from the power supply.
- Ensure that the protective conductor system of the domestic supply has been correctly installed.
- The electrical connection conditions must correspond with the specifications on the dishwasher rating plate 35.
- If the power cord of this appliance is damaged, it must be replaced with a particular power cord. To prevent injury, the power cord may be purchased from customer service only.
- If the dishwasher is installed in a high-sided unit, the unit must be secured properly.
- If the dishwasher is installed below or above other domestic appliances, follow the information for installation in combination with a dishwasher in the installation instructions for the particular appliances.

- Also follow the installation instructions for the dishwasher to ensure that all appliances are operated safely.
- If there is no information or if the installation instructions do not include the appropriate information, contact the manufacturer of these appliances to ensure that the dishwasher can be installed above or below these appliances.
- If you cannot obtain any information from the manufacturer, you must not install the dishwasher above or below these appliances.
- If you install a microwave oven above the dishwasher, the microwave oven may be damaged.
- Install built-under or integratable appliances only under continuous worktops which have been screwed to adjacent cupboards to ensure stability.
- Do not install the appliance near heat sources (radiators, heat storage tanks, cookers or other appliances which generate heat) and do not install under a hob.

- Please note that the insulation material of the dishwasher power cord mav melt next to heat sources (e.g. heating / hot water installations) or hot appliance parts. Make sure that the power cord of the dishwasher never comes into contact with heat sources or hot appliance parts.
- After installing the appliance, ensure that the plug is easily accessible. → "Electrical connection" on page 58
- For some models: The plastic housing on the water connection contains an electric valve. The supply hose contains electrical connection cables. Do not cut through the supply hose. Do not immerse the plastic housing in water.

#### In daily use

Read and observe the safety information and instructions for use on the packaging for cleaning and rinsing agents.

Ensure that you follow the safety instructions, even when operating the appliance via the Home Connect app, which are out of sight when you are away from home. Follow the instructions in the app.

#### **Damage**

- The appliance may be repaired and opened up by a technician only. To do this, disconnect the appliance from the power supply. Pull out the mains plug or switch off the fuse. Turn off the tap.
- If the appliance is damaged. especially the control panel (cracks, holes, broken buttons), or the door function is impaired, stop operating the appliance. Pull out the mains plug or switch off the fuse. Turn off tap, call customer service.

#### **Disposal**

- 1. Make redundant appliances unusable to prevent subsequent accidents.
- 2. Dispose of the appliance in an environmentally friendly manner.

### 🗥 Warning Risk of injury!

- To prevent injuries, e.g. caused by stumbling, open the dishwasher only briefly in order to load and unload the dishwasher.
- Knives and other utensils with sharp points must be placed with the points downwards in the cutlery basket\* 30 or horizontally on the knife shelf\* or in the cutlery drawer\* 21.

- Do not lean or sit on the open door.
- In the case of free-standing appliances, ensure that the baskets are not overloaded. The appliance could tip.
- If the appliance is not in a cavity and a side panel is accessible, the door hinge area must be covered at the side for reasons of safety (risk of injury). The covers are available as optional accessories from customer service or specialist outlets.
- \* depending on the features of your dishwasher

#### 

Do not add any solvents to the rinsing compartment. Danger of explosion!

#### 

Open the door carefully when the programme is still running. There is a risk of hot water spraying out of the appliance.

#### 

- If fitted, use the childproof lock.
- Do not allow children to play with or operate the appliance.

- Keep children away from detergents and rinse aid. These may cause chemical burns in the mouth, throat and eyes or asphyxiation.
- Keep children away from open dishwasher. There may be small parts in the dishwasher which children could swallow and the water inside the dishwasher is not drinking water as it may contain detergent residue.
- Ensure that children do not place fingers in the tablet collecting tray 24. Small fingers could become caught in the slots.
- When opening and closing the door on an eye-level appliance, ensure that children do not become jammed or crushed between the appliance door and the cupboard door below.
- Children could become locked in the appliance (danger of suffocation) or get into another dangerous situation.

Redundant appliances: Pull out the mains plug, sever and dispose of the power cord. Destroy the door lock so that the door can no longer be closed.

#### Childproof lock (door lock) \*


The child-proof lock (door lock) protects children from potential hazards which the dishwasher poses.

### 🗥 Warning Risk of suffocation!

Children may become locked in the dishwasher and suffocate. Always completely close the appliance door when leaving the dishwasher.


#### Activate the child-proof lock (door lock) as follows:

- 1. Pull the catch of the child-proof lock towards yourself (1).
- 2. Close the door (2). The child-proof lock is activated.



#### Open the door with activated child-proof lock (door lock) as follows:


- 1. Press the catch of the child-proof lock to the right
- 2. Open the door (2).



#### Deactivate the child-proof lock (door lock) as follows:

- i. Press the catch of the child-proof lock to the right (1).
- 2. Press the catch of the child-proof lock backwards (2).

The childproof lock is deactivated.



\* depending on the features of your dishwasher

# **Environmental** protection

Both the packaging of new appliances and the old appliances themselves contain valuable raw materials and recyclable materials.

Please dispose of the individual parts separated according to type.

Please ask your dealer or inquire at your local authority about current means of disposal.

#### **Packaging**

All plastic parts of the appliance are identified with internationally standardised abbreviations (e.g. PS polystyrene). Therefore, plastic waste can be sorted out when the appliance is being disposed of.

Please follow the safety instructions under "Delivery"  $\rightarrow$  Page 5.

#### Old appliances

Please follow the safety instructions under "Disposal of your appliance"  $\rightarrow$  Page 7.



This appliance has been identified in accordance with the European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE). The directive provides a framework for the collection and recycling of old appliances, which is valid across the FU.

# Getting to know your appliance

Diagrams of the control panel and the interior of the appliance can be found at the front of the manual, Individual positions are referred to in the text.

#### Control panel

- On/off switch
- 2 Programme buttons \*\*
- 3 Info button .....
- 4 Display window at top
- 5 Rinse aid refill indicator
- 6 Salt refill indicator
- 7 ] WLAN display
- 8 Selection buttons
- Time preselection 9
- 10 Remote start button
- [11] Additional functions/programme buttons \*\*
- 12 START button
- 13 Front display \*
- 14 Door opener
- 15 Remote start display \*
- **16** < > button
- \* depending on the features of your dishwasher
- \*\* number depending on the features of vour dishwasher

#### **Appliance interior**

- 20 Interior light \*
- 21 Cutlery drawer \*
- 22 Top basket
- 23 Upper spray arm
- 24 Tablet collecting tray
- 25 Intake opening
- [26] Blow opening (Zeolith container)
- [27] Lower spray arm
- 28 Dispenser for special salt
- [29] Filters
- 30 Cutlery basket \*
- 31 Bottom basket
- 32 Dispenser for rinse aid
- 33 Detergent dispenser
- 34 Lock for detergent dispenser
- 35 Rating plate
- \* depending on the features of your dishwasher

#### Info button .....

The Info button in can be used to display additional programme information.

- 1. Press the Info button .... 3.
- 2. Press the programme button. Information on the selected programme is indicated on the display window at the top 4.
- 3. To leave, press Info button 3.

#### Time setting

When the appliance is switched on the for the first time, the time starts at 12:00 o'clock

#### Set the time as follows:

- 1. Open the door.
- 2. Switch on ON/OFF switch 1.
- 3. Press Info button 3 for 3 seconds until the following text is indicated on the display window at the top  $\boxed{4}$ :

Scroll with <> Set with - +

Leave with Setup 3 sec.

- 4. Keep pressing button > 16 until the time setting is indicated on the display window at the top 4.
- 5. Make the setting with setting buttons + - 8. If the selection buttons + -8 are held down, the set values are changed in 10-minute steps.
- 6. Press and hold the Info button 3 for 3 seconds.

The chosen setting has now been stored.

Note: If the appliance was disconnected from the power supply for a prolonged period, the time starts at 12:00 o'clock. Set the time.

#### **Initial start-up**

When the dishwasher is switched on for the first time, you are taken directly to the settings for the initial start-up.

Note: If you select Home Connect during the initial start-up, make further settings via your dishwasher App. Observe the supplied Home Connect documents

On the display window at the top 4 the following text appears for manual selection:

#### Scroll with <> Set with - + Leave with Setup 3 sec.

The required settings for the initial start-up are listed in the table below.

#### To change the setting:

- 1. Keep pressing button > 16 until the required setting is displayed. Change the setting with setting buttons + - 8.
- 2. Press and hold the Info button 3 for 3 seconds.

The chosen setting has now been stored.

Initial start-up settings	Factory setting	Infotext by pressing Info button <b>i</b>
Language	Deutsch	Language selection.
Home Connect	Manual/Home Connect	Manual/Home Connect.
Time format	24 h	12h or 24h.
Time setting	12:00	Set the current time.
Water hardness	°E 16 - 20 medium	Adjustment to the local water hardness. When using Multitabs, select the lowest setting.
Rinse aid disp.	Level 5	Amount of rinse aid affects drying. When using Multitabs, select setting 0.
Water connection *	Cold water	Connection to hot water (40-60°C) or cold water (<40°C) possible.
* depending on the feature	s of your dishwasher	

#### **Settings**

The dishwasher has been preset with certain settings for your convenience. However you can also change this factory setting.

#### To change the setting:

- 1. Open the door.
- 2. Switch on ON/OFF switch 1.
- 3. Press Info button 3 for 3 seconds until the following text is indicated on the display window at the top 4

Scroll with <> Set with - +

Leave with Setup 3 sec.

- 4. Keep pressing button > 16 until the required setting is displayed. Make the setting with setting buttons + - 8
- 5. Press and hold the Info button 3 for 3 seconds.

The chosen setting has now been stored.

You have the option of resetting all changed settings back to the original factory settings.

Note: When you reset your dishwasher to the factory settings, you are taken directly to the settings for the initial start-up.

Basic setting	Factory setting	Infotext; by pressing Info button <b>i</b>
Time setting	12:00	Set the current time.
Time format	24h	12h or 24h.
Time display	Time	Show end of programme with display "Ready in" or "Finish at".
Sprache/Language	Deutsch	Language selection.
Water hardness	°E 16 - 20 medium	Setting water hardness. When using Multitabs, select the lowest setting.
Rinse aid dispenser	Level 5	Amount of rinse aid affects drying. When using Multitabs, select setting 0.
Sensor setting	Standard	Adjustment of soiling detection for optimum cleaning result.
ExtraDry	Off	Improved drying for glasses and plastic tableware.
Water connection *	Cold water	The dishwasher can be connected to either hot (40-60°C) or cold water (<40°C).
Eco forecast	Off	Show the water and energy consumption.
Auto Power Off	After 1 min.	Appliance automatically switches off at end of rinsing process.
emotionLight	On	Interior light.
Emotion Light 1	Level 4	Brightness setting for interior lighting.

#### en Getting to know your appliance

Basic setting	Factory setting	Infotext; by pressing Info buttoni_	
Emotion Light 2	Depending on the specific configuration of your dishwasher	Colour setting for the interior lighting.	
Emotion Light 3	On	Visual signalling of faults.	
Front display *	On	The front display can be selected.	
timeLight *	On	While a programme is running, status information is projected onto the floor.	
infoLight *	On	Light is projected to signal an active washing cycle.	
Start up programme	Eco 50°	When you switch on, the most recently selected programme appears.	
Tone volume *	Level 2	Volume of the signal at the end of a programme.	
Button volume	Level 2	Volume when using button.	
Child-proof lock *	Off	Activated child-proof lock impedes opening of door.	
Wi-Fi	On/Off	Switch wireless network connection on/off.	
Network login	Manual/Automatic	Test WPS function on router. No WPS function: Manual WPS function: Automatic	
Connect to App	Start with +	Connect dom. appliance to mobile terminal device.	
Energy manager *	Connect with +	Connect dom. appliance to energy manager of home system.	
Eco drying *	On	Door opens automatically at the end of the programme.	
Greeting	On	When switching on the appliance, the brand logo can be switched off.	
Factory setting	Reset	Reset to factory setting.	

<sup>\*</sup> depending on the configuration of your specific dishwasher

#### Note:

- The "Network login" menu option is not available unless Wi-Fi has been switched on.
- The "Connect to App" menu option is not available unless there was a connection to the home network.
- The "Energy manager" menu option is not available unless there was a connection to the home network and the appliance is connected to the app.

# Home Connect

The availability of the Home Connect function depends on the availability of Home Connect services in your country. Home Connect services are not available in every country. You can find more information here at www.home-connect.com.

This dishwasher is Wi-Fi capable and can be remotely controlled via a mobile device

If your dishwasher does not connect to the home network, you can also operate the dishwasher manually by pressing the buttons.

#### Info button ....

The Info button i can be used to display additional programme information.

- 1. Press the Info button 3.
- 2. Press the programme button. Information on the selected programme is indicated on the display window at the top 4.
- 3. To leave, press Info button 3.

#### Setting up the App

To be able to operate the appliance via Home Connect, the Home Connect App must be installed on your mobile terminal device.

Observe the supplied Home Connect documents.

Follow the steps specified by the App to make the settings.

#### **Setting up Home Connect**

You can set your dishwasher by pressing the remote start button or proceed as follows:

- 1. Open the door.
- 2. Switch on ON/OFF switch 1.
- 3. Press Info button \_i\_\_ 3 for 3 seconds until the following text is indicated on the display window at the top 4:

Scroll with < > Set with - +

Leave with Setup 3 sec.

- Keep pressing button > 16 until the required setting is indicated on the display window at the top 4.
- Make the setting with setting buttons
   + 8
- 6. Press and hold the Info button of for 3 seconds.

The chosen setting has now been stored.

#### Wi-Fi 🛜

In the Wi-Fi menu you can activate the wireless network connection with "on" and deactivate it with "off".



#### Notes

- If you have selected the Wi-Fi "off" setting, the "Network login" and "Connect to App" settings are not available.
- Remote control of the appliance requires a stable wireless network connection.

#### **Network login**

The "Network login" menu option is not available unless you have activated Wi-Fi.

In the "Network login" menu you can select between "Autom./WPS" and "Manual" to connect the dishwasher to your home network.



**Automatic:** Connect to the home network using the WPS function of your router.



**Manual:** Connect your mobile terminal device to the Home Connect network. The network settings are then manually entered using the Home Connect App to connect to your home network.

Following successful connection, the following text is indicated on the display window at the top 4.



Observe the supplied Home Connect documents.

#### Connect to App

The "Connect to App" menu option is not available unless there was a connection to the home network.

The "Connect to App" setting establishes the link between the dishwasher, App and your user account.



Following successful connection, the following text is indicated on the display window at the top 4.



Observe the supplied Home Connect documents

#### About data protection:

When your Home Connect dishwasher is connected for the first time to a WI AN network, which is connected to the Internet, your Home Connect dishwasher transmits the following categories of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the installed Wi-Fi communication module).
- Security certificate of the Wi-Fi communication module (to ensure a secure IT connection).
- The current software and hardware version of your dishwasher.
- Status of any previous resetting to factory settings.

This initial registration prepares the Home Connect functions for use and is activated the first time you use these Home Connect functions. Please ensure that the Home Connect functions can be used only in conjunction with the Home Connect App. Information on data protection can be accessed in the Home Connect app.

#### Remote start button

When the dishwasher is connected to the home network, activate the dishwasher remote control by pressing the remote start button 1 10.

If the dishwasher has still not logged into Home Connect, access the Home Connect settings by pressing the remote start button 1 10.

Observe the supplied Home Connect documents

#### Notes

- When the login process is complete, the remote start button 1 10 goes
- To activate the remote control, press the remote start button  $\Box$  10.
- If the Home Connect Assistant was aborted during start-up, press the remote start button 1 10 again.
- If the connection to the router fails, the WLAN 7 display flashes on the display.

# Wi-Fi without a connection to the Home Connect server ♥

You can use the Home Connect app to disconnect from the Home Connect server.

The appliance is then locally connected to your mobile device without however any connection to the Home Connect server.

**Note:** If you did not deactivate the connection to the Home Connect server, check your Internet connection.

### Remote diagnostics is

Customer Service can use Remote diagnostics in to access your appliance if you contact them.

#### **Notes**

- You have to confirm Customer Service access on your appliance.
- You can switch off Remote diagnostics using the on/off switch or deactivate Customer Service access in the Home Connect app.

#### Setting up energy manager 🖱

With the energy manager by your dishwasher is automatically started during a time period you select with the cheapest power supply offered at the time by your alternative energy source (e.g. photovoltaic system).

Should the energy manager be unable to start the dishwasher remotely (e.g. no power available), it will start the dishwasher at the latest possible time with a conventional power supply.

# This is how to set up the energy manager ♥:

- 1. Open the door.
- 2. Switch on ON/OFF switch 1.
- 3. Press Info button \_i\_\_\_3 for 3 seconds until the following text is indicated on the display window at the top \_4:

Scroll with < >
Set with - +

Leave with Setup 3 sec.

- Keep pressing button > 16 until the required setting is indicated on the display window at the top 4.
- Make the setting with setting buttons
   + 8
- 6. In the next 2 minutes connect your dishwasher with the energy manager of the home system. When doing so, also activate connection to the energy manager of your home system (observe the instruction manual of your energy manager manufacturer).

Following successful connection of the dishwasher to the energy manager of your home system, the following message is indicated on the display window at the top 4. If login of the energy manager is unsuccessful, please repeat Step 6.

**Note:** The "Energy manager" menu option is not available unless there was a connection to the home network and the appliance is connected to the app.

Further information and system requirements for using the energy manager can be found at www.home-connect.com/energymana gement

## Activating energy manager 🖱

To start the energy manager 🖰, vou must activate the remote start button 10 and select time preselection 9.

Once you have activated the remote start button (1) 10, you can use the Home Connect app to perform time preselection 9.

You can also activate the energy manager manually using the buttons on the dishwasher

#### This is how to activate the energy manager 🖰 on the dishwasher:

- 1. Open the door.
- 2. Switch on ON/OFF switch 1.
- 3. Select programme 2.
- 4. Press time preselection button 9.
- 5. Keep pressing the setting buttons + -8 until the displayed time corresponds with your requirements.
- 6. Press START button 12. Time preselection is activated.
- 7. Activate the remote start button
- 8. Following successful activation. 4 "Flex Start" is indicated on the display window at the top. The energy manager now has access to the dishwasher and can start it during the time period selected.

#### Note:

- Where the energy manager 🖰 starts the programme earlier, the time display "Ready in" / "Finish at" will be updated.
- To activate the energy manager  $\mathfrak{D}$ , vou must have set it up beforehand.

# Deactivating energy manager

The menu option "Disconnect with +" is available when the dishwasher is connected with the energy manager of the home system.

#### This is how to deactivate the energy manager:

- 1. Open the door.
- 2. Switch on ON/OFF switch 1.
- 3. Press Info button 3 for 3 seconds until the following text is indicated on the display window at the top  $\boxed{4}$ :

Scroll with <> Set with - +

#### Leave with Setup 3 sec.

- 4. Keep pressing button > 16 until the required setting is indicated on the display window at the top 4.
- 5. Make the setting with setting buttons + - 8.
- 6. Press Info button 3 for 3 seconds.

At the end of this process the energy manager is deactivated. A new energy manager can now be connected.

# **Declaration of Conformity** CE

Robert Bosch Hausgeräte GmbH hereby declares that the appliance which features Home Connect is in accordance with the basic requirements and the other relevant provisions of the directive 2014/53/FU.

A detailed RED Declaration of Conformity can be found online at www.bosch-home.com/de on the product page for appliance in the additional documents.

Wi-Fi is a registered trade mark of Wi-Fi Alliance.

# **S** Water softening system / special salt

To ensure good rinsing results, the dishwasher requires soft water, i.e. water which is low in lime, otherwise limescale will be deposited on the utensils and interior container. Tap water above 7° dH (1.2 mmol/l) must be softened. The water is softened with special salt (regeneration salt) in the water softening system of the dishwasher. The setting and therefore the required amount of salt

depends on the degree of hardness of

your tap water (see following water

Water hardness table

hardness table).

Water hardness value °E	Hardness range	mmol/l	Set value on the machine
0-8	soft	0-1.1	0-8
9-10	soft	1.2-1.4	9-10
11-12	medium	1.5-1.8	11-12
13-15	medium	1.9-2.1	13-15
16-20	medium	2.2-2.9	16-20
21-26	hard	3.0-3.7	21-26
27-38	hard	3.8-5.4	27-38
39-62	hard	5.5-8.9	39-62

#### Adjusting the water softening system

The amount of salt dispensed can be set from **0** to **62**°E. Salt is not required at the set value 0-8.

#### Set the softening system as follows:

- 1. Ask your local water utility company for the water hardness value of the tap water.
- 2. Required setting can be found in the water hardness table.
- 3. Open the door.
- 4. Switch on ON/OFF switch 1.
- 5. Press Info button 3 for 3 seconds until the following text is indicated on the display window at the top  $\boxed{4}$ :

Scroll with <> Set with - + Leave with Setup 3 sec.

- 6. Keep pressing button > 16 until the water hardness is indicated on the display window at the top 4.
- 7. Make the setting with setting buttons + - 8.
- 8. Press and hold the Info button 3 for 3 seconds.

The chosen setting has now been stored.

#### Using special salt


As soon as the low salt indicator 6 is lit on the control panel or is requested on the front display \* 13, salt should be topped up. Always refill with special salt immediately before switching on the appliance. This ensures that overrun special salt solution is immediately washed out and does not corrode the rinsing tank.

#### Caution!

Detergent will destroy the water softening system! Never pour detergent into the salt dispenser.

#### Top up the salt as follows:

- 1. Undo the screw plug on the dispenser [28].
- 2. Fill the dispenser with water (required only when switching on the appliance for the first time).
- 3. Add salt as illustrated (do not use table salt or tablets). The water is displaced and runs out.



\* depending on the features of your dishwasher

#### Using detergents with salt component

If combined detergents with a salt component are used, special salt can usually be omitted up to a water hardness of 21° dH (37° fH, 26° Clarke, 3.7 mmol/l). If the water hardness is over 21° dH, salt must be used

#### Switching off low salt indicator / water softening system

If the use of combined detergents with a salt component impairs the low salt indicator 6 on the control panel or the text on the display window at the top 4 (enough salt for x rinse cycles), the displays can be switched off.

Proceed as described under "Setting water softening system" and set the value to **0-8**. The water softening system and salt refill indicator are now switched off.


# Rinse aid

As soon as the low rinse-aid indicator 5 is lit on the control panel or is requested on the front display \* 13, rinse-aid should be topped up. The rinse aid is required for stain-free utensils and clear glasses. Use only rinse aid for domestic dishwashers. Combined detergents with rinse-aid component may be used up to a water hardness of 21° dH (37° fH, 26° Clarke, 3.7 mmol/l) only. If the water hardness is over 21° dH, rinse-aid must be used.


\* depending on the features of your dishwasher

#### Top up the rinse-aid as follows:

1. Open dispenser 32; press lug on the lid (1) and lift (2).



2. Add rinse-aid up to the max. mark.



- 3. Close the lid.
  Lid "clicks" into position.
- Remove overflowed rinse aid with a cloth.
   This prevents excessive frothing

#### Setting amount of rinse aid

during the next rinse cycle.

The amount of rinse aid to be dispensed can be set from **0** to **6**. Set the amount of rinse aid to be dispensed to **5** to obtain a very good drying result. Do not change the amount of rinse aid unless there are streaks or water stains on the utensils. Set a lower level to avoid streaks. Set a higher level to avoid water stains.

#### Set the amount of rinse aid as follows:

- 1. Open the door.
- 2. Switch on ON/OFF switch 1.
- 3. Press Info button i. 3 for 3 seconds until the following text is indicated on the display window at the top 4:

Scroll with < > Set with - +

#### Leave with Setup 3 sec.

- Keep pressing button > 16 until the rinse aid dispenser is indicated on the display window at the top 4.
- Make the setting with setting buttons
   + 8
- 6. Press and hold the Info button of for 3 seconds.

The chosen setting has now been stored.

# Switching off rinse aid refill indicator

If the use of combined detergents with a rinse-aid component impairs the low rinse-aid indicator 5 on the control panel or the text on the front display \* 13 (enough rinse aid for x rinse cycles), the displays can be switched off.

Proceed as described under "Setting amount of rinse aid" and select setting **0**.

\* depending on the features of your dishwasher



#### Not suitable

- Cutlery and utensils made of wood.
- Delicate decorative glasses, craft and antique utensils. These decors are not dishwasher-proof.
- Plastic parts not resistant to heat.
- Copper and tin utensils.
- Utensils which are soiled with ash, wax, lubricating grease or ink.

Aluminium and silver parts have a tendency to discolour and fade during the wash cycle. Even some types of glass (e.g. crystal glass objects) may turn cloudy after many wash cycles.

#### Glass and utensil damage

#### Causes:

- Glass type and glass production process.
- Chemical composition of the detergent.
- Water temperature of the wash programme.

#### Recommendation:

- Use only glasses and porcelain which the manufacturer designates as dishwasher-proof.
- Use a detergent which protects utensils.
- Take glass and cutlery out of the dishwasher as soon as possible after the programme ends.


#### Loading the dishwasher

- Remove large food remnants. It is not necessary to prerinse utensils under running water.
- 2. Place the utensils so that
  - they are secure and cannot tip over.
  - all utensils with their openings face down.
  - parts with curves or indentations are at an angle, thereby allowing water to drain.
  - does not obstruct rotation of the two spray arms 23 and 27.

Very small utensils should not be washed in the machine, as they may fall out of the baskets.


#### **Upper basket**

Arrange cups and glasses in the upper basket [22].




\* depending on the features of your dishwasher

Note: Utensils must not be placed above the tablet collecting tray 24. These may block the lid of the detergent dispenser and prevent it from opening fully.



#### Lower basket

Arrange pots and plates in the lower basket [31].



\* depending on the features of your dishwasher


**Tip:** Heavily soiled utensils (pans) should be placed in the lower basket. The more powerful spray jet provides a better dishwashing result.

**Tip:** Other examples, such as the best way of loading your dishwasher, can be found on our homepage. These can be downloaded free of charge. The corresponding Internet address can be found on the back page of these instructions for use.

#### Cutlery basket \*

Place cutlery, always unsorted with the tips face down, in the cutlery basket \*.

To prevent injuries, place long, pointed implements and knives on the knife shelf \*




\* depending on the features of your dishwasher


#### **Cutlery drawer \***


Arrange the cutlery in the cutlery drawer 21 as illustrated. Separately arranged utensils are easier to remove after washing.

You can take out the cutlery drawer.



Depending on the features of your dishwasher, you can fold down the side shelves to provide more room for taller items of cutlery. The front rows of prongs can be folded down to provide room for wider handles.






\* depending on the features of your dishwasher

#### Etagere \*

The etagere and the space underneath can be used for small cups and glasses or for larger items of cutlery, such as wooden spoons or serving cutlery. If you do not require the etagere, it can be folded up.



\* Depending on the features of your dishwasher, you can adjust the etagere 3 times the height.

# Adjust the height of the etagere as follows:


- 1. Position the etagere vertically and pull upwards.
- 2. Push etagere at a slight angle downwards to the required height (1, 2, or 3).
- 3. Engage etagere. Etagere "clicks" into position.

### Folding spikes \*

\* Depending on the features of your dishwasher, the spikes can be folded down. This facilitates arrangement of pots, bowls and glasses.


#### Fold down the spikes as follows:

- 1. Press lever forwards (1).
- 2. Fold down spikes (2).




#### Small items holder \*

\* Depending on the features of your dishwasher, the upper basket is fitted with small items holders. The small items holders can be used to securely attach light plastic parts.



#### Knife rack \*

\* Depending on the features of your dishwasher, the upper basket is fitted with a knife shelf. Long knives and other utensils can be placed in the knife shelf.




#### Baking sheet spray head \*

\* depending on the features of your dishwasher

Large trays or grilles as well as large plates (gourmet plates, pasta plates, dinner plates) can be cleaned with this spray head.

#### Insert the spray head as follows:

- 1. Remove upper basket 22.
- 2. Insert spray head as illustrated and turn to the right. Spray head is engaged.



To ensure that the spray jet can reach all parts, arrange the baking sheets as illustrated (max. 2 baking sheets and 2 arilles).

Note: Ensure that the dishwasher is always operated with upper basket [22] or baking tray spray head.

#### Unloading the dishwasher

To prevent water from dripping off the upper basket onto the utensils in the lower basket, it is recommended to empty the appliance from the bottom up.

**Tip:** Hot utensils are sensitive to shock! Therefore, when the programme ends, leave the utensils to cool down in the dishwasher until they can be handled.

**Note:** When the programme ends, water droplets can still be seen inside the appliance. This does not affect the drying of the utensils.

# Adjusting the height of the basket \*

\* depending on the features of your dishwasher

If required, the height of the upper basket 22 can be adjusted to create more space for taller utensils either in the upper or lower basket.

#### Appliance height 81.5 cm

With cutlery basket	Upper basket	Lower basket
Setting 1 max. ø	22 cm	31 cm
Setting 2 max. ø	24.5 cm	27.5 cm
Setting 3 max. ø	27 cm	25 cm


With cutlery drawer	Upper basket	Lower basket
Setting 1 max. ø	16 cm	31 cm
Setting 2 max. ø	18.5 cm	27.5 cm
Setting 3 max. ø	21 cm	25 cm

#### Appliance height 86.5 cm

With cutlery basket	Upper basket	Lower basket
Setting 1 max. ø	24 cm	34 cm
Setting 2 max. ø	26.5 cm	30.5 cm
Setting 3 max. ø	29 cm	28 cm

With cutlery drawer	Upper basket	Lower basket
Setting 1 max. ø	18 cm	34 cm
Setting 2 max. ø	20.5 cm	30.5 cm
Setting 3 max. ø	23 cm	28 cm

Arrange large plates up to a diameter of 31/34\* cm in the lower basket 31 as illustrated.




\* depending on the features of your dishwasher

#### Upper basket with side levers

- 1. Pull out upper basket 22.
- 2. Hold the sides of the basket along the upper edge. This prevents it from suddenly

dropping.


3. To lower the upper basket; press in both levers on the left and right on the outside of the basket. The upper basket lowers.



- 4. To lift the upper basket; grip the sides of the upper basket along the upper edge and lift.
- 5. Ensure that both sides of the upper basket are at the same height.
- 6. Push in upper basket.

#### Upper basket with upper and lower pairs of rollers

- 1. Pull out upper basket 22.
- 2. Remove upper basket.
- 3. Re-attach upper basket to the upper (Setting 3) or lower (Setting 1) rollers.



4. Push in upper basket.



### Detergent

You can use tablets as well as powder or liquid detergents for dishwashers, but never use washing-up liquid. The dosage can be individually adjusted with powder or a liquid detergent according to the degree of soiling. Tablets contain an adequately large amount of active ingredients for all cleaning tasks. Modern, powerful detergents predominantly use a low-alkaline formulation with enzymes. Enzymes break down starch and remove protein. To remove coloured stains (e.g. tea, ketchup), oxygen-based bleaching agents are generally used.

Note: To ensure a good washing result, always follow the instructions on the detergent packaging! If you have further questions. we recommend that you contact the detergent manufacturers' helplines.




#### Warning

Risk of injury and damage due to non-observance of the safety instructions for detergent and rinse-aid products!


Always follow the safety instructions for detergent products and rinse-aid products.

#### **Adding detergent**

- If the detergent dispenser 33 is still closed, actuate locking bar 34 to open it.
- 2. Pour detergent into the dry detergent dispenser 33 only (insert tablet flat, not on its edge).
- 3. Dosage: see manufacturer's instructions on the packaging. Use graduated detergent dispenser. Usually 20 ml-25 ml are adequate for normal soiling. If using tablets, one tablet is adequate.



Close cover on the detergent dispenser. Cover "clicks" into position.



The detergent dispenser opens automatically at the optimum time depending on the programme. The powder or liquid detergent is distributed in the appliance and is dissolved, the tablet falls into the tablet collecting tray where it dissolves in doses.

**Tip:** If the utensils are only lightly soiled, slightly less than the indicated amount of detergent is usually adequate.

Suitable detergents and care products can be purchased online via our website or via customer service (see back page).

#### **Combination detergent**

Apart from conventional detergents (Solo), a number of products are offered with additional functions. These products contain not only the detergent but also rinse-aid and salt replacement substances (3in1) and, depending on the combination (4in1, 5in1, ...), additional components such as glass protection or stainless steel cleaner. Combination detergents function only up to a specific degree of hardness (usually 21°dH). Over this limit salt and rinse-aid must be added.

As soon as combined detergents are used, the rinse programme is adjusted automatically to ensure the best possible rinsing and drying result.

#### **Notes**

- If you want to add more utensils after the programme has started, do **not** use the tablet collecting tray 24 as a handle for the upper basket. The tablet could already be there and you will touch the partially dissolved tablet.
- Do not place small parts for washing in the tablet collecting tray 24; this prevents the tablet from dissolving
- You will obtain optimum rinsing and drying results by using solo detergents and applying salt and rinse aid separately.

- If programmes are short, tablets may not have full cleaning effect due to different dissolving properties and there may even be undissolved detergent residue. It is recommended to use washing powder for these programmes.
- The dosing of a tablet is adequate for the "Intensive" programme (for some models). When using washing powder, you can apply some of this cleaning agent to the inside of the appliance's door.
- Even if the rinse-aid and/or salt refill indicator is lit, the rinse programme will run correctly with combined detergents.
- If using detergents in a water-soluble protective cover: Take hold of the cover with dry hands only and put the detergent into an absolutely dry detergent dispenser only, otherwise the detergent may stick.
- If you switch from combined detergents to solo detergents, ensure that the water softening system and amount of rinse aid have been set to the correct value.
- Biological/eco detergents: Detergent products identified as "Bio" or "Eco" (to protect the environment) usually use lower quantities of active agents or completely dispense with certain substances. The cleaning effect of such products may occasionally be restricted.

# Overview of programmes

The max. possible number of programmes is illustrated in this overview. The corresponding programmes and their arrangement can be found on the fascia.

Type of dish	Type of soiling	Programme	Possible additional options	Programme sequence
pots and pans, non-sensitive utensils and cutlery	very stubborn burned or dried-on food remains containing starch or protein	Intensive 70°	all	Intensive: Pre Rinse Cleaning 70° Intermediate rinse Final rinse 65° Drying
mixed utensils and cutlery	part dried, common household food remnants	auto / 🖳 Auto 45° - 65°	all	Sensor-controlled: Is optimised according to the soiling with the aid of sensors.
mixed utensils and cutlery	part dried, common household food remnants	Yo / eco	all	Most economical: Pre Rinse Cleaning 50° Intermediate rinse Final rinse 35° Drying
mixed utensils and cutlery	part dried, common household food remnants	Silence 50°	intensiveZone Half load HygienePlus ExtraDry Shine and Dry	Reduced noise: Pre Rinse Cleaning 50° Intermediate rinse Final rinse 35° Drying
sensitive utensils, cutlery, temperature-sen sitive plastic and glasses	lightly adhering, fresh food remains	Ÿ□/Ÿ Glass 40°	intensiveZone VarioSpeedPlus Half load ExtraDry Shine and Dry	Particularly gentle: Pre Rinse Cleaning 40° Intermediate rinse Final rinse 50° Drying
mixed utensils and cutlery	part dried, common household food remnants	<b>D</b> / <b>N</b> Quick 65°	Extra Dry Shine and Dry	Time-optimised: Cleaning 65° Intermediate rinse Rinsing Drying

Type of dish	Type of soiling	Programme	Possible additional options	Programme sequence
mixed utensils and cutlery	part dried, common household food remnants	"□ / □, / □, Short 60°C	all	Time-optimised: Cleaning 60° Intermediate rinse Rinsing Drying
sensitive utensils, cutlery, temperature-sen sitive plastic and glasses	lightly adhering, fresh food remains	<b>D</b> / <b>»</b> / <b>D</b> Quick 45°	Extra Dry Shine and Dry	<b>Time-optimised:</b> Cleaning 45° Intermediate rinse Final rinse 50°
all types of dishes	cold rinsing, intermediate cleaning	Pre Rinse	None	<b>Cold rinse</b> Pre Rinse
-	-	Easy Clean Machine Care	None	Machine cleaning cycle 70°

#### **Programme selection**

You can select a suitable programme according to the type of utensils and type of soiling.

#### Information for test institutes

Test institutes receive the information for comparability tests (e.g. according to EN60436).

These are the conditions for conducting the tests, however these are not the results or consumption values.
Request by e-mail to:
dishwasher@test-appliances.com
The product number (E no.) and the production number (FD) are required which you can find on the rating plate 35 on the appliance door.

# P+ Additional functions

\* Depending on the features of your dishwasher, you can select different additional functions 11.

# Save time (VarioSpeedPlus) \*

The "Save time" function can reduce the running time by approx. 20% to 66% depending on the selected rinse programme. To obtain optimum cleaning and drying results at a reduced running time, water and energy consumption are increased.

# 1/2 Half load \*

If you have only a few items to wash (e.g. glasses, cups, plates), you can switch to "half load". This will save water, energy and time. It is recommended to put a little less detergent in the detergent dispenser than for a full load.

# hygienePlus (HygienePlus) \*

This function increases the temperatures and retains them for an extra long time to obtain a defined disinfection performance. Continuous use of this function increases the hygiene status. This additional option is ideal for cleaning e.g. chopping boards and baby bottles.

# [트] intensiveZone \*

Perfect for a mixed load. You can wash very soiled pots and pans in the lower basket together with normally soiled utensils in the upper basket. The spray pressure in the lower basket is intensified, the rinsing temperature is increased slightly.



# extraDry \*

An increased temperature during the final rinse and an extended drying phase ensure that even plastic parts dry better. There is a slight increase in the energy consumption.



# | ? | Shine and Dry $^*$

By increasing the amount of water during the rinse cycle and extending the drying phase, stains are prevented and the drying result is improved. There is a slight increase in the energy consumption. Rinse aid is recommended for the high gloss drying function (even when using combination detergents).



# **Energy Save** \*

The "Energy Save" function can be used to reduce water and energy consumption. The running time is extended for optimum cleaning and drying results.

# Operating the appliance

#### Programme data

The programme data (consumption values) can be found in the summary of instructions. They refer to normal conditions and the water hardness set value °E 16 - 20 medium. Different influencing factors such as water temperature or line pressure may result in deviations.

#### Changing the settings

The dishwasher has been preset with certain settings for your convenience. You can change these factory settings.

#### Change the setting as follows:

- 1. Open the door.
- 2. Switch on ON/OFF switch 1.
- 3. Press Info button 3 for 3 seconds until the following text is indicated on the display window at the top  $\boxed{4}$ :

Scroll with <> Set with - +

Leave with Setup 3 sec.

- 4. Keep pressing button > 16 until the required setting is indicated on the display window at the top 4.
- 5. Make the setting with setting buttons + - 8 .
- 6. Press and hold the Info button 3 for 3 seconds.

The chosen setting has now been stored.

Tip: If you change several settings, first make all changes in succession. Now press the Info button 3 for 3 seconds. This saves all set values in the appliance.

#### AguaSensor \*

\* depending on the features of your dishwasher

The Agua sensor is an optical measuring device (light barrier) which measures the turbidity of the rinsing water

The AguaSensor is used according to the programme. If the AquaSensor is active, "clean" rinsing water can be transferred to the next rinse bath and water consumption can be reduced by 3–6 litres. If the turbidity is greater, the water is drained and is replaced with fresh water. In the automatic programmes the temperature and running time can also be adjusted to the degree of soiling.

## Zeolith drying



#### **⚠** Warning

Risk of burns from touching the blow opening 26!

Never touch the blow opening. The blow opening becomes hot and, furthermore, any damage will result in a chargeable callout by customer service.

#### Caution!

Please ensure that the intake opening [25] is not obstructed and do not place any temperature-sensitive utensils in the lower basket at the rear right side above the blow opening 26.

The appliance features a Zeolith container. Zeolith is a mineral which can store moisture and heat energy and release them again.

During the washing step this heat energy is used to dry the mineral and heat up the rinsing water.

During the drying phase moisture from the rinsing compartment is stored in the mineral and heat energy is released. This released heat energy is blown into the rinsing compartment with dry air. This accelerates and improves drying.

These processes therefore save a great deal of energy.

#### Time display

The running time is determined during the programme by the water temperature, the number of utensils as well as the degree of soiling and may vary (depending on the selected programme). You can change the time display in time or hours/minutes so that the remaining running time of the rinsing progamme appears in the display window "Ready at" (for example 15:20 hours) or "Ready in" (for example 3:25).

# Sensor setting

The programme sequence is optmised in Auto programmes with the aid of sensors. The sensors adjust the programme strength of Auto programmes depending on the amount and type of soiling. You can adjust the sensitivity of the sensors in 3 stages.

Standard: This setting is ideal for a mixed load and heavily soiled utensils, but also saves energy and water.

Sensitive: This setting adjusts the programme strength for the effective removal of food remnants, even if the amount of soiling is low. The energy and water consumption is adjusted accordingly.

Very sensitive: This setting adjusts the programme strength for difficult conditions of use, for example firmly dried on food remnants. This setting is recommended if using biological or eco detergents which contain lower amounts of active agents. The energy and water consumption is adjusted accordingly.

# extraDry

The final rinse uses a higher temperature which improves the drying result. The running time may increase slightly. (Caution if utensils are delicate!) You can switch the extraDry function on or off.

#### Eco forecast

When Eco forecast is activated, the average water and energy consumption of the selected programme is briefly displayed on the display window at the top 4.

# AutoPowerOff (Switching off automatically after the end of the programme)

To save energy, the dishwasher is switched off 1 minute after the programme ends. You can also change this setting.

#### Possible settings are:

- off: The appliance does not switch off automatically.
- After one minute: The appliance switches off after 1 minute.
- **After two hours:** The appliance switches off after 2 hours.

**Note:** Note that for the settings "After one minute" and "After two hours", the interior lighting 20 is switched off. To activate the interior lighting, press the ON/OFF switch 1.

# emotionLight (interior lighting) \*

\* depending on the configuration of your specific dishwasher

emotionLight 20 is the interior lighting for your dishwasher. You can switch the interior lighting on or off. Once you have switched on emotionLight, you can select other settings.

#### Possible settings are:

Emotion Light 1 (brightness setting for interior lighting):

In the setting Emotion Light 1 you can adjust the brightness of the interior lighting in 4 levels.

Emotion Light 2 (colour setting of interior lighting):

In the setting Emotion Light 2 you can select a colour for the interior lighting.

Emotion Light 3 (visual signalling of faults):

In the setting Emotion Light 3 you can switch the visual indication of a fault on or off. If you have switched on Emotion Light 3 and a fault occurs on your dishwasher, the interior lighting will flash.

#### **Notes**

- Depending on the setting of AutoPowerOff, the interior lighting is either switched on or off.
- Note that the interior lighting is automatically switched off after 1 hour when it is switched on and the door is open.
- When the interior lighting is switched off, the settings for emotionLight 1 to emotionLight 3 cannot be selected.
- If you have used the Home Connect app to create a colour, you cannot select the setting Emotion Light 1.

# Front display \*

\* depending on the features of your dishwasher

You can switch the front display 13 on or off (additional programme information).

# TimeLight (Optical display while the programme is running) \*

\* depending on the features of your dishwasher

While programme is running, an optical display (additional programme information) is indicated on the floor under the appliance door. If the base panel is pulled forwards or if the appliance is installed at eye-level with flush furniture front, the display is not visible.

You can switch the optical display on or off.

# Infolight \*

\* depending on the features of your dishwasher

While the programme is running, a light spot shines on the floor under the appliance door. Do not open the appliance door until the light point is no longer visible on the floor. If the appliance door is not completely closed, the light spot flashes \*. If the appliance is installed at eye-level, with flush furniture front, the light point is not visible. You can switch the Infolight on or off.

# Changing start programme

You can change the "Start programme" setting.

#### Tone volume\*

\* depending on the configuration of vour specific dishwasher

The end of the programme is indicated by a buzzer. You can also change this settina.

#### **Button volume**

When you are operating the dishwasher, a signal sounds whenever a button is pressed. You can control the volume of the signal. If you do not like the button volume, you can switch it off.

# Child-proof lock \*

\* depending on the features of your dishwasher

The dishwasher features an electronic child-proof lock. The child-proof lock protects children from potential hazards which the dishwasher poses.

You can switch the child-proof lock on or off. When the child-proof lock is on, it is difficult to open the door.

# Greeting

When you switch on the dishwasher, the brand logo appears. You can switch off the brand logo.

# Factory setting

You can reset all settings to the factory setting.

# Switching the appliance on

- 1. Turn on tap fully.
- 2. Open the door.
- 3. Switch on ON/OFF switch 1. The Eco 50° programme has been preset for environmentally friendly operation whenever the appliance starts. This programme remains selected if no other programme button 2 is pressed.
- 4. Press START button 12.
- 5. Close the door.

Programme sequence starts.

#### Note:

For ecological reasons the Eco 50° programme is preset whenever the appliance starts. This conserves environmental resources and not least saves you money. The Eco 50° programme is a

particularly environmentally friendly programme. According to EU regulation 1016/2010 it is the "Standard programme" which is the most efficient standard cleaning cycle for cleaning normally soiled utensils in terms of the combined energy and water consumption for cleaning these types of utensils.

# **Time preselection**

You can delay the start of the programme by up to 24 hours. Depending on the setting of the time display, the end of programme is indicated with "Finish in" (for example 3h 25m) or "Finish at" (for example 15:20 hours).

- 1. Open the door.
- 2. Switch on ON/OFF switch 1.
- 3. Selects programme 2.
- 4. Press time preselection button 9.
- Keep pressing the setting buttons + until the displayed time corresponds with your requirements.
- 6. Press START button 12, timer programming is activated.
- 7. To delete the time preselection, press START button 12 for approx. 3 seconds.

Time preselection was terminated.

8. Close the door.

# **Programme end**

- \* The programme has ended when "Finished" is indicated on the display window at the top 4 and on the front display \* 13.
- \* The end of the programme is displayed on the floor – provided the TimeLight (optical display) is switched on and is visible.
- \* depending on the features of your dishwasher

# Switching off the appliance

# Short time after the end of the programme:

- 1. Open the door.
- 2. Switch off ON/OFF switch 1.
- 3. Turn off tap (does not apply to appliances with Aqua-Stop).
- Remove the utensils when they have cooled down.

**Note:** When the programme ends, leave the appliance to cool down a while before opening it. This will prevent steam from escaping and causing long-term damage to your built-in furniture.

# Interrupting the programme

#### Caution!

Expansion (overpressure) may cause the appliance door to jump open and/or water to escape! If the door was opened on an appliance which has a hot water connection or is heated, always leave the door ajar for several minutes and then close.

- 1. Open the door.
- Switch off ON/OFF switch 1.
   The LEDs go out. The programme is saved.
- 3. To continue the programme, switch on the ON/OFF switch 1 again.
- 4. Close the door.

# Terminating the programme (Reset)

- 1. Open the door.
- 2. Press the START button 12 and hold for 3 seconds The display window at the top 4 and the front display \* 13 show: "Program was terminated".
- 3. Close the door. The programme sequence lasts approx. 1 min. The display window at the top 4 shows: "Finished".
- 4. Open the door.
- 5. Switch off ON/OFF switch 1.
- Close the door.
- \* depending on the features of your dishwasher

# Changing the programme

When the START button 12 has been pressed, the programme cannot be changed. The only way a programme can be changed is by Cancel programme (Reset).

# Cleaning and maintenance

A regular inspection and maintenance of your machine will help to prevent faults. This saves time and prevents problems.

### Overall status of the dishwasher

- \*The interior of your dishwasher is predominantly self-cleaning. In order to remove deposits, your dishwasher automatically changes the running of the programme (such as by increasing the cleaning temperature) at certain intervals. This will lead to higher consumption values when running this programme.
- \*Depending on the features of your dishwasher

#### If you should find deposits in the interior of the dishwasher in spite of this, remove these deposits as follows:

- 1. Fill the detergent dispenser 33 with deteraent.
- 2. Select the programme with the highest temperature.
- 3. Start the programme without dishes.



Health hazard due to detergents containing chlorine!

Always use chlorine-free detergents.

#### **Notes**

- Only clean the appliance with special detergents/appliance cleaners which are suitable for use with dishwashers.
- Regularly wipe the door seals using a damp cloth and a little washing-up liquid. This will keep the door seal clean and hygienic.
- Leave the door open slightly if the appliance will not be used for a while. This will prevent an unpleasant odour from developing.
- Never clean the dishwasher using a steam cleaner. The manufacturer is not liable for any consequential damage.
- Wipe the front of the dishwasher and the control panel regularly using a damp cloth and a little washing-up liauid.
- Do not use sponges with a rough surface or abrasive detergents. These could scratch the surface.
- For dishwashers with a stainless. steel front, avoid using sponge cloths, or rinse these thoroughly several times before using them for the first time. This will prevent corrosion.

# Machine Care <sup>□</sup> \*



Machine Care used in combination with commercially available machine cleaning detergent is a suitable programme for cleaning your dishwasher. Deposits such as grease and limescale can cause your dishwasher to malfunction. In order to avoid such faults and to reduce the development of odours, we recommend cleaning the dishwasher at regular intervals

\* As soon as the Machine Care display lights up in the control panel, or you are advised to do so on the front display. run the Machine cleaning programme Machine Care without loading any tableware. After you have run the Machine Care the display in the control panel will go out.

If your dishwasher does not have a reminder function, follow the instructions for use on the machine cleaning deteraents.

#### **Notes**

- Remove any coarse soiling in the interior using a damp cloth.
- Run the programme without dishes. and in combination with a machine cleaning detergent.
- Use a special machine cleaning detergent, and not dishwasher detergent.
- Observe the safety instructions and the instructions for use on the machine cleaning detergent packaging.
- \*After three rinse cycles, the display in the control panel will go out automatically, even if you have not run the Machine cleaning cycle programme.
- \* depending on the features of your dishwasher

# Special salt and rinse aid

Top up the salt and/or rinse aid as soon as the refill indicators on the fascia 6 and 5 are lit or there is a prompt on the front display \* 13.


\* depending on the features of your dishwasher


#### **Filters**

The filters 29 keep large foreign objects in the rinsing water away from the pump, hese foreign objects may occasionally block the filters.

The filter system consists of

- a coarse filter
- a flat fine filter
- a microfilter
- 1. After each washing cycle check the filters for residue.
- 2. Unscrew filter cylinder as illustrated and take out filter system.






- 3. Remove any residue and clean filters under running water.
- 4. Re-install filter system in reverse sequence and ensure that the arrow marks are opposite each other after closing the filter system.

# Spray arms

Limescale and contaminants in the rinsing water may block nozzles and bearings on the spray arms 23 and 27

- 1. Check outlet nozzles on the spray arms for blockages.
- 2. Unscrew the upper spray arm [23] (1) and remove downwards (2).
- 3. Remove the lower spray arm 27 upwards.



- 4. Clean spray arms under running water.
- 5. Re-engage or screw on spray arms.



# Fault, what to do?

Experience has shown that you can rectify most faults which occur in daily operation yourself. This ensures that the appliance is quickly available to you again. In the following overview you can find possible causes of malfunctions and helpful information for rectifying them

Note: If the appliance stops during dishwashing or does not start for no obvious reason, first run the Abort programme function (Reset) → "Operating the appliance" on page 35.



#### **M** Warning

#### **Improper**

repairs or use of non-original spare parts may cause considerable damage and put the user at considerable risk!

Always have repairs carried out by technicians. If a component has to be replaced, always use original spare parts.

# **Error message**

Some faults are indicated at the top of the display window 4 and on the front display \* 13 and possible remedies are offered (for example Filter system soiled (E22) -> Clean filters). If you have switched on emotionLight 3 (visual indication of faults), the interior lighting will additionally flash.

\* depending on the features of your dishwasher

# Waste water pump

Large food remnants or foreign objects which were not captured by the filters may block the waste water pump. The rinsing water will then be above the filter

# **Warning**


#### Danger of cutting!

Sharp and pointed objects or glass fragments may block the waste water gump.


Always carefully remove foreign objects.

#### Clean the waste water pump as follows:

- 1. Disconnect the dishwasher from the power supply.
- 2. Take out top basket 22 and bottom basket 31 i.
- 3. Remove the filters 29.
- 4. Scoop out water, use a sponge if required.
- **5.** Prise off the pump cover (as shown) using a spoon. Grip the pump cover by the crosspiece and lift diagonally inwards (1). Remove cover completely.



- 6. Check impeller wheel and remove any foreign objects.
- 7. Place pump cover in the original position (2) and press down until it engages (3).



- 8. Install filters.
- Re-insert baskets.

# **Fault table**

Fault	Reason	Remedial action
Fault code <i>E</i> : <i>IB</i> is lit.	Supply hose kinked.	Install supply hose without kinks.
	Water supply turned off.	Turn on water supply.
	Water supply jammed or calcified.	Turn on water supply. Flow rate must be at least 10 l/min. when water supply is open.
	Filter in the water supply blocked.	Switch off the appliance and pull out the mains plug. Turn off water supply. Unscrew water connection.
		Clean filter in the supply hose. Screw water connection on again. Check for leaks. Reconnect power supply. Switch on the appliance.
Fault code <i>E:07</i> is lit.	Intake opening (on right inside of appliance) covered by utensils.	Arrange utensils so that the intake opening is not obstructed.
Fault code <i>E</i> : <i>I2</i> is lit.	Heating element calcified or soiled.	Clean appliance with dishwasher cleaning agent or descaler. Operate the dishwasher with water softening system and check the setting.   "Water softening system/special salt" on page 20
Fault code <i>E</i> : <i>I'</i> is lit.	Water protection system activated.	Turn off water supply. Call customer service and quote the fault code.
Fault code <i>E</i> : <i>1</i> 5 is lit.		
Fault code <i>E</i> : <i>IB</i> is lit.	Constant water supply.	- 6646.
Fault code <i>E:22</i> is lit.	Filters 29 are soiled or blocked.	Clean filters. → "Filters" on page 43
Fault code <i>E:24</i> is lit.	Waste-water hose kinked or blocked.	Install hose without kinks, remove any residue.
	Siphon connection still sealed.	Check connection to siphon and open if required.
	Cover on the waste water pump loose.	Lock cover correctly. → "Waste water pump" on page 45

Fault	Reason	Remedial action
Fault code <i>E:25</i> is lit.	Waste water pump blocked or cover on the waste water pump is not locked in position.	Clean pump and lock cover correctly.  → "Waste water pump" on page 45
Fault code <i>E:27</i> is lit.	Mains voltage too low.	No appliance fault, have the mains voltage and electrical installation checked.
A different fault code is indicated on the digital display. (E:0 1 to E:30)	A technical fault has probably occurred.	Switch off the appliance with the ON/OFF switch 1. After a short time restart the appliance. If the problem recurs, turn off water supply and pull out the mains plug. Call customer service and quote the fault code.
Home network is not loading.	WLAN is not active on the router.	Check the wireless network connection of your router.
WLAN display flashes.	Connection to the home network is not available.	Activate the wireless network on your router.
Home Connect cannot be implemented correctly.	Possible setting errors or a technical fault.	Observe the supplied documents and support information for Home Connect.
Energy manager does not connect to the energy manager of the home system. *	Connection to the energy manager of the home system is not available.	Refer to the instructions for use from the energy manager manufacturer for your home system.
Refill indicator for salt 6	No rinse aid.	Refill rinse aid.
and/or rinse aid 5 is lit.	No salt.	Refill with special salt.
	Sensor does not detect salt tablets.	Use different special salt.
Refill indicator for salt 6 and/or rinse aid 5 is not lit.	Refill indicator switched off.	Activation/deactivation (see chapter "Water softening system/Special salt" → Page 20 or "Rinse aid" → Page 22).
	There is still enough special salt/rinse aid available.	Check refill indicator, levels.
Water is left in the appliance at the end of the	Filter system or area under the filters 29 is blocked.	Clean filters and area underneath.
programme.	Programme has not yet finished	Wait until programme ends or reset.

### en Fault, what to do?

Fault	Reason	Remedial action
Utensils not dry.	Not enough rinse aid in the dispenser, or none at all.	Refill rinse aid.
	Programme without drying was selected.	Select programme with drying.  → "Overview of programmes" on page 32
	Water collecting in depressions on the utensils and cutlery.	Arrange utensils in a sloping position, arrange affected utensils as sloping as possible.
		X
	The combined detergent used has a poor drying performance.	Use different combination detergent with better drying performance. Use of rinse aid also improves the drying performance.
	ExtraDry to increase drying not activated.	Activate ExtraDry. → "extraDry" on page 37
	Utensils were removed too early or drying process had not ended yet.	Wait until the programme ends, or wait until 30 minutes after the end of the programme before removing the utensils.
	The eco rinse aid used has a limited drying performance.	Use a proprietary rinse aid. Eco products may have limited effectiveness.
Plastic utensils not dry.	Special properties of plastic.	Plastic has a lower heat storage capacity and therefore dries less well.
Cutlery not dry.	Cutlery not arranged properly in the cutlery basket.	Separate cutlery if possible, prevent contact points.
	Cutlery not arranged properly in the cutlery drawer.	Arrange cutlery properly and separate if possible.
Appliance interior wet after wash cycle.	No appliance fault.	On account of the "Condensation drying" principle, water droplets are physically induced and required in the container. The humidity in the air condenses on the inner walls of the dishwasher, drains and is pumped out.

Fault	Reason	Remedial action
Food remnants on the utensils.	Utensils placed too closely together, utensils basket overfilled.	Arrange utensils with adequate clearance between them ensuring that the spray jets can reach the surface of the utensils. Prevent contact points.
	Spray arm rotation obstructed.	Arrange utensils so that the spray arm can rotate without obstruction.
	Spray arm nozzles are blocked.	Clean the spray arm nozzles.  → "Cleaning and maintenance" on page 41
	Filters 29 dirty.	Clean filters. → "Cleaning and maintenance" on page 41
	Filters 29 inserted incorrectly and/or not engaged.	Insert and engage filters correctly.
	Wash programme too weak.	Select a more intensive wash programme. Increase sensitivity of the sensors.  — "Sensor setting" on page 37
	Utensils precleaned too intensely; sensors therefore decide on weak programme sequence. Stubborn soiling cannot be completely removed.	Do not prerinse utensils. Remove only large food remnants. Increase sensitivity of the sensors.  → "Sensor setting" on page 37 Recommended programme Eco 50° or Intensive.
	Tall narrow receptacles in corner areas are not rinsed adequately.	Do not place hollow receptacles too obliquely and do not place in the corner area.
	Top basket 22 on right and left not set to same height.	Set top basket to same height using side levers.

# en Fault, what to do?

Fault	Reason	Remedial action
Detergent residue	Detergent dispenser cover 33 blocked by utensils and therefore does not open fully.	Utensils must not be placed above the tablet collecting tray [24]. These may block the lid of the detergent dispenser and prevent it from opening fully.  —> "Upper basket" on page 24  Do not place utensils or fragrance dispenser in the tablet collecting tray.
	Detergent dispenser cover 33 blocked by the tablet.	Tablet must be inserted flat and not upright.
	Tablets used in the quick or short programme. Dissolving time of the detergent is not reached in the selected short programme.	Dissolving time of tablets too long for a quick or short programme. Use a detergent powder or select a more intensive programme.
	Washing effect and dissolving performance are reduced after a prolonged storage time or detergent is very lumpy.	Change detergent.
Water stains on plastic parts.	Droplet formation on plastic surface is physically unavoidable. After drying, water stains are visible.	Use a more intensive programme (more water changes). Arrange utensils in a sloping position. Use rinse aid. If required, increase softening setting.
Washable or water-soluble coatings in the container or on the door.	Detergent substances are deposited. These coatings cannot usually be removed with chemicals (appliance cleaner,).	Change detergent brand. Clean appliance mechanically.
	If there is a "white coating" on the container floor, the water softening system has been set marginally.	Increase softening setting and change detergent if required.
	Salt dispenser cover 28 not closed.	Close salt dispenser cover correctly.
	Only for glasses: Initial glass corrosion – can only apparently be wiped off.	See "Glass and utensil damage".  → "Glass and utensil damage" on page 23

Plastic parts inside the appliance

may become discoloured during

the service life of the dishwasher.

Discolouration of the

appliance.

plastic parts inside the

Discolouration is normal and will not

impair the function of the dishwasher.

# en Fault, what to do?

Fault	Reason	Remedial action
Plastic parts discoloured.	Too low rinsing temperature.	Select programme with higher washing temperature.
	Utensils precleaned too intensely; sensors therefore decide on weak programme sequence. Stubborn soiling cannot be completely removed.	Do not prerinse utensils. Remove only large food remnants. Increase sensitivity of the sensors.  → "Sensor setting" on page 37 Recommended programme Eco 50°
Removable streaks on	Too much rinse aid.	Set rinse aid amount to lower setting.
glasses, glasses with metallic appearance and cutlery.	No rinse aid added or setting too low.	Add rinse aid and check dosage (recommended setting 4–5).
cutery.	Detergent residue in the final rinse. Detergent dispenser cover blocked by utensils (cover does not open fully).	Detergent dispenser cover must not be obstructed by utensils.  Do not place utensils or fragrance dispenser in the tablet collecting tray.
	Utensils precleaned too intensely; sensors therefore decide on weak programme sequence. Stubborn soiling cannot be completely removed.	Do not prerinse utensils. Remove only large food remnants. Increase sensitivity of the sensors.  → "Sensor setting" on page 37 Recommended programme Eco 50°
Initial or existing, irreversible clouding of glass.	Glasses not dishwasher-proof, only suitable for dishwasher.	Use dishwasher-proof glasses. Avoid long steam phase (standing time after wash cycle ends). Use wash cycle at lower temperature. Set water softening system according to the water hardness (if required one setting lower). Use detergent with glass protection component.
Rust spots on the cutlery.	Cutlery is not sufficiently rust-resistant. Knife blades are frequently more severely affected.	Use rust-resistant cutlery.
	Cutlery will also rust if rusting parts are rinsed at the same time (pan handles, damaged utensil baskets, etc.).	Do not wash rusting parts.
	Salt content in the rinsing water too high, as salt dispenser lock not fastened firmly or salt was spilled while being refilled.	Fasten salt dispenser lock firmly or remove spilled salt.

Fault	Reason	Remedial action
Appliance cannot be switched on or operated.	Malfunction.	Disconnect appliance from the power supply; pull out the mains plug or switch off the fuse. Wait at least 5 seconds, then connect the appliance to the power supply.
Appliance does not start.	The mains fuse has tripped.	Check mains fuse.
	Power cord not inserted.	Ensure that the power cord is plugged all the way into the back of the appliance and into the socket. Check that the socket functions.
	The appliance door has not been shut properly.	Close the door.
Programme starts automatically.	You did not wait until programme ended.	Perform reset.
The door is difficult to open.	Child-proof lock is activated.	Deactivate childproof lock.  → "Childproof lock (door lock) *" on page 9
Door cannot be closed.	Door lock has been activated.	Close door with increased force.
	Door cannot be closed due to installation.	Check appliance installation: Door or attached parts must close without obstruction.
Cover on the detergent dispenser cannot be closed.	Detergent dispenser or cover guide blocked by sticky detergent residue	Remove detergent residue.
Detergent residue in the detergent dispenser 33 or in the tablet collecting tray 24.	Spray arms blocked by utensils, therefore detergent is not rinsed out.	Ensure that the spray arms can rotate freely.
	The detergent dispenser was damp when filled.	Pour detergent into the dry detergent dispenser only.
Appliance stops in the	Door not closed properly.	Close the door.
programme or programme is interrupted.	Do not place utensils or fragrance dispenser in the tablet collecting tray.  Top basket presses against the door and prevents door from being closed securely.	Check whether rear panel is being pressed in, e.g. by socket or by hose holder which has not been removed.
	Power and/or water supply interrupted.	Restore power and/or water supply.
Filling valves making striking noises.	Depends on domestic installation, as no appliance fault. No effect on appliance function.	No remedial action possible.

# en Fault, what to do?

Fault	Reason	Remedial action
Knocking or rattling noise.	Spray arm strikes the utensils, utensils not positioned correctly.	Position utensils so that the spray arms do not strike the utensils.
	If there is a low load, the water jets strike the washing tank directly.	Load the appliance with more utensils or distribute the utensils more evenly in the dishwasher.
	Light utensils move during the wash cycle.	Arrange light utensils securely.
Unusual foam formation.	Hand washing-up liquid in the rinse aid dispenser.	Immediately refill rinse aid dispenser with rinse aid.
	Rinse aid spilled.	Remove rinse aid with a cloth.

<sup>\*</sup> depending on the features of your dishwasher

# **Customer service**

If you are unable to rectify the fault, please contact your customer service. We will always find an appropriate solution in order to avoid unnecessary visits by engineers. Contact information for your nearest customer service can be found on the back of these instructions for use or on the enclosed customer service list. When calling. please state the appliance number (E-Nr. = 1) and the production number (FD = 2) which can be found on the rating plate 35 on the appliance door.



Trust the expertise of the manufacturer. Contact us for assistance. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your domestic appliances.

Please note that customer service employees would never ask for your Home Connect password.



The dishwasher must be connected correctly, otherwise it will not function properly. The specifications for the inlet and outlet as well as the electrical connected loads must correspond with the required criteria as specified in the following paragraphs or in the installation instructions.

#### Install the appliance in the correct sequence:

- 1. Checking appliance on delivery
- 2. Installation
- 3. Drainage connection
- 4. Drinking water connection
- 5. Flectrical connection

# Contents of package

If you have any complaints, contact the dealer from whom you purchased the appliance or our customer services.

- Dishwasher
- User manual
- Installation instructions
- Quick reference guide\*
- Warrantv\*
- Installation materials
- Steam guard plate\*
- Rubber apron\*
- Power cord
- \* depending on the features of your dishwasher

# Safety instructions

Please follow the safety instructions under  $\rightarrow$  "Installation" on page 6.

# **Delivery**

Your dishwasher has been checked thoroughly in the factory to ensure that it is in working order. This may cause small water stains. These will disappear after the first wash cycle.

# **Technical specifications**

- Weight:
  - up to 60 kg
- Voltage:

220-240 V, 50 Hz or 60 Hz

- Connected load: 2000 - 2400 W.
- Fuse: 10/16 A (UK 13 A).
- Power input: Off mode (Po) 0.50 W. Left-on mode (PI) 0.50 W. Networked standby mode 2.00 W.

Time in left-on mode (TI) 0 min. Time in networked standby mode 2 min.

According to regulations (EU) nos. 1016/2010, 1059/2010, 1275/2008 and 801/2013. Additional functions and settings may increase the power input and times.

Water pressure:

at least 0.05 MPa (0.5 bar), maximum 1 MPa (10 bar). At a higher water pressure: connect pressure-reducing valve ahead.

Inlet rate:

minimum 10 litres/minute

Water temperature:

cold water. Hot water:

Maximum temperature 60 °C.

Capacity:

12-15 place settings (depending on the features of your dishwasher).

#### Installation

The required installation dimensions can be found in the installation instructions. Level the appliance with the aid of the height-adjustable feet. Ensure that the appliance is situated securely on the floor.

- A built-under or integrated appliance which is installed subsequently as a free-standing appliance must be secured to prevent it from overturning, e.g. by screwing it to the wall or by installing it under a continuous worktop which is screwed to adjacent cupboards.
- The appliance can easily be installed in a fitted kitchen between wooden and plastic walls.

# **Drainage connection**

- The required work sequence can be found in the installation instructions. If required, fit a siphon with an drainage connection.
- Connect the waste-water hose to the drainage connection of the siphon with the enclosed parts.
   Ensure that the drainage hose is not kinked, crushed or twisted and that there is no cover plate in the drainage to prevent the waste water from flowing out!

# **Drinking water connection**

- **1.** Fasten the drinking water connection to the tap according to the installation instructions using the enclosed parts. Ensure that the drinking water connection is not kinked, crushed
- 2. When replacing the appliance, always use a new water supply hose.

#### Water pressure:

or twisted.

at least 0.05 MPa (0.5 bar), maximum 1 MPa (10 bar).

At a higher water pressure:

connect pressure-reducing valve ahead. Inlet rate:

# minimum 10 litres/minute

Water temperature: cold water.

Hot water:

Maximum temperature 60 °C.

### Warm water connection \*

\* depending on the features of your dishwasher

The dishwasher can be connected to cold or hot water up to max. 60 °C. Connection to hot water is recommended if the hot water can be supplied by energetically favourable means and from a suitable installation. e.g. solar heating system with circulation line. This will save energy and time. The "Hot water" setting allows you to adjust your dishwasher optimally to operation with hot water. It is recommended to have a water temperature (temperature of the incoming water) of at least 40 °C and no more than 60 °C. It is not recommended to connect the appliance to hot water if the water is supplied from an electric boiler.

#### To change the setting:

- 1. Open the door.
- 2. Switch on ON/OFF switch 1.
- 3. Press Info button 3 for 3 seconds until the following text is indicated on the display window at the top  $\boxed{4}$ :

Scroll with <> Set with - +

# Leave with Setup 3 sec.

- 4. Keep pressing the button > 16 until water connection appears of the display window at the top 4.
- 5. Make the setting with setting buttons + - 8 .
- 6. Press and hold the Info button 3 for 3 seconds.

The chosen setting has now been stored.

#### **Electrical connection**

- Connect the appliance to an alternating current only, ranging from 220 V to 240 V and 50 Hz or 60 Hz via a correctly installed socket with protective earth conductor. See rating plate for required fusing 35.
- The socket must be near the appliance and freely accessible following installation. If the plug is not freely accessible, an allpole disconnector with a contact opening of at least 3 mm must be fitted on the installation side to satisfy the relevant safety instructions.
- The connection may be modified by technicians only.
- A power cord extension may be purchased from customer service only.
- Use only a residual current operated circuit-breaker which features the symbol . Only this extension guarantees compliance with the currently valid regulations.
- The appliance features a water damage protection system. Please note the system will function **only** when the power supply is connected.

#### Removal

# Also observe the sequence of worksteps here.

- 1. Disconnect the appliance from the power supply.
- 2. Turn off the tap.
- Undo the waste water and drinking water connection.
- **4.** Loosen fastening screws for the furniture parts.
- 5. If fitted, remove the base panel.
- 6. Pull out the appliance, carefully pulling the hose behind.

# **Transporting**

Empty the dishwasher and secure loose parts.

#### Drain the appliance according to the following steps:

- 1. Turn on the tap.
- 2. Open the door.
- 3. Switch on ON/OFF switch 1.
- 4. Select programme with the highest temperature. The estimated programme duration is indicated on the display window at
- the top  $\boxed{4}$ . 5. Press START button 12.
- 6. Close the door.
  - Programme sequence starts.
- 7. Open the door after approx. 4 minutes.
- 8. Press START button 12 until "Program was terminated"/"Ready in one minute." is indicated at the top of the display window 4.
- 9. Close the door.
- 10. Open the door after approx. 1 minute.
  - The display window at the top 4 indicates; "Finished".
- 11. Switch off ON/OFF switch 11.
- 12. Turn off the tap, disconnect supply hose and drain water.

Note: Transport appliance upright only. This prevents residual water from running into the machine control and damaging the programme sequence.

# **Protection against frost**

If the appliance is in a room where there is a risk of frost (e.g. holiday home), empty the appliance completely (see Transportation).

In addition to warranty claims against the seller based on the purchase contract and in addition to our appliance warranty we will pay damages under the following conditions:

- If our AquaStop system is defective and causes water damage, we will make good the damage for private users.
   To ensure water damage protection, the appliance must be connected to the power supply.
- 2. This liability guarantee is valid for the service life of the appliance.
- 3. A prerequisite for the warranty claim is that the appliance has been correctly installed and connected with AquaStop according to our instructions. This also includes the correct installation of the AquaStop extension (original accessory). Our warranty does not extend to defective feed lines or fittings up to the AquaStop connection on the tap.
- 4. If your appliance is fitted with AquaStop, you can leave your appliance unattended during operation and leave the tap turned on afterwards. The tap should only be turned off if you are absent from home for a prolonged period, e.g. several weeks holiday.

#### Repair order and advice on faults.

GB 0344 892 8979 Calls from a BT landline will be charged at up to 3 pence per minute.

A call set-up fee of up to 6 pence may apply.

IE 01450 2655 0.03 € per minute at peak. Off peak 0.0088 € per minute.

US 800 944 2904 toll-free

Contact information for all countries can be found on the enclosed customer service list.

Robert Bosch Hausgeräte GmbH Carl-Wery-Straße 34 81739 München Germany



**9001221773** (9708) 642 TW