



Tumble dryer WTG8640SSA



 $\boldsymbol{en}$  Installation and operating instructions

#### Your new tumble dryer

You have opted for a tumble dryer manufactured by Bosch.

Please take a few minutes to read and become familiar with the advantages of your tumble dryer.

To meet the high quality demands required by Bosch, every tumble dryer that leaves our factory is carefully checked to ensure that it functions correctly and is in perfect condition.

For more information on our products, accessories, replacement parts and services, see our website www.boschhome.com or contact our Customer Service centres.

If the operating and installation instructions describe different models, any differences will be pointed out at the relevant points in the text.



Read these operating and installation instructions before operating the tumble dryer.

#### Display rules

#### 

This combination of symbol and signal word indicates a possibly dangerous situation. Not heeding the warning can cause death or injuries.

#### Caution!

This signal word indicates a possibly dangerous situation. Not heeding the caution can cause property and/or environmental damage.

#### Note/tip

Information about the optimum use of the appliance/any other useful information.

#### 1. 2. 3. / a) b) c)

The steps are represented by numbers or letters.

#### \_ / -

Lists are represented by a small box or a dash.

### **Contents**

S Intended use	.4
Safety instructions  Children/people/pets Installation Operation Cleaning/Maintenance	. 5 . 6 . 8 11
Environmental protection	13
Installation and connection Scope of delivery	14 14 16
Getting to know your appliance	
Dryer	18 19
Preparing the laundry	21 21
Programs and buttons	22
Operating the appliance	26
Loading laundry and switching on the dryer  The basket for woollens  Drying with the basket	
for woollens	28 28

or ac Prog Prog	nging the program dding laundry	29
and Clea Emp	switching off the dryer	29
cont	ainer	30
	Signal setting	31
	Cleaning	32
and Clea	aning the dryer the control panel	32
(%)	Faults and what to do about them	34
	After-sales service	36
	Consumption values	37
	Technical data	38

#### § Intended use

- For private domestic use only.
- Only to dry and refresh fabrics that have a care label specifying that they are suitable for use in a dryer.
- The dryer can be operated by children 8 years old and older, by persons with reduced physical, sensory or mental abilities and by persons with insufficient experience or knowledge if they are supervised or have **been instructed** in its use by a responsible adult.
- Keep children under the age of 3 years old away from the dryer.
- This appliance is intended for use up to a maximum height of 4000 metres above sea level.
- Do not let children carry out any unsupervised cleaning or maintenance work on the dryer.
- Keep pets away from the dryer.

### ▲ Safety instructions

The following safety information and warnings are provided to protect you from injury and to prevent material damage to your surroundings.

It is nevertheless important to take the necessary precautions and to proceed with care when installing, maintaining, cleaning and operating the appliance.

#### Children/people/pets

#### 

Children and other people who are unable to assess the risks involved when using the appliance may injure themselves or may find themselves in life-threatening situations. Therefore please note:

- The appliance may be used by children over the age of 8 years and by persons with reduced physical, sensory or mental capacity or by persons with a lack of experience or knowledge as long as they are supervised or have received instruction on how to use the appliance safely and they have understood the potential risks of using the appliance.
- Children must not play with this appliance.

- Do not allow children to clean or maintain this appliance unsupervised.
- Keep children under 3 years and pets away from this appliance.
- Do not leave the appliance unattended when children or other people who are unable to assess the risks are in the vicinity.

#### 

Children may lock themselves inside appliances and find themselves in a life-threatening situation.

- Do not position the appliance behind a door, as this may obstruct the appliance door or prevent it from opening completely.
- Once an appliance has reached the end of its life, pull the mains plug from the socket **before** severing the mains cable, and then destroy the lock on the appliance door.

#### ⚠ Warning Risk of suffocation!

If allowed to play with the packaging/plastic film or packing components, children may become caught in these or pull them over their heads and suffocate.

Keep packaging, plastic film and packing components away from children.

# **⚠** Warning Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

If accidentally swallowed, seek medical advice. Keep detergents and care products out of the reach of children.

# **⚠** Warning Eye/skin irritation!

Contact with detergents or care products may cause eye/skin irritation.

Rinse eyes/skin thoroughly if they/it come(s) into contact with detergents or care products. Keep detergents and care products out of the reach of children.

#### Installation

### **Marning**

#### Risk of electric shock/fire/ material damage/damage to the appliance!

If the appliance is not installed properly, this may lead to a dangerous situation. Make sure that:

- The mains voltage on your power socket matches the rated voltage specified on the appliance (identification plate). The connected loads and the required fuse protection are specified on the identification plate.
- The appliance is only connected to a source of alternating current via a nationally recognized and grounded outlet that has been correctly installed.
- The mains plug and the grounded socket match and the earthing system has been correctly installed.
- The cross section of the cable is sufficiently large enough.
- The mains plug is accessible at all times.
- If using a residual current circuit breaker, only use one that bears the following mark: . The presence of this mark is the only way to be sure that it fulfils all the applicable regulations.

# Marning Risk of electric shock/fire/ material damage/damage to the appliance!

If the appliance's mains cable is altered or damaged, this may result in electric shock, short circuiting or fire due to overheating.

The mains cable must not be kinked, crushed or altered, and must not come into contact with any heat sources.

## **⚠** Warning

# Risk of fire/material damage/damage to the appliance!

The use of extension cords or power strips may result in fire due to overheating or short circuiting.

Connect the appliance directly to an earthed socket that has been correctly installed. Do not use extension cords, power strips or multi-way couplers.

#### 

The appliance may vibrate or move when in operation, potentially resulting in injury or material damage. Place the appliance on a clean, even, solid surface and, using a spirit level to guide you, level it with the screw-in feet.

- Incorrectly placing (stacking) this appliance on top of a washing machine may result in injury, material damage and/or damage to the appliance. If this appliance is to be placed on top of a washing machine, the washing machine must be of at least the same depth and width as the appliance, and it must be secured in place with the appropriate connection set if available  $\rightarrow$  Page 16. The appliance MUST be secured with this connection set. Stacking the appliance in any other way is forbidden.
- If you take hold of any of the appliance's protruding parts (e.g. the appliance door) in order to lift or move it, these parts may break off and cause injury.
  Do not take hold of any of the appliance's protruding parts in order to move the appliance.

#### ▲ Warning Risk of injury!

- The appliance is very heavy. Lifting it may result in injury. Do not lift the appliance on your own.
- The appliance has sharp edges on which you could cut your hands.
   Do not take hold of the appliance by its sharp edges. Wear protective gloves to lift it.
- If the hoses and mains cables are not correctly routed, they may constitute a tripping hazard, which may result in injury. Route hoses and cables such that they do not constitute a tripping hazard.

#### **Operation**

#### 

Laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when dried in the machine, or even cause the appliance to explode. Therefore please note:

- Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- Do not place laundry in this appliance to be dried if the laundry has not been washed first.
- Do not use the appliance if industrial chemicals have been used to clean the laundry.

#### ⚠ Warning Risk of explosions/fire!

- If there is any residual material left in the fluff filter, this may ignite when drying is in progress, or even cause the appliance to catch fire or explode.
  - Clean out the fluff filter each time the appliance is used to dry laundry.
- Certain objects may ignite when drying is in progress, or even cause the appliance to catch fire or explode.
   Remove any lighters or matches from pockets on items of clothing.
- If there is coal dust or flour in the air around the appliance, this may cause an explosion. Make sure that the area around the appliance is kept clean when it is in operation.

# ↑ Warning Risk of fire/material damage/ damage to the appliance!

If a program is terminated before the drying cycle has finished, this prevents the laundry from cooling down sufficiently and may cause the laundry to ignite, or may result in material damage or damage to the appliance.

- During the last part of the drying cycle, the laundry in the drum is not heated (cooling cycle). This is to ensure that it remains at a temperature at which it will not be damaged.
- Do not switch off the appliance before the drying cycle has finished unless you remove all items of laundry from the drum immediately and spread them out (to dissipate the heat).

#### 

Condensation water is not suitable for drinking and may be contaminated with lint. Contaminated condensation water may be hazardous to health and may cause material damage.

Do not drink or reuse.

#### 

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

#### ▲ Warning Risk of injury!

- If you support your weight/sit on the appliance door when it is open, the appliance may tip over, which may result in injury.
  - Do not support your weight on the appliance door when it is open.
- If you climb onto the appliance, the worktop may break, which may result in injury.
   Do not climb onto the appliance.
- If you reach into the drum while it is still rotating, you risk injuring your hands. Wait until the drum has stopped rotating.

#### 

The exterior of the appliance's rear panel becomes very hot during operation.

Never touch the surface of the appliance's rear panel when it is hot, and keep children away.



# Caution! Material damage/damage to the appliance

- If the amount of laundry in the appliance exceeds its maximum load capacity, it may not be able to operate properly, or this may result in material damage or damage to the appliance.
  - Do not exceed the maximum load capacity of dry laundry. Make sure you comply with the maximum load capacities specified for each of the programs  $\rightarrow$  *Page 22*.
- If you operate the appliance without a fluff filter, or if the fluff filter is defective, this may result in damage to the appliance.
  - Do not operate the appliance without a fluff filter, or with a fluff filter that is defective.
- Light objects such as hair and lint may be sucked into the air inlet when the appliance is in operation. Keep these away from the appliance.
- Foam and foam rubber may deform or melt if dried in the appliance.
  - Do not dry laundry items that contain foam or foam rubber in the appliance.

- If you pour the wrong quantity of detergent or cleaning agent into the appliance, this may result in material damage or damage to the appliance. Use detergents/care products/cleaning agents and softeners in accordance with the manufacturers' instructions.
- If the appliance overheats, it may not be able to operate properly, or this may result in material damage or damage to the appliance. Make sure that the appliance's air inlet is never obstructed when the appliance is in operation, and that the area around the appliance is adequately ventilated.

#### Cleaning/Maintenance

#### 

The appliance is powered by electricity. There is a risk of electric shock if you come into contact with live components. Therefore please note:

- Switch off the appliance. Disconnect the appliance from the power supply (pull out the plug).
- Never take hold of the mains plug with wet hands.

- When removing the mains plug from the socket, always take hold of the plug itself and never the mains cable, otherwise this may damage the mains cable.
- Do not make any technical modifications to the appliance or its features.
- Repairs and any other work on the appliance must only be conducted by our customer service or by an electrician. The same applies for replacing the mains cable (when necessary).
- Spare mains cables can be ordered from our customer service.

#### 

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

#### 

If moisture penetrates the appliance, this may cause it to short circuit.

Do not use a pressure washer or steam cleaner to clean your appliance.

#### 

The use of spare parts and accessories supplied by other brands is dangerous and may result in injury, material damage or damage to the appliance. For safety reasons, use genuine spare parts and accessories only.

# Caution! Material damage/damage to the appliance

Cleaning agents and agents for pretreating laundry (e.g. stain removers, prewash sprays, etc.) may cause damage if they come into contact with the surfaces of the appliance. Therefore please note:

- Do not allow these agents to come into contact with the surfaces of the appliance.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove any detergent, spray or other residues immediately.

# Environmental protection

#### Packaging/old appliance



Dispose of packaging in an environmentally-responsible manner.

This appliance is designated according to European directive 2012/19/EC which governs waste electrical and electronic equipment (WEEE).

The directive provides a framework for the collection and recycling of old appliances, which is valid across the EU.

#### **Energy-saving tips**

- Spin the laundry before drying. The drier the laundry, the shorter the drying time will be, thus consuming less energy.
- Load the dryer with the maximum load
  - **Note:** Do not exceed the maximum load for the programs, as this prolongs the drying time and increases energy consumption.
- Ventilate the room and keep the air inlet on the dryer free to ensure air exchange.
- Clean the fluff filter after each drying cycle. If the fluff filter is dirty, the drying time is prolonged and energy consumption is increased.
- Energy-saving mode: If the dryer is not operated for a prolonged period, it automatically switches off before the program starts and when the program has ended to save energy. The display panel and indicator lamps go off after a few minutes and the Start button flashes. To activate the lighting, press any button, open or close the dryer door or turn the program selector.



#### Scope of delivery

- Dryer
- Installation and operating instructions
- Basket for woollens\*
- Condensation drain\*

# Installing and connecting the dryer

# ⚠ Warning Risk of death!

There is a risk of electric shock as the dryer is operated with electricity.

- Check the dryer for visible damage. You must not operate the dryer if it is damaged.
- Before connecting the dryer to the power supply, ensure that the electric voltage specified on the rating plate matches the voltage of your socket.
- Only use earth-leakage circuit breakers with the following symbol:
- Ensure that the mains cable is not kinked or trapped, and that it does not come into contact with heat sources or sharp edges.

#### 

Do not set up the dryer behind a door or sliding door, as this may obstruct the dryer door or prevent it from opening.

#### Caution! Risk of injury

- Due to the heavy weight of the dryer, you may injure yourself if you lift it.
   Do not lift the dryer on your own.
- You could cut your hands on the sharp edges of the dryer. Do not hold the dryer by the sharp edges.
- Protruding parts on the dryer may break off when it is lifted or pushed.
   Do not move the dryer by holding onto protruding parts.

# Caution! Risk of material damage to the dryer or fabrics.

- Check the dryer for damage caused during transportation. Never operate a dryer if it is damaged.
- Any residual water in the dryer may freeze and damage the dryer. Do not install the dryer in rooms that are at risk of frost.

#### During installation, ensure that:

- The dryer is placed on a clean, level and firm surface.
- The mains plug can be accessed at all times,
- The air inlet on the dryer is kept clear and there is sufficient ventilation.
- The area around the dryer is kept clean and
- The dryer is levelled using the threaded feet.

**Note:** Check the alignment of the appliance with a spirit level and correct if necessary. Change the height by turning the appliance feet. All appliance feet must stand firmly on the ground.





Incorrect alignment may cause high noise levels, vibrations and improper movement of the drum.

**Note:** If in doubt, have the appliance connected by a specialist.

#### **Optional accessories**

Connecting kit for the condensation drain:

Use a hose to draw off the condensation immediately. Order number: **WTZ1110**.

#### **Transport and frost protection**

#### To empty the condensate container:

- 1. Use the program selector to select any program.
- 2. Press the Start button.
- 3. Wait for 5 minutes.

Note: The condensation is drained.


- **4.** Empty the condensate container again.
- 5. Switch off the dryer.

#### Caution!

Any residual water may leak out and cause material damage.

Transport the dryer in an upright position.

# The main points in brief



Load the laundry and close the door.

Switch on the dryer.

Select a program and, if necessary, adjust the program default settings.



Select the start button **D**(1).

Dry.

Unload the laundry.




Switch off the dryer.

Empty the condensate container.


Clean the fluff filter.

# Getting to know your appliance



- Condensate container
- 2 Control and display panel
- 3 Drum interior light (depending on the model)
- 4 Dryer door
- 5 Air inlet
- 6 Fluff filter
- 7 Heat exchanger


#### **Control panel**



- Use the **program selector** to switch the dryer on and off and to select the program.
- $\bigcirc$  Programm  $\rightarrow$  Page 22.
- 3 Start button for starting or interrupting the program  $\rightarrow$  Page 24.
- 4 Buttons  $\rightarrow$  Page 24.
- 5 Display panel with buttons  $\rightarrow$  Page 20.

#### Display panel

#### Buttons in the display panel



- Dry Level, Time Dry, Finish in Selectable Option Settings for customizing Programs are desired.
  Indicator Symbol lights or desired
  - Indicator Symbol lights or desired time is dislpayed if setting is active—→ Page 24.
- 2 Wrinkle Block, Low Heat, Signal Additional option settings. Indicator Symbol lights if setting is active → Page 24,→ Page 31.
- 3 Start/Pause Starts or pauses the programme.

#### Display panel



- Time program selected.
   "Ready in" time selected.
   Anti-crease selected.
- Anti-crease selected.
  Childproof lock selected.
  Low-Heat Drying selected.
- △)) Audible signal active.
   ▷ III Start or Pause selected.
   3 h Program delay in hours
- when "Finish in" time is selected.
- 1:27 Expected program duration in hours and minutes.
- ※ ② 田 ◎ End-P Program progress: Damp; Iron Dry; Cupboard Dry; Anti-Crease; End and Pause.
- Empty the condensate container; → Page 30.

  Clean the fluff filters;
  - $\rightarrow$  Page 29.

# Laundry

#### Preparing the laundry

### **Marning**

#### Risk of explosion or fire!

Remove any cigarette lighters and matches from pockets.

#### Caution!

# The dryer drum and fabrics may be damaged.

Remove all objects from pockets and observe the following information:

- Tie cloth belts, apron strings, etc. together or use a laundry bag.
- Close zips, hooks and eyelets and buttons. Button up large items of laundry, such as covers.
- Remove any metal objects, such as paper clips, from pockets.
- To ensure a consistent drying result, sort laundry by fabric type and drying programme.
- Always dry very small items of laundry, e.g. babies' socks, together with large items such as towels.
- Knitted fabrics such as T-shirts and jerseys often shrink the first time they are tumble-dried. Use a gentle programme.
- Do not overdry easy-care laundry.
   This increases creasing of the laundry.
- Use timed programmes for single garments.
- Some detergents and care products, e.g. starch or softeners, contain particles which may be deposited on the moisture sensor. This may impair the sensor function and in consequence the drying result.

#### **Notes**

- When washing laundry to be tumble-dried, use the correct amount of detergent and care products as specified in the manufacturer's instructions.
- Clean the moisture sensor regularly → Page 33.

#### Sorting laundry according to:

- ☐ Suitable for tumble drying
- □ Dry at normal temperature
- Dry at low temperature
- Do not tumble-dry

**Note:** Do not load laundry from the washing machine directly into the tumble dryer. Sort the spun laundry before placing it in the dryer drum.

If you dry thin, thick and multi-layer fabrics together, they will dry to differing degrees. To achieve an even drying result, you should therefore only dry together laundry of the same type of fabric and structure. If you feel that the laundry is still too damp, you can select a timed programme for subsequent drying  $\rightarrow$  Page 22.

#### Caution!

Possibility of material damage to the dryer or laundry.

# Do not tumble-dry the following fabrics:

- Laundry contaminated with oil.
- Unwashed fabrics.
- Non-breathable fabrics (e.g. rubbercoated).
- Easily damaged fabrics such as silk, synthetic curtains.



# Programs and buttons

#### **Programs**

Programs	Max. load up to:	Type of laundry (For laundry which is:)		
Standard programs				
Cottons Cupboard Dry	full load	Normal cotton and linen type load (bed linen, cotton clothes, etc.)		
Cottons Cupboard Extra Dry	full load	Terry bathrobes and terry bed linen (particularly thick or multi-ply)		
Iron Dry	1/2 load	Trousers, dresses, skirts, shirts, blouses, leggins, sports clothing with synthetic-rich fibers, lingerie (not to be or only lightly ironed)		
Easy-Care Cupboard Dry	1/2 load	Shirts, blouses, sports clothing (not to be ironed)		
Easy-Care Cupboard Extra Dry	1/2 load	Bed linen and table linen, track suits, paraks, blankets (not to be ironed, thick or multi-ply)		
Delicates	1/4 load	Lingerie made of synthetic fibers, cotton or blended fabric		
Super 40 min	1/3 load	Multi-layered, sensitive fabrics made of acrylic fibers or separate small items of laundry also for subsequent drying		
Timed Dry Variable	1/3 load	Pre-dried, multi-layered, sensitive fabrics made of acrylic fibers or separate small items of laundry also for subsequent drying		
Wool Finish	1/3 load	Wool fabrics suitable for washing used to refresh or fluff up wool articles but not dry completely remove fabrics after program end, lay on flat surface and allow to dry		
Air Fluff/No Heat	1/3 load	All type of fabrics for freshening up or ironing of items of laundry that have been worn for a short period of time		
Quick Dry Auto	1/4 load	Laundry made of synthetic fibers, cotton or blended fabrics (for example) that needs to be dried quickly  Values may differ from those specified depending on the type of fabric, mixture of laundry to be dried and residual moisture in the fabric		

For best results it is recommended to load the drum depending on the fabric type:

full load: Cottons and Linens
1/2 load: Permanent Press, Synthetic Blends and poly Knits
1/3 load: Wool, Mixed
1/4 load: Delicates

Programs	Max. load up to:	Type of laundry (For laundry which is:)	
Special programs			
Towels	1/2 load	Terry-towelling laundry e.g. towels and bathrobes	
Sanitize	1/2 load	Cotton fabrics for drying in higher temperatures to keep them more hygienic	
Jeans	1/2 load	Fabrics made from jeans/denim	
Bulky/Large Items	full load	Garments with down feather fillings, pillows and blankets but not quilts only dry one article at a time	
For best results it is recommended to load the drum depending on the fabric type: full load: Cottons and Linens 1/2 load: Permanent Press, Synthetic Blends and poly Knits 1/3 load: Wool, Mixed 1/4 load: Delicates			

### **Buttons**

Buttons	Explanations and notes		
Default Program	and Option settings		
<b>Note:</b> At the fact lows.	ory initial settings are pre-set for all cycles. You can change some program settings as fol-		
The dryeness level can be increased in 3 steps )i.e. the laundry is drier) by the <b>Dry level</b> button for certain programs.  Default setting = 0 (No LED Symbol shown)  Selectable values: 0, +1, +2, +3  After the dryness level for a program is set, it is retained until changed again			
Time Dry	Available only for Time programs, $\longrightarrow$ Page 22 can be selected from minimum 20 minutes to maximum 3 hours, in 10-minute steps.		
Finished in  Additional Progr	The program end (Finish in) time can be set in one hour increments to a maximum of 24 h (hours).  After selecting the desired drying program (at the dial) but before touching the Start button, touch the <b>Finish in</b> button until the desired time is displayed, e.g. 8 h, then touch the Start button to start the dryer.  Note: The cycle duration is included in the set Finish in time.  8 h is displayed (until Energy-Saving mode activates) and counts down (approximately 5hr:30min) until the drying cycle begins (at 2hrs:30min) then the cycle duration 2:30 is displayed and drying begins. Total time approximately 8 hours.  ram Option settings  To prevent the laundry from creasing or wrinkling, the dryer drum rotates at specific intervals following the drying process.  If the Wrinkle Block button is touched, this function is set to 60 (+60) or 90 (+90) minutes.  The laundry remains loose and fluffy until it is removed.		
Low Heat	The laundry should be removed before this time has elapsed.  Reduced temperature for delicate fabrics, e.g. polyacrylic, polyamide or elastane, with longer drying time.		
	Observe the care information or symbols on the textile's label.		

Buttons	Explanations and notes
Other buttons	
Signal	A signal sounds after the program has ended $\longrightarrow$ Page 31
□ 3 sec.     (Childproof lock)	You can secure the dryer against inadvertent changing of the set functions. To do this, activate the childproof lock after cycle start.
	To <b>Activate/Deactivate</b> , touch Time Dry and Finish in buttons at the same time for 3 seconds. In the display field, you will see the symbol light indicating the childproof lock is active.
	<b>Note:</b> The childproof lock will remain activated until the next cycle start even after switching the machine off. You must deactivate the childproof lock before the next cycle and, if necessary, activate it again after starting the cycle.
Start/Pause	Starts or pauses the selescted cycle; indicator lamp on (steady) - cycle running, can be paused; indicator lamp blinking - options can be changed; cycle can be started; door is closed; childporoof lock is active; cycle is in Pause mode.



### **Operating the** appliance

#### Loading laundry and switching on the drver

Note: The drver must be correctly positioned and connected.  $\rightarrow$  Page 14.

- 1. Place the laundry in the drum.
- 2. To switch the dryer on, turn the program selector to any program.
- 3. Close the dryer door.

#### Caution!

#### Risk of material damage to the dryer or laundry.

Take care not to trap any laundry in the door.


#### The basket for woollens

Note: The basket for woollens is supplied with your dryer\* or it can be purchased as an accessory from the after-sales service.

#### Caution!

#### Risk of material damage to the dryer and fabrics.

Never operate the dryer if the basket for woollens is damaged.




- Basket for woollens
  - 2 Insert for the basket for woollens
- 3 Recesses for mounting the basket for woollens
- 4 Notch for the basket for woollens

#### Drying with the basket for woollens

 Insert the feet of the basket for woollens into the holes on the fluff filter



2. Lean the basket for woollens against the upper notch.



Depending on the model

The basket for woollens should now be firmly inserted in the drum.


Place the required fabric in the insert of the basket for woollens

#### **Notes**


- Spin the fabrics before placing them in the insert.
- Place the laundry loosely in the insert. Do not squash the fabrics.

#### Application examples:

#### a) Trousers or skirt



#### b) Pullover



#### c) Sports shoes

Place sports shoes in the basket for woollens **without** the insert. Pull out the tongues of the shoes and remove the insoles or heel cushions.

Roll up a towel and place it under the sports shoes to create an inclined surface. Place the shoes so that the heels are on the towel.



#### d) Soft toys

Dry soft toys in the basket for woollens without the insert. Only place as many soft toys in the basket for woollens as is possible without any falling out.



**4.** Place the insert or the sports shoes in the basket for woollens.

#### Caution!

### Risk of material damage to the fabrics.

Place the fabrics in the insert of the basket for woollens so that they do not come into contact with the drum.



- Use the program selector to select the program for the basket for woollens or a time program.
- Modlens or a time program.

  Set the drying time.
  Thin woollen pullover:
  Approx. 1:20 hrs
  Thick woollen pullover:
  Approx. 1:30 hrs 3:00 hrs
  Skirt: Approx. 1:00 hr 1:30 hrs
  Trousers: Approx. 1:00 hrs 1:30 hrs
  Gloves: Approx. 30 min
  Sports shoes:
  Approx. 1:30 hrs/
  with airing max. 2:00 hrs


**Note:** For thicker or multi-layered fabrics, you must extend the drying time, as required, to achieve the required level of dryness.

- 7. Start the program.
- **8.** Remove the fabrics and switch off the dryer.

#### Setting a program

**Note:** If you have activated the childproof lock, you must deactivate it before you can set a program, see → *Page 24*.

- Select the required program; detailed information on the programs can be found from → Page 22 onwards.
- Use the program selector to set the required program. The default program settings for the selected program appear in the display panel.



**Note:** Default program settings are standard settings that are already defined when a program is selected. After selecting a program, you can see the default program settings in the display panel.

 If required, adjust the default program settings. You can find detailed information on this from → Page 22 onwards.

#### Starting the program

Press the Start button.

**Note:** If you want to lock the program to prevent it from being inadvertently adjusted, you can select the childproof lock, see  $\rightarrow$  *Page 24*.

#### **Program sequence**

The programme status is indicated in the display field.

e.g. Expected programme duration in hours and minutes.

Note: When a programme is selected, the expected drying time for the recommended load is displayed. During drying moisture sensors detect the remaining moisture in the load and adjust the programme length (except timed programmes). This is visible via the time remaining leaping forward.

☐ Iron Dry

Cupboard Dry

AntiCrease

-P - Pause

End End

# Changing the program or adding laundry

You can remove or add laundry and change or alter the program at any time during drying.

- 1. To pause the program, open the dryer door or press the Start button.
- 2. Add or remove laundry.
- 3. Select another program or an additional function, if required.
- 4. Close the drver door.
- 5. Press the Start button.

**Note:** The program duration in the display panel is updated depending on the load and residual moisture in the laundry. The values displayed may change after the program is changed or the load is adapted.

#### **Program interruption**

The program can be interrupted at any time; to pause, open the dryer door or press the Start button.

#### Caution!

#### Risk of fire. Laundry may catch fire.

If you cancel the program, you must remove the laundry items and spread them out so that the heat can disperse.

#### **Program end**

End appears in the display panel.

# Removing laundry and switching off the dryer

- 1. Remove the laundry.
- 2. Turn the program selector to the "off" position.



#### Clean the fluff filter

**Note:** During drying, fluff and hair from the laundry is trapped by the fluff filter. If the fluff filter is blocked or dirty, this reduces the flow of air, which prevents the dryer from achieving its maximum performance. Clean fluff filters also reduce energy consumption and the drying time.

Clean the fluff filter **after each** drying cycle:

- Open the dryer door and remove all fluff from the door.
- 2. Remove the fluff filter.




Remove the fluff from the recess in the fluff filter.



**Note:** Ensure that no fluff falls into the open shaft.

- **4.** Open the fluff filter and remove all the fluff.
- Rinse away the fluff under running water or clean the fluff filter in the dishwasher.



**6.** Dry the fluff filter, close it and reinsert the fluff filter.



# Caution! The dryer may be damaged.

Do not operate the dryer without a fluff filter or if the fluff filter is defective.

# **Emptying the condensate container**


By default, the condensation from the appliance runs into the condensation container.

Alternatively, you have the option of discharging the condensation water\* supplied depending on the model. If you choose to discharge the condensation water into the waste-water system, you will not need to empty the condensation container during the drying programme or after each time you use the dryer.

1. Pull out the condensate container horizontally.



2. Pour out the condensation water.



#### Caution!

# Dirty condensation water may be harmful to your health and cause material damage.

Condensation water is not suitable for drinking and may be contaminated with fluff. Do not drink the condensation water or reuse it.

Push in the condensate container until you feel it lock back into place in the dryer.



 into the waste-water system via a drain hose

## Signal setting

You can change the following settings:

- The spin speed that is used for spinning your laundry before it is dried.
- The volume of the audible signal at the end of the program,
- The volume of the audible button signals.

You will need to activate the setting mode in order to change these settings.



#### **Activating setting mode**

- 1. Switch the dryer on.
- 2. Select the "Cottons" programme in position 1 and wait for five seconds.

The symbols go out in the display panel and the programme duration is displayed.

- Press and hold the Start button and, at the same time, turn the programme selector clockwise to position 2.
- 2. The **spin speed** is shown in the display.
- Press the "Finish in" time button or the drying time button to change the spin speed.
- **4.** Turn the program selector clockwise to position 3.

 The volume of the audible signal at the end of the program is shown in the display.



- 0 = off, 1 = quiet, 2 = medium, 3 = loud, 4 = very loud
- Press the "Finish in" time button or the drying time button to change the volume.
- 7. Turn the program selector clockwise to position 4.
- **8.** The volume for the **audible button signal** is shown in the display.



- 0 = off, 1 = quiet, 2 = medium, 3 = loud, 4 = very loud
- Press the "Finish in" time button or the drying time button to change the volume.

#### **Exiting setting mode**

Turn the program selector to the "Off" position once you have set the required spin speed and the volume. The settings have now been saved.



### **Cleaning**

#### Cleaning the dryer and the control panel

#### **Marning** Risk of death!

There is a risk of electric shock as the dryer is operated with electricity. Disconnect the dryer from the mains before cleaning.

Clean the dryer using only water and a soft, damp cloth.

Remove all detergent residue, spray residue or other residues immediately. Do not use cleaning agents or agents for pre-treating laundry (e.g. prewash sprays, stain removers). Do not use high-pressure cleaners or steam iet cleaners to clean your appliance.

#### Cleaning the heat exchanger


#### **Notes**

- The heat exchanger requires cleaning once a month, however this varies depending on how frequently the drver is used.
- If there is debris in the heat exchanger, this will increase the amount of time required for drying and will compromise the drying results.
- 1. Allow the dryer to cool down and place an absorbent cloth beneath the maintenance flap.


Note: Residual water may leak out. 2. Open the maintenance flap fully.




3. Turn both locking levers towards each other.



4. Remove the top cap from the heat exchanger.



5. Remove the heat exchanger.



6. Flush water through the heat exchanger from all sides to completely remove all fluff.




#### Caution!

#### There is a risk of damage to the heat exchanger.

Only use water to clean the heat exchanger, and do not use any hard objects or objects with sharp edges to remove the fluff.

- 7. Remove all fluff from the seals on the dryer and on the heat exchanger.
- 8. Allow all the water to drip off.

- First insert the heat exchanger, and then fit the heat exchanger's top cap in place.
- 10. Turn both locking levers back and close the maintenance flap until it locks into place.



**11.** Close the maintenance flap and press on it until you feel it click in place.



#### **Cleaning the moisture sensor**

**Note:** The dryer is equipped with a stainless-steel moisture sensor. The moisture sensor measures how damp the laundry is.

After long periods of usage the moisture sensor may become covered by a fine layer of limescale or residues of detergents and care products. Such residues must be removed regularly as the sensor function and in consequence the drying result may be impaired.

Open the door and clean the moisture sensor with a coarse sponge.



#### Caution! Moisture sensor may be damaged.

Do not clean moisture sensors with abrasives and steel wool.



# Faults and what to do about them

Faults	Cause/remedy
on the display panel and drying has been interrupted.	<ul> <li>■ Empty the condensate container and press the Start button → Page 24.</li> <li>■ If the optional condensation drain is installed, the drain hose may be blocked. Check the hose for deposits and flush the hose out.</li> </ul>
on the display panel.	Clean the fluff filter and/or the heat exchanger, then select the Start button $\rightarrow$ Page 29; $\rightarrow$ Page 32.
Dryer does not start.	<ul> <li>Mains plug plugged in or fuse checked?</li> <li>program selected? Select a program.</li> <li>Dryer door open? Close the door.</li> <li>Childproof lock activated? Deactivate the childproof lock.</li> <li>"Finish in" time selected? program starts after a delay.</li> </ul>
Display panel goes off and Start button flashes.	Not a fault. Energy saving mode is active $\longrightarrow$ Page 13.
Creasing.	<ul> <li>Creasing occurs when you have exceeded the maximum load or selected the wrong program for the type of fabric. All the required information can be found in the program table.</li> <li>Remove clothes immediately after drying; creasing may occur if they are left in the drum.</li> </ul>
Water is leaking out.	Not a fault; the dryer may be positioned on an incline. Level the dryer.
Change in the programme duration displayed during drying.	Not a fault. The moisture sensors detect the remaining moisture in the load and adjust the programme length (except timed programmes).
Laundry is not dried correctly or is still too damp.	<ul> <li>After the end of the program, warm laundry feels damper than it actually is. Spread the laundry out and allow the heat to disperse.</li> <li>Finely adjust the dryness level – this extends the drying time but does not increase the temperature. Your laundry will become drier → Page 24.</li> <li>Select a program with a longer drying time or increase the drying level. This does not increase the temperature.</li> <li>Select a timed program for subsequent drying of laundry that is still damp → Page 22.</li> <li>If you have exceeded the maximum load for the program, the laundry may not be dried properly.</li> <li>Clean the moisture sensor in the drum. The sensor may become covered by a fine layer of limescale or residues of detergents and care products which then impair its function. Your laundry is not being dried correctly → Page 33.</li> <li>Drying has been interrupted as a result of a power cut, because the condensate container is full or because the maximum drying time has been exceeded.</li> <li>Note: See also the laundry tips → Page 21.</li> </ul>
* depending on the mode	

Faults	Cause/remedy
Drying time too long?	<ul> <li>The fluff filter may be dirty and cause a longer drying time. Clean the fluff filter.</li> <li>The heat exchanger may be dirty and cause a longer drying time. Clean the heat exchanger.</li> <li>If the air inlet on the dryer is blocked or not freely accessible, this may increase the drying time. Make sure that the air inlet remains unobstructed.</li> <li>If the ambient temperature is higher than 35 °C, this may extend the drying time.</li> <li>Insufficient air circulation in the room may increase the drying time. Ventilate the room.</li> </ul>
Displayed drying time changes during drying process.	Not a fault. The dryer recognizes the load and adapts the remaining program duration.
Humidity in the room increases.	Not a fault. Make sure the room is sufficiently ventilated.
Power cut.	The drying program is interrupted. Remove the laundry and spread it out, or restart the program.
* depending on the mode	el

**Note:** If you cannot rectify the fault yourself by turning the dryer off and on, please contact our after-sales service.

#### After-sales service

#### After-sales service

If you cannot rectify the fault yourself (faults, what to do?), please contact our after-sales service. We will always find an appropriate solution to avoid unnecessary visits by engineers.

The contact information for your nearest after-sales service can be found here or in the enclosed after-sales service directory.

Please provide after-sales service with the dryer's product number (E-no.) and production number (FD).



You can find this information on the inside of the dryer door or on the rear of the dryer.

### Trust the expertise of the manufacturer.

Contact us. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts.

# **Consumption values**

Program	Spin speed which is used for spinning the laundry	Duration**		Energy consumption**	
Cottons		8 kg	4 kg	8 kg	4 kg
Cupboard Dry*	1400 rpm	129 min	67 min	4.22 kWh	2.33 kWh
	1000 rpm	142 min	79 min	4.92 kWh	2.71 kWh
	800 rpm	155 min	92 min	5.62 kWh	3.09 kWh
Easy-Care		3.5 kg		3.5 kg	
Cupboard Dry*	800 rpm	52 min		1.51 kWh	
	600 rpm	63 min		1.85 kWh	

Program setting for testing in accordance with the applicable IEC 61121 standard. The values may differ from those specified, depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric and the amount of laundry being loaded.



## Technical data

#### **Dimensions:**

85 x 60 x 60 cm

Height x width x depth

Weight:

Approx. 45 kg

Maximum load:

8 kg

Condensate container:

4.6 I

Connected voltage:

220 - 240 V

Connected load:

Max. 2600 W

Fuse:


13 A

Drum interior light\*

**Ambient temperature:** 

5 - 35 °C

Depending on the model





#### Advice and repair order in the event of faults

GB 0344 892 8979 (Calls charged at local or mobile rate.) ΙE

01450 2655 (0.03 € per minute at peak. Off peak 0.0088 € per minute.)

You can find the contact information for all countries in the attached after-sales service directory.

Robert Bosch Hausgeräte GmbH Carl-Wery-Straße 34 81739 München, GERMANY



9001275443 (9612)