

Register your new device on MyBosch now and get free benefits: bosch-home.com/ welcome



# Washing machine

WLK20261IN WLK24269IN

en Instruction Manual and Installation Instructions

### Your new washing machine

You have chosen a Bosch washing machine.

Please take a few minutes to read and become familiar with the advantages of your washing machine.

To meet the high quality demands required by Bosch, every washing machine that leaves our factory is carefully checked to ensure that it functions correctly and is in perfect condition.

For more information on our products, accessories, replacement parts and services, see our website www.boschhome.com or contact our after-sales service centres.

If the operating and installation instructions describe different models, any differences will be pointed out at the relevant points in the text.



Read these operating and installation instructions before switching on the washing machine.

#### **Display rules**

#### ▲ Warning!

This combination of symbol and signal word indicates a possibly dangerous situation. Not heeding the warning can cause death or injuries.

#### Caution!

This signal word indicates a possibly dangerous situation. Not heeding the caution can cause property and/or environmental damage.

#### Note/tip

Information about the optimum use of the appliance/any other useful information.

#### 1. 2. 3. / a) b) c)

The steps are represented by numbers or letters.

/ -

Lists are represented by a small box or a dash.

## **Contents**

Sev Intended use	4
Safety instructions           Children/people/pets           Installation           Operation           Cleaning/Maintenance	5 6 8
Environmental protection1 Packaging/used appliance1 Tips on economical use1	1
Positioning and connecting1Standard accessories	233 4 44556789
Cetting to know the appliance 2 Appliance	0 1
Laundry.    2      Prepare the laundry    2      Sorting laundry    2      Starching    2      Dyeing/bleaching    2	3 3 4
Detergent	4

<ul> <li>P+ Programme default settings</li> <li>↓ Temperature</li> <li>⊙ Spin Speed</li> <li>○ Finished in</li> </ul>	.25 .25 .26
P <sup>++</sup> Additional programme setting =♡ Speed/@ Eco We Rinse Plus Soak Easy Iron	.26 .27 .27
<b>Operating the appliance</b> Preparing the washing machine Select programme/switch on the appliance	.27
Change the programme default settings	.28
settings Placing laundry into the drum Measure and add detergent and car	.28 re
products	.29 .30 .30 .30 .30 .31
appliance	
Sensors     Unbalanced load detection system.	
Cleaning and maintenance Machine housing/control panel Drum Descaling Detergent drawer and housing Detergent solution pump blocked	.32 .32 .33 .33

## <sup>§</sup> Intended use

- This appliance is intended for private domestic use only.
- Do not install or operate this appliance anywhere that is liable to experience frost and/or outdoor conditions. There is a risk that the appliance will be damaged if residual water in it freezes. If hoses freeze up, they may crack/burst.
- This appliance must only be used for washing domestic laundry, consisting of machine-washable items and hand-washable woollens (see label on item). Using the appliance for any other purpose is outside of the scope of its intended application and is forbidden.
- This appliance is suitable for operation with mains water and commercially available detergents and care products (must be suitable for use in washing machines).
- This appliance is intended for use up to a maximum height of 4000 metres above sea level.

#### Before you switch on the appliance:

Check that there is no visible damage to the appliance. Do not operate the appliance if it is damaged. Should you have any problems, please contact your specialist dealer or our customer service.

Read and follow the operating and installation instructions and all other information provided with this appliance.

Retain the documents for subsequent use or for subsequent owners.

## A Safety instructions

The following safety information and warnings are provided to protect you from injury and to prevent material damage to your surroundings.

It is nevertheless important to take the necessary precautions and to proceed with care when installing, maintaining, cleaning and operating the appliance.

### Children/people/pets

### ▲ Warning Risk of death!

Children and other people who are unable to assess the risks involved when using the appliance may injure themselves or may find themselves in life-threatening situations. Therefore please note:

- The appliance may be used by children over the age of 8 years and by persons with reduced physical, sensory or mental capacity or by persons with a lack of experience or knowledge as long as they are supervised or have received instruction on how to use the appliance safely and they have understood the potential risks of using the appliance. Children must not play with
- Children must not play with this appliance.

- Do not allow children to clean or maintain this appliance unsupervised.
- Keep children under 3 years and pets away from this appliance.
- Do not leave the appliance unattended when children or other people who are unable to assess the risks are in the vicinity.

## ▲ Warning Risk of death!

Children may lock themselves inside appliances and find themselves in a life-threatening situation.

- Do not position the appliance behind a door, as this may obstruct the appliance door or prevent it from opening completely.
- Once an appliance has reached the end of its life, pull the mains plug from the socket **before** severing the mains cable, and then destroy the lock on the appliance door.

## Marning Risk of suffocation!

If allowed to play with the packaging/plastic film or packing components, children may become caught in these or pull them over their heads and suffocate.

Keep packaging, plastic film and packing components away from children.

## ▲ Warning Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

If accidentally swallowed, seek medical advice. Keep detergents and care products out of the reach of children.

## ▲ Warning Risk of burns!

When washing at high temperatures, the glass in the appliance door becomes hot. Stop children from touching the appliance door when it is hot.

# Warning Eye/skin irritation!

Contact with detergents or care products may cause eye/skin irritation.

Rinse eyes/skin thoroughly if they/it come(s) into contact with detergents or care products. Keep detergents and care products out of the reach of children.

## Installation

## **M**Warning

#### Risk of electric shock/fire/ material damage/damage to the appliance!

If the appliance is not installed properly, this may lead to a dangerous situation. Ensure the following:

- The mains voltage on your power socket must match the rated voltage specified on the appliance (identification plate). The connected loads and the required fuse protection are specified on the identification plate.
- The mains plug and the protective contact socket must match and the earthing system must be correctly installed.
- The installation must have an adequate cross section.
- The mains plug must be freely accessible at all times. If this is not possible, in order to comply with the relevant safety regulations, a switch (all pole disconnection) must be built into the permanent installation in accordance with electrical installation regulations.
- If using a residual current circuit breaker, only use one that bears the following mark: A line presence of this mark is the only way to be sure that it fulfils all the applicable regulations.

#### **Marning** Risk of electric

#### Risk of electric shock/fire/ material damage/damage to the appliance!

If the appliance's mains cable is altered or damaged, this may result in electric shock, short circuiting or fire due to overheating.

The mains cable must not be kinked, crushed or altered, and must not come into contact with any heat sources.

## **M**Warning

#### Risk of fire/material damage/ damage to the appliance!

The use of extension cords or power strips may result in fire due to overheating or short circuiting.

Connect the appliance directly to an earthed socket that has been correctly installed. Do not use extension cords, power strips or multi-way couplers.

#### Warning Risk of injury/material damage/damage to the appliance!

 The appliance may vibrate or move when in operation, potentially resulting in injury or material damage.
 Place the appliance on a clean, even, solid surface and, using a spirit level to guide you, level it with the screw-in feet. If you take hold of any of the appliance's protruding parts (e.g. the appliance door) in order to lift or move it, these parts may break off and cause injury.
 Do not take hold of any of the appliance's protruding parts in order to move the appliance.

## ▲ Warning Risk of injury!

- The appliance is very heavy. Lifting it may result in injury. Do not lift the appliance on your own.
- The appliance has sharp edges on which you could cut your hands.
   Do not take hold of the appliance by its sharp edges. Wear protective gloves to lift it.
- If the hoses and mains cables are not correctly routed, they may constitute a tripping hazard, which may result in injury.
   Route hoses and cables such that they do not constitute a tripping hazard.

## Caution!

## Material damage/damage to the appliance

 If the water pressure is too high or too low, the appliance may not be able to operate properly, and it may also result in material damage or damage to the appliance.
 Make sure that the water pressure in the water supply facility is at least 100 kPa (1 bar), and does not exceed

1000 kPa (10 bar).

- If the water hoses are altered or damaged, this may result in material damage or damage to the appliance. The water hoses must not be kinked, crushed, altered or severed.
- The use of hoses supplied by other brands to connect to the water supply may result in material damage or damage to the appliance. Use the hoses supplied with the appliance or genuine spare part hoses only.
- The appliance is secured for transportation by transport locking devices. If the transport locking devices are not removed before the appliance is operated, this may result in damage to the appliance.

It is important to completely remove all transport locking devices before using the appliance for the first time. Make sure that you retain these transport locking devices separately. It is important to refit the transport locking devices if the appliance is to be transported, in order to prevent the appliance from being damaged in transit.

## Operation

### ▲ Warning Risk of explosions/fire!

Laundry that has been pretreated with cleaning agents that contain solvents, e.g. stain remover/cleaning solvent, may cause an explosion in the drum. Rinse the laundry thoroughly with water before washing it in the machine.

## ▲ Warning Risk of poisoning!

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

## ⚠ Warning Risk of injury!

 If you support your weight/sit on the appliance door when it is open, the appliance may tip over, which may result in injury.

Do not support your weight on the appliance door when it is open.

 If you climb onto the appliance, the worktop may break, which may result in injury.
 Do not climb onto the

appliance.

 If you reach into the drum while it is still rotating, you risk injuring your hands. Wait until the drum has stopped rotating.

## ▲ Warning Risk of scalding!

When washing at high temperatures, there is a risk of scalding if you come into contact with hot detergent solution (e.g. when draining hot detergent solution into a washbasin).

Do not reach into the hot detergent solution.

## Marning Eye/skin irritation!

Detergent and care products may spray out if the detergent drawer is opened while the appliance is in operation. Rinse eyes/skin thoroughly if they/it come(s) into contact with detergents or care products. If accidentally swallowed, seek medical advice.

#### Caution! Material damage/damage to the appliance

 If the amount of laundry in the appliance exceeds its maximum load capacity, it may not be able to operate properly, or this may result in material damage or damage to the appliance.

Do not exceed the maximum load capacity of dry laundry. Make sure you comply with the maximum load capacities specified for each of the programs  $\rightarrow$  Supplementary sheet for the operating and installation instructions.

 If you pour the wrong quantity of detergent or cleaning agent into the appliance, this may result in material damage or damage to the appliance. Use detergents/care products/cleaning agents and softeners in accordance with the manufacturers' instructions.

## Cleaning/Maintenance

## ▲ Warning Risk of death!

The appliance is powered by electricity. There is a risk of electric shock if you come into contact with live components. Therefore please note:

- Switch off the appliance. Disconnect the appliance from the power supply (pull out the plug).
- Never take hold of the mains plug with wet hands.
- When removing the mains plug from the socket, always take hold of the plug itself and never the mains cable, otherwise this may damage the mains cable.
- Do not make any technical modifications to the appliance or its features.
- Repairs and any other work on the appliance must only be conducted by our customer service or by an electrician. The same applies for replacing the mains cable (when necessary).
- Spare mains cables can be ordered from our customer service.

## ▲ Warning Risk of poisoning!

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

## \Lambda Warning

# Risk of electric shock/material damage/damage to the appliance!

If moisture penetrates the appliance, this may cause it to short circuit.

Do not use a pressure washer, steam cleaner, hose or spray gun to clean your appliance.

#### Warning Risk of injury/material damage/damage to the appliance!

The use of spare parts and accessories supplied by other brands is dangerous and may result in injury, material damage or damage to the appliance. For safety reasons, use genuine spare parts and accessories only.

### Caution!

## Material damage/damage to the appliance

Cleaning agents and agents for pretreating laundry (e.g. stain removers, prewash sprays, etc.) may cause damage if they come into contact with the surfaces of the appliance. Therefore please note:

- Do not allow these agents to come into contact with the surfaces of the appliance.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove any detergent, spray or other residues immediately.

# Environmental protection

X

## Packaging/used appliance

Dispose of packaging in an environmentally-responsible manner.

This appliance is certified in accordance with the guidelines on E-waste (Management) Rules 2016 which govern waste electrical and electronic equipment. The guidelines provide a framework for the return and recycling of used appliances.

**Note:** This product doesn't contain any of hazardous substances as specified in the E-waste (Management) Rules 2016.

#### Do's

 Hand over the old/discarded electronic equipment only to authorized collection centers for disposal www.bosch-home.com/in/aboutbosch/responsibility.html See also:

Contact No: 180042535287 (toll-free) E-mail: recycle@ewasteindia.com Online www.ewasteindia.com website:

- Consult the authorized service center as to whether the Electronic Equipment can be repaired or not, before discarding
- Consult the retailer about appliance take back schemes

#### Don'ts

- Don't dump the discarded Electronic Equipment in the open or in any land fill site, as this will result in contamination of the soil and the ground water
- Don't dispose of the discarded Electronic Equipment in household bins or Municipal bins
- The product is not meant for re-sale to any unauthorized agencies/scrap dealers
- Don't keep any replaced spare part(s) from the product in an exposed area

## Tips on economical use

- Fill the appliance with the maximum amount of laundry for each programme to save energy and water to an optimum.
   Overview of programmes
   → Supplementary sheet for the operating and installation instructions.
- Wash normally soiled laundry without a prewash.
- Save energy and detergent when washing lightly and normally soiled laundry.

 $\rightarrow$  "Detergent" on page 24

- The selectable temperatures apply to the care labels on the textiles. The temperatures in the machine may deviate from this so that you get the optimum mix of energy-saving and washing results.
- Information about the energy consumption\*:

The display provides information about the relative energy consumption in the selected program.

The more indicator lights light up, the higher the program's consumption.

This enables you to compare the consumption levels of the different programs when choosing your program settings and to decide on an energy- and water-saving program setting for the selected program.

Energy-saving mode: The display panel lighting goes out after a few minutes and the start button flashes. To activate the lighting, press any button.

Energy-saving mode is not activated if a programme is running.

- If the laundry is subsequently dried in a tumble dryer, select the spin speed according to the tumble dryer manufacturer's instructions.
- \* depending on the model

# Positioning and connecting

### **Standard accessories**

**Note:** Check the appliance for transport damage. Never use a damaged appliance. If you have any complaints, contact the dealer from whom you purchased the appliance or our Customer Service.





- A Mains lead
- B Bag:
  - Installation and operating instructions
  - Customer Service location directory\*
  - Warranty\*
  - Supplementary sheet for the installation and operating instructions\*
  - Cover caps for openings after the transport braces have been removed
  - Home Connect Installation Guides\*
- C Water inlet hose on aquaStop models
- D Water outlet hose
- E Elbow for securing the water outlet hose\*
- F Cold water inlet hose on Standard/Aqua-Secure models
- \* Depending on the model

**In addition**, a hose clamp (24 - 40 mm diameter, available from specialist retailers) is required to connect the water outlet hose to a siphon.

### Useful tool

- Spirit level for aligning
- Wrench with:
  - WAF13 for loosening the transport braces and
  - WAF17 for aligning the appliance feet → Page 17

## Safety instructions

## Warning Risk of injury!

- The washing machine is very heavy. Be careful when lifting/transporting the washing machine.
- When the washing machine is lifted by its protruding parts (e.g. the washing machine door), the components may break off and cause injuries.
   Do not lift the washing machine by protruding parts.
- If the hose and mains cables are not routed properly, there is a risk of tripping and injury.
   Lay hoses and cables in such a way that there is no risk of tripping.

#### Caution! Damage to the appliance

Frozen hoses may rip/burst. Do not install the washing machine in areas exposed to frost or outdoors.

#### Caution! Water damage

The connection points for the water supply hose and water drain hose are under high water pressure. To prevent leaks and water damage, you must follow the instructions in this section.

#### Notes

- In addition to the safety information listed here, the local water and electricity supplier may have special requirements.
- If in doubt, have the appliance connected by a specialist.

## Installation surface

**Note:** The washing machine must be aligned in a stable manner so that it does not move around.

- The installation surface must be firm and level.
- Soft floors/floor coverings are not suitable.

## Installation on a base or a wooden joist floor

#### **Caution!**

#### Damage to the appliance

The washing machine may "wander" and tip/topple from the base when spinning.

The feet of the appliance must be secured with holding brackets. Order no. WMZ 2200, WX 975600, CZ 110600, Z 7080X0.

**Note:** On wooden joist floors, install the washing machine:

- In a corner, if possible,
- On a water-resistant wooden board (min. 30 mm thick) which is screwed tightly to the floor.

## Installing the appliance in a kitchenette

## Warning Risk of death!

There is a risk of electric shock if you touch live components.

Do not remove the appliance covering plate.

#### Notes

- Recess width of 60 cm required.
- Only install the washing machine underneath a continuous worktop that is securely connected to adjacent cabinets.

## Removing the transport locks

#### Caution! Damage to the appliance

- The machine is secured for transportation using transport locks. If the transport locks are not removed, the machine may become damaged when it is operated. Before using the appliance for the first time, make sure that you completely remove all four transport locks. Keep the locks in a safe place.
- To prevent transport damage from occurring if the appliance is moved at a later date, you must refit the transport locks before transporting the appliance.

**Note:** Keep the screws and sleeves in a safe place.



1. Take the hoses out of the holders.



 Unscrew and remove all four transport brace screws. Remove the sleeves. To do this, remove the mains cable from the holders.



3. Fit the covers. Lock the covers firmly in place by applying pressure to the snap-in hooks.



## Hose and cable lengths

Left-hand connection



### Right-hand connection



\*depending on the model

**Tip:** If the supply hose is too short for your connection, you can order an extension from the after-sales service.

## Water inlet

## Warning Risk of death!

There is a risk of electric shock if you touch live components.

Observe the following when connecting the machine:

#### Notes

- Only operate the washing machine using cold mains water.
- Do not connect the machine to the mixer tap of an unpressurised hotwater boiler.
- Do not use a used supply hose. Only use the supply hose supplied with the machine or one that was purchased from an authorised retailer.
- Do not bend, squash, modify or cut through the water supply hose (otherwise its strength is no longer guaranteed).
- Only tighten the screw connections by hand. If the screw connections are tightened too much with a tool (pliers), the thread may be damaged.

## Optimum water pressure in the supply network

At least 0.1 MPa (1 bar)

Maximum 1 MPa (10 bar)

When the tap is open, the water flow is at least 8 l/min.

If the water pressure is higher than this, a pressure-reducing valve must be installed.

#### Connection

- Connect the water supply hose to the water tap (<sup>3</sup>/<sub>4</sub>" = 26.4 mm) and to the appliance:
  - Model: Standard



- Model: Aqua-Secure



- Model: Aqua-Stop



**Tip:** Connect also an external water filter (depending on the model) between water supply hose and tap. The filter filters dirt particles out of the water.

Water filter must be cleaned regularly to remove contaminants. This will prevent blockages. See also  $\rightarrow$ separate installation and cleaning instruction for water filter.

2. Open the water tap carefully, checking the leak tightness of the connection points. The screw connection is under mains water pressure.

### Water outlet

#### Caution! Water damage

When water is being pumped away, the outlet hose is under water pressure and may slip out of the wash basin or connection point. Secure the outlet hose so that it cannot slip out.

**Note:** Do not kink the water drain hose or put strain on it lengthways.

You can lay the water drain hose as follows:

# Outlet in a sink Warning Risk of scalding!

When you are washing at high temperatures, there is a risk of scalding if you come into contact with hot water e.g. if hot water is being drained into a wash basin. Do not reach into the hot water. **Caution!** 

#### Damage to the appliance/fabrics

If the end of the drain hose is immersed in the drained water, water may be sucked back into the appliance and may damage the appliance/fabrics. Make sure that:

Make sure that:

- The plug does not block drainage from the sink.
- The end of the drain hose is not immersed in the drained water.
- The water drains away quickly enough.

Secure the outlet hose so that it cannot slip out.

Elbow available from after-sales service:

Individual part number 00655300



**Drainage into a siphon** The connection point must be secured using a hose clamp with a diameter of 24-40 mm (available from specialist dealers).



 Outlet into a plastic pipe with rubber bushing or into a drainage pit



#### Levelling

Level the appliance using a spirit level.

Incorrect levelling may result in intense noise, vibrations and "wandering".

- 1. Loosen the lock nuts using a wrench, by turning it in a clockwise direction.
- 2. Check the alignment of the washing machine with a spirit level, and adjust it if necessary. Change the height by turning the appliance feet. All four appliance feet must stand firmly on the ground.
- Tighten the lock nut against the housing. In doing so, hold the foot tight and do not adjust its height. The lock nuts on all four appliance feet must be screwed tightly against the housing.



### **Electrical connection**

## Warning Danger of death!

There is a risk of electric shock if you touch live components.

- Never touch or hold the mains plug with wet hands.
- Only pull out the mains cable by the plug and never by the cable, as this could damage it.
- Never unplug the mains plug during operation.

Observe the following information and ensure that:

#### Notes

- The mains voltage and voltage indicated on the washing machine (rating plate) are the same.
   The connected load and fuse required are specified on the rating plate.
- The mains plug fits the socket.
- The cable cross-section is adequate.
- The mains cable is only replaced by a qualified electrician (if this is necessary). Replacement mains cables are available from the aftersales service.
- No multiple plugs/couplings or extension cables are used.
- If an earth-leakage circuit breaker is used, only a type which displays this symbol is used: <a>[CC]</a>.
   Only this symbol guarantees compliance with the currently applicable regulations.
- The mains plug can be accessed at all times.
- The mains cable is not bent, squashed, modified, cut through, or in contact with heat sources.

#### **Grounding Instructions**

## Warning Danger of death!

Improper connection of the ground may result in electric shock. Have the appliance checked by a qualified technician or licensed electrician if you are in doubt as to whether the washing machine has been properly grounded.

This appliance must be grounded. In the event of malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for the electric current. This appliance is equipped with a cord that has an equipment grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with local codes and ordinances. To ground the appliance use a 3 pin plug and properly grounded socket of 16 A rating.

#### Notes

- Do not modify the plug provided with the appliance. If the plug will not fit into outlet have a properly grounded outlet installed by qualified electrician. Do not cut, remove or bypass the grounding prong on the washing machine power cord plug.
- The wiring for the eletrical outlet circuit must be sufficient to meet the appliance requirements. Use of Ground Fault Circuit Interrupter (GFCI) is recommended.
- Do not use the machine with an extension box, extension cord, spike busters etc., as this may lead to improper grounding conditions.

#### Before washing for the first time

The washing machine was thoroughly tested before leaving the factory. To remove any water that may be left over from the test, run the first wash cycle without any laundry.

#### Notes

- The washing machine **must be** correctly installed and connected  $\rightarrow$  Page 12
- Never use a damaged machine. Inform customer services.
- 1. Check the machine.
- Remove the protective film from the control panel.
- 3. Connect the mains plug.
- 4. Turn on the tap.
- 5. Close the door (do not load any laundry).
- 6. Depending on the model, run the Drum Clean 🕑 90 °C or 🏠 Cottons 90 °C program. For AU variant, two cycles of **Cottons** 90 °C programme without laundry are required to be run at initial setup. and this operation only needs to be completed once.
- 7. Open the detergent drawer.
- 8. Pour approximately 1 litre of water into compartment II.
- 9. Pour standard detergent into compartment II.

Note: To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergent designed for wool or delicates.

- **10.** Close the detergent drawer.
- **11.**Press the D Start/Reload button.
- 12. When the program ends, switch off the appliance.

#### Your washing machine is now ready to use.

### **Transportation**

e.g. when moving home

#### **Preparatory work:**

- **1.** Turn off the water tap.
- 2. Reduce the water pressure in the supply hose. Maintenance – filter in the water supply  $\rightarrow$  Page 34
- 3. Disconnect the washing machine from the main plug. 4. Drain the remaining detergent
- solution. Maintenance - detergent solution pump blocked  $\rightarrow$  Page 33 5. Remove the hoses.

#### Installing the transport locks:

1. Remove the covers and keep them in a safe place. Use a screwdriver if necessary.



2. Insert all four sleeves. Clip the mains cable securely in the holders. Insert and tighten the screws.



#### Before switching on the appliance again:

#### Notes

- The transport locks **must** be removed.  $\rightarrow$  "Removing the
- transport locks" on page 14 To prevent unused detergent from . flowing straight into the drain during the next wash: Pour approx. 1 litre of water into compartment II and start the Spin program.

## Getting to know the appliance

### Appliance





Detergent dispenser Control panel Door

3 <b>a</b>	
3b	
4	

Open the door Close the door Service flap

### **Control panel**

You can find possible programme default settings and additional programme settings in the overview; these differ depending on the model.





 Programme default settings can be changed.
 Our is a setting of all programme default

Overview of all programme default settings  $\rightarrow$  Page 25

- 2 additional programme settings can be selected. Overview of all additional programme settings  $\rightarrow$  Page 26
- Start button for starting, interrupting, (e.g. adding laundry) and cancelling a programme.
- **Programme selector** for selecting the programme and for switching the washing machine on and off.

### **Display panel**

In the table you can find possible settings and information in the display panel; these differ depending on the model.



Settings for the selected programme		
₩ - 90*	Temperature in °C	Temperature
, 0 - 1200*	Spin speed in rpm (revolutions per minute)	Maximum spin speed or (Rinse stop = no final drain, washing remains in the water after the last rinse)
1:30	Programme length	Depends on the programme selection in h: min (hours: min- utes)
1 - 24	Finish in h (hours)	End of programme after Hours
6.5	Load in kg	Maximum load
* Depending on the model		

Status indicators for the programme progress (programme sequence)		
🗁, 🖅, ©, End		Wash, rinse, spin/drain, programme end.
<del>س</del> ر)	Childproof lock	Lights up: The childproof lock is activated. Flashes: The childproof lock is activated, and if the pro- gramme selector has been adjusted or the buttons have been pressed.
¢	Door lock	Lights up: When the door can not be opened.
严	Тар	Lights up: Water pressure is too low. This extends the pro- gramme duration. Flashes: The tap has not been turned on or there is no water supply.
~~~	Overdosage	On if too much foam detected, one additional rinse cycle switched on.
<b>S</b> t=*		Power consumption.
* Depending on the model		

## Laundry

## Prepare the laundry

#### Caution!

#### Damage to the appliance/fabrics

Foreign objects (e.g. coins, paperclips, needles, nails) may damage the laundry or components in the washing machine.

You should therefore note the following tips when preparing your laundry:

Empty any pockets.



- Look out for metal items (paperclips, etc.) and remove them.
- Wash delicates in a laundry bag (tights, underwired bras, etc.).
- Close any zips; button up any cover buttons.
- Brush sand out of pockets and collars.
- Remove curtain fittings or place curtains in a laundry bag.

## Sorting laundry

Sort your laundry according to the care instructions and manufacturer's information on the care labels, depending on:

- Type of fabric/fibre
- Colour

Note: Laundry can discolour or not be cleaned correctly.Wash white and coloured items separately. Wash new coloured items separately the first time you wash them.

Soiling

Wash laundry with the same level of soiling together. Some examples of soiling levels can be found in the chapter

- Light: Do not prewash; if necessary, select the additional programme setting speed (Quick).
- Normal
- **Heavy**: Load less laundry, select a programme with prewash.
- Stains: Remove/pretreat stains while they are still fresh. First dab with soapy water; do not rub.Then wash the items of laundry with the appropriate programme. Stubborn or dried-in stains can sometimes only be removed by washing several times.

- Symbols on the care labels
   Note: The numbers in the symbols indicate the maximum washing temperature that may be used.
  - Suitable for normal washing process; e.g. Cottons programme
  - A gentle washing process is required:
    - e.g. Easy Care programme
  - An especially gentle washing process is required; e.g. Delicates/Silk programme
  - ✓ Suitable for washing by hand;
     e.g. 
     ✓ Wool program
  - 🕅 Do not machine wash.

## Starching

**Note:** Laundry should not be treated with fabric softener.

Liquid starch can be used to stiffen fabrics particularly in the Rinse and Cottons programmes. Measure starch into compartment & in accordance with the manufacturer's instructions (clean first if necessary).

## **Dyeing/bleaching**

Dye should only be used in normal household quantities. Salt may damage stainless steel. Always follow the dye manufacturer's instructions.

Do **not** use the washing machine to bleach clothes.

## Detergent

### **Correct selection of detergent**

The care label is crucial to ensure correct detergent selection, temperature and laundry treatment.

 Standard detergent with optical brighteners

suitable for heat-resistant white washing made from linen or cotton Programme: 🏠 Cottons/ cold – max. 90 °C

- Detergent for colours without bleach or optical brighteners suitable for coloured washing made from linen or cotton Programme: A Cottons/ cold – max. 60 °C
- Detergent for colours/delicates without optical brighteners suitable for coloured laundry made from easy-care fibres, synthetic fibres
   Programme: A Synthetics/ cold – max. 60 °C
- Detergent for delicates suitable for delicate, fine fabrics, silk or viscose Programme: Delicates/Silk b/ cold – max. 40 °C
- Detergent for woollens suitable for woollen fabrics Programme: W Wool/ cold – max. 40 °C

## Saving energy and detergent

For light and normal soiling, you can save energy (lower washing temperature) and detergent.

Saving	Soiling/note
Reduced temper- ature and deter- gent quantity as per the recom- mended dosage	<ul> <li>Light No visible dirt or stains. Cloth- ing has taken on some body odour, e.g.: <ul> <li>Light summer/sports clothing (worn for a few hours)</li> <li>T-shirts, shirts, blouses (worn for up to one day)</li> <li>Guest bed linen and hand towels (used for one day)</li> </ul> </li> <li>Normal Visible dirt or a few light stains, e.g.: <ul> <li>T-shirts, shirts, blouses (sweat soaked, worn a few times)</li> <li>Towels, bedding (used for up to one week)</li> </ul> </li> </ul>
Temperature as per the care label and detergent quantity as per the recom-	Heavy Dirt and/or stains clearly visible, e.g. tea towels, baby items, work clothing

**Note:** When measuring the amount of all detergents/additives/care products and cleaning agents, please always check the manufacturer's instructions and information.

mended dosage

for heavy soiling

## P+ Programme default settings

**Note:** You can find possible programme default settings in the overview; these differ depending on the model.

The programme default settings for all programmes are preset at the factory and are displayed in the display panel after the programme is selected.

## **8** Temperature

₿ Temperature

Setting depending on the model

Depending on what stage the program is in, you can change the set temperature before and at the beginning of the program.

The maximum temperature that can be set depends on the program that has been selected.

## Spin Speed

Spin Speed

Depending on what stage the program is in, you can change the spin speed (in rpm; revolutions per minute) before and during the program.

**Setting 0**: The rinsing water is drained but there is no final spin. The laundry stays wet inside the drum, e.g. for items that should not be spun.

**Setting** - - - -: (Rinse Stop) = no final spin. The laundry stays in the water after the final rinse.

You can select "Rinse Stop" to prevent creasing if the laundry will not be taken out of the washing machine immediately after the program has ended.

To continue/end the program  $\rightarrow$  Page 31

The maximum speed that can be set depends on the model and program that has been selected.

### Image: Second Second

#### (9) Finished in

**Before starting the program**, you can preselect the program end ("Ready in" time) in hourly increments (h = hour) up to a maximum of 24 hours.

To do this:

- 1. Select a program. The program duration is displayed for the selected program, e.g. 2:30 (hours:minutes).
- Press the <sup>()</sup> Finished in button repeatedly until the required number of hours is displayed.
- Press the D∭ Start/Reload button. The door will be locked. The selected number of hours (e.g. 8 h) is shown in the display panel and counts down until the wash program starts. The duration of the program is then displayed.

**During the timer count-down**, you can change the preselected number of hours as follows:

- 1. Press the D Start/Reload button.
- 2. Use the <sup>()</sup> Finished in button to change the number of hours.
- 3. Press the ▷ Start/Reload button.

**During the timer count-down**, you can add or remove laundry as required:

- **1.** Press the **▷II** Start/Reload button.
- 2. Open the door and add or remove laundry.
- 3. Close the door.
- 4. Press the D II Start/Reload button.

**Note:** The length of the program is automatically adjusted when the program is running.

Certain factors can affect the program length, e.g.:

- Program settings,
- Detergent dosage (additional rinse cycles if required due to foaming),
- Load size/type of textiles (longer washing for higher load and for textiles which absorb more water),
- Imbalances (e. g. due to fitted sheets) are offset with several startups of spin cycles,
- Fluctuations in power supply,
- Water pressure (infeeding speed).

# P<sup>+</sup> Additional programme settings

**Note:** You can find possible additional programme settings in the overview; these differ depending on the model.

## =<sup>1</sup> Speed/<sup>®</sup> Eco

=Ü Speed/@ Eco

Button with two possible settings for adapting the selected program:

#### ■ =<sup>CD</sup> Speed

Washing in a shorter time while achieving a washing result that is consistent with, but uses more energy than, the selected program, without the =<sup>O</sup> Speed/<sup>®</sup> Eco setting.

Note: Do not exceed the maximum load.

#### Eco

Energy-optimised washing by reducing the temperature while achieving a washing result that is consistent with the selected program, without the =<sup>O</sup> Speed/<sup>®</sup> Eco setting. Press the button to do this. First of all, you can select the = 🖱 **Speed** setting. If you press the button again, the 🔊 **Eco** setting is active. The respective symbol is shown in the display when the setting is activated.

If you press the button again, no setting is active.

#### 🖙 Rinse Plus

#### 📼 Rinse Plus

Increased water level and additional rinse cycle, extended washing time. For areas with very soft water or for further enhancing the spin result.

#### 🖙 Soak

#### (🖙 Soak)

Before the main wash cycle starts, the washing remains for longer in the water to partially dissolve intensive soiling.

#### Notes

- Put detergent in dispenser I before starting the appliance.
- Load laundry of the same colour.
- If your appliance does not have this additional programme setting, you can soak as follows:
- 1. Put detergent in dispenser **II** before starting the appliance.
- Select the î Cottons 40 °C programme and the D Start/ Reload button.
- 3. Select the D**II Start/Reload** button after approx. 10 minutes. The laundry remains in the soaking solution.
- Leave the laundry to soak for as long as required, then either select the ▷**II** Start/Reload button again to continue the programme or change the programme.

### **Easy Iron**

#### (<u> </u>Easy Iron)

Special spin sequence with subsequent fluffing. Gentle final spin – residual moisture in the laundry slightly increased.

# Operating the appliance

Note: Install and connect washing machine properly. Before the 1st wash  $\rightarrow$  Page 19

## Preparing the washing machine

#### Notes

- Never switch on a damaged washing machine!
- Inform customer service!
- 1. Connect the mains plug.
- 2. Turn on the tap.
- 3. Open the door.
- 4. Check that the drum is completely emptied. Empty if necessary.



## Select programme/switch on the appliance

**Note:** If you have activated the childproof lock, you must first deactivate it before you can set a program.

Use the program selector to select the required program. Can be rotated in either direction.

The appliance is switched on.

The **program default settings** for the selected program appear in the display panel:

- Temperature\*,
- Spin speed\*,
- The maximum load and the duration of the program (alternately),
- Energy consumption\*.

\*depending on the model

## Change the programme default settings

You can use the default settings or change them.

To do this, repeatedly select the corresponding button until the required setting is displayed.

The settings are activated without needing to be confirmed.

They are not saved when the appliance is switched off.

 $\rightarrow$  "Programme default settings" on page 25

Overview of programmes  $\rightarrow$  Supplementary sheet for the operating and installation instructions.

## Select additional programme settings

By selecting additional settings, you can better adapt the washing process to your items of laundry.

The settings can be selected or deselected depending on the programme progress.

The indicator lamp for the button lights up if a setting is active.

The settings are not saved when the appliance is switched off.

 $\rightarrow$  "Additional programme settings" on page 26

Overview of programmes  $\rightarrow$  Supplementary sheet for the operating and installation instructions.

## Placing laundry into the drum

## Warning Danger of death!

Items of laundry pretreated with cleaning agents that contain solvents, e.g. stain remover/cleaning solvent, may cause an explosion after being loaded into the washing machine. Hand-rinse items of laundry thoroughly beforehand.

#### Notes

- Mix items of laundry of varying sizes. Laundry items of different sizes distribute themselves better during the spin cycle. Individual items of laundry may lead to imbalances.
- Observe the specified maximum load. Overfilling has a negative impact on the washing result and promotes creasing.
- 1. Place presorted items of laundry unfolded in the washing drum.
- 2. Make sure that no items of laundry are trapped between the washing machine door and the rubber seal, and close the door.



The DII Start/Reload button indicator lamp flashes to indicate that the washing program can be started. It is possible to change the settings.  $\rightarrow$  " $\odot$  Spin Speed" on page 25

## Measure and add detergent and care products

#### Caution!

#### Damage to the appliance!

Detergents and agents for the pretreatment of laundry (e.g. stain remover, prewash sprays, etc.) may damage the surfaces of the appliance. Keep these agents away from the surfaces of the appliance. Using a damp cloth, immediately remove any fine spray residue and other residue or droplets.

#### Dosing

Dose the detergents and care products according to:

- water hardness (ask your water supply company),
- the manufacturer's specifications on the packaging,
- the amount of laundry,
- soiling.

#### Filling the dispensers

1. Pull out the detergent drawer.

## Warning

#### Eye / skin irritation!

If the detergent drawer is opened while the appliance is running, detergent or care product may run out.

Open the drawer carefully.

If detergent or care product comes into contact with eyes or skin, rinse thoroughly.

If accidentally swallowed, seek medical advice.

2. Pour in detergent and/or cleaning product.



Dispenser I	Clothing disinfectant. ( <b>Disinfectant</b> additional programme setting or <b>Disinfectant</b> programme is selected only.)
Dispenser &	Softener. Do not exceed the maximum load.
Dispenser <b>II</b>	Detergent for main wash, liquid detergent.

#### Notes

- Dilute viscous fabric softener and fabric conditioner with water. This will prevent blockages.
- Be careful when opening the detergent drawer while the appliance is running.

### Starting the programme

Press the  $\bigcirc$  Start/Reload button. The indicator lamp lights up and the program starts.

The display panel shows the Ready in time while the program is running or the program duration and the program progress symbols once the wash cycle has started.

#### Note: Foam detection

If the registrowsymbol also lights up in the display panel, the washing machine has detected too much foam during the wash cycle and automatically activated additional rinse cycles to remove the foam.

Add less detergent to the next wash cycle with the same load.

If you want to lock the program to prevent it from being inadvertently adjusted, you can select the childproof lock as follows.

## **Childproof lock**

~

You can lock the washing machine to prevent the functions you have set from being changed inadvertently. To do this, activate the childproof lock when the program has started.

To **activate/deactivate**, press and hold the  $\odot$  **Spin Speed** and  $\bigcirc$  **Finished in** buttons at the same time after the washing program has started. Keep pressing the two buttons for approx. three seconds. The  $\simeq$  symbol appears in the display panel.

- Ights up: The childproof lock is active.
- Image: Second Second

**Note:** To avoid the program to terminate, do not turn the program selector beyond the Off position.

**Note:** The childproof lock remains active after the program has ended and the appliance is switched off. You must always deactivate the childproof lock if you want to start a new program.

## Adding/removing laundry

Following the start of the program, you can add or remove laundry as required.

Press the  $\bigcirc$  Start/Reload button to do this.

The DI Start/Reload button indicator lamp flashes and the machine checks whether it is possible to add laundry.

If the following appears in the display panel:

- The C symbol disappears: adding laundry is possible.
- The C symbol lights up: it is not possible to add laundry.

#### To continue the program, press the

button **D** Start/Reload. The program continues automatically.

#### Notes

- Do not leave the door open for too long when adding laundry as water from the laundry may leak out.
- For safety reasons, the door remains locked when the water level or temperature is high, or while the drum is turning, and it is not possible to add laundry during this time.
- The load display is not active during reloading.

## Changing the programme

- 1. Press the D Start/Reload button.
- 2. Select another program.
- Press the DII Start/Reload button.The new program starts from the beginning.

### Cancel the programme

For programs at high temperature:

- 1. Press the D Start/Reload button.
- 2. To cool down laundry: Select **Rinse .**
- 3. Press the D Start/Reload button.

For programs at low temperature:

- 1. Press the D Start/Reload button.
- 2. Select O Spin.
- 3. Press the D Start/Reload button.

## Programme end during rinse hold

 $\odot$  ---- appears in the display panel and the indicator lamp of the DM Start/ Reload button flashes.

Continue the program by:

- Pressing the D Start/Reload button (the laundry will be drained with the default spin speed setting\*) or
- Selecting a spin speed or set the program selector to **Spin** and then pressing the DM Start/Reload button.
- \* depending on the chosen program -> Overview of programmes

### **Programme end**

**End** appears in the display panel and the indicator lamp of the ▷ 11 Start/ Reload button is off.

## Removing laundry/switching off the appliance

- 1. Open the washing machine door and remove the laundry.
- Turn the programme selector to
   Off. Appliance is switched off.
- 3. Turn off the tap. Not required for Aqua-Stop models. Contents of package Notes
  - Do not leave any items of laundry in the drum. They may shrink in the next wash or discolour another item.
  - Remove any foreign objects from the drum and the rubber seal – risk of rusting.



- Leave the washing machine door and detergent drawer open so that any residual water can dry away.
- Always remove the washing.
- Always wait until the programme ends, as the appliance could still be locked. Switch the appliance on and wait for the unlocking device.
- If at the end of the programme the display has gone out, the energy saving mode is active. To activate, select any button.

## Setting the signal

You can change the following settings:

- The volume for the information signals (e.g. at the end of the program) and/or
- The volume of the audible button signals.

You will need to activate the setting mode in order to change these settings.



1/2/3/... positions on the program selector

#### Activate setting mode:

- 1. Set the program selector to position 1. The washing machine is switched on.
- 2. Press the ▷ Start/Reload button and, at the same time, turn the program selector clockwise to position 2.Release the button.

The setting mode is activated and the preset volume for the information signals appears in the display panel (e.g. at the end of the program).

#### Changing the volume

Use the <sup>()</sup> **Finished in** button to change the following settings at the corresponding program selector positions:

- 2: The volume of the information signals and/or
- 3: The volume of the button signals.

01234

0 = off, 1 = quiet, 2 = medium, 3 = loud, 4 = very loud

#### Exiting setting mode

You can now end the process and set the program selector to the **Off** position. The settings are saved.

## ·)) Sensors

## Unbalanced load detection system

The automatic unbalanced load detection system detects imbalances and ensures even distribution of the laundry by repeatedly starting and stopping drum spinning.

If the laundry is extremely unevenly distributed, the spin speed is reduced or the spin cycle is not performed for safety reasons.

**Note:** Place large and small items of laundry evenly in the drum.

# Cleaning and maintenance

## Warning Danger of death!

There is a risk of electric shock if you touch live components. Switch off the appliance and unplug the mains plug.

#### ▲ Warning Risk of poisoning!

Toxic vapours can be produced by cleaning agents that contain solvents, e.g. cleaning solvent. Do not use cleaning agents that contain solvents.

#### Caution!

#### Damage to the appliance

Cleaning agents that contain solvents, e.g. cleaning solvent, can damage surfaces and components in the machine.

Do not use cleaning agents that contain solvents.

## Machine housing/control panel

- Wipe the housing and the control panel with a soft, damp cloth.
- Remove the detergent residue immediately.
- Do not clean with a water jet.

### Drum

Use chlorine-free cleaning agents, do not use steel wool.

If there are odours in the washing machine, or to clean the drum, run the

Drum Clean ♂ 90 °C or ↑ Cottons 90 °C program without laundry. Add washing powder.→ "Faults and what to do about them" on page 37

### Descaling

Descaling should not be necessary if the detergent is measured out correctly. However, if it is required, follow the manufacturer's instructions for the descaling agent. Suitable descalers can be obtained via our website or from our after-sales service.  $\rightarrow$  Page 39

### **Detergent drawer and housing**

If the detergent drawer contains detergent or fabric softener residues:

- 1. Pull out the detergent drawer. Press down the insert and fully remove the drawer.
- To remove the insert: Push the insert upwards from below with your finger.



- Clean the detergent dispenser tray and insert with water and a brush, and dry it. Clean the inside of the housing as well.
- Fit the insert and lock it in place (push the cylinder onto the guide pin).
- 5. Push in the detergent drawer.

**Note:** Leave the detergent drawer open so that any residual water can evaporate.

## Detergent solution pump blocked

#### Warning Risk of scalding!

When you wash at high temperatures, the water gets very hot. If you come into contact with the hot water, you may be scalded.

Allow the water to cool down.

#### After the water has cooled down:

- 1. Turn off the water tap so that no more water can flow in and has to be drained via the drain pump.
- 2. Switch off the appliance.
- 3. Disconnect the mains plug.
- 4. Open and remove the service flap.



5. Take the drain hose out of the retainer.

Remove the sealing cap, allow the water to flow out into a suitable container.

Replace the sealing cap and place the drainage hose in the retainer.



6. Carefully unscrew the pump cover, residual water may leak out. Clean the interior, pump cover thread and pump housing. The impeller in the detergent solution pump must be able to rotate. Refit the pump cover and screw it on tightly. The handle must be in a vertical position.



7. Place the service flap back on, lock it into place, and close it.



**Note:** To prevent unused detergent from flowing straight into the drain during the next wash, pour 1 litre of water (without detergent) into compartment **II** and start the **Spin** programme. Do the next wash as usual.

## The drain hose at the siphon is blocked

- 1. Switch off the appliance.
- 2. Disconnect the mains plug.
- 3. Loosen the hose clamp. Carefully remove the drain hose; residual water may leak out.
- 4. Clean the drain hose and siphon connecting piece.



5. Reattach the drain hose and secure the connection using the hose clamp.

## Filter in the water supply is blocked

First, reduce the water pressure in the supply hose:

- 1. Turn off the tap.
- Select any program (except ⊙ Spin).
   Press the D Start/Reload button.
- 4. Turn the program selector to off position.
- 5. Pull out the mains plug.
- 6. Clean the filter on the tap: Disconnect the hose from the tap. Clean the filter with a small brush.



7. For standard and Aqua-Secure models, clean the filter on the rear of the appliance:

Remove the hose from the rear of the appliance.

Use pliers to remove the filter and then clean it.



8. Insert the filter, connect the hose and check for leaks.

# Faults and what to do about them

## **Emergency release**

(depending on the model)

e.g. in the event of a power outage

**Note:** The programme will continue running when the power supply has been restored.

#### Marning Risk of scalding!

When you are washing at high temperatures, there is a risk of scalding if you come into contact with detergent solution and laundry.

If possible, leave it to cool down.

## Marning Risk of injury!

You may injure your hands if you reach into the drum while it is turning. Do not reach into the drum when it is turning. Wait until the drum has stopped turning.

#### Caution! Water damage

Any escaping water may cause water damage. Do not open the washing machine door if water can be seen through the glass.

# If the laundry has to be removed, the washing machine door can be opened as follows:

- 1. Switch off the appliance.
- Disconnect the mains plug.
- **3.** Drain the water.  $\rightarrow$  Page 33
- Pull the emergency release downwards with a tool and release. The washing machine door can now be opened.



## Information on the display panel

Display	Cause/Remedy
¢	<ul> <li>Flashes fast + warning signal: The door was opened and the water level is too high. Close the door, continue the programme with D II Start/Reload button or select S pin programme.</li> <li>Flashes slowly: The door lock temperature is too high to open the door. Wait approx. 30 seconds until the door lock temperature cools down.</li> </ul>
产	<ul> <li>Flashes (no water supply): Tap turned on? Water inlet filter blocked? Clean the water inlet filter. If an additional water filter has been installed (depending on the model), check for contaminants and clean if required → separate installation and cleaning instruction for water filter. Water hose kinked or blocked?</li> <li>Lights up (low water pressure): For information only. This will not affect the programme progress. The programme duration is extended.</li> </ul>
E:18	Drain pump blocked; clean the drain pump. Clean the drainage hose on the siphon.
Other displays	Switch off the appliance, wait for five seconds and then switch it on again. If the dis- play appears again, call customer services.

## Faults and what to do about them

Faults	Cause/Remedy
Water is leaking from the machine.	<ul><li>Attach the drain hose correctly or replace it.</li><li>Tighten the screw connection of the drain hose.</li></ul>
The machine is not filling with water. Detergent is not being dispensed.	<ul> <li>Have you pressed the ▷ ① Start/Reload button?</li> <li>Is the tap turned on?</li> <li>Could the filter be clogged? Clean the filter → Page 34</li> <li>Note: If an additional water filter has been installed (depending on the model), check for contaminants and clean if required → separate installation and cleaning instruction for water filter.</li> <li>Is the supply hose kinked or trapped?</li> </ul>
The door cannot be opened.	<ul> <li>The safety function is activated. Stop the program?</li> <li>Is the c= childproof lock activated? Deactivate.</li> <li>Is "" selected (Rinse Stop = no final drain)?</li> <li>Can the door only be opened by the emergency release?</li> </ul>
The program will not start.	<ul> <li>Have you pressed the ▷ II Start/Reload or ⊙ Finished in button?</li> <li>Is the door closed?</li> <li>Is the ∽ childproof lock activated? Deactivate.</li> </ul>
The drum briefly jerks or judders after the pro- gram has started.	Not a fault – the internal motor test may cause the drum to jerk or judder briefly when the wash program starts.
The water is not drain- ing.	<ul> <li>Is "" selected (Rinse Stop = no final drain)?</li> <li>Clean the drain pump → Page 33</li> <li>Clean the drain pipe and/or the drain hose.</li> </ul>
Water is not visible in the drum.	Not a fault – the water is below the visible area.
The spin result is not sat- isfactory. Laundry is wet/too damp.	<ul> <li>Not a fault - the unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. Distribute small and large items of laundry evenly in the drum.</li> <li>Anti-crease (depending on the model) selected?</li> <li>Is the selected speed too low?</li> </ul>
The spin cycle runs sev- eral times.	Not a fault – the unbalanced load detection system is adjusting an imbalance.
The program is taking longer than usual.	<ul> <li>Not a fault – the unbalanced load detection system is adjusting an imbalance by repeatedly distributing the laundry.</li> <li>Not a fault – the foam detection is system active – a rinse cycle has been switched on.</li> </ul>
The length of the pro- gram changes during the wash cycle.	Not a fault – the program sequence is optimised for the specific washing pro- cess. This may change the length of the program shown in the display panel.
Residual water in the care-product compart- ment & .	<ul> <li>Not a fault – the effect of the care product is not affected.</li> <li>Clean the insert if necessary.</li> </ul>

Faults	Cause/Remedy
Odours in the washing machine.	Depending on the model, run the <b>Drum Clean</b> (3) <b>90</b> °C or <b>(2) Cottons 90</b> °C program without laundry.
	Add washing powder or a detergent containing bleach.
	<b>Note:</b> To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergents designed for wool or delicates.
The 🥗 symbol lights	Have you used too much detergent?
up in the display panel. Foam may also be leak- ing from the detergent drawer.	Mix one tablespoon of fabric softener with $1/2$ litre of water and pour it into compartment <b>II</b> (not suitable for outdoor clothing, sportswear or items stuffed with down).
ulawel.	Use less detergent in the next wash cycle.
Loud noises, vibrations and machine "move- ment" during the spin cycle.	<ul> <li>Is the appliance aligned? Align the appliance → Page 17</li> <li>Are the appliance's feet fixed? Secure the appliance's feet → Page 17</li> <li>Have the transport braces been removed? Remove the transport braces → Page 14</li> </ul>
The display panel/indica- tor lights do not work while the appliance is running.	<ul> <li>Has there been a power failure?</li> <li>Have the fuses blown? Reset/replace the fuses.</li> <li>If the fault occurs repeatedly, call customer services.</li> </ul>
There is detergent resi- due on the laundry.	<ul> <li>Some phosphate-free detergents contain water-insoluble residue.</li> <li>Select <b>Rinse</b> w or brush the laundry after washing.</li> </ul>
The C symbol lights up in the display in pause mode.	<ul> <li>Door is locked due to safety reasons (water level and/or temperature are too high). It is not possible to add laundry. Close the door immediately, if necessary.</li> <li>Press the DI Start/Reload button to continue the program.</li> </ul>
	It yourself (after switching the machine off and on again) or a repair is required:

- Switch off the appliance and pull out the mains plug. Turn off the tap and call customer services.

## After-sales service

If you cannot correct the fault yourself  $\rightarrow$  "Faults and what to do about them" on page 35 please contact our aftersales service.  $\rightarrow$  Back page

We will always find an appropriate solution in order to avoid unnecessary visits by engineers.

Please give the after-sales service the product number (E no.) and the production number (FD) of the appliance.

E-Nr	FD

Product number

Production number

#### You can find this information:

- on the inside of the washing machine door\*
- in the opened service flap\*
- on the rear of the appliance\*

\*depending on the model

## Trust the expertise of the manufacturer.

Contact us for assistance. By doing so, you will ensure that the repairs are carried out by trained service personnel using genuine spare parts.

## Technical data

#### **Dimensions:**

848 mm x 598 mm x 446 mm (height x width x depth)

#### Weight:

63 kg

#### Mains connection:

Nominal voltage 220V-240V, 50Hz

Nominal power 1900-2300W

#### Water pressure:

100-1000 kPa (1\*-10 bar)

#### Note:

\*Appliance can function even at 0.3bar/ 30kPa water pressure under specified loading conditions.



## Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- Expert tips & tricks for your appliance
- Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones:

www.bosch-home.com/welcome

#### BOSCH HOME APPLIANCES SERVICE

## Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, need help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you:

#### www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

Robert Bosch Hausgeräte GmbH Carl-Wery-Straße 34 81739 München, GERMANY

www.bosch-home.com

## 

9001367723 (9904)