

### Register your new device on MyBosch now and get free benefits: bosch-home.com/ welcome



## Steam oven

CDG634A.0

[en] Instruction manual

Steam oven

### **Table of contents**

Sevent Intended use
Important safety information4
Causes of damage5
Environmental protection         6           Tips for saving energy         6           Environmentally-friendly disposal         6
Getting to know your appliance       7         Control panel       7         Controls       7         Display       8         Heating types       8         Further information       8         Cooking compartment functions       8
Accessories
Before using for the first time.10Before using for the first time.10Initial use10Calibrating the appliance and cleaning the cooking compartment11Cleaning the accessories.11
Operating the appliance11Switching the appliance on and off11Starting the operation12Filling the water tank12Setting the type of heating and temperature12After each use13
Time-setting options14Setting the cooking time14Setting the end time14Setting the timer15
Dishes15Applying settings for dishes15Instructions for the dishes16Table17
Childproof lock

Basic settings.18Changing the basic settings.18List of basic settings.18Power cut.18Changing the time18
Cleaning       19         cleaning agents       19         Descale       19         Detaching and refitting the appliance door       21         Removing and installing the door panels       22
Trouble shooting       23         Rectifying faults yourself       23         Replacing the cooking compartment bulb       25         Replacing the glass cover or seals       25         Changing the door seal       25
Customer service.       26         E number and FD number       26
Settings table and tips.26Accessories.26Ovenware.26Cooking time and quantity.26Distributing food evenly.26Pressure-sensitive food26Cooking a menu.26Vegetables.27Side dishes and pulses.27Poultry and meat.28Fish.28Soup vegetables, miscellaneous.29Dessert, compote.29Reheating food.30Prove dough.30Extracting juice.30Preserving.31Frozen products.31Test dishes.32

Additional information on products, accessories, replacement parts and services can be found at **www.bosch-home.com** and in the online shop **www.bosch-eshop.com** 

### See Intended use

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual and installation instructions for future use or for subsequent owners.

This appliance is only intended to be fully fitted in a kitchen. Observe the special installation instructions.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The appliance must be supervised during operation. Only use this appliance indoors.

This appliance is intended for use up to a maximum height of 2000 metres above sea level.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 15 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always slide accessories into the cooking compartment the right way round.

 $\rightarrow$  "Accessories" on page 9

## Important safety information

#### ▲Warning – Risk of burns!

- The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.
- Accessories and ovenware become very hot. Always use oven gloves to remove accessories or ovenware from the cooking compartment.
- Hot steam may escape during operation. Do not touch the ventilation openings. Keep children away.

#### ▲ Warning – Risk of scalding!

- The accessible parts become hot during operation. Never touch the hot parts. Keep children at a safe distance.
- Water in a hot cooking compartment may create hot steam. Never pour water into the cooking compartment when the cooking compartment is hot.
- When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.
- The water in the evaporator dish is still hot even after the appliance has been switched off. Do not empty the evaporator dish immediately after switching off the appliance. Allow the appliance to cool down before cleaning it.
- Hot liquid may spill over the sides of the accessory when it is removed from the cooking compartment. Remove hot accessories with care and always wear oven gloves.

#### ▲ Warning – Risk of injury!

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- Flammable liquids can catch fire in the cooking compartment when it is hot (explosion). Do not fill the water tank with any flammable fluids (e.g. alcoholic drinks). Only fill the water tank with water or with the descaling solution that is recommended by us.

#### Marning – Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out by one of our trained after-sales engineers. If the appliance is faulty, unplug the mains plug or switch off the fuse in the fuse box. Contact the after-sales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- When replacing the cooking compartment bulb, the bulb socket contacts are live.
   Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

### Causes of damage

#### Caution!

- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: Do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. The cooking compartment floor and the evaporator dish must always be kept clear. A build-up of heat may damage the appliance. Always place the cookware in a perforated cooking container.
- Aluminium foil in the cooking compartment must not come into contact with the door panel. This could cause permanent discolouration of the door panel.
- Ovenware: Ovenware must be heat and steam resistant.
- Ovenware with areas of rust: Do not use any ovenware which displays areas of rust. Even the smallest spots of rust can lead to corrosion in the cooking compartment.
- Dripping liquids: When steaming with a perforated cooking container, always insert the baking tray, the universal pan or the solid cooking container underneath. Dripping liquid is caught.
- Moisture in the cooking compartment: Over an extended period of time, moisture in the cooking compartment may lead to corrosion. Allow the cooking compartment to dry after use. Do not keep moist food in the closed cooking compartment for extended periods of time. Do not store food in the cooking compartment.
- Extremely dirty seal: If the seal is very dirty, the appliance door will no longer close properly during operation. The fronts of adjacent units could be damaged. Always keep the seal clean. Never operate the appliance if the seal is damaged or missing. → "Cleaning" on page 19
- Appliance door as a seat, shelf or worktop: Do not sit on the appliance door, or place or hang anything on it. Do not place any cookware or accessories on the appliance door.
- Inserting accessories: depending on the appliance model, accessories can scratch the door panel when closing the appliance door. Always insert the accessories into the cooking compartment as far as they will go.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.
- Looking after the appliance: The cooking compartment on your appliance is made of highquality stainless steel. Improper care may lead to corrosion in the cooking compartment. Refer to the care and cleaning instructions in the instruction manual. Remove food residues from the cooking compartment as soon as the appliance has cooled.
- Hot water in the water tank: Hot water may damage the steam system. Only fill the water tank with cold water.

- Descaling solution: Do not allow any descaling solution to come into contact with the control panel or other surfaces on the appliance. This damages the surfaces. If this does happen, remove the descaling solution immediately with water.
- Cleaning the water tank: Do not clean the water tank in the dishwasher. Otherwise, the water tank will be damaged. Clean the water tank with a soft cloth and standard washing-up liquid.

### **Environmental protection**

Your new appliance is particularly energy-efficient. Here you can find tips on how to save even more energy when using the appliance, and how to dispose of your appliance properly.

#### Tips for saving energy

- Only preheat the appliance if this is specified in the recipe or in the operating instructions table.
- Open the appliance door as infrequently as possible while the food is cooking.
- When steaming, you can cook on several levels at the same time. When preparing foods with different cooking times, those with the longest cooking time should be placed in the oven first.

#### Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances

(waste electrical and electronic equipment -WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

### Getting to know your appliance


In this section, we will explain the indicators and controls. You will also find out about the various functions of your appliance.

**Note:** Depending on the appliance model, individual details and colours may differ.

#### **Control panel**

In the control panel, you can use the various buttons, touch fields and the rotary selector to set the different appliance functions. The current settings are shown on the display.

The overview shows the control panel when the appliance is switched on with a selected heating type.



#### **Buttons**

The buttons on the left- and right-hand side of the control panel have a pressure point. Press these buttons to activate them.

For appliances that do not have a stainless steel front, these two button touch fields do not have a pressure point.

#### **2** Touch fields

There are sensors under the touch fields. Simply touch the respective symbol to select the function.

#### **3** Rotary selector

The rotary selector is fitted so that you can turn it indefinitely to the left or right. Press it lightly and move it in the direction required using your finger.

#### 4 Display

You can see the current adjustment values, options or notes in the display.

#### Controls

The individual controls are adapted for the various functions of your appliance. You can set your appliance simply and directly.

#### **Buttons and touch fields**

Here you can find a short explanation of the various buttons and touch fields.

Symbol		Meaning
Buttons		
1	on/off	Switching the appliance on and off
D	Start/Stop	Starting, pausing or cancelling (hold down for approx. 3 secs) an operation

#### External touch fields

LAIGH			
$\mathbb{X}$	Timer	Selects the timer	
Ś	Childproof lock	Activating and deactivating (hold down for approx. 4 secs) the childproof lock	
Ô	Information	Appliance switched on: Display notes Appliance switched off: Press and hold (approx. 3 seconds) to call up the basic settings	
••• •••	Descale	Selects Descale	
Interna	Internal touch fields		
ŝ	Steam	Selects the Steam heating type	
£	Prove dough	Selects the Prove dough heating type	
Ś	Reheat	Selects the Reheat heating type	
⊘*	Defrost	Selects the Defrost heating type	
Ð	Temperature	Selects the temperature in the cooking compartment	
TT.	AutoCook	Selects the operating mode for dishes with cooking programmes	
	Time-setting options	Select time-setting options	
ß	Weight	Selects the weight for the operating mode	

The touch field, which has a value on the display that can be changed or displayed in the foreground, lights up red.

for dishes

#### **Rotary selector**

You can use the rotary selector to change the setting values shown in the display.


In most selection lists, such as the temperature, you have to turn the rotary selector back the other way if you reach the minimum or maximum value.

#### Display

The display is structured so that the information can be read at a glance in any situation.

The value that you can currently set is in focus. It is displayed in white lettering and underlined in white. The value in the background is displayed in grey.

Focus	The value in focus can be changed directly wit out first being selected. After starting an operation, either the temperat or the level is always in focus. At the same tim the white line is the heating line and gradually turns red.	
Enlargement	As you change the value in focus using the rotary selector, only this value is displayed larger.	



#### **Display ring**

The display ring can be found around the outside of the display.

If you change a value, the display ring shows you where you are in the selection list. Depending on the settings area and length of the selection list, the display ring may be continuous or divided into segments.

During operation, the display ring turns red at secondlong intervals. After every full minute, the segments turn red again from the beginning. As the cooking time counts down, one segment disappears every second.

#### **Temperature display**

After operation has started, the current cooking compartment temperature is displayed graphically in the display.

Heating line	The white line under the temperature turns red from left to right as the cooking compartment heats up. When you are preheating the appliance, the optimal time for placing the food in the cooking compart- ment is when the line has completely turned red.
Residual heat indicator	When the appliance is switched off, the display ring shows the residual heat in the cooking compart- ment. As the residual heat cools down, the display ring becomes darker and disappears completely at some point.

**Note:** Due to thermal inertia, the temperature displayed may be slightly different to the actual temperature inside the oven.

#### **Heating types**

Your appliance has various heating types which can be selected using the control panel.

Type of heating Temperature		Temperature	Use
$\widehat{\boldsymbol{x}}$	Steaming	30-100 °C	For vegetables, fish, side dishes, for juicing fruit and for blanching
<u>ش</u>	Reheating	80-100 °C	For plated meals Cooked food is gently reheated. The steam ensures that the food does not dry out
£J	Dough proving	30-50 °C	For yeast dough Dough will rise considerably more quickly than at room temperature. The surface of the dough does not dry out
	Defrosting	30-60 °C	For fruit and vegetables The moisture gently transfers the heat to the food. The food does not dry out or lose its shape

#### **Default values**

The appliance suggests a temperature or setting for each heating type. You can accept this value or change it in the appropriate area.

#### **Further information**

In most cases, the appliance provides notes and further information on the action just carried out.

Touch the i field. The note is shown in the display for a few seconds. Use the rotary selector to scroll to the end of longer notes.

Some notes are displayed automatically, for example as confirmation, or to provide an instruction or warning.

#### **Cooking compartment functions**

The functions in the cooking compartment make your appliance easier to use. This, for example, enables the cooking compartment to be well lit and a cooling fan to prevent the appliance from overheating.

#### Opening the appliance door

If you open the appliance door during an on-going operation, the operation is paused. The operation continues to run when you close the door.

#### **Interior lighting**

When you open the appliance door, the interior lighting switches on. If the door remains open for longer than around 15 minutes, the lighting switches off again.

For most operating modes, the interior lighting switches on as soon as the operation is started. When the operation has finished, the lighting switches off.

**Note:** You can set the interior lighting not to come on during the operation in the basic settings.  $\rightarrow$  "Basic settings" on page 18

#### **Cooling fan**

The cooling fan switches on and off as required. The hot air escapes above the door.

#### **Caution!**

Do not cover the ventilation slots. Otherwise, the appliance may overheat.

So that the cooking compartment cools down more quickly after the operation, the cooling fan continues to run for a certain period afterwards.

**Note:** You can change how long the cooling fan continues to run in the basic settings.  $\rightarrow$  "Basic settings" on page 18



Your appliance is accompanied by a range of accessories. Here, you can find an overview of the accessories included and information on how to use them correctly.

#### **Accessories included**

Your appliance is equipped with the following accessories:



#### **Steam container, perforated, size L** For steaming whole fish or large quanti-

ties of vegetables, for juicing berries, etc.



Steam container, unperforated, size


For catching dripping liquid when steaming and for cooking rice, pulses and cereals

Only use genuine accessories. They are specially adapted for your appliance.

You can buy accessories from the after-sales service, from specialist retailers or online.

#### **Inserting accessories**

The cooking compartment has three shelf positions. The shelf positions are counted from the bottom up.



1 Evaporator dish

2 Water tank in the water tank recess

#### **Caution!**

Do not place anything directly on the cooking compartment floor. Do not cover it with aluminium foil. A build-up of heat may damage the appliance. The cooking compartment floor and the evaporator dish must always be kept clear. Always place the cookware in a perforated cooking container.

#### Locking function


The accessories can be pulled out approximately halfway before they lock in place. The locking function prevents the accessories from tilting when they are pulled out.

- The accessories must be inserted into the cooking compartment the right way round for the tilt protection to work properly.
- Always insert the accessories fully into the cooking compartment so that they do not touch the appliance door.


#### Insert the steam container

#### Notes


• Make sure that the lug **a** is at the rear and is facing downwards.



Do not push the steam container out via the recess
 b.



Take hold of the steam container in the middle and insert it.



#### **Optional accessories**

You can buy optional accessories from the after-sales service, from specialist retailers or online. \*You will find a comprehensive range of products for your appliance in our brochures and online.

Both availability and whether it is possible to order online differ between countries. Please see your sales brochures for more details.

Note: Not all optional accessories are suitable for every appliance. When purchasing, please always quote the exact identification number (E-no.) of your appliance. → "Customer service" on page 26

#### **Decorative trims**

For concealing the lower shelf of the unit and the base of the appliance.

## Before using for the first time

Before you can use your new appliance, you must make some settings. You must also clean the cooking compartment and accessories.

#### Before using for the first time

Before using the appliance for the first time, enquire about the water hardness of your tap water from your water supplier.

So that the appliance can reliably remind you to decalcify it when required, you must correctly set your water hardness range.

#### **Caution!**

The appliance may become damaged due to the use of unsuitable liquids.

Do not use distilled water, highly chlorinated tap water (> 40 mg/l) or other liquids.

Only use cold, fresh tap water, softened water or uncarbonated mineral water.

#### Notes

- If your water is very hard, we recommend that you use softened water.
- If you only use softened water, you can set the water hardness range to "softened" in this case.
- If you use mineral water, set the water hardness range to "4 very hard".
- If you use mineral water, you must only use noncarbonated mineral water.

Water hardness range	Setting
0	00 softened
1 (up to 1.3 mmol/l)	01 soft
2 (1.3 - 2.5 mmol/l)	02 medium
3 (2.5 - 3.8 mmol/l)	03 hard
4 (above 3.8 mmol/l)	04 very hard

#### **Initial use**

After connecting the appliance to the power or following a power cut, the settings for initial use are shown on the display. It may take a few seconds for the instruction to appear.

**Note:** You can change these settings at any time in the basic settings.  $\rightarrow$  "Basic settings" on page 18

#### Setting the language

- 1. Turn the rotary selector to set the required language.
- 2. Touch the 🔄 field to confirm. The next setting appears.

#### Setting the time

- 1. Set the time using the rotary selector.
- 2. Touch the 🕒 field to confirm.
  - The next setting appears.

#### Setting the water hardness

- 1. Use the rotary selector to set the water hardness.
- 2. Touch the 🕑 field to confirm.

A note appears in the display confirming that the initial use has been completed. The current time is displayed.

Switch the appliance off using the ① On/Off button if you do not need to use it.

### Calibrating the appliance and cleaning the cooking compartment

The boiling point of water depends on the air pressure. During calibration, the appliance sets itself to the pressure ratio at the installation location. This occurs automatically during the first steam operation. This results in a lot of steam.

#### Preparing the calibration

- 1. Remove the accessories from the cooking compartment.
- 2. Remove leftover packaging, such as polystyrene pellets, from the cooking compartment.
- 3. Before calibrating the appliance, wipe the smooth surfaces in the cooking compartment with a soft, damp cloth.

### Calibrating the appliance and cleaning the cooking compartment

#### Notes

- The calibration can only be started once the cooking compartment is cold (room temperature).
- Do not open the appliance door during calibration. Calibration will otherwise be interrupted.
- 1. Press the ① On/Off button to switch on the appliance.
- **2.** Fill the water tank.  $\rightarrow$  "Filling the water tank" on page 12
- **3.** Set the specified heating type, temperature and cooking time.

#### Settings

Heating type	Steam 🕾
Temperature	100 °C
Cooking time	20 minutes

- Press the ① On/Off button to switch on the appliance.
- 5. Wait until the cooking compartment has cooled down.
- 6. Clean the smooth surfaces with soapy water and a dish cloth.
- 7. Empty the water tank and dry the cooking compartment. → "After each use" on page 13

#### Notes

- So that the appliance adapts to a new installation location after moving house, reset the appliance to the factory settings. Repeat the initial use settings and the calibration.
- The appliance saves the calibration settings, even in the event of a power cut or disconnection from the mains. Recalibration is not necessary.

#### **Cleaning the accessories**

Clean the accessories thoroughly using soapy water and a dish cloth or soft brush.

### Section 2 Sectio

You have already learnt about the controls and how they work. Now we will explain how to set your appliance. You will learn about what happens when you switch the appliance on and off, and how to select the operating mode.

#### Marning – Risk of scalding!

When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.

#### Marning – Risk of scalding!

The water in the evaporator dish is still hot even after the appliance has been switched off. Do not empty the evaporator dish immediately after switching off the appliance. Allow the appliance to cool down before cleaning it.

#### Marning – Risk of scalding!

When you open the appliance door, hot water may flow out of the appliance. When opening the door, do not stand too close to the appliance. Open the appliance door carefully. Keep children away from the appliance. If the evaporator dish overflows, do not pour more water into the water tank.

#### Switching the appliance on and off

Before you are able to set the appliance, you must switch it on.

**Note:** The childproof lock and the timer can also be set when the appliance is switched off. Certain displays and notes, such as those relating to the residual heat in the cooking compartment, remain visible on the display after the appliance has been switched off.

Switch off your appliance when you do not need to use it. If no settings are applied for a long time, the appliance switches itself off automatically.

#### Switching on the appliance

Press the ① On/Off button to switch on the appliance.

All touch fields light up red. The Bosch logo appears on the display, and then the first heating type in the selection list.

#### Switching off the appliance

Press the ① On/Off button to switch off the appliance.

Any functions that may be running are cancelled.

The time, or if applicable, the residual heat indicator, appears on the display.

**Note:** In the basic settings, you can set whether the clock should be displayed when the appliance is switched off.  $\rightarrow$  "Basic settings" on page 18

#### Starting the operation

You must press the > Start/Stop button to start each operation.

After starting the appliance, the time display is shown on the display along with the settings. The display ring and the heating line also appear.

#### Pausing the operation

You can also interrupt and then continue an operation using the  $\triangleright$  Start/Stop button.

If you press and hold the  $\triangleright$  Start/Stop button for approx. 3 seconds, the operation is cancelled and all settings are reset.

**Note:** The fan may continue to run after an operation has been paused or cancelled.

#### Filling the water tank

When you open the appliance door, you will see the water tank on the right-hand side. Before starting the operation, fill the water tank with water.

Ensure that you have correctly set the water hardness range.  $\rightarrow$  "Basic settings" on page 18

#### **Caution!**


The appliance may become damaged due to the use of unsuitable liquids.

Do not use distilled water, highly chlorinated tap water (> 40 mg/l) or other liquids.


Only use cold, fresh tap water, softened water or uncarbonated mineral water.

Fill the water tank before each use:

- **1.** Open the appliance door.
- 2. Remove the water tank from the water tank recess (picture 1).
- 3. Fill the water tank with cold water up to the "max." mark. (Picture 2).



- 4. Close the tank cover until you feel it engage.
- 5. Insert the filled water tank (picture 3).
- Check whether the water tank is pushed in flush with the water tank recess (picture 4).



7. Close the appliance

door.

The water tank has been filled. You can now start the operation.

#### Refilling the water tank

If the water tank is empty, the prompt to fill the water tank appears on the display. The operation is stopped.

#### Marning – Risk of scalding!

When you open the appliance door, hot water may flow out of the appliance. When opening the door, do not stand too close to the appliance. Open the appliance door carefully. Keep children away from the appliance. If the evaporator dish overflows, do not pour more water into the water tank.

- **1.** Carefully open the appliance door.
- 2. Remove the water tank and fill it.
- 3. Slide the water tank back in and close the appliance door.
- 4. Start the operation. The operation continues.

#### Setting the type of heating and temperature

Example in the picture: 15 minutes steaming at 90 °C.


1. Touch the left of the field for a type of heating. The temperature is highlighted in white in the display.



- 2. Use the control ring to set the temperature.
- 3. Touch the 🕑 button. The cooking time is highlighted in white in the display.



 Use the control ring to set the cooking time.
 Press the Start/Stop button () to start. The appliance starts heating.



When your dish is ready, use the On/Off button to switch off the appliance.

#### Notes

- If you have started the steaming 🕾 type of heating, the cooking time only begins to count down once the set temperature has been reached.
- If you open the appliance door during steaming, the appliance operation stops. After the appliance door has been closed again, the appliance must first heat up to the set temperature before the cooking time continues to count down.

#### "Fill water tank?" message

This message appears if you set a type of heating and the water tank is only half full.

If you think that the water in the water tank is sufficient for the cooking procedure, you can start the appliance.

If not, fill the water tank to the "max" mark, slide it back in and start the appliance.

#### Changing

After starting the appliance, the temperature is highlighted. When you move the rotary selector, the temperature is changed and applied immediately.

To change the type of heating, interrupt the operation beforehand using the  $\triangleright$  Start/Stop button. Touch the symbol for the type of heating. The type of heating appears with the corresponding default temperature.

**Note:** When you change the type of heating, the other settings are also reset.

#### After each use

#### Marning – Risk of scalding!

When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.

Moisture and dirt remain in the cooking compartment after each operation. Therefore dry and clean the appliance after each use. Also empty the water tank after each use.

#### Drying the cooking compartment

#### Marning – Risk of scalding!

The water in the evaporator dish may still be hot. Allow it to cool before wiping.

- 1. Leave the appliance door ajar until the appliance has cooled down.
- 2. Remove any dirt from the cooking compartment immediately.
- 3. Wipe out the cooled cooking compartment and evaporator dish with the cleaning sponge and dry with a soft cloth.
- 4. Wipe the front of the units dry if condensation has formed.

#### Emptying the water tank

The water tank must be emptied and dried after each steam operation.

#### **Caution!**

- Do not dry the water tank in the hot cooking compartment. This will damage the water tank.
- Do not clean the water tank in the dishwasher. This will damage the water tank.
- 1. Open the appliance door.
- 2. Remove the water tank and empty the residual water.
- **3.** Thoroughly dry the seal in the tank cover and the water tank recess in the appliance.
- 4. Insert the water tank into the water tank recess.
- 5. Close the appliance door.

### Time-setting options

Your appliance has different time-setting options.

Time	-setting option	Use
Ğ	Cooking time	After the set cooking time has elapsed, the appliance ends the operation automatically.
C	End	Enter a cooking time and the required end time. The appliance starts automatically so that the operation ends at the required time.
8	Timer	The timer functions like an egg timer. It runs independently from the operation and the other time-setting options. After the set time has elapsed, the appliance does not switch on or off automatically.

You can call up the cooking time and the end time after setting a operation using the 0 field. The timer has a separate 2 field and can be adjusted at any time.

A signal sounds after a cooking time or timed period has elapsed. You can cancel the signal early by touching the O field.

**Note:** You can change how long the signal sounds for in the basic settings.  $\rightarrow$  "Basic settings" on page 18

#### Setting the cooking time

You can set the cooking time for your dish on the appliance. This means that the cooking time is not unintentionally exceeded and you do not need to interrupt other work in order to end the operation.

You can set a cooking time for each heating type.

#### **Applying settings**

The cooking time can be set in one-minute increments up to one hour, and then in five-minute increments.

Example in the picture: Cooking time of 45 minutes. **1.** Set the type of heating and temperature.

- 2. Touch the 🖾 field before starting.
- The cooking time is highlighted in white in the display.
- 3. Turn the rotary selector to set the cooking time.



The value is applied after a few seconds, or touch the 🖸 field twice. The cooking time is shown in the display under the type of heating and temperature or level.  Press the D Start/Stop button to start. The appliance begins to heat up.



Once the cooking time has elapsed, an audible signal sounds. The appliance stops heating. The cooking time 00 m 00 s is shown on the display.

You can use the  $\bigcirc$  field to set another cooking time, or use the  $\triangleright$  Start/Stop button to continue the operation without a cooking time.

When your dish is ready, switch the appliance off using the ① On/Off button.

#### **Changing and cancelling**

To change the cooking time, touch the 🖸 field. The cooking time is highlighted white and can be changed using the rotary selector. Use the 🖸 field to accept the change.

If you want to cancel the cooking time, reset the cooking time to zero. After the change has been applied, you can continue the operation without a cooking time using the  $\triangleright$  Start/Stop button.

#### Setting the end time

You can delay the time that the cooking time ends. You can, for example, put your dish in the cooking compartment in the morning and set the cooking time so that it is ready at lunch time.

#### Notes

- Ensure that food is not left in the cooking compartment for too long as it may spoil.
- Do not adjust the end time once the operation has started. The cooking result would no longer be satisfactory.

#### **Applying settings**

The end of the cooking time can be delayed by a maximum of 23 hours and 59 minutes.

Example in the picture: The set cooking time is 45 minutes and you want the dish to be ready at 12.00 p.m.

- 1. Set the type of heating and temperature or level.
- 2. Set the cooking time.
- **3.** Before starting, touch the O field again once. The cooking time is highlighted in white in the display.

4. Use the rotary selector to set a later end time.



The value is applied after a few seconds, or touch the 🖸 field again. The end time is shown in the display under the operating mode and temperature or level.

5. Press the D Start/Stop button to start.

The time at which the appliance will start is shown in the display.



The appliance is in standby mode. When the appliance starts, the cooking time counts down on the display.

Once the cooking time has elapsed, an audible signal sounds. The appliance stops heating. The cooking time 00 m 00 s is shown on the display.

You can use the O field to set another cooking time, or use the O Start/Stop button to continue the operation without a cooking time.

When your dish is ready, switch the appliance off using the  $\bigcirc$  On/Off button.

#### **Changing and cancelling**

To change the end time, interrupt the operation using the  $\triangleright$  Start/Stop button and then touch the  $\bigcirc$  field twice. The end time is highlighted white and can be changed using the rotary selector. Continue the operation using the  $\triangleright$  Start/Stop button.

If you want to cancel the end time, reset the end time to zero. You can start the set cooking time immediately using the  $\triangleright$  Start/Stop button.

**Note:** The end time can only be changed if the cooking time has not elapsed. Otherwise the cooking result would no longer be satisfactory.

#### Setting the timer

The timer runs alongside other settings. You can set it at any time, even if the appliance is switched off. It has its own audible signal so that you can tell whether it is the timer or a cooking time which has elapsed.

#### **Adjusting settings**

The timer duration always starts at zero minutes.

The higher the value, the greater the time steps when setting the timer.

The maximum setting is 24 hours.

- 2. Set the timer duration using the rotary selector.

The timer duration counts down.

The timer remains visible on the display if the appliance is switched off. When an operation is running, the settings for this operation are shown in the foreground. When you touch the  $\boxtimes$  field, the timer duration is displayed for a few seconds.

When the timer duration comes to an end, an audible signal sounds and a note appears on the display. The symbol is no longer lit up.

**Tip:** If the set timer duration relates to the appliance operation, use the cooking time. The time is visible in the foreground and the appliance switches off automatically.

#### **Changing and cancelling**

To change the timer duration, touch the  $\boxtimes$  field. The timer duration is displayed in white and in focus, and can be changed by using the rotary selector.

If you want to cancel the timer, reset the timer duration to zero. Once the change has been applied, the symbol is no longer lit up.

### **P**Dishes

You can use the "Dishes" operating mode to very easily prepare food. The appliance chooses the optimal setting for you.

#### Applying settings for dishes

Using the rotary selector, go through all the dishes to see which dishes are available in AutoPilot.

The cooking time depends on the dish and cannot be changed.

- 1. Touch the M field.
- The first dish is highlighted in white in the display.
- 2. Turn the rotary selector to set the required dish.
- 3. Use the ▷ Start/Stop button to confirm. A note on accessories and shelf position is displayed.
- 4. Press the ▷ Start/Stop button to start.

The appliance begins to heat up.

Once the cooking time has elapsed, an audible signal sounds. The appliance stops heating.

When your dish is ready, use the ① On/Off button to switch off the appliance.

#### **Continuing cooking**

After the cooking time has ended, you can leave some dishes to continue cooking if you are not satisfied with the cooking result.

A query appears on the display, which asks if you want to continue cooking. If you want to continue cooking, press the  $\triangleright$  Start/Stop button. A cooking time is suggested, which can be changed. Press the  $\triangleright$  Start/Stop button to start.

**Note:** You can extend the cooking time as often as required.

When you are satisfied with the cooking result, touch the  $\ensuremath{\mathbbmm}$  field.

Press the ① On/Off button to switch off the appliance.

#### Setting a later end time

You can set a later end time for some dishes. Before starting the appliance, touch the  $\bigcirc$  field and set a later end time using the rotary selector.

The appliance switches to standby after it is started. The end time can no longer be changed.

#### Changing and cancelling

After starting the appliance, the settings can no longer be changed.

If you would like to cancel the operation, switch the appliance off using the ① On/Off button. You can no longer pause the operation using the  $\bigcirc$  Start/Stop button.

#### Instructions for the dishes

All programmes are designed for cooking on one level.

The cooking result may vary according to the size and quality of the food.

#### Cookware

Use the suggested cookware. All meals have been tested using this cookware. The cooking result may change if you use different cookware.

When cooking in the perforated steam container, also insert the solid steam container at level 1. Dripping liquid is caught.

#### Amount/weight

Do not fill the food more than 4 cm deep in the accessory.

The total weight must be within the specified weight range.

#### **Cooking time**

The displayed temperature may change during the first few minutes, as the heating-up time depends on the temperature of the food and the water, amongst other things.

#### Preparing vegetables

Do not season vegetables until after cooking.

#### Preparing cereal products/lentils

Weigh the food and add the correct ratio of water:

Basmati rice 1:1.5

Couscous 1:1

Brown rice 1:1.5

Lentils 1:2

Stir cereal products after cooking. The remaining water is quickly absorbed.

#### Steaming chicken breast

Do not place chicken breasts on top of each other in the cookware.

#### Steaming fish

When preparing fish, grease the perforated steam container.

Do not place whole fish or fish fillets on top of each other. Enter the weight of the heaviest fish and choose pieces as similar in size as possible.

#### **Preparing yoghurt**

Heat the milk to 90 °C on the hob. Then leave to cool to 40 °C. It is sufficient to heat UHT milk to 40 °C. Stir in 150 g (chilled) yogurt.

Pour into cups or small jars and cover with cling film. Place the cups or jars onto the steamer tray and position as indicated in the table. After preparation, leave the yogurt to cool in the refrigerator.

#### Making rice pudding

Weigh the rice and add 2.5 times the amount of milk. Ensure the level of rice and milk in the accessory is no higher than 2.5 cm. Stir after cooking. The remaining milk is quickly absorbed.

#### Making fruit compote

The programme is only suitable for fruits with stones and pips. Weigh the fruit and add approximately  $\frac{1}{3}$  of the water, and add sugar and spices according to taste.

#### **Sterilising bottles**

Always clean the bottles with a bottle brush immediately after use. Then clean them in the dishwasher.

Place the bottles in the perforated steam container so that they do not touch one another.

Dry the bottles with a clean cloth after sterilising. The process corresponds to normal sterilisation by boiling.

#### **Cooking eggs**

Pierce the eggs before cooking. Do not place eggs on top of each other.

#### Table

Follow the instructions for the dishes.

Dish	Notes	Accessories	Level
Steam cauliflower florets*	Florets of equal size	perforated + solid steam container	2 1
Steam broccoli florets*	Florets of equal size	perforated + solid steam container	2 1
Steam green beans*	-	perforated + solid steam container	2 1
Steam sliced carrots*	slices, approx. 3 mm thick	perforated + solid steam container	2 1
Steam frozen mixed vegetables	-	perforated + solid steam container	2 1
Unpeeled boiled potatoes*	medium-sized, dia. 4 - 5 cm	perforated + solid steam container	2 1
Basmati rice	max. 0.75 kg	solid steam container	2
Brown rice	max. 0.75 kg	solid steam container	2
Couscous	max. 0.75 kg	solid steam container	2
Lentils	max. 0.55 kg	solid steam container	2
Reheat cooked side dishes*		solid steam container	2
Steam fresh chicken breast	Total weight 0.2 - 1.5 kg	perforated + solid steam container	2 1
Steam fresh fish fillet	max. 2.5 cm thick	perforated + solid steam container	2 1
Steam whole fresh fish	0.3 - 2 kg	perforated + solid steam container	2 1
Yogurt in glass jars	-	jars + solid steam container	2
Rice pudding	-	solid steam container	2
Fruit compote*	-	solid steam container	2
Sterilising bottles*		solid steam container	2
Soft-boiled eggs*	Eggs, size M, max. 1 kg	perforated + solid steam container	2 1
Hard-boiled eggs*	Eggs, size M, max. 1.8 kg	perforated + solid steam container	2 1

You can set an end time for this dish

### Childproof lock

Your appliance is equipped with a childproof lock so that children cannot switch it on accidentally or change any settings.

The control panel is locked and no settings can be made. The appliance can only be switched off using the ① On/Off button.

#### Activating and deactivating

You can activate and deactivate the childproof lock when the appliance is switched on or off.

In each case, press the  $\[mathcase]$  field for approx. 4 seconds.

A confirmation note appears on the display.

The  $\[cond mathcal{cond}$  field lights up red when the appliance is switched on. The  $\[cond mathcal{cond}$  field does not light up when the appliance is switched off.

### Basic settings

There are various settings available to you in order to help use your appliance effectively and simply. You can change these settings as required.

#### Changing the basic settings

The appliance must be switched off.

- 1. Touch the i field for approx. 3 seconds. Notes on the process appear on the display.
- Press the O field to confirm the notes. The first setting "language" appears on the display.
- **3.** Turn the rotary selector to change the setting as required.
- 4. Touch the I field. The next setting is shown on the display and can be changed using the rotary selector.
- Touch the D field to go through all the settings and use the rotary selector to make changes as required.
- When finished, press and hold the i field for approx.
   3 seconds to confirm the settings.

A note is shown on the display to confirm that the settings have been saved.

#### Cancelling

If you do not want to save the settings, you can press the ① On/Off button to cancel. A note is shown on the display to confirm that the settings have not been saved.

#### List of basic settings

Depending on the features of your appliance, not all basic settings are accessible.

Setting	Options
Language	Additional languages are possible.
Clock	Clock in 24-hour format
Water hardness	00 (softened)
	01 (soft)
	02 (medium)
	03 (hard)
	04 (very hard)
Audible signal	Short cooking time (30 sec.)
	Medium cooking time (1 min.)*
	Long cooking time (5 min.)
Button tone	Switched on
	Switched off* (tone remains for $\bigcirc$ On/ Off)
Display brightness	5 levels
Clock display	Off
	Digital*
Lighting	Off during operation
	On during operation*
Operation after switching	Types of heating*
on	AutoCook

Night-time darkening	Switched off* Switched on				
Drand lago					
Brand logo	Display*				
	Do not display				
Fan run-on time	Recommended*				
	Minimum				
Factory settings	Restore				
	Do not restore*				
* Factory setting (factory settings may vary depending on the appli-					

**Note:** Changes to the language, button tone and display brightness settings take effect immediately. All other changes take effect after the settings have been changed.

#### **Power cut**

ance model)

The changes you make to the settings are saved even after a power cut.

You only have to reset the settings for the initial use following a long-term power cut. The appliance can bridge a short-term power cut.

#### Changing the time

If you want to change the time, for example from summer to winter time, you have to change the basic setting.

The appliance must be switched off.

- 1. Touch the i field for approx. 3 seconds. Notes on the process appear on the display.
- Press the O field to confirm the notes. The first setting "language" appears in the display.
- 3. Touch the 🖸 field.
- The setting for the clock appears.
- 4. Turn the rotary selector to change the clock time.
- Press and hold the i field for approx. 3 seconds to confirm the setting.

A note is shown on the display to confirm that the settings have been saved.

### 

With good care and cleaning, your appliance will retain its appearance and remain fully functioning for a long time to come. We will explain here how you should correctly care for and clean your appliance.

#### Marning – Risk of short circuit!

Do not use high-pressure cleaners or steam jet cleaners to clean your appliance.

#### Caution! Risk of surface damage Do not use

- Do not use
- harsh or abrasive cleaning agents
- oven cleaners
- corrosive or aggressive cleaners, or those containing chlorine

cleaning agents

cleaning agents with a high alcohol content
 If such an agent comes into contact with the front of the appliance, wash it off immediately with water.

#### **Caution!**

#### **Risk of surface damage**

If descaler comes into contact with the front of the appliance or any other sensitive surfaces, wash it off immediately with water.

Remove food residues from the cooking compartment as soon as the appliance has cooled.

Salts are very corrosive and can cause rust. Remove remains of acidic sauces (ketchup, mustard) or salted food from the cooking compartment immediately after cooling.

Do not use hard scouring pads or cleaning sponges.

Appliance exterior (with aluminium front)	Use soapy water and dry with a soft cloth. Mild window cleaning agent - wipe over the aluminium front horizontally and without applying pres- sure using a soft window cloth or a lint-free microfibre cloth.
Appliance exterior (with stainless steel front)	Use soapy water and dry with a soft cloth. Always remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Spe- cial stainless steel cleaning agents can be obtained from the after-sales service or from specialist retailers.
Cooking compartment interior with evaporator dish	Hot, soapy water or a vinegar solution - use the enclosed cleaning sponge or a soft washing-up brush. Caution! The cooking compartment could rust. Do not use steel pads or scourers.
Water tank	Soapy water - do not clean in the dishwasher.
Tank recess	Rub dry after every use
Seal in the water tank lid	Thoroughly dry after every use
Door panels	See section: Cleaning the door panels Caution! Risk of surface damage After cleaning, wipe the door panels with glass cleaner, then dry. Otherwise, stains will be caused that will not be able to be removed.
Door seal	Hot soapy water
Accessories	Soak in hot soapy water. Clean with a brush or washing-up sponge or in the dishwasher. If the rails are discoloured by starchy foods (e.g. rice), clean them with a vinegar solution.

#### **Cleaning sponge**

The enclosed cleaning sponge is very absorbent. Use the cleaning sponge only for cleaning the cooking compartment and for removing residual water from the evaporator dish.

Wash the cleaning sponge thoroughly before using for the first time. You can wash the cleaning sponge in the washing machine (hot wash).

#### **Microfibre cloth**

The honeycomb microfibre cloth is particularly suitable for cleaning sensitive surfaces such as glass, glass ceramic, stainless steel or aluminium (product no. 460 770, also available from our online eShop). It removes liquid and greasy deposits in one go.

#### Descale

The appliance must be descaled regularly in order for it to continue operating correctly.

There are several steps in the descaling programme. All steps must be completed in full. Only after this is the appliance ready for use again.

**Note:** If you touch the ① On/Off button during the descaling programme, the process is interrupted and the appliance switches off. Once the appliance has been switched back on again, it must first be rinsed twice in order to remove any remaining descaling solution from the appliance. The appliance is locked for other applications until the second rinsing cycle is complete.

- Descale (approx. 30 minutes), then empty the evaporator dish and refill the water tank
- First rinsing cycle (20 seconds), then empty the evaporator dish
- Second rinsing cycle (20 seconds), then remove the remaining water

The frequency with which the appliance must be descaled depends on the hardness of the water used. When only another five or fewer steam-assisted operations are possible, the appliance reminds you to descale it with a message on the display. The number of remaining operations is displayed after the appliance is switched on. You can therefore prepare for the descaling in good time.

#### Starting

#### **Caution!**

- Risk of damage to the appliance: Only use liquid descalers recommended by us for the descaling programme. The time the product needs to work during descaling depends on the type of descaler used.Other descalers may damage the appliance. Descaler order no. 311 680
- Descaling solution: Do not allow any descaling solution or descaler to come into contact with the control panel or other surfaces on the appliance, as this will damage the surfaces. If this does happen, remove the descaling solution immediately with water.
- 1. Mix 300 ml water with 60 ml liquid descaler to make a descaling solution.
- 2. Remove the water tank and fill it with descaling solution.
- **3.** Once the water tank has been filled with descaling solution, push it back in again fully.
- 4. Close the appliance door.
- 5. Touch the On/Off button ().
- 6. Touch Descale mode ..... The duration of the descaling programme will be displayed.lt cannot be changed.
- Press the Start/Stop button ▷ to start. The appliance will now be descaled. The time will count down on the display. An audible signal will sound once descaling has finished.

#### First rinsing cycle

- 1. Use the cleaning sponge provided to remove the descaling solution from the evaporator dish.
- 2. Remove the water tank, rinse thoroughly, fill with water and reinsert.
- 3. Close the appliance door.
- Press the D Start/Stop button to start. The appliance rinses. The first rinsing cycle ends after around 20 seconds.
- 5. Open the appliance door.
- 6. Thoroughly rinse out the cleaning sponge with water.
- 7. Use the cleaning sponge to remove the remaining water in the evaporator dish.
- 8. Proceed with the second rinsing cycle.

#### Second rinsing cycle

- 1. Remove the water tank, rinse thoroughly, fill with water and reinsert.
- 2. Close the appliance door.
- Press the ▷ Start/Stop button to start. The appliance rinses. The second rinsing cycle ends after around 20 seconds.
- 4. Use the cleaning sponge to remove the remaining water in the evaporator dish.
- 5. Use the cleaning sponge to wipe out the cooking compartment and then dry it with a soft cloth.
- 6. Switch off the appliance. Descaling is complete and the appliance is ready for use again.

#### Descaling the evaporator dish only

You can also use "Descale" if you do not wish to descale the whole appliance, but only the evaporator dish in the cooking compartment.

The only difference is as follows:

- 1. Mix 100 ml water with 20 ml liquid descaler to make a descaling solution.
- 2. Completely fill the evaporator dish with descaling solution.
- 3. Fill the water tank with water only.
- 4. Start "Descale" as described.


You can also descale the evaporator dish manually.

#### Detaching and refitting the appliance door

For cleaning purposes or to remove the door panels, you can detach the appliance door.

The appliance door hinges each have a locking lever. When the locking levers are closed (fig. **1**), the appliance door is secured in place. It cannot be detached.

When the locking levers are open in order to detach the appliance door (fig. 2), the hinges are locked. They cannot snap shut.




#### **Warning** Risk of injury!

- If the hinges are not locked, they can snap shut with great force. Ensure that the locking levers are always fully closed or, when detaching the appliance door, fully open.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.

#### Detaching the appliance door


- **1.** Open the appliance door fully.
- Open the two locking levers on the left and right (fig. ■).
- Close the appliance door fully a. Take hold of the appliance door with both hands, one on the left and one on the right b, and pull it up and out (fig. 2).



#### Refitting the appliance door

Follow the instructions in the reverse order to refit the appliance door.

- When fitting the appliance door, ensure that both hinges are inserted straight into the opening (fig. 1). Slide the appliance door down as far as it will go.
- Open the appliance door fully. Close the two locking levers (fig. 2).



3. Close the cooking compartment door.

#### Removing and installing the door panels

To facilitate cleaning, you can remove the glass panels from the appliance door.


### Warning


#### **Risk of injury!**

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.
- Components inside the appliance door may have sharp edges. Wear protective gloves.


#### Removing the door from the appliance

- 1. Open the appliance door slightly.
- Press on the right and left side of the cover (figure
   ).
- 3. Remove the cover (figure 2).






- Loosen and remove the screws on the left and right of the appliance door (figure 3).
- Before closing the door again, trap a tea towel which has been folded several times in the door (figure 4). Pull out the front panel upwards and lay it on a flat surface with the door handle facing downwards.




Clean the panels with glass cleaner and a soft cloth.

#### Fitting the door on the appliance

- Insert the front panel at the bottom into the retainers (figure ■).
- Close the front panel until both upper hooks are opposite the opening (figure 2).



- Press the front panel at the bottom until it clicks audibly into place (figure 3)
- 4. Open the appliance door again slightly and remove the tea towel.
- 5. Screw both screws back in on the left and right.
- Put the cover back in place and press on it until it clicks audibly into place (figure 4).



7. Close the appliance door.

#### **Caution!**

Do not use the cooking compartment again until the panels have been correctly fitted.

### Trouble shooting

If a fault occurs, there is often a simple explanation. Before calling the after-sales service, please refer to the fault table and attempt to correct the fault yourself.

**Tip:** If a meal does not turn out exactly as you wanted, refer to the "Tested for you in our cooking studio" section.Here, you will find plenty of cooking tips and notes.

#### Marning – Risk of injury!

Incorrect repairs are dangerous. Do not attempt to repair the appliance yourself. Repairs must only be carried out by one of our trained after-sales engineers. If the appliance is defective, call the after-sales service.

#### Marning – Risk of electric shock!

Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

#### **Rectifying faults yourself**

You can often easily rectify technical faults on the appliance yourself.

If a dish does not turn out exactly as you wanted, you can find many tips and instructions for preparation at the end of the operating manual.

Fault	Possible cause	Notes/remedy
The appliance does not work.	Faulty fuse.	Check the circuit breaker in the fuse box.
	Power cut	Check whether the kitchen light or other kitchen appliances are working.
"Sprache Deutsch" appears on the display.	Power cut	Reset the language and the time.
The time does not appear when the appliance is switched off.	Basic setting is changed.	Change the basic setting for the clock display.
The appliance does not heat up; the [2] symbol lights up on the display.	Demo mode is activated in the basic settings.	Briefly disconnect the appliance from the mains (switch off the circuit breaker in the fuse box) and then deactivate demo mode in the basic settings within 3 minutes.
The rotary selector has fallen out of the support in the control panel.	The rotary selector has been accidentally disengaged.	The rotary selector can be removed. Simply place the rotary selector back in its support in the control panel and push it in so that it engages and can be turned as usual.
The rotary selector can no longer be turned easily.	There is dirt under the rotary selector.	The rotary selector can be removed. To disengage the rotary selector, simply remove it from the support. Alternatively, press on the outer edge of the rotary selector so that it tips and can be picked up easily.
		Carefully clean the rotary selector and its support on the appliance using a cloth and soapy water. Dry with a soft cloth. Do not use any sharp or abrasive materials. Do not soak or clean in the dishwasher.
		Do not remove the rotary selector too often so that the support remains stable.
The appliance cannot be started	The appliance door is not fully closed	Close the appliance door
	The appliance is not switched off	Switch the appliance off and back on again
The appliance is prompting you to wipe down the cooking compartment and fill the water tank	The power supply has been disconnected or the appli- ance has been switched off during the descaling process	Once the appliance is switched on again, rinse it twice
After switching on an operating mode, a message is shown on the display which indicates that the temperature is too high	The appliance has not cooled down sufficiently	Allow the appliance to cool down and switch the operating mode on again
The appliance prompts you to descale without the counter appearing before-hand	The set water hardness range is too low	Carry out descaling Check the set water hardness range and adjust it, if necessary
Buttons flash	Normal occurrence caused by condensation behind the control panel	As soon as the condensation has evaporated, the buttons no longer flash

Liquid in the evaporator dish has fully	The water tank has not been	Push in the water tank completely until you feel it engage
evaporated, even though the water	inserted properly	ashin the water tally completely until you leen t engage
tank is full	The feed line to the water	Descale the appliance
	tank is blocked	Check the set water hardness range and change it, if necessary
The water tank empties for no dis- cernible reason. The evaporator dish	The water tank was not closed properly	Close the lid until you feel it lock into place
overflows	The tank lid seal is dirty	Clean the seal
	The tank lid seal is faulty	Obtain a new water tank from the after-sales service
The appliance's display prompts you to fill up the water tank even though it	The water tank has not been inserted properly	Push in the water tank completely until you feel it engage
is full.	The detection system is not working	Call the after-sales service
The appliance's display prompts you to fill up the water tank even though it is not yet empty, or the water tank is empty but no corresponding message appears on the display	The water tank is dirty.The moving water level indicators are jammed	Shake and clean the water tank. If the jammed parts cannot be freed, obtain a new water tank from the after-sales service
The question "Fill the water tank?" appears in the display while the oper- ation is running	Water tank half filled	No remedial action required, operation continues
"Appliance heating" appears on the display but the appliance is not reaching the selected temperature	Automatic calibration values not optimal	Restore the appliance's factory settings and repeat the steps required for first-time operation $\rightarrow$ "Basic settings" on page 18 $\rightarrow$ "Before using for the first time" on page 10
		The next time you use the steam function at 100 °C, calibration will run auto- matically and more steam will be produced
When you cook with steam, a lot of steam is produced	The appliance is being auto- matically calibrated	Normal procedure
When cooking with steam, a lot of steam is produced repeatedly	The appliance is unable to cal- ibrate itself automatically if cooking times are too short	Reset the appliance to the factory settings and repeat the calibration process
Steam escapes from the ventilation slots during cooking	Normal procedure	Not possible

#### Marning – Risk of injury!

Incorrect repairs are dangerous. Do not attempt to repair the appliance yourself. Repairs must only be carried out by one of our trained after-sales engineers. If the appliance is defective, call the after-sales service.

#### Marning – Risk of electric shock!

Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

#### Error messages on the display

When an error message appears on the display with "D" or "E", e.g. D0111 or E0111, switch the appliance off and on again using the ① On/Off button.

If it was a one-off error, the display goes out. If the error message appears again, call the after-sales service and quote the exact error message.

#### Replacing the cooking compartment bulb

Heat-resistant 230 V/25 W halogen bulbs with seals are available from the after-sales service. Please specify the E number and FD number of your appliance.

#### Marning – Risk of electric shock!

When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

#### \Lambda Warning – Risk of burns!

The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.


- 1. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- 2. Turn the cover anti-clockwise to remove it.
- 3. Remove the bulb.

Insert the new bulb, making sure that the pins are in the correct position.Push the bulb in firmly.

#### **Caution!**

Only operate the appliance with the glass cover and seals.

4. Slide the new seals and the clamping ring onto the glass cover in the right order.



Screw the glass cover with the seals back on again.
 Connect the appliance to the power supply and carry out commissioning again.


#### Replacing the glass cover or seals

If the glass cover for the halogen bulb or the seals are damaged, they must be replaced. A new glass cover can be obtained from the after-sales service. Please specify the E number and FD number of your appliance.

#### Changing the door seal

If the seal around the outside of the cooking compartment is faulty, it must be replaced. Replacement seals for your appliance can be obtained from the after-sales service. Please specify the E number and FD number of your appliance.

- 1. Open the appliance door.
- 2. Pull off the old seal.
- **3.** Push in the new door seal at one point and pull it in all the way round. The joint must be at the side.
- 4. Check again that the seal is correctly fitted in the corners.



### Customer service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find an appropriate solution, also in order to avoid after-sales personnel having to make unnecessary visits.

#### E number and FD number

When calling us, please quote the full product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate bearing these numbers can be found when you open the appliance door.

On some appliances with a steam-assisted cooking function, you will find the rating plate behind the control panel.

	E-Nr: FD:	Z-Nr:
Type:		

To save time, you can make a note of the numbers for your appliance and the telephone number of the aftersales service in the space below in case you need them.

E no.

FD no.

#### After-sales service 🕾

Please note that a visit from an after-sales service engineer is not free of charge in the event that the appliance has been misused, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

#### To book an engineer visit and product advice

- **GB** 0344 892 8979
- Calls charged at local or mobile rate. IE 01450 2655
  - 0.03 € per minute at peak. Off peak 0.0088 € per minute.

Rely on the professionalism of the manufacturer. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your appliances.

### Settings table and tips

Steaming is a particularly gentle way of cooking food. The steam surrounds the dish thereby preventing a loss of nutrients from the food. Cooking takes place without excess pressure. As a result, the shape, colour and typical aroma of the dishes are retained.

The tables contain a selection of dishes which are particularly suitable for your steam oven. You can find out which heating type, accessories, temperature and cooking time are best to select. Unless otherwise stated, the information given applies to inserting accessories when the appliance is cold.

#### Accessories

Use the accessories provided.

When steaming in the perforated steam container, always insert the solid steam container underneath. Dripping liquid is caught.

#### **Ovenware**

When using ovenware, always place it in the middle of the perforated steam container.

Ovenware must be heat and steam resistant. Cooking times are increased if thick-sided ovenware is used.

Food which would normally be prepared in a bain-marie should always be covered with foil (e.g. when melting chocolate).

#### **Cooking time and quantity**

The cooking times when steaming depend on the item size, but do not depend on the total quantity. The appliance can steam food to a maximum of 2 kg.

Follow the unit sizes given in the tables. The cooking time is reduced for smaller pieces and increased for larger ones. Cooking time is also influenced by the quality and ripeness of the food. The values quoted can therefore only serve as a guideline.

#### **Distributing food evenly**

Always distribute the food evenly in the ovenware. It will not cook evenly if the layers are of different depths.

#### **Pressure-sensitive food**

When layering delicate foods in the steam container, do not pile them too high. You should ideally use two steam containers.

#### Cooking a menu

With steam, you can cook a whole menu at once, without the different flavours mixing. Place the food with the longest cooking time in the appliance first and delay the rest until the appropriate time. This means that all the food will be ready at the same time. The overall cooking time is extended with menu cooking, as a little steam escapes each time the appliance door is opened and has to be reheated.

#### Vegetables

Place the vegetables in the perforated steam container and insert at level 3. Always insert the solid steam container underneath at level 1. Any dripping liquid will be caught.

Food	Size	Accessories	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Artichokes	whole	perforated + solid	Steaming	100	30 - 35
Cauliflower	whole	perforated + solid	Steaming	100	25 - 35
Cauliflower	florets	perforated + solid	Steaming	100	10 - 15
Broccoli	florets	perforated + solid	Steaming	100	8 - 10
Peas	-	perforated + solid	Steaming	100	5 - 10
Fennel	sliced	perforated + solid	Steaming	100	10 - 14
Vegetable flan	-	1.5 I bain-marie dish + perfo- rated at level 2	Steaming	100	50 - 70
Green beans	-	perforated + solid	Steaming	100	20 - 25
Carrots	sliced	perforated + solid	Steaming	100	10-20
Kohlrabi	sliced	perforated + solid	Steaming	100	20 - 25
Leek	sliced	perforated + solid	Steaming	100	6 - 9
Sweetcorn	whole	perforated + solid	Steaming	100	25 - 35
Swiss chard*	shredded	perforated + solid	Steaming	100	8 - 10
Green asparagus*	whole	perforated + solid	Steaming	100	7 - 12
White asparagus*	whole	perforated + solid	Steaming	100	10-15
Spinach*	-	perforated + solid	Steaming	100	2-3
Romanesco	florets	perforated + solid	Steaming	100	8 - 10
Brussels sprouts	florets	perforated + solid	Steaming	100	20 - 30
Beetroot	whole	perforated + solid	Steaming	100	40 - 50
Red cabbage	shredded	perforated + solid	Steaming	100	30 - 35
White cabbage	shredded	perforated + solid	Steaming	100	25 - 35
Courgette	sliced	perforated + solid	Steaming	100	3 - 4
Mangetout	-	perforated + solid	Steaming	100	8 - 12
* Preheat the appliance					

#### Side dishes and pulses

Add water or liquid in the proportion specified. For example: 1:1.5 = add 150 ml liquid for every 100 g rice.

You may select any shelf position you wish for the solid steam container.

Food	Ratio	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Unpeeled boiled potatoes (medium size)	-	perforated + solid	2 1	Steaming	100	35 - 45
Boiled potatoes (quartered)	-	perforated + solid	2 1	Steaming	100	20 - 25
Brown rice	1:1.5	solid	-	Steaming	100	35 - 45
Long grain rice	1:1.5	solid	-	Steaming	100	20-30
Basmati rice	1:1.5	solid	-	Steaming	100	20-30
Parboiled rice	1:1.5	solid	-	Steaming	100	15-20
Risotto	1:2	solid	-	Steaming	100	30 - 35
Lentils	1:2	solid	-	Steaming	100	35 - 50
Canellini beans, pre-softened	1:2	solid	-	Steaming	100	65-75
Couscous	1:1	solid	-	Steaming	100	6 - 10

#### en Settings table and tips

Food	Ratio	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Unripe spelt grain, coarse ground	1:2.5	solid	-	Steaming	100	15-20
Millet, whole	1:2.5	solid	-	Steaming	100	25 - 35
Wheat, whole	1:1	solid	-	Steaming	100	60 - 70
Dumplings	-	perforated + solid	2 1	Steaming	95	20-25

### Poultry and meat

#### Poultry

Food	Amount	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Chicken breast	0.15 kg each	solid	2	Steam	100	15-25
Duck breast*	0.35 kg each	solid	2	Steam	100	12-18
* Sear first and wrap in foil						
Beef						

Food	Amount	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Thin slice of sirloin, medium*	1 kg	solid	2	Steam	100	25-35
Thick piece of sirloin, medium*	1 kg	perforated + solid	3 1	Steam	100	30 - 40
* Coor first and wron in fail						

#### \* Sear first and wrap in foil

#### Pork

Food	Amount	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Fillet of pork	0.5 kg	solid	2	Steaming	100	16-20
Pork medallions*	approx. 3 cm thick	solid	2	Steaming	100	10 - 12
Smoked pork ribs	sliced	solid	2	Steaming	100	15-20
* Sear first and wrap in foil						

#### Sausages

Food	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Wiener sausages	perforated + solid	2 1	Steaming	80 - 90	12-18
Bavarian veal sausages	perforated + solid	2 1	Steaming	80 - 90	20-25

### Fish

Food	Amount	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Sea bream, whole	0.3 kg each	perforated + solid	2 1	Steam	80 - 90	15-25
Sea bream fillet	0.15 kg each	perforated + solid	2 1	Steam	80 - 90	10-20
Fish terrine	1.5 l bain- marie dish	solid	2	Steam	70-80	40 - 80
Trout, whole	0.2 kg each	perforated + solid	2 1	Steam	80 - 90	12 - 15

Food	Amount	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Cod fillet	0.15 kg each	perforated + solid	2 1	Steam	80 - 90	10 - 14
Salmon fillet	0.15 kg each	perforated + solid	2 1	Steam	100	8 - 10
Mussels	1.5 kg	solid	2	Steam	100	10-15
Ocean perch fillet	0.15 kg each	perforated + solid	2 1	Steam	80 - 90	10-20
Sole rolls, stuffed		perforated + solid	2 1	Steam	80 - 90	10-20

#### Soup vegetables, miscellaneous

Food	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Royale (egg custard)	solid	2	Steam	90	15-20
Semolina dumplings	perforated + solid	2 1	Steam	90 - 95	7 - 10
Hard-boiled eggs (Size M, max. 1.8 kg)	perforated + solid	2 1	Steam	100	10 - 12
Soft-boiled eggs (Size M, max. 1 kg)	perforated + solid	2 1	Steam	100	6 - 8

#### Dessert, compote

#### Compote

Weigh the fruit and add approximately  $\frac{1}{3}$  of the water, then add sugar and spices according to taste.

#### **Rice pudding**

Weigh the rice and add 2.5 times the amount of milk. Ensure the level of rice and milk in the accessory is no higher than 2.5 cm. Stir after cooking. The remaining milk is quickly absorbed.

#### Yogurt

Heat the milk to 90  $^{\circ}$ C on the hob. Then leave to cool to 40  $^{\circ}$ C. It is sufficient to heat UHT milk to 40  $^{\circ}$ C.

Stir in 150 g (chilled) yogurt. Pour into cups or small jars and cover with cling film. Place the cups or glasses onto the steamer tray and set as indicated in the table.

After preparation, leave the yogurt to cool in the refrigerator.

Food	Accessories	Type of heating	Tempera- ture in °C	Cooking time in min.
Yeast dumplings	solid	Steaming	100	20-25
Crème caramel	small moulds + perforated	Steaming	80	15-20
Rice pudding*	solid	Steaming	100	25 - 35
Yoghurt*	Portion-sized glasses + perfo- rated	Steaming	40	300 - 360
Apple compote	solid	Steaming	100	10-15
Pear compote	solid	Steaming	100	10-15
Cherry compote	solid	Steaming	100	10-15
Rhubarb compote	solid	Steaming	100	10 - 15
Plum compote	solid	Steaming	100	15-20

You can also use the appropriate programme (see section: Automatic programmes)

#### **Reheating food**

Using Reheat, dishes can be gently reheated. They taste and look like they have been freshly prepared.

Food	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Vegetables	solid steam container	2	Reheating	100	12-15
Pasta, potatoes, rice	solid steam container	2	Reheating	100	5 - 25

#### Defrosting

The steam function "Defrost" is suitable for defrosting frozen fruit and vegetables. It is best to allow poultry, meat and fish to defrost in the refrigerator. To defrost the frozen food, remove it from its packaging. Place frozen fruit and vegetables into the steaming pan with the perforated base, and place the steaming pan with the unperforated base underneath. This keeps the food away from the water that forms as it defrosts, and allows this water to be collected as it drips down. For frozen food that needs to retain liquid when it is cooked, e.g. creamed spinach, use the steaming pan with the unperforated base.

The times specified in the table are intended as a guide. They are dependent on the quality, freezing temperature (-18  $^{\circ}$ C) and composition of the food.Time ranges are specified. Set the shortest time initially, and then extend the time if necessary.

**Tip:** Food that has been frozen in thinner pieces or in portions defrosts more quickly than food items frozen in a block.

Food	Amount	Accessories	Level	Tempera- ture in °C	Cooking time in min.
Berries	0.5 kg	perforated + solid	2 1	50 - 55	15-20
Vegetables	0.5 kg	perforated + solid	2 1	40 - 50	15-50

#### **Prove dough**

When the Prove dough type of heating is used, dough proves considerably more quickly than at room temperature.

You may select any shelf position you wish or place the cooking container carefully on the cooking

compartment floor.

Caution: Do not scratch the cooking compartment floor. Place the dough bowl in the perforated cooking container. Do not cover the dough.

Food	Amount	Accessories	Tempera- ture in °C	Cooking time in min.
Yeast dough	1 kg	Bowl + perforated cooking container	35	20-30

#### **Extracting juice**

Before juicing, place the berries in a bowl and sprinkle with sugar. Leave to stand for at least one hour to draw out the juice. Pour the berries into the perforated steam container and insert at level 3. Insert the solid steam container at level 1 to catch the juice.

Finally, place the berries in a cloth and squeeze out the rest of the juice.

Food	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Raspberries	perforated + solid	2 1	Steam	100	30 - 45
Redcurrants	perforated + solid	2 1	Steam	100	40 - 50

#### Preserving

Preserve food which is as fresh as possible. When foods are stored for a relatively long period, their vitamin content is reduced and they ferment and spoil more easily.

Only use fruit and vegetables which are in perfect condition.

The following foods cannot be preserved with your appliance:

Contents of tins, meat, fish or pastry dough.

Check preserving jars, rubber rings, clips and springs.

Clean rubber rings and jars thoroughly with hot water. The "Sterilise bottles" programme is also suitable for cleaning jars.

Place the jars into the perforated steam container. They must not touch each other.

After the specified cooking time, open the appliance door.

Do not remove the preserving jars from the appliance until they have completely cooled down.

Food	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Vegetables	1-litre preserving jars	2	Steam	100	30 - 120
Stone fruits	1-litre preserving jars	2	Steam	100	25 - 30
Pip fruits	1-litre preserving jars	2	Steam	100	25 - 30

#### **Frozen products**

Observe the manufacturer's instructions on the packaging.

The cooking times indicated apply to dishes placed in a cold cooking compartment.

Food	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Pasta, fresh, refrigerated*	solid	2	Steaming	100	5-10
Trout	perforated + solid	2 1	Steaming	80 - 100	20 - 25
Salmon fillet	perforated + solid	2 1	Steaming	80 - 100	20 - 25
Broccoli	perforated + solid	2 1	Steaming	100	6 - 10
Cauliflower	perforated + solid	2 1	Steaming	100	5-8
Beans	perforated + solid	2 1	Steaming	100	6 - 10
Peas	perforated + solid	2 1	Steaming	100	5-12
Carrots	perforated + solid	2 1	Steaming	100	4 - 6
Mixed vegetables	perforated + solid	2 1	Steaming	100	6 - 10
Brussels sprouts	perforated + solid	2 1	Steaming	100	5 - 10

#### **Test dishes**

These tables have been produced for test institutes to facilitate the inspection and testing of the various appliances.

Test dishes in accordance with EN 60350-1.

Food	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Broccoli (Steam distribution)	perforated + solid	2 1	Steaming	100	7 - 9
Broccoli (Steam supply)	perforated + solid	2 1	Steaming	100	7 - 9
Peas* (Maximum load)	perforated + solid	2 1	Steaming	100	5 - 12
* Spread out 2.0 kg peas evenly in the	container.				

ſ	
	<i>K//</i>
l	12


ſ	
	<i>K//</i>
l	12




BOSCH

SERVICE

# Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- Expert tips & tricks for your appliance
- Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones:

www.bosch-home.com/welcome

### Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, need help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you:

#### www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

Robert Bosch Hausgeräte GmbH Carl-Wery-Straße 34 81739 München Germany

www.bosch-home.com

