



Washing machine

WAJ20180EG **WAJ2018SEG**

[en] User manual and installation

instructions

Table of contents

Safety	Degrees of soiling	
Restriction on user group	Detergents and care products Detergent recommendation Detergent dosage	28 29
Safe cleaning and maintenance 9	Basic operation	
Preventing material damage 11	Switching on the appliance	
Environmental protection and saving energy	Adjusting the programme settings	30 30 30
Installation and connection12Unpacking the appliance12Contents of package13Requirements for the installation13Incation13Removing the transit bolts14Connecting the appliance15Aligning the appliance16	Adjusting the "Ready in" time before the programme starts	31 31 31 31
Familiarising yourself with	Switching off the appliance	32
your appliance18Appliance18Detergent drawer19Controls19	Childproof lock	32 32
Display20Programmes22Buttons24	Overview of the basic settings	33
Accessories25	Cleaning and servicing	
Before using for the first time 25 Starting an empty washing cycle 25	Tips on appliance care	34
Laundry26Preparing the laundry26Sorting laundry27	Descaling Cleaning the drain pump Before the next wash	35 35

Technical specifications	51
Consumption values	51
Customer Service	
Inserting the transit bolts	49
Disposing of old appliance	
Transportation, storage and disposal	
Odours Emergency release	
Leakage	46
Noise Problem with results	
Malfunctions	42
Troubleshooting Error code / Fault display / Signal	
Cleaning the water outlet hose at the siphon	



△ Safety

Please read the safety information to ensure that you use the appliance safely.

General information

You can find general information about this instruction manual here.



- Read this instruction manual carefully. Only this will ensure you use the appliance safely and efficiently.
- This manual is intended for the installer and the user of the appliance.
- Follow the safety instructions and warnings.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Check the appliance after unpacking it. Do not connect the appliance if it has been damaged in transit.

Intended use

Read the information on intended use to ensure that you use the appliance correctly and safely.

Only use this appliance:

- According to this installation and instruction manual.
- For washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- With tap water and commercially available detergents and care products suitable for washing machines.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

Avoid risks to children and vulnerable persons.

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

Safe installation

Take note of the safety instructions when installing the appliance.

- Improper installation is dangerous.
 - ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
 - Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
 - ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
 - ► When using a residual current circuit breaker, only use a type with the ☐ mark.
 - ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
 - ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
 - ► When installing the appliance, check that the power cable is not trapped or damaged.

en Safety

- If the insulation of the power cord is damaged, this is dangerous.
 - ▶ Never let the power cord come into contact with hot appliance parts or heat sources.
 - ► Never let the power cord come into contact with sharp points or edges.
 - ▶ Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ▶ If the power cord is too short, contact Customer Service.
- ▶ Only use adapters approved by the manufacturer.

⚠ WARNING – Risk of injury!

- The high weight of the appliance may result in injury when lifted.
 - ▶ Do not lift the appliance on your own.
- If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.
 - Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
 - ▶ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
 - ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
 - ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

△ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

⚠ CAUTION – Risk of injury!

- The appliance may vibrate or move when in use.
 - ▶ Place the appliance on a clean, even, solid surface.
 - ► Align the appliance using the appliance feet and a spirit level.
- If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
 - Lay hoses and power cords in such a way that there is no risk of tripping.
- If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.
 - Do not move the appliance by holding onto protruding parts.

Touching sharp edges on the appliance may lead to cuts.

- ▶ Do not touch the sharp edges on the appliance.
- Wear protective gloves when installing and transporting the appliance.

Safe use

Follow these safety instructions when using the appliance.

⚠ WARNING – Risk of electric shock!

- If the appliance or the power cord is damaged, this is dangerous.
 - ► Never operate a damaged appliance.
 - ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
 - ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
 - ► Call Customer Service. → Page 50
 - ► Repairs to the appliance should only be carried out by trained specialist staff.
- An ingress of moisture can cause an electric shock.
 - ▶ Only use the appliance in enclosed spaces.

en Safety

- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

△ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

⚠ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of explosion!

Laundry that has been pretreated with cleaning agents that contain solvents may cause an explosion in the appliance.

► Rinse pretreated laundry thoroughly with water before washing.

△ CAUTION – Risk of injury!

- The worktop may break if you stand on or climb onto the appliance.
 - ▶ Do not stand on or climb onto the appliance.

- The appliance may tip over if you sit on or lean against the open door.
 - ▶ Do not sit on or lean against the appliance door.
 - ▶ Do not place any objects on the appliance door.
- Reaching into the drum while it is still turning may cause hand injuries.
 - ► Wait for the drum to come to a complete stop before reaching inside.

When washing at high temperatures, the glass in the appliance door becomes hot.

- ▶ Do not touch the appliance door when it is hot.
- ► Keep children away from the appliance door when it is hot.

△ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

▶ Do not touch the hot detergent solution.

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- ► Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

Safe cleaning and maintenance

Take note of the safety instructions when cleaning and performing maintenance work on the appliance.

- Improper repairs are dangerous.
 - ► Repairs to the appliance should only be carried out by trained specialist staff.

en Safety

- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.
- An ingress of moisture can cause an electric shock.
 - ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

Preventing material damage

Follow these instructions to avoid material damage and damage to the appliance.

ATTENTION!

- The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.
 - ► Follow the dosage recommendations from the manufacturer.
- Exceeding the maximum load capacity impairs the function of the appliance.
 - Observe the maximum load capacity → Page 22 for each programme and do not exceed it.
- The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.
 - ▶ Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
 - ▶ Before transport, fit the transit bolts fully in order to prevent damage in transit.
- If the water pressure is too high or too low, this may impair functioning of the appliance.
 - ► Make sure that the water pressure in the water supply system is min. 100 kPa (1 bar) and max. 1000 kPa (10 bar).
 - ▶ If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.

- Modified or damaged water hoses may result in material damage and damage to the appliance.
 - ▶ Never kink, crush, modify or cut through water hoses.
 - ► Only use the water hoses supplied with the appliance or genuine spare hoses.
 - ▶ Never re-use water hoses that have been used before.
- Unsuitable cleaning products may damage the surfaces of the appliance.
 - Do not use harsh or abrasive detergents.
 - ► Do not use cleaning products with a high alcohol content.
 - Do not use hard scouring pads or cleaning sponges.
 - ► Clean the appliance with nothing but water and a soft, damp cloth.
 - Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

Environmental protection and saving energy

Help protect the environment by using your appliance in a way that conserves resources and by disposing of reusable materials properly.

Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

- Sort the individual components by type and dispose of them separately.
 - Information about current disposal methods are available from your specialist dealer or local authority.

Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

Do not exceed the programme's maximum load capacity → Page 22.

+ A higher load capacity extends the programme duration and increases energy consumption.

Use the programme's maximum load capacity → Page 22.

+ The energy and resource consumption is the most efficient.

Add → Page 29 detergent based on the laundry's degree of soiling.

+ For light to normal soiling, a smaller amount of detergent is sufficient. Observe the dosage recommendation from the detergent manufacturer.

Reduce the washing temperature for lightly and normally soiled laundry.

+ At low temperatures, the appliance consumes less energy. For light to normal soiling, lower temperatures than indicated on the care label are also sufficient.

Set the maximum spin speed if you want to dry the laundry in a tumble drver afterwards.

+ The drier the laundry, the shorter the programme duration when drying which, in turn, reduces energy consumption.

Wash the laundry without prewash.

+ Washing with prewash increases the programme duration and increases energy and water consumption.

The appliance has a continuous automatic load adjustment function.

+ Depending on the type of fabric and load capacity, the continuous automatic load adjustment function optimally adjusts the water consumption and programme duration.

Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. All displays go out and Start / Reload DII flashes.

Energy-saving mode ends when you use the appliance again, e.g. if you open or close the door.

Installation and connection


You can find out where and how best to install your appliance here. You will also learn how to connect the appliance to the water and power sup-

Unpacking the appliance

- 1. Remove any packaging and protective covers completely from the appliance.
- 2. Check the appliance for visible damage.
- 3. **ATTENTION!** Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.
- ► Remove these objects, along with all supplied accessories, from the drum before starting the appliance. Open the door and remove the accessory from the drum.

Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.



Washing machine Accompanying documents Water inlet hose Cover caps

Requirements for the installation location

The appliance may "wander" when it spins. Observe the instructions for the installation location.

Note: Please read the safety information \rightarrow Page 4 to ensure that you use the appliance safely.

WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

▶ Do not operate the appliance without a cover cap.

WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

► Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 25 before using the appliance for the first time.

ATTENTION!

- If the appliance is installed in areas exposed to frost or outdoors, frozen residual water may damage the appliance and frozen hoses may crack or split.
 - Do not install or operate this appliance anywhere that is liable to experience frost and/or outdoors.
- The appliance underwent a function test before leaving the factory and may, therefore, contain residual water. This residual water may leak out if the appliance is tilted at an angle greater than 40°.
 - ► Tilt the appliance carefully.


Installation location	Requirements
On a base	Secure the appliance with fixing brackets → Page 25.

On a wooden joist floor



Place the appliance on a water-resistant wooden board which is screwed tightly to the floor. The wooden board should be at least 30 mm thick.


In a kitchen unit



- A niche width of 60 cm is required.
- Only install the appliance underneath a continuous worktop that is securely connected to adjacent cabinets.

Installation location Requirements

On a wall




Do not trap the hoses between the wall and the appliance.

Removing the transit bolts


The appliance is secured for transportation using transit bolts on the rear of the appliance.

Notes

- Please read the safety information
 → Page 4 to ensure that you use
 the appliance safely.
- Keep the transit bolts, screws and sleeves in a safe place for future transport → Page 48.
- 1. Pull the hoses out of the holders.




2 Unscrew ① and remove ② all four screws for the transit bolts with a WAF 13 wrench.




3. Pull the power cord out of the holder.




4. Remove the four sleeves.



5. Put on the four cover caps.



6. Press down on the four cover caps.




Connecting the appliance

Connect your appliance to the power supply, water inlet and water outlet.


Connecting the water inlet hose

Note: Please read the safety information → Page 4 to ensure that you use the appliance safely.

1. Connect the water inlet hose.



2. Connect the water inlet hose to a tap (26.4 mm = 3/4").



Open the water tap carefully and check that the connection points are tight.

Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.


Note: Please read the safety information → *Page 4* to ensure that you use the appliance safely.

ATTENTION!

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

 Secure the water outlet hose against unintentional loosening.

Drainage into a siphon.
Secure the connection point with a (24–




Drainage into a wash basin.

40 mm) hose clamp.

Fix and secure the water outlet hose with an elbow \rightarrow *Page 25*.



Drainage into a plastic pipe with rubber sleeve or into a gully. Fix and secure the water outlet hose with an elbow $\rightarrow Page~25$.



Connecting the appliance to the electricity supply

Note: Please read the safety information \rightarrow *Page 4* to ensure that you use the appliance safely.

 Insert the mains plug of the appliance's power cable in a socket nearby.

The connection details of the appliance can be found under Technical data \rightarrow *Page 51*.


2. Check the mains plug is inserted properly.

Aligning the appliance


In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

Note: Please read the safety information \rightarrow *Page 4* to ensure that you use the appliance safely.

 Loosen the lock nuts using a WAF 17 wrench by turning it in a clockwise direction.




2. To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

3. Screw the lock nuts tightly against the housing using a WAF 17 wrench.




In doing so, hold the foot tight and do not adjust its height.

Familiarising yourself with your appliance

Familiarise yourself with the parts of your appliance.

Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

1	Maintenance flap for the drain pump → Page 35
2	Door
3	Detergent drawer → Page 19
4	Controls → Page 19
5	Water outlet hose → Page 16
6	Power cord → Page 16

Detergent drawer


Below is an overview of the structure of the detergent drawer.



- Compartment II:
 - Detergent for main wash
 - Water softener
 - Bleach
 - Stain remover
- Compartment ::
 - Fabric softener
 - Liquid starch
 - Waterproofing agent
- Compartment I:
 - Detergent for prewash
 - Hygiene detergent

Controls


The controls are used to configure all functions of your appliance and to obtain information about the operating status.



- Programmes → Page 22
- Programme selector → *Page 29*
- Buttons → Page 24
- Display → Page 20

Display

The display shows the current settings, options or relevant information.



Display	Designation	Description
0:40 1	Programme duration/ programme time re- maining	Expected programme duration or programme time remaining.
10h ¹	"Ready in" time	The programme end has been set and the remaining number of hours is displayed. → "Buttons", Page 24
8 kg ¹	Recommended load	The maximum load capacity for the selected programme in kg.
1000	Spin speed	Set spin speed in rpm. → "Buttons", Page 24 - 0 - = No final spin, only draining : Rinse Hold, no draining
_	Start/Pause	Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be started or continued.
	Wash	Programme status
	Rinse	Programme status
<u>•</u>	Spin	Programme status
	Rinse Hold	Programme status
¹ Example		

End End of programme Programme status Childproof lock ■ Lights up: The childproof lock is activated. ■ Flashes: The childproof lock is active and the programme selector has been adjusted. → "Deactivating the childproof lock", Page 32 ■ SpeedPerfect Short wash activated. → "Buttons", Page 24 : Voltage control system Flashes: The automatic voltage control system detects unauthorised voltage drops. → "Error code / Fault display / Signal", Page 41 Note: The programme is interrupted Image: The programme duration is extended. Note: The programme duration is extended. Image: The door is locked and cannot be opened. ■ Lights up: The door is locked and cannot be opened. Image: The door is not closed properly. ■ Off: The door is unlocked and can be opened. Image: The door is not closed properly. ■ No water pressure. → "Error code / Fault display / Signal", Page 41 Image: The door is not closed properly. ■ No water pressure is too low. E:60 / -2B 1 Error Error code / Fault display / Signal", Page 41 Image: The door is play, signal. → "Error code / Fault display / Signal", Page 41	Display	Designation	Description
Flashes: The childproof lock is active and the programme selector has been adjusted. → "Deactivating the childproof lock", Page 32 SpeedPerfect Short wash activated. → "Buttons", Page 24 Flashes: The automatic voltage control system detects unauthorised voltage drops. → "Error code / Fault display / Signal", Page 41 Note: The programme is interrupted Voltage control system Flashes: The automatic voltage control system detects unauthorised voltage drops. → "Error code / Fault display / Signal", Page 41 Note: The programme duration is extended. Door Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened. Flashes: The door is unlocked and can be opened. Flashes: The water pressure. → "Error code / Fault display / Signal", Page 41 The water pressure is too low. E:60 / -28 Fror Serror code, error display, signal. → "Error code / Fault display / Signal", Page 41	End	End of programme	Programme status
Tap Pauttons", Page 24 Flashes: The automatic voltage control system detects unauthorised voltage drops. "Error code / Fault display / Signal", Page 41 Note: The programme is interrupted Flashes: The automatic voltage control system detects unauthorised voltage drops. "Error code / Fault display / Signal", Page 41 Note: The programme duration is extended. Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened. No water pressure. "Error code / Fault display / Signal", Page 41 The water pressure is too low. E:60 / -2B ¹ Error Error code, error display, signal. "Error code / Fault display / Signal", Page 41 "Fror code / Fault display / Signal", Page 41	Cm	Childproof lock	 Flashes: The childproof lock is active and the pro- gramme selector has been adjusted.
unauthorised voltage drops. → "Error code / Fault display / Signal", Page 41 Note: The programme is interrupted Flashes: The automatic voltage control system detects unauthorised voltage drops. → "Error code / Fault display / Signal", Page 41 Note: The programme duration is extended. Door Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened. Tap No water pressure. → "Error code / Fault display / Signal", Page 41 The water pressure is too low. E:60 / -2B ¹ Error Error code, error display, signal. → "Error code / Fault display / Signal", Page 41	= ₩	SpeedPerfect	
Voltage control system Flashes: The automatic voltage control system detects unauthorised voltage drops. "Error code / Fault display / Signal", Page 41 Note: The programme duration is extended. Door Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened. Flashes: The door is unlocked and can be opened. No water pressure.	:	Voltage control system	unauthorised voltage drops. → "Error code / Fault display / Signal", Page 41
unauthorised voltage drops. → "Error code / Fault display / Signal", Page 41 Note: The programme duration is extended. □ Lights up: The door is locked and cannot be opened. □ Flashes: The door is not closed properly. □ Off: The door is unlocked and can be opened. □ No water pressure. □ "Error code / Fault display / Signal", Page 41 □ The water pressure is too low. □ Error code / Fault display / Signal", Page 41 □ The water pressure is too low.		1	Note: The programme is interrupted
Door Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened. No water pressure. → "Error code / Fault display / Signal", Page 41 The water pressure is too low. E:60 / -2B ¹ Error Error code, error display, signal. → "Error code / Fault display / Signal", Page 41	•	Voltage control system	unauthorised voltage drops. → "Error code / Fault display / Signal", Page 41
 → "Error code / Fault display / Signal", Page 41 ■ The water pressure is too low. E:60 / -2B ¹ Error Error code, error display, signal. → "Error code / Fault display / Signal", Page 41 	C	Door	 Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly.
→ "Error code / Fault display / Signal", Page 41	足	Тар	→ "Error code / Fault display / Signal", Page 41
1 Evample	E:60 / -2B ¹	Error	
LXAIIIPIE	¹ Example		

Programmes

Below is an overview of the programmes. You can find information on the load and on the setting options. **Tip:** The laundry's care labels provide you with additional information on programme selection. → "Care symbols on the care labels", Page 27

Program:	Description	Max. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) ¹	SpeedPerfect	Spin Speed ⑤ - — (Rinse Hold)
Cottons	Wash hard-wearing items made from cotton, linen or blended fabrics. Also suitable as a short programme for normally soiled laundry when you activate SpeedPerfect ≡℧ . If Speed-Perfect ≡℧ is activated, the maximum load capacity is reduced to 5 kg.	∞	06	1000	•	•
Cottons	Wash hard-wearing items made from cotton, linen or blended fabrics. Energy-saving programme. Note: To save energy, the actual washing temperature may deviate from the set washing temperature. The washing performance meets legal requirements.	ω	09	1000	1	•
Prewash	Wash hard-wearing items made from cotton, linen or blended fabrics. Programme with prewash for heavily soiled laundry. Divide the detergent between the detergent drawer for the prewash and the main wash. → "Detergent drawer", Page 19	80	40	1000	•	•
EasyCare Wa The specified value is rounded	Wash items made from synthetic or blended fabrics.	4	40	1000	•	•

Program:	Description	Max. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) ¹	SpeedPerfect =0	Spin Speed ③ - — (Rinse Hold)
Delicates / Silk	Wash delicate, washable items made from silk, viscose and synthetics. Use a detergent that is suitable for delicates or silk. Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag.	2	30	800	ı	•
Wool &	Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool.	2	30	800	ı	•
Rinse	Rinses and then spins the laundry, and then drains the water.	ı	I	1000	I	•
Spin / Drain	Spins and drains the water. If you only want to drain the water, activate – 0 – . The laundry is not spun.	I	I	1000	1	•
Dark Laundry	Wash dark-coloured and colour-intense items made from cotton or easy-care fabric, e.g. jeans. Turn laundry inside-out before washing. Use liquid detergent.	4	30	1000	•	•
Sportswear	Wash sports and leisure items made from synthetic fibres, microfibre or fleece. Use a detergent that is suitable for sports items. Do not use fabric softener. Tip: Use the EasyCare programme to wash heavily soiled laundry.	Cl	40	008	I	I
¹ The specified value is rounded	ded.					

Buttons

Below is an overview of the buttons and their setting options. The selection of programme settings depends on the selected programme. You can see the selection options for each programme in the overview for

— "Programmes", Page 22.

Button	Selection	Description
Start / Reload D 11	StartCancelPause	Start, cancel or pause the programme.
SpeedPerfect = (SpeedPerfect)	ActivateDeactivate	Activate or deactivate a short washing programme. Note: Energy consumption increases. The washing result is not affected by this.
Ready in (9)	1-24 hours	Set the programme end. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
Spin Speed ©	- 0 1000 rpm	Adjust the spin speed or deactivate the spin cycle. If - 0 - is selected, the water is drained and the spin cycle is deactivated at the end of the washing cycle. The laundry stays wet inside the drum.
Spin Speed ©	1000	Adjust the spin speed or activate – – (Rinse Hold). If – – is selected, the water is not drained at the end of the washing cycle and the spin cycle is deactivated. The laundry remains in the water used for rinsing.
c∞ 3 sec.	ActivateDeactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 32

Accessories

Only use original accessories. These have been made especially for your appliance. Here you can find an overview of your appliance's accessories and how to use them.

	Use	Order number
Water inlet hose extension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Longer water inlet hose	Replace the standard water inlet hose with a longer hose (2.20 m).	00353925
Elbow	Secure the water outlet hose in place.	00655300

Before using for the first time


Prepare the appliance for use.

Starting an empty washing cvcle


Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

Note: Please read the safety information \rightarrow Page 4 to ensure that you use the appliance safely.

1. Turn the programme selector to 90 °C Cottons .




- 2. Close the door.
- 3. Pull out the detergent drawer.




4. Pour approx. 1 litre of tap water into compartment II.

en Laundry




5. Pour washing powder into compartment II.



To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

6. Push in the detergent drawer.



- 7. Press **Start / Reload** DW to start the programme.
- The display shows the remaining programme duration.

- ✓ After the programme has ended, the display shows: "End" .
- Start the first wash cycle or set the programme selector to Off to switch off the appliance.
 - → "Basic operation", Page 29

Laundry

You can wash all items that the manufacturer has marked as machinewashable on the care label and fabrics made from hand-washable wool using your appliance.

Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

- Remove all items from any pockets in your laundry before using the appliance.
- To protect your appliance and the laundry, prepare the laundry beforehand.
 - Empty all pockets
 - Brush sand out of all collars and pockets
 - Close bed covers and cushion covers
 - Close all zips, Velcro fasteners, hooks and eyes
 - Tie cloth belts and apron strings together or use a mesh laundry bag
 - Remove curtain hooks and lead strips or use a mesh laundry bag
 - Use a mesh laundry bag for small items of laundry such as children's socks
 - Separate items of laundry and shake them out
 - Wash large and small items of laundry together

- Dab fresh stains with soapy water (do not rub them)
- Some stubborn or dried-in stains can be removed by washing several times

Sorting laundry

Note: Please read the safety information → Page 4 to ensure that you use the appliance safely.

- ► To improve washing results and prevent discolouration, sort the laundry according to the following criteria before washing.
 - Type of fabric and fibre type
 - Whites
 - Colours

Wash new coloured items separately the first time you wash them.

- Soiling → Page 27
- Care symbols on the care labels → Page 27

Degrees of soiling

Degree of soiling	Soiling	Examples
Light	No dirt or stains are visibleLaundry has absorbed odours	Light summer clothing or sports clothing that has been worn for a just a few hours
Normal	Dirt or light stains are visible	 T-shirts, shirts or blouses are sweat-soaked or have been worn a few times Towels or bedding that has been used for up to one week
Heavy	Dirt or stains are clearly visible	Tea towels, baby items or work clothing

Care symbols on the care labels

The symbols indicate the recommended programme and the numbers in the symbols indicate the maximum recommended washing temperature.

Symbol	Washing process	Recommended programme
ART ART ART ART	Normal	Cottons
ARTA ARTA ARTA	Gentle	Easy Care
##Y ##Y	Particularly gentle	Delicates/Silk for washing by hand
The state of the s	Hand wash	Wool
**	Not suitable for machine-washing	-

Tip: You can find more information about care symbols at www.ginetex.ch.

Detergents and care products

You can protect your appliance and your laundry by selecting and using the correct detergents and care products. You can use all detergents and care products which are suitable for domestic washing machines.

Note: Please read the safety information \rightarrow Page 4 to ensure that you use the appliance safely.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- Only use liquid detergents that are self-flowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products which have developed a top layer or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances (e.g. bleach)
- Use dyes sparingly as salt may damage stainless steel
- Do not use bleaching agents in the appliance

Detergent recommendation

This information is intended to help you to choose the right detergent for your items.

Fabrics	Detergent	Programme	Temperature	
Heat-resistant white fabrics made from cotton or linen			From cold up to 90 °C	
Coloured fabrics made from linen or cotton	Detergent for colours without bleach or optical brighteners	Cottons	From cold up to 60 °C	
Coloured fabrics made from easy-care fibres or synthetic materials	,	Easy Care	From cold up to 60 °C	
Delicate fabrics made from Delicates silk or viscose		Delicates/Silk	From cold up to 40 °C	
Wool	Detergent for woollens	Wool	From cold up to 40 °C	

Tip: Visit www.cleanright.eu to find further information on detergents, care products and cleaning agents for domestic use.

Detergent dosage

Use the correct detergent dosage to achieve optimal washing results and save resources.

The detergent dosage depends on:

- The amount of laundry
- Degree of soiling

Water hardness You can find out how hard your water is from your local water company or measure it yourself using a water hardness tester.

Water hardness

Hardness range	Total hardness in mmol/l	German degrees in °dH
soft (I)	0-1.5	0-8.4
medium (II)	1.5- 2.5	8.4-14
hard (III)	over 2.5	over 14

Example of a manufacturer's instructions for detergent

These example values refer to a standard load of 4-5 kg.

Soiling	Light	Normal	Heavy
Water hardness: Soft/medium	40 ml	55 ml	80 ml
Water hardness: Hard/very hard	55 ml	80 ml	105 ml

The dosages can be found on the manufacturer's packaging.


 Adjust the dosage to the actual load.

Basic operation

You can find out everything you need to know about operating your appliance here.


Switching on the appliance

▶ Turn the programme selector to a programme.



Setting a programme

1. Set the programme selector to the required programme → Page 22.



2. If necessary, adjust the programme settings → Page 30.

Adjusting the programme settings

Depending on the programme and programme progress, you can adjust or activate/deactivate the settings.

Note: Overview of all programme settings:

→ "Buttons", Page 24

Requirement: A programme has been set.

 Adjust the programme settings. The programme settings are not saved permanently for the programme.


Loading laundry

Notes

- Please read the safety information → Page 4 to ensure that you use the appliance safely.
- To prevent creasing, take note of the maximum load for the relevant programme → Page 22.

Requirement: Prepare and sort the laundry.

- → "Laundry", Page 26
- 1. Open the door.



- **2.** Ensure that the drum is empty.
- 3. Separate the laundry and place it in the drum.
- 4. Note: Ensure that there is no laundry trapped in the door. Close the door.

Adding detergent and care product

Note: Please read the safety information → Page 4 to ensure that you use the appliance safely.

Requirement: Find out the optimum dosage for detergent and care product. → Page 28

- 1. Pull out the detergent drawer.
- **2.** Pour in detergent.
 - → "Detergent drawer", Page 19
- 3. If required, add the care product.
- 4. Push in the detergent drawer.

Starting the programme

Note: If you want to change the time until the programme ends, set the "Ready in" time first.

- ▶ Press Start / Reload DM.
- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- ✓ The display shows either the programme duration or the "Ready in" time.

 After the programme has ended, the display shows: "End".

Adjusting the "Ready in" time before the programme starts

You can readjust the selected "Ready in" time before the programme starts.

- Press Start / Reload DM .
- 2. Press **Ready in** (2) repeatedly until the display indicates the desired "Ready in time.
- 3. Press Start / Reload DIII.

Soaking laundry

You can soak the laundry before washing in the appliance by pausing the programme.

Note: No additional detergent is reguired. The soaking solution is then used for washing.

- 1. Start the programme.
- 2. To pause the programme, after approx. 10 minutes, press Start / Reload DII.
- 3. To resume the programme, after the desired soaking time, press Start / Reload DM.

Adding laundry

Note: Please read the safety information → Page 4 to ensure that you use the appliance safely.

Press Start / Reload DM .

The appliance is paused and checks whether it is possible to add or remove laundry. Take note of the programme status.

- → "Display", Page 20
- 2. Add or remove laundry.
- **3.** Close the door.
- 4. Press Start / Reload DIII.

Cancelling the programme

Once the programme has started, you can cancel it at any time.

Note: Please read the safety information → Page 4 to ensure that you use the appliance safely.

- Press Start / Reload DM.
- 2. Open the door.

The appliance door remains locked for safety reasons if the temperature and water levels are hiah.

- If the temperature is high, start the **Rinse** programme.
- If the water level is high: Start the **Spin** or **Drain** programme.
- 3. Remove the laundry.


Resuming the programme when the programme status is Rinse Hold

- 1. Set the Spin or Drain programme.
- Press Start / Reload DM.

Unloading the laundry


Note: Please read the safety information \rightarrow Page 4 to ensure that you use the appliance safely.

- 1. Open the door.
- 2. Remove the laundry.



Switching off the appliance

1. Turn the programme selector to **Off** .



- 2. Turn off the tap.
- **3.** Wipe the rubber gasket dry and remove any foreign objects.



 Leave the door and detergent drawer open so that residual water can evaporate.

Childproof lock

Secure your appliance against being operated unintentionally using the controls.

Activating the childproof lock

- ► Press and hold the two c 3 sec. buttons for approx. 3 seconds.
- The controls are locked.

 The childproof lock remains active even after the appliance has been switched off.

Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.


- ► Press and hold the two c⇒ 3 sec. buttons for approx. 3 seconds. So that the programme currently running is not cancelled, the programme selector must be set to the initial programme.
- ✓ congoes out in the display.

Basic settings

You can configure the appliance to meet your needs.

Overview of the basic settings


Below is an overview of the basic settings on your appliance.



Basic setting	Programme position	Value	Description
End signal	2	0 (off) 1 (quiet) 2 (medium) 3 (loud) 4 (very loud)	Set the volume of the signal at the end of the programme.
Button signal	3	0 (off) 1 (quiet) 2 (medium) 3 (loud) 4 (very loud)	Set the volume of the audible signal emitted when selecting the buttons.

Changing the basic settings

1. Set the programme selector to position 1.



- 2. Press **Start** / **Reload** DM and, at the same time, turn the programme selector to position 2.
- The display shows the current value.
- **3.** Set the programme selector to the required position.
 - → "Overview of the basic settings", Page 33
- 4. To change the value, press **Ready** in .
- **5.** To save the changes, switch off the appliance.

Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

Tips on appliance care

Follow the tips for appliance care to ensure your appliance works correctly in the long term.

Wipe down the housing and the control panel with nothing but water and a damp cloth.	The appliance parts remain clean and hygienic.
Remove all detergent residue, spray residue or other residues immediately.	Fresh deposits are easier to remove without leaving any residue.
Keep the appliance door and detergent drawer open after use.	This allows the residual water to dry, reducing odours in the appliance.

Cleaning the drum


If you often wash at a washing temperature of 40 °C and lower or the appliance has not been used for a long period, clean the drum.

Run the 90 °C Cottons programme without laundry.
 Add washing powder.


Cleaning the detergent drawer

Note: Please read the safety information → *Page 4* to ensure that you use the appliance safely.


- 1. Pull out the detergent drawer.
- **2.** Press down on the insert and remove the detergent drawer.




3. Press out the insert upwards from below.



Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and lock it into place.



6. Cleaning the opening for the detergent drawer.



7. Push in the detergent drawer.

Descaling

If you add detergent correctly, you do not need to descale your appliance. If you still wish to use descaler, follow the manufacturer's instructions for use.

ATTENTION!

The use of unsuitable descaling agents, e.g. for coffee machines, may damage the appliance.

► For this appliance, only use descaling agents that are available from the manufacturer's website or our after-sales service.


Cleaning the drain pump

Clean the drain pump in the event of faults, e.g. blockages or rattling noises.

Emptying the drain pump


Note: Please read the safety information → Page 4 to ensure that you use the appliance safely.

- 1. Turn off the water tap.
- 2. Switch off the appliance.
- 3. Disconnect the appliance's mains plug from the power supply.
- 4. Open the maintenance flap.




5. Remove the maintenance flap.


en Cleaning and servicing



6. Push a receptacle under the opening.




7. Take the drain hose out of the holder.




- ► Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



9. Firmly press on the sealing cap.



10. Insert the drain hose into the holder.




Cleaning the drain pump


Note: Please read the safety information \rightarrow *Page 4* to ensure that you use the appliance safely.

Requirement: The drain pump is empty. → Page 35


1. Because water may remain in the drain pump, remove the pump cap carefully.



2. Clean the inside and the thread on the pump cap and pump housing.




- 3. Make sure that the impeller in the drain pump can be turned.
- 4. Insert the pump cap and screw it on.



The handle on the pump cap must be in a vertical position.

5. Insert the maintenance flap and lock it into place.



6. Close the maintenance flap.

Before the next wash

To prevent unused detergent from flowing straight into the outlet in the next wash, run the Drain programme after you have emptied the drain pump.


- 1. Turn on the tap.
- 2. Insert the mains plug.
- **3.** Switch on the appliance.
- 4. Pour 1 litre of water into compartment II.
- **5.** Start the **Drain** programme.

Cleaning the water outlet hose at the siphon

If the water outlet hose at the siphon is dirty or the detergent solution is not being pumped out, you must clean these.


- 1. Switch off the appliance.
- 2. Disconnect the appliance's mains plug from the power supply.
- 3. Loosen the hose clamp and carefully remove the water outlet hose.

en Cleaning and servicing




Residual water may leak out.

4. Clean the water outlet hose and siphon connecting piece.



5. Reattach the water outlet hose and secure the connection point using the hose clamp.



Clean the water inlet filters.

Clean the filter in the water inlet in the event of blockages or if the water pressure is too low.

Emptying the water inlet hose


- **1.** Turn off the tap.
- 2. Set a programme, except for Rinse, Spin or Drain.
- **3.** Start the programme and leave it to run for approx. 40 seconds.
- 4. Switch off the appliance.
- 5. Disconnect the appliance's mains plug from the power supply.

Cleaning the filter on the tap


Note: Please read the safety information → *Page 4* to ensure that you use the appliance safely.

Requirement: The water inlet hose is empty.


1. Remove the water inlet hose from the tap.



2. Clean the filter with a small brush.



3. Connect the water inlet hose and check for leaks.




Cleaning the filter on the appliance


Note: Please read the safety information → Page 4 to ensure that you use the appliance safely.

Requirement: The water inlet hose is empty.


- → "Emptying the water inlet hose", Page 38
- 1. Disconnect the hose from the rear of the appliance.



2. Use pliers to remove the filter.




3. Clean the filter with a small brush.



- 4. Reinsert the filter.
- 5. Connect the hose and check for leaks.

en Cleaning and servicing



Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.



. WARNING

Risk of electric shock!

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Error code / Fault display / Signal

Errors	Cause Troubleshooting		
The display goes out and Start / Reload DM flashes.	Energy-saving mode is active	Press any button.The symbol lights up again.	
"E:36 / -10"	Drain pipe or water outlet hose is blocked.	Clean the drain pipe and the water outlet hose.	
	Drain pipe or water drain hose is caught or jammed.	 Ensure that the drain pipe and water drain hose are not kinked or trapped. 	
	Drain pump is blocked.	► → "Cleaning the drain pump", Page 35	
	The water outlet hose is connected too high.	 Install the water outlet hose at a maximum height of 1 metre. → "Technical specifications", Page 51 	
"E:36 / -25 / -26"	Drain pump is blocked.	► → "Cleaning the drain pump", Page 35	
"E:60 / -2B"	The unbalanced load detection system has interrupted	Redistribute the laundry in the drum.	
	the spin cycle because the laundry is unevenly distributed.	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.	
^논	The water pressure is low.		
	The filters in the water inflow are blocked.	► Clean the filters in the water inflow → Page 38.	

en Troubleshooting

Errors	Cause	Troubleshooting		
是	The tap is turned off.	► Turn on the tap.		
	The water inlet hose is kinked or jammed.	► Ensure that the water inlet hose is not kinked or jammed.		
flashes.	The automatic voltage con-			
	trol system detects an unau- thorised voltage under-us- age.	Note: If the power supply is stable, the programme continues to run as normal.		
• flashes.	Voltage under-usage causes a programme extension.	No remedial action possible.		
lights up.	The temperature is too high.	Wait until the temperature has dropped.		
		► → "Cancelling the programme", Page 31		
	Water level is too high.	► Start the Drain programme.		
	Laundry is caught in the door.	 Open the door again. Remove any trapped laundry. Close the door. Press Start / Reload DW to start the programme. 		
© flashes.	Door is not closed.	 Close the door. Press Start / Reload DW to start the programme. 		
All other error codes.	Malfunction	► Call the after-sales service. → "Customer Service", Page 50		

Malfunctions

Errors	Cause Troubleshooting		
The appliance is not working.	The mains plug of the power cord is not plugged in.	Connect the appliance to the power supply.	
	The circuit breaker is faulty.	Check the circuit breaker in the fuse box.	
	There has been a power cut.	 Check whether the lighting in your kitchen or other appliances are working. 	
The programme does not start.	You have not pressed Start / Reload DM .	► Press Start / Reload D 1 1.	
	Door is not closed.	1. Close the door.	

Errors	Cause	Troubleshooting		
The programme does not start.		2 Press Start / Reload DM to start the programme.		
	Childproof lock is activated.	→ "Deactivating the childproof lock", Page 32		
	Ready in (3) is activated.	 Check whether Ready in ⑤ is activated. → "Buttons", Page 24 		
	Laundry is caught in the door.	 Open the door again. Remove any trapped laundry. Close the door. Press Start / Reload DW to start the programme. 		
The door cannot be opened.	"" is activated.	► Continue the programme by selecting Spin or Drain and pressing Start / Reload ▷ 𝔞 . → "Resuming the programme when the programme status is Rinse Hold", Page 31		
	The temperature is too high.	Wait until the temperature has dropped.		
		► → "Cancelling the programme", Page 31		
	Water level is too high.	► Start the Drain programme.		
	Power failure.	 Open the door using the emergency release. → "Emergency release", Page 48 		
The water is not draining.	Drain pipe or water outlet hose is blocked.	Clean the drain pipe and the water outlet hose.		
	Drain pipe or water drain hose is caught or jammed.	 Ensure that the drain pipe and water drain hose are not kinked or trapped. 		
	Drain pump is blocked.	► → "Cleaning the drain pump", Page 35		
	"" is activated.	► Continue the programme by selecting Spin or Drain and pressing Start / Reload ▷ 𝔰 . → "Resuming the programme when the programme status is Rinse Hold", Page 31		

en Troubleshooting

Errors	Cause	Troubleshooting	
The water is not draining.	The water outlet hose is connected too high.	 Install the water outlet hose at a maximum height of 1 metre. → "Technical specifications", Page 51 	
Water is not flowing in. Detergent is not being dis-	You have not pressed Start / Reload D0 .	► Press Start / Reload D 1 .	
pensed.	The filters in the water inflow are blocked.	► Clean the filters in the water inflow → Page 38.	
	The tap is turned off.	► Turn on the tap.	
	The water inlet hose is kinked or jammed.	► Ensure that the water inlet hose is not kinked or jammed.	
The spin cycle runs several	The unbalanced load detec-	► Not a fault – no action required.	
times.	tion system eliminates an imbalance by repeatedly redistributing the laundry.	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.	
The programme duration changes during the wash cycle.	The programme operation is optimised electronically. This may change the programme duration.	► Not a fault – no action required.	
	The unbalanced load detec-	► Not a fault – no action required.	
	tion system eliminates an imbalance by repeatedly redistributing the laundry.	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.	
	Foam detection system switches on a rinse cycle if foam build-up is too high.	► Not a fault – no action required.	
No water is visible in the drum.	Water is below the visible area.	► Not a fault – no action required.	
Drum jerks after the programme starts.	This is caused by an internal motor test.	► Not a fault – no action required.	
Residual water is present in the compartment %.	Insert in compartment & is blocked.	► → "Cleaning the detergent drawer", Page 34	
Vibrations and movement of the appliance whilst spinning.	Appliance is not correctly aligned.	→ "Aligning the appliance", Page 16	

Errors	Cause	Troubleshooting		
Vibrations and movement of the appliance whilst spinning.	The appliance feet are not fixed.	► Secure the appliance feet. → "Aligning the appliance", Page 16		
	Transit bolts have not been removed.	→ "Removing the transit bolts", Page 14		
Heavy foam build-up	Detergent dosage is too high.	► Immediate measure: Mix one table spoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear outems stuffed with down).		
		 Reduce the amount of detergent for the next washing cycle with the same load. 		
Drum does not turn, water	Load detection is active.	▶ Not a fault – no action required.		
does not flow in.		Note: The load detection can take up to two minutes.		

Noise

Errors	Cause Troubleshooting	
Rushing, hissing noise.	Water is flushed under pressure into the detergent drawer. Not a fault – normal operating noise.	
Banging noises, rattling in the drain pump.	Foreign bodies have got into the drain pump.	→ "Cleaning the drain pump", Page 35
Loud noises during the spin cycle.	Appliance is not correctly aligned.	► → "Aligning the appliance", Page 16
	The appliance feet are not fixed.	➤ Secure the appliance feet. → "Aligning the appliance", Page 16
	Transit bolts have not been removed.	➤ → "Removing the transit bolts", Page 14
Slurping, rhythmical suction noise.	The drain pump is active, the detergent solution is pumped out.	Not a fault – normal operating noise.

Problem with results

Errors	Cause Troubleshooting	
Creasing.	The spin speed is too high.	► The next time you run a wash cycle, set a lower spin speed.
	The load is too large.	► The next time you run a wash cycle, reduce the amount of laundry being loaded.
	The wrong programme is selected for the type of fabric.	➤ Select the programmes that are suitable for the type of fabric. → "Programmes", Page 22
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	Too much detergent/fabric softener in the detergent drawer.	When dosing liquid detergent and fabric softener, observe the mark- ing in the detergent drawer and do not dose above this.
The spin result is not satisfactory. The laundry is too wet/too damp.	A low spin speed is selected.	► The next time you run a wash cycle, set a higher spin speed.
	The unbalanced load detection system has interrupted	Redistribute the laundry in the drum.
	the spin cycle because the laundry is unevenly distributed.	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
Detergent residue on the damp washing.	Detergents may contain water-insoluble substances that deposit on the laundry.	► Start the Rinse programme.
Detergent residue on the dry laundry.	Detergents may contain water-insoluble substances that deposit on the laundry.	Brush out the laundry after washing and drying.

Leakage

Errors	Cause	Troubleshooting		
Water is leaking out at the water inlet hose.	Water inlet hose is not correctly/securely connected.	 Connect the water supply hose correctly. → "Connecting the water inlet hose", Page 15 Tighten the screw connection. 		
Water is leaking out at the water outlet hose.	The water outlet hose is damaged.	Replace the damaged water outlet hose.		

Errors	Cause	Troubleshooting
Water is leaking out at the water outlet hose.	Water outlet hose is not connected correctly.	► Connect the water outlet hose correctly. → "Water outlet connection types", Page 16

Odours

Errors	Cause	Troubleshooting	
Odours have formed in the appliance.	Humidity and detergent residue may promote the formation of bacteria.	► → "Cleaning the drum", Page 34	

Emergency release


To remove the laundry in the event of a power failure, for example, you can manually release the door.

Releasing the door

Requirement: The drain pump is empty. → Page 35

- 1. **ATTENTION!** Escaping water may cause material damage.
- ▶ Do not open the door if you can see water through the glass.

Pull the emergency release downwards with a tool and release.



- The door lock is released.
- 2. Insert the service flap and lock it into place.
- 3. Close the maintenance flap.

Transportation, storage and disposal

You can find out here how to prepare your appliance for transportation and storage. You will also find out how to dispose of old appliances.

Disposing of old appliance

Valuable raw materials can be reclaimed by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from openina.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- **2.** Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The auideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.


Removing the appliance

- 1. Turn off the tap.
- 2. → "Emptying the water inlet hose". Page 38.
- 3. Switch off the appliance.
- 4. Unplug the appliance's mains plug.
- 5. Drain the remaining detergent solution.
 - → "Cleaning the drain pump", Page 35
- 6. Detach the hoses.

Inserting the transit bolts


Secure the appliance for transportation using transit bolts in order to prevent damage.

- 1. Remove the four cover caps.
 - If necessary, use a screwdriver to remove the cover caps.




Keep the cover caps.


2. Insert the four sleeves.




3. Insert all screws into the four transit bolts and tighten slightly.



4. Insert the power cord into the holder ① and tighten all four screws for the transit bolts with a WAF 13 wrench 2.



5. Insert the hose into holder.



Using the appliance again

1. Remove the transit bolts → Page 14.

- Pour approx. 1 litre of water into compartment II in the detergent drawer.
- 3. Start the **Drain** programme.
- The unused detergent cannot flow straight into the outlet during the next wash.

Customer Service

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service.

You can solve many problems yourself by consulting the information on troubleshooting in these instructions or on our website. If this is not the case, contact our Customer Service. We will always find an appropriate solution and try to avoid unnecessary visits being made by a Customer Service technician.

With any warranty claims we will make sure that your appliance is repaired by trained Customer Service technicians using genuine spare parts, including after the manufacturer's warranty has expired. Detailed information about the warranty period and terms of warranty in your country are available from Customer Service, your dealer or our website.

When contacting Customer Service, you will need the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

Product number (E-Nr.) and production number (FD)

The product number (E-Nr.) and the production number (FD) can be found on the rating plate of the appliance.

Depending on the model, the rating plate can be found:

- on the inside of the door.
- on the inside of the service flap.
- on the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

Consumption values

The indicated consumption values are approximate.

The values may deviate from the indicated values depending on water pressure, water hardness, water inlet temperature, ambient temperature, type of laundry, amount and soiling of laundry, detergent used, fluctuations in the mains voltage and selected settings.

Program:	Temperat- ure (°C)	Load (kg)	Energy consumption (kWh) ¹	Water consumption (I)1	Programme duration (hours) ¹
Cottons	20	8	0,26	90	3
Cottons	40	8	1,00	90	3
Cottons	60	8	1,30	90	3
Cottons	90	8	2,30	100	3
EasyCare	40	4	0,78	62	2 1/2
Delicates / Silk	30	2	0,21	35	3/4
Wool 	30	2	0,20	41	3/4

¹ Values in accordance with the applicable version of IEC60456

Technical specifications

Facts and figures for your appliance can be found here.

Appliance height	850 mm
Appliance width	600 mm
Appliance depth	590 mm
Weight	70 kg ¹
Maximum load capacity	8 kg
Mains voltage	220 - 240 V, 50 Hz
→ Minimum installation protection	10 A
Rated power	2300 W
Power consumption	Off mode: 0,12 WLeft-on mode: 0,50 W

Depending on the appliance specifications

Water pressure	Minimum: 100 kPa (1 bar)Maximum: 1000 kPa (10 bar)
Length of the water in- let hose	150 cm
Length of the water outlet hose	150 cm
Length of the power cord	160 cm
Max. draining height	100 cm
Depending on the appliance specifications	



Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome**



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

Robert Bosch Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München GERMANY www.bosch-home.com



9001463275 (990930)