



Washing machine

WAU28PH1ES

[en]

User manual and installation instructions

Table of contents

10 Before using for the	
first time	. 36
10.1 Starting an empty washing	0.0
cycle	. 36
11 Laundry	. 37
11.4 Care symbols on the care labels	
nroducts	30
12.1 Detergent recommendation	. ა მ
	. 41
	. 41
	11
	. 4 1
	42
ance	. 43
14 Childproof look	42
14.1 Activating the children	. 43
Inck	43
lock	. 44
15 Intelligent dosing system	. 44
15.1 Filling the dispenser	
15.2 Dispenser contents	
15.3 Basic dosage	
	first time

		ome Connect	
		Home Connect settings	45
16.	2	Connecting the appliance	
		to a WLAN home network (Wi-Fi) with WPS function	16
16	3	Connecting the appliance	+0
10.	.0	to a WLAN home network	
		(Wi-Fi) without WPS func-	
		tion	46
16.	4	Connecting your appliance	47
16	_	to the Home Connect app Activating Wi-Fi on the ap-	4 /
10.	J	pliance	47
16.	6	Deactivating Wi-Fi on the	1 /
		appliance	48
		Software update	48
16.	8	Resetting the appliance	
40	^	network settings	48
16.	9	Data protection	48
17	В	asic settings	49
17.	.1	Overview of the basic set-	
	_	tings	49
17.	2	Changing the basic settings	10
		leaning and servicing	
18.	.1	Tips on appliance care	50
		Cleaning the drum	50
18.	3	Cleaning the detergent drawer	50
18	4	Descaling	
		Cleaning the drain pump	
		Cleaning the water outlet	
		hose at the siphon	
18.	7	Clean the water inlet filters	55
19	T	roubleshooting	58
20	Т	ransportation, storage and	
	d	isposal	69
		Removing the appliance	
		Inserting the transit bolts	
		Using the appliance again	
20	4	Disposing of old appliance	70

21 Customer Service	71
21.1 Product number (E-Nr.) and production number (FD)	71
22 Consumption values	72
23 Technical specifications	73
24 Declaration of Conformity	73



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- For washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- With tap water and commercially available detergents and care products suitable for washing machines.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Take note of the safety instructions when installing the appliance.

Improper installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ▶ When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ▶ If the power cord is too short, contact Customer Service.
- ▶ Only use adapters approved by the manufacturer.

⚠ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- ► Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- ➤ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

△ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

⚠ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ▶ Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- ► Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

▶ Do not touch the sharp edges on the appliance.

► Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call Customer Service. → Page 71
- ► Repairs to the appliance should only be carried out by trained specialist staff.

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

△ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of explosion!

Laundry that has been pretreated with cleaning agents that contain solvents may cause an explosion in the appliance.

► Rinse pretreated laundry thoroughly with water before washing.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

▶ Wait for the drum to come to a complete stop before reaching inside.

⚠ CAUTION – Risk of burns!

When washing at high temperatures, the glass in the appliance door becomes hot.

- ▶ Do not touch the appliance door when it is hot.
- ► Keep children away from the appliance door when it is hot.

△ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

▶ Do not touch the hot detergent solution.

△ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- ► Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

Take note of the safety instructions when cleaning and performing maintenance work on the appliance.

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

△ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

△ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

Follow these instructions to avoid material damage and damage to the appliance.

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- ► Observe the maximum load capacity → Page 27 for each programme and do not exceed it. The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.
- ▶ Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- Before transport, fit the transit bolts fully in order to prevent damage in transit.

Material damage may be caused if the water inlet hose is connected incorrectly.

- Tighten the screw connections on the water inlet until they are handtight.
- ► Ideally, connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions, valves or similar.
- ► Ensure that the inner diameter of the water tap is at least 17 mm.
- Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- ► Make sure that the water pressure in the water supply system is min. 100 kPa (1 bar) and max. 1000 kPa (10 bar).
- If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- ▶ Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- ▶ Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may cause material damage.

► Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appli-

- ▶ Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- ► Clean the appliance with nothing but water and a soft, damp cloth.
- Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recvcled.

► Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

Choose programmes with low temperatures and longer wash times and use maximum load capacity

- → Page 27.
- Energy consumption and water consumption is most efficient.

Use the economy programme settings.

If you adjust the programme settings for a programme, the display shows the expected consumption.

Add → Page 40 detergent based on the laundry's degree of soiling.

✓ For light to normal soiling, a smaller amount of detergent is sufficient. Observe the dosage recommendation from the detergent manufacturer.

Reduce the washing temperature for lightly and normally soiled laundry.

✓ At low temperatures, the appliance consumes less energy. For light to normal soiling, lower temperatures than indicated on the care label are also sufficient.

Set the maximum spin speed if you want to dry the laundry in a tumble dryer afterwards.

 ✓ The drier the laundry, the shorter the programme duration when drying which, in turn, reduces energy consumption. A higher spin speed reduces the residual moisture in the laundry and increases the volume of the spin noise.

Wash the laundry without prewash.

 Washing with prewash increases the programme duration and increases energy and water consumption.

The appliance has a continuous automatic load adjustment function.

✓ Depending on the type of fabric and load capacity, the continuous automatic load adjustment function optimally adjusts the water consumption and programme duration.

The appliance comes with an Aqua-Sensor.

✓ During the rinse cycle, the Aqua-Sensor checks the degree of turbidity of the rinsing water, and adjusts the duration and number of rinse cycles accordingly.

3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. All displays go out and DII flashes. Energy-saving mode ends when you use the appliance again, e.g. if you open or close the door. If you do not use the appliance for an extended period, the appliance switches off automatically.

Note: If Wi-Fi is activated, the appliance will not switch itself off automatically.

4 Installation and connection

4.1 Unpacking the appliance

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.


- ► Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- 1. Remove any packaging and protective covers completely from the appliance.

For the environmentally friendly disposal of the packaging materials, observe the information on the topic of

- → "Disposing of packaging", Page 11.
- 2. Check the appliance for visible damage.
- 3. Open the door. → "Basic operation", Page 41
- 4. Remove the accessory from the drum.
- 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.



- Washing machine
- Accompanying documents
- Water inlet hose
- Cover caps

4.3 Requirements for the installation location

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

▶ Do not operate the appliance without a cover cap.

WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

► Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 36 before using the appliance for the first time.

ATTENTION!

If the appliance is installed in areas exposed to frost or outdoors, frozen residual water may damage the appliance and frozen hoses may crack or split.

► Do not install or operate this appliance anywhere that is liable to experience frost and/or outdoors.

The appliance underwent a function test before leaving the factory and may, therefore, contain residual water. This residual water may leak out if the appliance is tilted at an angle greater than 40°.

Tilt the appliance carefully.

Installation loca- Requirements tion

On a base



Secure the appliance with fixing brackets


→ Page 36.

On a wooden joist floor



Place the appliance on a water-resistant wooden board which is screwed tightly to the floor. The wooden board should be at least 30 mm thick.


In a kitchen unit



- A niche width of 60 cm is reauired.
- Only install the appliance underneath a continuous worktop that is securely connected to adjacent cabinets.

Installation loca- Requirements tion

On a wall




Do not trap the hoses between the wall and the appliance.

4.4 Removing the transit bolts

The appliance is secured for transportation using transit bolts on the rear of the appliance.

Notes


- Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.
- Keep the transit bolts, screws and sleeves in a safe place for future transport → Page 69.
- 1. Pull the hoses out of the holders.




2. Unscrew ① and remove ② all four screws for the transit bolts with a WAF 13 wrench.




3. Pull the power cord out of the holder.




4. Remove the four sleeves.



5. Put on the four cover caps.




6. Press down on the four cover caps.




4.5 Connecting the appliance Connecting the water inlet hose Note

Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

1. Connect the water inlet hose.



2. Connect the water inlet hose to a tap (26.4 mm = 3/4").



3. Open the water tap carefully and check that the connection points are tight.

Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.


Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.

ATTENTION!

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

Secure the water outlet hose against unintentional loosening. **Note:** Observe the draining heights. The maximum draining height is 100 cm.

Drainage into a siphon



Secure the connection point with a (24–40 mm) hose clamp.

Drainage into a washbasin



Fix and secure the water outlet using an elbow. → Page 36

Drainage into a plastic pipe with rubber sleeve or into a gully.

Fix and secure the water outlet using an elbow. → Page 36




4.6 Aligning the appliance


In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

Note: Please read the information in the Safety → *Page 4* and Preventing material damage → *Page 10* sections to ensure that you use the appliance safely.

1. Loosen the lock nuts using a WAF 17 wrench by turning it in a clockwise direction.




2. To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

3. Screw the lock nuts tightly against the housing using a WAF 17 wrench



In doing so, hold the foot tight and do not adjust its height.

4.7 Connecting the appliance to the electricity supply


Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

- 1. Insert the mains plug of the appliance's power cable in a socket nearby.
 - The connection details of the appliance can be found under Technical data → Page 73.
- 2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance


You can find an overview of the parts of your appliance here.



On certain models, specific details such as the colour and shape may differ from those pictured.

Maintenance flap for the drain pump → Page 52
 Door
 Detergent drawer → Page 19
 Controls → Page 19
 Water outlet hose → Page 16
 Power cord → Page 17
 Transit bolts → Page 14


5.2 Detergent drawer



- Manual dosing compartment
- ⊗/ ∆: Dispenser for fabric softener or detergent
- ♦: Dispenser for detergent

5.3 Controls

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- Programmes → Page 27
- Programme selector → Page 41
- Buttons → Page 24 and display → Page 21


5.4 Operating logic

ATTENTION!

Pressing on the display with force may cause damage.


- ▶ Do not apply heavy pressure on the display.
- ▶ Do not press on the display using pointed or sharp objects.

en Familiarising yourself with your appliance



6 Display

The display shows the current settings, options or relevant information.



Display	Designation	Description
0:40 1	Programme duration/programme time remaining	Approximate expected programme duration or programme time remaining.
©10 ¹	"Ready in" time	The programme end has been set and the remaining number of hours is displayed. → "Buttons", Page 24
9 kg ¹	Recommended load	The maximum load capacity for the selected programme in kg.
<u>→</u>	Pretreatment	Programme status
	Wash	Programme status
	Rinse	Programme status
<u>©</u>	Spin	Programme status
End	End of pro- gramme	Programme status
+1 / +2 / +3	Extra Rinse	Additional rinse cycles are activated. → "Buttons", Page 26
₹	Energy consumption	Energy consumption for the selected programme. - : Low energy consumption - : High energy consumption
¹ Example		

en Display

Display	Designation	Description
Ö	Water consumption	Water consumption for the selected programme. — : Low water consumption — — : High water consumption
Q	End signal	Basic setting
d))	Button signal	Basic setting
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□<	Display brightness	Basic setting
©	Reminder to clean the drum	Flashes: Drum is dirty. Run the Limp. tambor ⊕ programme for cleaning and caring for the drum and the outer tub. → "Cleaning the drum", Page 50
<u></u>	Wi-Fi	 Lights up: The appliance is connected to your home network. Flashes: The appliance is trying to connect to your home network.
		→ "Home Connect ", Page 45
<u></u>	Dispenser for liquid detergent	 Lights up: The intelligent dosing system for liquid detergent is activated. Flashes: The fill level of the dispenser is below the minimum level. → "Intelligent dosing system", Page 44
		♦ (liquid detergent)
2 ♦ ₩	Dispenser for liquid detergent or fabric softener.	 Lights up: The intelligent dosing system for liquid detergent or fabric softener is activated. Flashes: The fill level of the dispenser is below the minimum level. → "Intelligent dosing system", Page 44
		♦ (liquid detergent)♦ (fabric softener)
50 ml ¹	Basic dosage	Basic dosage for detergent or fabric softener. → "Basic dosage", Page 45
:	Voltage control system	Flashes: The automatic voltage control system detects impermissible voltage drops. This will pause the programme. Note: The programme will continue when the voltage is permissible again.
¹ Example		

Display	Designation	Description
•	Voltage control system	Flashes: The programme has been paused because of impermissible voltage drops. The voltage is permissible again and the programme will continue. Note: The programme duration is extended.
# *	Foam detection system	The appliance has detected too much foam.
©	Door	 Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened.
	Тар	No water pressure.The water pressure is too low.
	Detergent drawer	The detergent drawer has not been pushed in fully.
E:35 / -10 ¹	Error	Error code, error display, signal.
¹ Example		

7 Buttons

The selection of programme settings depends on the selected programme. You can see the selection options for each programme in the overview for → "Programmes", Page 27.

Button	Selection	Description
DII (Start/Pause)	StartCancelPause	Start, cancel or pause the programme.
Speed	ActivateDeactivate	Activate or deactivate a short washing programme. Note: Energy consumption increases. The washing result is not affected by this.
ப் i-DOS	ActivateDeactivateBasic dosage	Briefly press the button to activate or deactivate the intelligent dosing system for liquid detergent O. Press the button for approx. 3 seconds to set the basic dosage. → "Intelligent dosing system", Page 44
i-DOS	ActivateDeactivateDispenser contentsBasic dosage	Briefly press the button to activate or deactivate the intelligent dosing system for fabric softener ⊗ or liquid detergent o. Press the button for approx. 3 seconds to specify the contents of the dispenser or set the basic dosage. → "Intelligent dosing system", Page 44
一/十(Finish in)	1-24 hours	Set the programme end. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed. Note: Use the buttons to set the setting values.
	* − 90 °C	Adjust the temperature in °C.

Button	Selection	Description
Ø - 1400 (Spin)	Ø − 1400 rpm	Adjust the spin speed or deactivate the spin cycle. If \mathscr{O} is selected, the water is drained and the spin cycle is deactivated at the end of the washing cycle. The laundry stays wet inside the drum.
① (mains switch)	Switch onSwitch off	Switch the appliance on or off.
☐ (Remote Start)	 Activate Deactivate Open the Home Connect menu 	If you briefly press the button, the appliance will be enabled for remote start via the Home Connect app If you press the button for approx. 3 seconds, the Home Connect menu opens. Notes Remote start cannot be activated for safety reasons in the following circumstances: The door is open. The detergent drawer has not been pushed in fully. Remote start is deactivated for safety reasons in the following circumstances: Open the door. Press D. Switch off the appliance. Following a power cut.
C=3s (Child Lock 3 sec.)	ActivateDeactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 43
(Basic Settings)	Basic settings	Change the basic settings for the appliance.

en Buttons

Button	Selection	Description
Ů (Prewash)	ActivateDeactivate	Activate or deactivate prewash, e.g. for washing heavily soiled laundry. Note: If the intelligent dosing system is activated, the detergent will be dispensed automatically for the prewash and the main wash. If the intelligent dosing system is deactivated, place the detergent for the prewash directly in the drum.
(Rinse Plus)	ActivateDeactivate	Activate or deactivate up to three additional rinse cycles. Recommended for particularly sensitive skin or in regions with very soft water.
₩ (Rinse Hold)	ActivateDeactivate	Activate or deactivate spinning and draining at the end of the washing cycle. The laundry remains in the water after the last rinse cycle.
₩ (Soak)	ActivateDeactivate	Activate or deactivate soaking. Before the main wash cycle starts, the laundry remains in the water for longer. For laundry with particularly stubborn soiling.
a (Easy Iron)	ActivateDeactivate	Activate or deactivate the reduced creasing programme. In order to reduce creasing in the laundry, the spin cycle and the spin speed are adapted. The laundry is damp enough after washing that it needs to be hung out on a washing line.
☆ (Memory)	SavingSetting	Press the button for approx. 3 seconds to save your customised program settings. → "Saving the programme settings", Page 41 If you briefly press the button, you can set customised program settings for your program.

8 Programmes

Below is an overview of the programmes. You can find information on the load and on the adjustable programme options.

Tip: The laundry's care labels provide you with additional information on programme selection. → "Care symbols on the care labels", Page 39

Programme	Description	Ma			P	Programme settings	ne setti	ings			
		ax. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	Speed		L		<u>a</u>	ப்i-DOS ்	ப்-DOS ⊛
Algodón/Algodão (\$ (Cottons)	Wash hard-wearing items made from cotton, linen or blended fabrics. Also suitable as a short programme for normally soiled laundry when you activate Speed. If Speed is activated, the maximum load capacity is reduced to 5 kg.	0	90	1400	•	•	•	•	•	•	•
Algod. color/ Algod. cor & (Cottons Col- our)	Wash hard-wearing items made from cotton, linen or blended fabrics. Energy-saving programme.	6	90	1400	_	•	•	•	•	•	•
¹ Programme setting	etting										

Programme	Description	Mo			Progr	Programme settings	setti	ngs			
	x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) ¹	Speed					<u>a</u>	ப்i-DOS ்	்பi-DOS ⊛
	Note: To save energy, the actual washing temperature may deviate from the set washing temperature. The washing performance meets legal requirements.										
Eco 40-60	Wash items made from cot- 9 ton, linen or blended fabrics. Note: Textiles which can be washed from 40 °C var up to 60 °C var as per the care symbol can be washed together. The washing performance corresponds to the best possible washing performance class according to the legal requirements.	_	1400	_	•	•	•	•	•	•	•
¹ Programme setting	setting										

Programme	Description			P.	ogram	Programme settings	tings			
	x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	Speed Speed				2	ப்i-DOS ்	ப்-DOS ⊛
	For this programme, the washing temperature is automatically adjusted depending on the load size, in order to achieve the best possible energy efficiency with the best possible washing result. You cannot change the washing temperature.									
Sintéticos 合 (Easy Care)	Wash items made from syn-4 thetic or blended fabrics.	60	1200	•	•	•	•	•	•	•
Mix 協M (Mixed Fabrics)	Wash items made from cotton, linen, or synthetic or blended fabrics. Suitable for lightly soiled laundry.	60	1400	•	•	•	•	•	•	•
¹ Programme setting	etting									

Programme	Description	Ма			Prog	Programme settings	settin	sbu			
		x. load (kg)	(rpm) ' Max. temperature (°C)	Speed Max. spin speed (rpm) 1					 <u>a</u>	ப்i-DOS ்	i-DOS ⊛
Delicado/ Seda 🌬 (Delicate/Silk)	Wash delicate, washable items made from silk, viscose and synthetics. Use a detergent that is suitable for delicates or silk. Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag.	Q	40	800	•	•	•	•	•	•	•
Lana/Lās (Wool)	Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool.	Q	40	800	_	•	_	_	_	_	•
1 Programme setting	etting	-									

Programme	Description	Ma			Progra	ımme	Programme settings	gs			
		Max. temperature (°C) x. load (kg)	Max. spin speed (rpm) 1	Speed					 <u>교</u>	Ůi-DOS ◊	ا ك i-DOS ⊛
æ (Rinse)	Rinses and then spins the laundry, and then drains the water.	_	1400	_	•	•	_	_	•	_	•
⑤/零 (Spin/ Drain)	Spins and drains the water. If you only want to drain the water, activate . The laundry is not spun.	_	1400	_	_	_	_	_	•	_	_
Programas app ப் (App Programs)	Select additional programmes directly via the Home Connect app. A description of the programmes can be found in the Home Connect app. The selectable programme settings depend on the selectings depend on the selected programme. Note: Your appliance must be connected to your home network and registered in	_	_	_	_	_	_	_	_	_	-
¹ Programme s	setting										

Programme	Description			-	Programme settings	me seti	ings			
	x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	Speed				<u>a</u>	ப்i-DOS ்	ுi-DOS ⊛
	your Home Connect app. → "Home Connect ", Page 45									
Automático delicado \array (Automatic Soft)	Wash delicate items made 3,5 from cotton, synthetic or blended fabrics. Gentle laundry care. The degree of soiling and the type of fabric are automatically detected. The washing process is adapted.	-	1000	-	_	_	_	- -	•	•
Limp. tam- bor & (Drum Clean)	Cleaning and caring for the drum. Use this programme in the following cases: Before using the appliance for the first time If you regularly wash at temperatures of 40 °C or lower	-	1200	_	_	_	_	- -	_	_
1 Programme setting	setting									

Programme	Description	Ma			Progr	amm	Programme settings	ings			
	x. Ioad (kg)	Max. temperature (°C) x. load (kg)	Max. spin speed (rpm) 1	Speed					<u>a</u>	ப்i-DOS ்	்பi-DOS ⊛
	 After a prolonged period of non-use 										
	Use washing powder or a de-										
	Halve the amount of deter-										
	gent to avoid foaming.										
	Do not use labric sollener. Do not use liquid detergent										
	or detergent that is intended for woollens or delicates.										
	Note: The drum cleaning in-										
	dicator will flash to remind you if you have not used a										
	programme at 60 °C or higher for a long time.										
1 Programme s	setting										

Programme	Description	Ма			Progr	Programme settings	settir	sbu			
		x. load (kg)	Max. spin speed (rpm) ¹ Max. temperature (°C)	Speed Max spin speed					 골	ப்i-DOS ்	ار2 i-DOS ⊛
Camisas/Blusas @(Shirts)	Wash non-iron shirts and blouses made from cotton, linen, synthetic or blended fabrics. Tip: In order to avoid creasing in your laundry, you can activate ⊇. The laundry is only given a short spin and can be removed while still dripping wet. Hang out shirts and blouses while they are still dripping wet so that they drip dry. Note: Use the Delicado/Seda tapprogramme to wash shirts and blouses made from silk or delicate fabrics.	0	60	800	•	•	•	•	•	•	•
¹ Programme setting	setting										

Programme	Description	NA.		6	Programme settings	me sett	inds			
	ax. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	Speed				<u>a</u>	ப்i-DOS ்	ك i-DOS ↔
Rápido 15/30 min Ü (Super Quick 15'/30')	Wash items made from cot- ton, synthetic or blended fab- rics. Short programme for small items of lightly soiled laundry. The programme duration is approx. 30 minutes. If you wish to reduce the pro- gramme duration to 15 minutes, activate Speed. The maximum load is reduced to 2 kg.	40	1200	•	•	_	_	_	•	•
¹ Programme setting	etting									

9 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order number
Water inlet hose extension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Longer water inlet hose	Replace the standard water inlet hose with a longer hose (2.20 m).	00353925
Elbow	Secure the water outlet hose in place.	00655300

10 Before using for the first time


Prepare the appliance for use.

10.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.


1. Press ①.




It may take a few seconds for the appliance to switch on.

- 2. Set the **Limp. tambor** & programme.
- 3. Close the door.


4. Pull out the detergent drawer.



5. Pour approx. 1 litre of water into the manual dosing compartment.




6. Add washing powder to the manual dosing compartment.



To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

7. Push in the detergent drawer.



- 8. Press DII (Start/Pause) to start the programme.
- ✓ The display shows the remaining. programme duration.
- 9. Start the first wash cycle or press ① to switch off the appliance.
 - → "Basic operation". Page 41

11 Laundry

11.1 Preparing the laundry

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

- ► Remove all items from any pockets in your laundry before using the appliance.
- ► To protect your appliance and the laundry, prepare the laundry beforehand.
 - Empty any pockets
 - Brush sand out of all collars and pockets
 - Close bed covers and cushion covers

en Laundry

- Close all zips, Velcro fasteners, hooks and eyes
- Tie cloth belts, apron strings, etc. together or use a laundry bag.
- Remove curtain hooks and lead strips or use a mesh laundry bag
- Use a mesh laundry bag for small items of laundry, such as children's socks
- Some stubborn or dried-in stains can be removed by washing several times
- Wash large and small items of laundry together
- Do not rub fresh stains but dab them with soapy water
- Separate items of laundry and shake them out

11.2 Sorting laundry

Note: Please read the information in the Safety → *Page 4* and Preventing material damage → *Page 10* sections to ensure that you use the appliance safely.

- ► To improve washing results and prevent discolouration, sort the laundry according to the following criteria before washing.
 - Type of fabric and fibre Wash laundry of the same type of fabric and fibre together.
 - Care symbols on the care labels
 → Page 39
 - Description of the programmes
 → Page 27
 - Whites
 - Colours

Wash new coloured items separately the first time you wash them.

11.3 Degrees of soiling

Degree of soiling	Soiling	Examples
Light	No dirt or stains are visibleLaundry has absorbed odours	Light summer clothing or sports clothing that has been worn for a just a few hours
Normal	Dirt or light stains are visible	 T-shirts, shirts or blouses are sweat-soaked or have been worn a few times Towels or bedding that has been used for up to one week
Heavy	Dirt or stains are clearly visible	Tea towels, baby items or work clothing

11.4 Care symbols on the care labels

Washing care symbols

Symbol	Washing process	Recommended programme
<u> </u>	Normal	Cotton
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Gentle	Easy-Care
<u> </u>	Particularly gentle	Delicates/Silk for washing by hand
E	Hand wash	Wool
***	Not suitable for machine-washing	_

12 Detergents and care products

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- only use liquid detergents that are self-flowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed.
- Do not use products containing solvents, caustic agents or volatile substances (e.g. bleach)
- Use dyes sparingly as salt may damage stainless steel
- Do not use bleaching agents in the appliance

12.1 Detergent recommendation

Detergent	Fabrics	Pro- gramme	Temperature
Standard detergent with optical brighteners	Heat-resistant white fabrics made from cotton or linen	Cotton	From cold up to 90 °C
Detergent for colours without bleach or optical brighteners	Coloured fabrics made from linen or cotton	Cotton	From cold up to 60 °C
Detergent for colours/delicates without optical brighteners	Coloured fabrics made from easy-care fabrics or synthetic materials	Easy-Care	From cold up to 60 °C

en Detergents and care products

Detergent	Fabrics	Pro- gramme	Temperature
Detergent for delicates	Delicate fine textiles, silk or viscose	Delicates/ Silk	From cold up to 40 °C
Detergent for woollens	Wool	Wool	From cold up to 40 °C

Tip: Visit www.cleanright.eu to find further information on detergents, care products and cleaning agents for domestic use.

12.2 Detergent dosage

The detergent dosage depends on:

- The amount of laundry
- Degree of soiling
- Water hardness

You can find out how hard your water is from your local water company or measure it yourself using a water hardness tester.

Water hardness

Hardness range	Total hardness in mmol/	German degrees in °dH
soft (I)	0–1.5	0-8.4
medium (II)	1.5- 2.5	8.4-14
hard (III)	over 2.5	over 14

Example of a manufacturer's instructions for detergent

These example values refer to a standard load of 4–5 kg.

Soiling	Light	Normal	Heavy
Water hardness: Soft/medium	40 ml	55 ml	80 ml
Water hardness: Hard/very hard	55 ml	80 ml	105 ml

The dosages can be found on the manufacturer's packaging.


- If you are not using manual dosage, adjust the dosage to the actual load.
- If intelligent dosing is activated, do not adjust the dosage to the actual load capacity. The quantity of detergent and fabric softener is automatically calculated via the basic

dosage → Page 45 and the amount of laundry detected. The basic dosage setting must always comply with the dosage for a load of 4.5 kg.

13 Basic operation

13.1 Switching on the appliance

► Press ①.




It may take a few seconds for the appliance to switch on.

 ✓ The appliance performs an audible function test in the detergent drawer.

Note: The drum is lit up after the door is opened and closed and once the programme has started. The light goes out automatically.

13.2 Setting a programme

1. Set the programme selector to the required programme → Page 27.



2. If necessary, adjust the programme settings → Page 41.

13.3 Adjusting the programme settings

Depending on the programme and programme progress, you can adjust or activate/deactivate the settings.

Note: Overview of all programme settings:

Requirement: A programme has been set.

Adjust the programme settings. The programme settings are not saved permanently for the programme.

Note: The setting is saved if you activate or deactivate the intelligent dosing system.

13.4 Saving the programme settings

You can save your individual programme settings as favourites.

Requirements

- A programme has been set.
- The programme settings have been adjusted.
- ▶ Press and hold ☆ for approx. 3 seconds.

Press ☆ to call up the saved programme.

Note: To overwrite the saved programme, repeat the steps above.


13.5 Loading laundry

Notes

- Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.
- To prevent creasing, take note of the maximum load for the relevant programme → Page 27.

Requirement: Prepare and sort the laundry.

- → "Laundry", Page 37
- 1. Open the door.



- 2. Ensure that the drum is empty.
- **3.** Separate the laundry and place it in the drum.
- Note: Ensure that there is no laundry trapped in the door.
 Close the door.

13.6 Adding detergent and care product

For programmes in which intelligent dosing is not possible or desirable, you can add detergent to the manual dosing compartment.

Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.

Tip: In addition to intelligent dosing, you can also add additional care product for laundry, e.g. stain remover, starch or bleach, to the manual dosing compartment. Do not add any additional detergent to the manual dosing compartment to avoid overdosage and/or foaming.

Requirement: Find out the optimum dosage for detergent and care product.

- 1. Pull out the detergent drawer.
- 2. Pour in detergent.
 - → "Detergent drawer", Page 19
- 3. If required, add the care product.
- 4. Push in the detergent drawer.

13.7 Starting the programme

Note: If you want to change the time until the programme ends, set the "Ready in" time first.

- ► Press DII.
- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- The display shows either the programme duration or the "Ready in" time.

13.8 Adding laundry

Note: Please read the information in the Safety → *Page 4* and Preventing material damage → *Page 10* sections to ensure that you use the appliance safely.

1. Press DM.

The appliance is paused and checks whether it is possible to add or remove laundry. Take note of the programme status.

- 2. Add or remove laundry.
- 3. Close the door.
- 4. Press DII.

13.9 Cancelling the programme

Once the programme has started, you can cancel it at any time.

Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.

- 1. Press DII.
- 2. Open the door.


The appliance door remains locked for safety reasons if the temperature and water levels are hiah.

- If the temperature is high, start the programme.
- If the water level is high: Start the 6 or F programme.
- 3. Remove the laundry.

13.10 Unloading the laundry


Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

- 1. Open the door.
- 2. Remove the laundry.



13.11 Switching off the appliance

1. Press (1)



- 2. Turn off the tap.
- 3. Wipe the rubber gasket dry and remove any foreign objects.



4. Leave the door and detergent drawer open so that residual water can evaporate.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof lock

- ▶ Press and hold **3s** for approx. 3 seconds.
- The controls are locked.

 The childproof lock remains active even after the appliance has been switched off.

14.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

Press and hold c=3s for approx. 3 seconds.

15 Intelligent dosing system

The optimum quantities of liquid detergent and fabric softener are dispensed automatically depending on the programme and settings.

15.1 Filling the dispenser

Note

In order to use intelligent dosing, fill the dispenser.

- Fill the dispenser only with suitable detergent and care products.
- If you change the liquid detergent or fabric softener, empty and clean the dispenser beforehand.
 - → "Cleaning the detergent drawer", Page 50
- If you want to use both dispensers for liquid detergent, adjust the contents of the dispenser → Page 44.


Requirement: \lozenge / \otimes flashes.

1. Pull out the detergent drawer.

2. Open the dispenser lid.



- Pour liquid detergent ô and fabric softener ⊗ into the relevant dispensers.
 - → "Detergent drawer", Page 19



4. Close the dispenser lid.

Note: To prevent the detergent from drying out or drying up, do not leave the dispenser lid open for a long period of time.

- 5. Push in the detergent drawer.
- Adjust the basic dosage → Page 45.

15.2 Dispenser contents

Notes

- If you change the content of the dispenser, the basic dosage for this dispenser is reset.
- If you use both dispensers for liquid detergent, you must select a dispenser which is to be used during washing.

Adjusting the dispenser contents

- 1. Press and hold 2 i-DOS for approx. 3 seconds.
- **2.** To set ♦, press 2 **i-DOS**.
- ✓ The display shows δ.
- 3. To set ⊗, press 2 i-DOS again.
- **4.** To end the setting process, wait briefly.

15.3 Basic dosage

The basic dosage depends on the manufacturer's instructions for the detergent, the water hardness and the degree of soiling of the laundry. Always set a basic dosage that corresponds to the dosage for a standard load of 4.5 kg.

→ "Detergent dosage", Page 40

Adjusting the basic dosage

- Press and hold i-DOS for approx. 3 seconds.
- The display shows the basic dosage set for δ.
- 2. To adjust the setting, press / +.
- **3.** To end the setting process, wait briefly.

Note: To adjust the basic dosage for ⊕, repeat the steps with ② **i-DOS**.

16 Home Connect

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of

Home Connect services in your country. You can find information about this at: www.home-connect.com.

- → "Connecting the appliance to a WLAN home network (Wi-Fi) with WPS function", Page 46
- → "Connecting the appliance to a WLAN home network (Wi-Fi) without WPS function", Page 46

The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

Tips

- Please consult the documents supplied by Home Connect.
- Please also follow the instructions in the Home Connect app.

Notes

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app. → "Safety", Page 4
- Operating the appliance on the appliance itself always takes priority.
 During this time it is not possible to operate the appliance using the Home Connect app.

16.1 Home Connect settings


Adapt Home Connect to your needs. You can find the Home Connect settings in the basic settings for your appliance. Which settings the display shows will depend on whether Home Connect has been set up and whether the appliance is connected to your home network.

16.2 Connecting the appliance to a WLAN home network (Wi-Fi) with **WPS function**

Requirement: If your router has a WPS function, you can connect the appliance to your WLAN home network (Wi-Fi) automatically.

- 1. Press and hold of for approx. 3 seconds.
- ✓ The display shows Aut.
- 2. Press DII.
- 3. Press the WPS button on the router within the next 2 minutes. Take note of the information in the documents for your router.
- ✓

 ✓ flashes in the display.
- → The appliance attempts to connect to vour WLAN home network.
- ✓ If the display shows con and 🛜 lights up permanently, the appliance is connected to the home network.



- 4. If the display shows Home Connect Error, the appliance is not connected to the home network.
 - Check whether your appliance is in range of your home network.
 - Reconnect the appliance to the WLAN home network (Wi-Fi) with WPS function.
- 5. Connect your appliance to the Home Connect app. → Page 47

16.3 Connecting the appliance to a WLAN home network (Wi-Fi) without **WPS function**

If your router does not have a WPS function, you can connect the appliance to your WLAN home network (Wi-Fi) manually. The appliance briefly sets up its own Wi-Fi network. You can connect a mobile device to the WLAN network and transfer the network information for the WLAN home network (Wi-Fi) to your appliance.


Requirement: The Home Connect app is open and you have logged on.

- 1. Press and hold of for at least 3 seconds.
- ✓ The display shows Aut.
- 2. Set the programme to position 2.
- ✓ The display shows SAP.
- 3. Press DM.
- ▼ The appliance now sets up its own Wi-Fi network with the name (SSID) HomeConnect.



4. Call up the Wi-Fi settings on the mobile device.

- Connect the mobile device to the HomeConnect Wi-Fi network and enter the password (key) Home-Connect.
- Your mobile device now connects to the appliance. The connection process may take up to 60 seconds.



- 5. Open the Home Connect app on your mobile device and carry out the steps in the app.
- In the Home Connect app, enter the network name (SSID) and password (key) for your home network.
- Carry out the steps in the Home Connect app to connect the appliance.
- If the display shows con and fights up permanently, the appliance is connected to the home network.
- If the display shows Home Connect Error, the appliance is not connected to the home network.
 - Check whether your appliance is in range of your home network.
 - Reconnect the appliance to the WLAN home network (Wi-Fi) with WPS function.
- Connect your appliance to the Home Connect app → Page 47.

16.4 Connecting your appliance to the Home Connect app

Requirements

- The appliance is connected to the WLAN home network (Wi-Fi).
- The Home Connect app is open and you have logged on.
- **1.** Set the programme to position 3.
- ✓ The display shows APP.
- 2. Press DII.
- → The appliance connects to the Home Connect app.
- Once your appliance is displayed in the Home Connect app, carry out the last steps in the Home Connect app.
- If the display shows con, the appliance is connected to the Home Connect app.

16.5 Activating Wi-Fi on the appliance

Note: When Wi-Fi is activated, the energy consumption increases in comparison to the values specified in the consumption value table.

- 1. Press and hold \Box for approx. 3 seconds.
- 2. Set the programme to position 4.
- ✓ The display shows Con.
- 3. Press DII repeatedly until the display shows **on**.
- ✓ Wi-Fi is activated.

Notes

- If Wi-Fi is activated, the appliance will not switch itself off automatically.
- If Wi-Fi is activated, the appliance will not switch itself off automatically.

16.6 Deactivating Wi-Fi on the appliance

- **1.** Press and hold \Box for at least three seconds.
- 2. Set the programme to position 4.
- ✓ The display shows Con.
- 3. Press DII repeatedly until the display shows **oFF**.
- ✓ Wi-Fi is deactivated.

Note: If Wi-Fi is switched off and your appliance was previously connected to your home network, this connection will be re-established automatically when Wi-Fi is switched back on.

16.7 Software update

Requirement: The display shows.

- 1. Press and hold of for approx. 3 seconds.
- 2. Set the programme to position 6.
- ✓ UPd appears on the display.
- 3. Press DII.
- ▼ The software update is installed.
- If End is shown on the display, the software update is installed.

Note: The software update may take several minutes. Do not switch off the appliance while the software update is in progress.

16.8 Resetting the appliance network settings

- 1. Press and hold for at least 3 seconds.
- 2. Set the programme to position 5.
- ▼ The display shows rES.
- 3. Press DM.
- ✓ The display shows Yes.
- 4. Press DII.
- ✓ The network settings are reset.

If End is shown on the display, the network settings are reset.

Tip: If you wish to operate your appliance again via the Home Connect app, you will need to reconnect it to the Wi-Fi and to the Home Connect app.

16.9 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the Wi-Fi communication module installed).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous reset to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

Note: Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

17 Basic settings

You can configure the appliance to meet your needs.

17.1 Overview of the basic settings

Below is an overview of the basic settings on your appliance.

Basic setting	Symbol	Value	Description
End signal	Q	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	Set the volume of the signal at the end of the programme.
Button signal	4))	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	The volume of the audible signal emitted when the buttons are pressed.
Automatic switch-off	4	ON OFF	Activate or deactivate the "Automatic switch-off" function for the appliance. → "Save energy and conserve resources", Page 11 Note: If Wi-Fi is activated, the appliance will not switch itself off automatically.
Drum cleaning reminder	· ·	ON OFF	Activate or deactivate the reminder to clean the drum.
Display bright- ness	.	1 (low) 2 (me- dium) 3 (high) 4 (very high)	Set the display brightness.

17.2 Changing the basic settings

- 1. In order to set the basic settings, press the B button.
- 2. To set the required basic setting, press the button.
- ▼ The display shows the set basic setting and the current value.
- 3. To change the value, press -/+.

4. To exit the basic settings, switch off the appliance.

18 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

18.1 Tips on appliance care

Follow the tips for appliance care to ensure your appliance works correctly in the long term.

rectly in the long te	#1111 .
Wipe down the housing and the control panel with nothing but water and a damp cloth.	The appliance parts remain clean and hygienic.
Remove all detergent residue, spray residue or other residues immediately.	Fresh deposits are easier to remove without leaving any residue.
Keep the appliance door and detergent drawer open after use.	This allows the residual water to dry, reducing odours in the appliance.

18.2 Cleaning the drum

If you often wash at a washing temperature of 40 °C and lower or the appliance has not been used for a long period, clean the drum.

⚠ CAUTION Risk of injury!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.

- ► Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- Run the Limp. tambor ⊕ programme without laundry.
 Add washing powder.


18.3 Cleaning the detergent drawer

If you change detergent or the detergent drawer is dirty, clean the detergent drawer and the pump unit of the intelligent dosing system.


Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.

- 1. Switch off the appliance.
- 2. Pull out the detergent drawer.


3. Press down on the insert and remove the detergent drawer.




4. Remove the pump unit.




5. Unclip the detergent drawer lid and remove it.




6. Empty the detergent drawer.




- 7. ATTENTION! The pump unit contains electrical components.
- ▶ Do not clean the pump unit in the dishwasher and do not immerse it in water.
- ► Protect the electrical connection on the rear against water, detergent and fabric softener residue. Clean the pump unit with a damp cloth.




 Clean the detergent drawer and the lid with a soft, damp cloth or hand shower.




9. Dry the detergent drawer, lid and pump unit and reinsert them.





10. Clean the inside of the detergent drawer housing.



11. Push in the detergent drawer.

18.4 Descaling

If you add detergent correctly, you do not need to descale your appliance. If you still wish to use descaler, follow the manufacturer's instructions for use.

ATTENTION!

The use of unsuitable descaling agents, e.g. for coffee machines, may damage the appliance.

 For this appliance, only use descaling agents that are available from the manufacturer's website or our after-sales service.

18.5 Cleaning the drain pump


Clean the drain pump in the event of faults, e.g. blockages or rattling noises.

Emptying the drain pump


Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.

- 1. Turn off the water tap.
- 2. Switch off the appliance.


- **3.** Disconnect the appliance's mains plug from the power supply.
- 4. Open the maintenance flap.




5. Remove the maintenance flap.



6. Slide a sufficiently large receptacle under the opening.




7. Take the drain hose out of the holder.




- 8. A CAUTION Risk of scalding! When you wash at high temperatures, the detergent solution gets hot.
- ► Do not touch the hot detergent solution.

To allow the detergent solution to flow out into the container, remove the sealing cap.




9. Firmly press on the sealing cap.



en Cleaning and servicing

10. Insert the drain hose into the holder.




Cleaning the drain pump


Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.

Requirement: The drain pump is empty. → *Page 52*


 Since water may remain in the drain pump, remove the pump cap carefully.



Clean the interior, the thread on the pump cap and the pump housing.




- **3.** Make sure that the impeller in the drain pump can be rotated.
- 4. Insert the pump cap and screw it on as far as it will go.



The handle on the pump cap must be in a vertical position.

5. Insert the maintenance flap and lock it into place.



6. Close the maintenance flap.

Before the next wash


To prevent unused detergent from flowing straight into the outlet in the next wash, run the F programme after you have emptied the drain gump.

- 1. Turn on the tap.
- 2. Insert the mains plug.
- 3. Switch on the appliance.
- 4. Pour 1 litre of water into the manual dosing compartment.
- **5.** Start the \$\mathbb{F}\$ programme.

18.6 Cleaning the water outlet hose at the siphon


If the water outlet hose at the siphon is dirty or the detergent solution is not being pumped out, you must clean these.

- 1. Switch off the appliance.
- 2. Disconnect the appliance's mains plug from the power supply.
- 3. Loosen the hose clamp and carefully remove the water outlet hose.




Residual water may leak out.

4. Clean the water outlet hose and siphon connecting piece.



Reattach the water outlet hose and secure the connection point using the hose clamp.



18.7 Clean the water inlet filters.

Emptying the water inlet hose


- 1. Turn off the tap.
- 2. Set the Algodón/Algodão 🏗 programme.
- 3. Start the programme and leave it to run for approx. 70 seconds.
- 4. Switch off the appliance.
- 5. Disconnect the appliance's mains plug from the power supply.

Cleaning the filter on the tap


Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.

Requirement: The water inlet hose is empty.


1. Remove the water inlet hose from the tap.



2. Clean the filter with a small brush.



3. Connect the water inlet hose and check for leaks.




Cleaning the filter on the appliance


Note: Please read the information in the Safety → *Page 4* and Preventing material damage → *Page 10* sections to ensure that you use the appliance safely.

Requirement: The water inlet hose is empty.


- → "Emptying the water inlet hose", Page 55
- **1.** Disconnect the hose from the rear of the appliance.




2. Use pliers to remove the filter.



3. Clean the filter with a small brush.



- 4. Reinsert the filter.
- 5. Connect the hose and check for leaks.



19 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.



WARNING

Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.

hose.

▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

person in order to prevent any risk.	
Fault	Cause and troubleshooting
The display goes out and DIII flashes.	Energy-saving mode is active ► Press any button. ✓ The symbol lights up again.
"E:36 / -10"	Drain pipe or water outlet hose is blocked. • Clean the drain pipe and the water outlet hose.
	Drain pipe or water drain hose is caught or jammed.► Ensure that the drain pipe and water drain hose are not kinked or trapped.
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 52
	The water outlet hose is connected too high. ▶ Install the water outlet hose at a maximum height of 1 metre.
	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down). If intelligent dosing is activated, reduce the basic dosage → Page 45. If you dose manually, reduce the amount of detergent for the next washing cycle with the same load.
	Unapproved extension installed on the water drain

Fault	Cause and troubleshooting
"E:36 / -10"	 Remove any unapproved extensions from the water hose. Connecting the appliance
"E:36 / -25 / -26"	Drain pump is blocked. ► → "Cleaning the drain pump", Page 52
"E:10 / -00 / -10 / -20"	 The pump for the intelligent dosing system is blocked. 1. Switch off the appliance. 2. Clean the pump unit. → "Cleaning the detergent drawer", Page 50 3. If this indicator appears again, call our after-sales service. → "Customer Service", Page 71
	Note: You can start the washing programme if you deactivate the intelligent dosing system and dose manually. → "Buttons", Page 24
是	The water pressure is low. No remedial action possible.
	The filters in the water inflow are blocked. ► Clean the filters in the water inflow → Page 55.
	The tap is turned off. ► Turn on the tap.
	The water inlet hose is kinked or jammed.▶ Ensure that the water inlet hose is not kinked or jammed.
-	The detergent drawer has not been pushed in as far as it can go. Push the detergent drawer in as far as it will go.
	The pump unit is not inserted. 1. Insert the pump unit into the detergent drawer. → "Cleaning the detergent drawer", Page 50 2. Push the detergent drawer in as far as it will go.
: flashes.	The automatic voltage control system detects an unauthorised voltage under-usage. ▶ No remedial action possible.
	Note: If the power supply is stable, the programme continues to run as normal.
	Voltage under-usage may cause extension of a programme. No remedial action possible.

Fault	Cause and troubleshooting
**************************************	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down). If intelligent dosing is activated, reduce the basic dosage → Page 45. If you dose manually, reduce the amount of detergent for the next washing cycle with the same load.
© lights up.	The temperature is too high. ► Wait until the temperature has dropped. ► → "Cancelling the programme", Page 42 Water level is too high. ► Start the F programme.
	Laundry is caught in the door. 1. Open the door again. 2. Remove any trapped laundry. 3. Close the door. 4. Press DM to start the programme.
© flashes.	Door is not closed. 1. Close the door. 2. Press DII to start the programme.
All other error codes.	Malfunction ► Call the after-sales service. → "Customer Service", Page 71
The appliance is not working.	The mains plug of the power cord is not plugged in. Connect the appliance to the power supply.
	The circuit breaker is faulty. ► Check the circuit breaker in the fuse box.
	There has been a power cut. ► Check whether the lighting in your kitchen or other appliances are working.
The programme does not start.	You have not pressed DII. ► Press DII.
	Door is not closed. 1. Close the door. 2. Press DII to start the programme.
	Childproof lock is activated.

Fault	Cause and troubleshooting
The programme does	► → "Deactivating the childproof lock", Page 44
not start.	 / + is activated. Check whether - / + is activated. → "Buttons", Page 24
	 Laundry is caught in the door. Open the door again. Remove any trapped laundry. Close the door. Press ▷ II to start the programme.
	The detergent drawer has not been pushed in as far as it can go. Push the detergent drawer in as far as it will go.
	 The pump for the intelligent dosing system is blocked. 1. Switch off the appliance. 2. Clean the pump unit. → "Cleaning the detergent drawer", Page 50 3. If this indicator appears again, call our after-sales service. → "Customer Service", Page 71
	Note: You can start the washing programme if you deactivate the intelligent dosing system and dose manually. → "Buttons", Page 24
The door cannot be opened.	 is activated. Continue the programme by selecting ⑤ or ₮ and pressing ▷Ⅲ.
	The temperature is too high. ► Wait until the temperature has dropped. ► → "Cancelling the programme", Page 42
	Water level is too high. ► Start the F programme.
	Power failure. ► Open the door using the emergency release. → "Emergency release", Page 69
The water is not draining.	Drain pipe or water outlet hose is blocked. ► Clean the drain pipe and the water outlet hose.
	 Drain pipe or water drain hose is caught or jammed. ► Ensure that the drain pipe and water drain hose are not kinked or trapped.

Fault	Cause and troubleshooting		
The water is not draining.			
	▶ → "Cleaning the drain pump", Page 52		
	is activated. □		
	► Continue the programme by selecting ⑤ or ∜ and pressing ▷		
	The water outlet hose is connected too high. ► Install the water outlet hose at a maximum height of 1 metre.		
	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down). 		
	If intelligent dosing is activated, reduce the basic dosage → Page 45.		
	► If you dose manually, reduce the amount of detergent for the next washing cycle with the same load.		
	Unapproved extension installed on the water drain hose.Remove any unapproved extensions from the water		
	hose. Connecting the appliance		
Water is not flowing in. Detergent is not being dispensed.	You have not pressed DII. ▶ Press DII.		
	The filters in the water inflow are blocked. ► Clean the filters in the water inflow → Page 55.		
	The tap is turned off. ► Turn on the tap.		
	The water inlet hose is kinked or jammed.▶ Ensure that the water inlet hose is not kinked or jammed.		
The spin cycle runs several times.	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. Not a fault – no action required.		
	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		

Fault	Cause and troubleshooting			
The programme duration changes during the wash cycle.	The programme operation is optimised electronically. This may change the programme duration. ► Not a fault – no action required.			
	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. ▶ Not a fault – no action required.			
	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
	Foam detection system switches on a rinse cycle if foam build-up is too high. ▶ Not a fault – no action required.			
No water is visible in the drum.	 Water is below the visible area. Not a fault – no action required. Do not add any extra water to the appliance while is operating. 			
Drum jerks after the programme starts.	This is caused by an internal motor test. ► Not a fault – no action required.			
Vibrations and movement of the appliance whilst spinning.	Appliance is not correctly aligned. ▶ Aligning the appliance			
	The appliance feet are not fixed. ▶ Secure the appliance feet. Aligning the appliance			
	Transit bolts have not been removed. ▶ Removing the transit bolts			
Drum does not turn, water does not flow in.	Load detection is active. ► Not a fault – no action required.			
	Note: The load detection can take up to two minutes.			
Heavy foam build-up	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down). If intelligent dosing is activated, reduce the basic dosage → Page 45. If you dose manually, reduce the amount of deter- 			
1 i-DOS 2 i-DOS cannot be actuated.	gent for the next washing cycle with the same load. Intelligent dosing is not intended for this programme. Not a fault – no action required.			

Foult	Cause and traublesheating		
Fault 1 i-DOS 2 i-DOS	Cause and troubleshooting		
cannot be actuated.	Programme progress does not allow intelligent dosing.		
carriot be actuated.	No remedial action possible.		
High spin speed not	A low spin speed is selected.		
reached.	► The next time you run a wash cycle, set a higher spin speed.		
	 Select the programmes that are suitable for the type of fabric. → "Programmes", Page 27 		
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance. Redistribute the laundry in the drum.		
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	► Start the ⑤ programme.		
The spin programme does not start.	Drain pipe or water outlet hose is blocked. • Clean the drain pipe and the water outlet hose.		
	 Drain pipe or water drain hose is caught or jammed. ► Ensure that the drain pipe and water drain hose are not kinked or trapped. 		
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.		
	Redistribute the laundry in the drum.		
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	► Start the ⑤ programme.		
Rushing, hissing noise.	Water is flushed under pressure into the detergent drawer. ► Not a fault – normal operating noise.		
Longer, whirring noise	Intelligent dosing system dispenses detergent or care		
before the start of the wash cycle or fabric softening.	products. ► Not a fault – normal operating noise.		
Brief whirring noise after switching on the appliance.	Intelligent dosing system carries out a function test. ► Not a fault – normal operating noise.		

Fault	Cause and troubleshooting			
Loud noises during the spin cycle.	Appliance is not correctly aligned. Aligning the appliance			
	The appliance feet are not fixed. ▶ Secure the appliance feet. Aligning the appliance			
	Transit bolts have not been removed. ▶ Removing the transit bolts			
Banging noises, rattling in the drain pump.	Foreign bodies have got into the drain pump. ► → "Cleaning the drain pump", Page 52			
Slurping, rhythmical suction noise.	The drain pump is active, the detergent solution is pumped out. ► Not a fault – normal operating noise.			
Creasing.	The spin speed is too high.▶ The next time you run a wash cycle, set a lower spin speed.			
	The load is too large.▶ The next time you run a wash cycle, reduce the amount of laundry being loaded.			
	 The wrong programme is selected for the type of fabric. Select the programmes that are suitable for the type of fabric. → "Programmes", Page 27 			
The spin result is not satisfactory. The laundry is too wet/too damp.	 A low spin speed is selected. ► The next time you run a wash cycle, set a higher spin speed. ► Start the ⑤ programme. 			
	 ☐ is activated. Select the programmes that are suitable for the type of fabric. → "Programmes", Page 27 			
	Drain pipe or water outlet hose is blocked. ► Clean the drain pipe and the water outlet hose.			
	 Drain pipe or water drain hose is caught or jammed. ► Ensure that the drain pipe and water drain hose are not kinked or trapped. 			
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. • Redistribute the laundry in the drum.			

Fault	Cause and troubleshooting			
The spin result is not satisfactory. The laundry is too wet/too	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
damp.	► Start the ⑤ programme.			
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance. ▶ Redistribute the laundry in the drum.			
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
	► Start the ⑤ programme.			
Detergent residue on the damp washing.	Detergents may contain water-insoluble substances that deposit on the laundry. Start the programme.			
	Unsuitable detergent added to the dispenser of the intelligent dosing system. 1. Check whether the detergent used is suitable. 2. Drain the dispenser. → "Cleaning the detergent drawer", Page 50 3. Clean the dispenser. 4. Refill the dispenser. → "Filling the dispenser", Page 44			
	Basic dosage is not correctly adjusted. ► If intelligent dosing is activated, reduce the basic dosage → Page 45.			
Detergent residue on the dry laundry.	Detergents may contain water-insoluble substances that deposit on the laundry. Brush out the laundry after washing and drying.			
	Unsuitable detergent added to the dispenser of the intelligent dosing system. 1. Check whether the detergent used is suitable. 2. Drain the dispenser. → "Cleaning the detergent drawer", Page 50 3. Clean the dispenser. 4. Refill the dispenser. → "Filling the dispenser", Page 44 Basic dosage is not correctly adjusted.			
	 If intelligent dosing is activated, reduce the basic dosage → Page 45. 			

Fault	Cause and troubleshooting			
Insufficient cleaning.	sic dosage is not correctly adjusted. f intelligent dosing is activated, adjust the basic dosage → <i>Page 45</i> correctly.			
	 Detergent or care products have congealed in dispensers of the intelligent dosing system. 1. Check whether the detergent used is suitable. 2. Drain the dispenser. → "Cleaning the detergent drawer", Page 50 3. Clean the dispenser. 4. Refill the dispenser. → "Filling the dispenser", Page 44 			
	 Unsuitable detergent added to the dispenser of the intelligent dosing system. 1. Check whether the detergent used is suitable. 2. Drain the dispenser. → "Cleaning the detergent drawer", Page 50 3. Clean the dispenser. 4. Refill the dispenser. → "Filling the dispenser", Page 44 			
HomeConnect is not working correctly.	Different causes are possible. ► Go to www.home-connect.com.			
No connection to the home network.	Wi-Fi is switched off. ► → "Activating Wi-Fi on the appliance", Page 47			
	 Wi-Fi is activated but a connection to your home network cannot be established. 1. Ensure that the home network is available. 2. Reconnect the appliance to the home network. → "Connecting the appliance to a WLAN home network (Wi-Fi) with WPS function", Page 46 → "Connecting the appliance to a WLAN home network (Wi-Fi) without WPS function", Page 46 			
Water is leaking out at the water inlet hose.	 Water inlet hose is not correctly/securely connected. 1. Connect the water supply hose correctly. Connecting the water inlet hose 2. Tighten the screw connection. 			
Water is leaking out at the water outlet hose.	The water outlet hose is damaged. ▶ Replace the damaged water outlet hose.			
	Water outlet hose is not connected correctly. ► Connect the water outlet hose correctly. Water outlet connection types			

en Troubleshooting


Fault	Cause and troubleshooting	
Odours have formed in the appliance.	 Humidity and detergent residue may promote the formation of bacteria. ► → "Cleaning the drum", Page 50 ► If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate. 	

19.1 Emergency release

Releasing the door

Requirement: The drain pump is empty. → Page 52

- 1. **ATTENTION!** Escaping water may cause material damage.
- ▶ Do not open the door if you can see water through the glass. Pull the emergency release downwards with a tool and release.



- The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

20 Transportation, storage and disposal

You can find out here how to prepare your appliance for transportation and storage. You will also find out how to dispose of old appliances.

20.1 Removing the appliance


- 1. Turn off the tap.
- 2. → "Emptying the water inlet hose", Page 55.
- 3. Switch off the appliance.
- 4. Unplug the appliance's mains plug.

- 5. Drain the remaining detergent solution.
 - → "Cleaning the drain pump". Page 52
- 6. Detach the hoses.
- 7. Empty the dispensers.

20.2 Inserting the transit **bolts**


Secure the appliance for transportation using transit bolts in order to prevent damage.

- 1. Remove the four cover caps.
 - If necessary, use a screwdriver to remove the cover caps.




Keep the cover caps.


2. Insert the four sleeves.




3. Insert all screws into the four transit bolts and tighten slightly.



4. Insert the power cord into the holder ① and tighten all four screws for the transit bolts with a WAF 13 wrench ②.



5. Insert the hose into holder.



20.3 Using the appliance again

1. Remove the transit bolts.

- 2. Pour approx. 1 litre of water into the manual dosing compartment in the detergent drawer.
- **3.** Start the \mathcal{F} programme.
- The unused detergent cannot flow straight into the outlet during the next wash.

20.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- **1.** Unplug the appliance from the mains.
- 2. Cut through the power cord.
- Dispose of the appliance in an environmentally friendly manner.
 Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and elec-

tronic appliances (waste electrical and electronic equipment - WEEE). The auideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

21 Customer Service

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service.

You can solve many problems yourself by consulting the information on troubleshooting in these instructions or on our website. If this is not the case, contact our after-sales service. With any warranty claims, we will make sure that your appliance is repaired by trained after-sales technicians using genuine spare parts, including after the manufacturer's warranty has expired.

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

21.1 Product number (E-Nr.) and production number

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

22 Consumption values

The following information is provided in accordance with the EU Ecodesign Regulation. The values given for programs other than the **Eco 40-60** are indicative only and were determined in accordance with the applicable standard EN60456. The automatic dosing function has been deactivated for this purpose.

Note on the comparison test: Deactivate the automatic dosing function unless this function is the object of the test.

Programme	Load (kg)	Pro- gramm e dura- tion (hr:min	Energy con- sump- tion (kWh/ cycle) ¹	Water con- sump- tion (I/ cycle) ¹	Max- imum temper- ature (°C) 5 mins ¹	Spin speed (rpm) ¹	Residual moisture (%)1
Eco 40-60 ²	9,0	3:37	1,250	61,0	50	1400	50
Eco 40-60 ²	4,5	2:52	0,610	45,0	36	1400	50
Eco 40-60 ²	2,5	2:30	0,180	30,0	24	1400	54
Algodón/Al- godão 🛣 20 °C	9,0	3:28	0,370	90,0	23	1400	52
Algodón/Algodão 🏗 40 °C	9,0	3:28	1,350	90,0	45	1400	52
Algodón/Algodão 🏗 60 °C	9,0	3:28	1,450	90,0	55	1400	52
Algodón/Algodão 🏗 40 °C + 🗓	9,0	3:58	1,400	102,0	45	1400	52
Sintéticos 企 40 °C	4,0	2:28	0,780	61,0	44	1200	27
Mix % 40 °C	4,0	0:59	0,620	44,0	41	1400	53
	2,0	0:40	0,200	40,0	22	800	25

¹ Due to the influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions, the actual values may deviate from the stated values.

² Test programme in accordance with the EU Ecodesign Directive and the EU Energy Labelling Regulation with cold water (15 °C).

23 Technical specifications

Facts and figures for your appliance can be found here

can be found here.				
Appliance height	85,0 cm			
Appliance width	59,8 cm			
Appliance depth	59,0 cm			
Weight	80 kg ¹			
Maximum load	9 kg			
Mains voltage	220 - 240 V, 50 Hz			
Minimum installation protection	10 A			
Rated power	2300 W			
Power consumption	 Off mode: 0,10 W Left-on mode: 0,50 W Time until the networked standby mode is set (Wi-Fi): 5 Min. Networked standby mode (Wi-Fi): 1,20 W 			
Water pressure	Minimum: 100 kPa (1 bar)Maximum: 1000 kPa (10 bar)			
Length of the water inlet hose	150 cm			
Length of the water outlet hose	150 cm			

Depending on the appliance spe-

cifications

Depending on the appliance specifications

This product contains light sources from energy efficiency class F. These light sources are available as a spare part and must only be replaced by trained specialist staff.

More information about your model can be found online at https://energylabel.bsh-group.com¹. This web address is linked to the official EU EPREL product database. At the time of printing its web address had not vet been published. Please then follow the instructions on searching for models. The model identifier is made up of the characters before the slash in the product number (E-Nr.) on the rating plate. Alternatively you can also find the model identifier in the first line of the EU energy label.

24 Declaration of Conformity

Robert Bosch Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality meets the essential requirements and other relevant provisions of the Directive 2014/53/FU.

A detailed RED Declaration of Conformity can be found online at www.bosch-home.com among the additional documents on the product page for your appliance.




2.4 GHz band: 100 mW max. 5 GHz band: 100 mW max.

Length of the 160 cm power cord

Only applies to countries in the European Economic Area

en Declaration of Conformity



5 GHz WLAN (Wi-Fi): For indoor use only.





Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- · Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome**



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

Robert Bosch Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München GERMANY www.bosch-home.com



9001502600 (001214)

en