



Washing machine

WIW28541EU

[en]

User manual and installation instructions

Table of contents

1 Safety	10 Before using for the first time3
1.2 Intended use	10.1 Starting an empty washing cycle
1.4 Safe installation 5	
1.5 Safe use 7	11 Laundry 3
1.6 Safe cleaning and mainten-	11.1 Preparing the laundry 3
ance9	11.2 Sorting laundry 3
	11.3 Degrees of soiling
2 Preventing material damage 10	11.4 Care symbols on the care labels4
3 Environmental protection and	10 Determents and save
saving energy11	12 Detergents and care products 4
3.1 Disposing of packaging 11	
3.2 Save energy and conserve	12.1 Detergent recommendation 4
resources11	12.2 Detergent dosage 4
3.3 Energy saving mode11	13 Basic operation 4
4 Installation and connection 12	13.1 Switching on the appliance 4
4.1 Unpacking the appliance 12	13.2 Setting a programme 4
4.2 Contents of package	13.3 Adjusting the programme
4.3 Requirements for the install-	settings4
ation location13	13.4 Loading laundry 4
4.4 Removing the transit bolts 15	13.5 Using a measuring aid for
4.5 Tools for assembly16	liquid detergent 4
4.6 Installing the appliance 16	13.6 Use the measuring aid for
4.7 Connecting the appliance 21	liquid detergent4
4.8 Aligning the appliance22	13.7 Adding detergent and care
4.9 Connecting the appliance to	product 4
the electricity supply22	13.8 Starting the programme 4
E Comiliariaing vauraalf with	13.9 Adjusting the "Ready in" time before the programme
5 Familiarising yourself with your appliance24	starts4
5.1 Appliance 24	13.10 Soaking laundry 4
5.2 Detergent drawer	13.11 Adding laundry 4
5.3 Controls	13.12 Cancelling the pro-
3.3 CONTROIS23	gramme 4
6 Display 26	13.13 Resuming the programme
7 Buttons 28	when the programme
	status is Rinse Hold4
8 Programmes 30	13.14 Unloading the laundry 4
9 Accessories 37	13.15 Switching off the appli-
9 Accessories 37	ance 4

	hildproof lock	46
14.1	Activating the childproof lock	46
14.2	Deactivating the childproof lock	
	asic settings	47
15.1	Overview of the basic settings	47
15.2	Changing the basic settings	
	leaning and servicing	
	Tips on appliance care	
	Cleaning the drum	48
10.5	drawer	48
	Descaling	49
	Cleaning the drain pump	50
16.6	Cleaning the water outlet	
	hace at the cinhan	52
16.7	hose at the siphon	52
16.7	hose at the siphon	
	Cleaning the water inlet fil-	53
17 T 18 T	Cleaning the water inlet filter roubleshooting ransportation, storage and	53 54
17 T 18 T d	ransportation, storage and isposal	53 54 62
17 T 18 T d 18.1	roubleshootingransportation, storage and isposal	53 54 62 62
17 T 18 T d 18.1 18.2	ransportation, storage and isposal	53 54 62 62
17 T 18 T d 18.1 18.2 18.3	roubleshootingransportation, storage and isposal	53 54 62 62 63
17 T 18 T d 18.1 18.2 18.3 18.4	roubleshooting	53 54 62 62 63
17 T 18 T d 18.1 18.2 18.3 18.4	roubleshooting	53 54 62 62 63 63
17 T 18 T d 18.1 18.2 18.3 18.4 19 C 19.1	roubleshooting	53 54 62 62 63 63 64
17 T 18 T d 18.1 18.2 18.3 18.4 19 C 19.1	roubleshooting	53 54 62 62 63 63 64
17 T d 18.1 18.2 18.3 18.4 19 C 19.1 19.2 20 C	roubleshooting	53 54 62 63 63 64 64



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- For washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- With tap water and commercially available detergents and care products suitable for washing machines.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Take note of the safety instructions when installing the appliance.

Improper installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ▶ When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ▶ If the power cord is too short, contact Customer Service.
- ▶ Only use adapters approved by the manufacturer.

⚠ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- ► Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- ➤ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

△ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

⚠ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ▶ Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- ► Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

▶ Do not touch the sharp edges on the appliance.

► Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call Customer Service. → Page 64
- ► Repairs to the appliance should only be carried out by trained specialist staff.

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

△ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of explosion!

Laundry that has been pretreated with cleaning agents that contain solvents may cause an explosion in the appliance.

► Rinse pretreated laundry thoroughly with water before washing.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

▶ Wait for the drum to come to a complete stop before reaching inside.

⚠ CAUTION – Risk of burns!

When washing at high temperatures, the glass in the appliance door becomes hot.

- ▶ Do not touch the appliance door when it is hot.
- ► Keep children away from the appliance door when it is hot.

△ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

▶ Do not touch the hot detergent solution.

△ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- ► Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

Take note of the safety instructions when cleaning and performing maintenance work on the appliance.

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

△ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

△ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

Follow these instructions to avoid material damage and damage to the appliance.

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

► Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity → Page 30 for each programme and do not exceed it. The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.
- ▶ Before starting up the appliance. remove the transit bolts completely and keep them in a safe place.
- Before transport, fit the transit bolts fully in order to prevent damage in transit.

Material damage may be caused if the water inlet hose is connected incorrectly.

- Tighten the screw connections on the water inlet until they are handtight.
- ► Ideally, connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions, valves or similar.
- Make sure that the valve housing for the water inlet hose does not come into contact with its surroundings and is not subjected to any external forces.

- ▶ Ensure that the inner diameter of the water tap is at least 17 mm.
- ► Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- Make sure that the water pressure in the water supply system is min. 100 kPa (1 bar) and max. 1000 kPa (10 bar).
- ▶ If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- ▶ Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- ▶ Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may cause material damage.

 Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- ▶ Do not use harsh or abrasive detergents.
- ▶ Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.

 Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

Choose programmes with low temperatures and longer wash times and use maximum load capacity → Page 30.

 Energy consumption and water consumption is most efficient.

Add → Page 41 detergent based on the laundry's degree of soiling.

 For light to normal soiling, a smaller amount of detergent is sufficient. Observe the dosage recommendation from the detergent manufacturer.

Reduce the washing temperature for lightly and normally soiled laundry.

✓ At low temperatures, the appliance consumes less energy. For light to normal soiling, lower temperatures than indicated on the care label are also sufficient.

Set the maximum spin speed if you want to dry the laundry in a tumble dryer afterwards.

 ✓ The drier the laundry, the shorter the programme duration when drying which, in turn, reduces energy consumption. A higher spin speed reduces the residual moisture in the laundry and increases the volume of the spin noise.

Wash the laundry without prewash.

 Washing with prewash increases the programme duration and increases energy and water consumption.

The appliance has a continuous automatic load adjustment function.

✓ Depending on the type of fabric and load capacity, the continuous automatic load adjustment function optimally adjusts the water consumption and programme duration.

3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. All displays go out and Start/Reload DII flashes.

Energy-saving mode ends when you use the appliance again, e.g. if you open or close the door.

4 Installation and connection

4.1 Unpacking the appliance

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appli-


► Remove these objects, along with all supplied accessories, from the drum before starting the appliance. 1. Remove any packaging and protective covers completely from the appliance.

For the environmentally friendly disposal of the packaging materials, observe the information on the topic of

- → "Disposing of packaging", Page 11.
- 2. Check the appliance for visible damage.
- 3. Open the door. → "Basic operation", Page 42
- 4. Remove the accessory from the drum.
- 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.



- Washing machine
- Accompanying documents
- Elbow for fixing the water outlet hose
- Parts for the installation
- Cover caps

4.3 Requirements for the installation location

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

► Do not operate the appliance without a cover cap.

/!\ WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

► Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 37 before using the appliance for the first time.

ATTENTION!

If the appliance is installed in areas exposed to frost or outdoors, frozen residual water may damage the appliance and frozen hoses may crack or split.

▶ Do not install or operate this appliance anywhere that is liable to experience frost and/or outdoors.

The appliance underwent a function test before leaving the factory and may, therefore, contain residual water. This residual water may leak out if the appliance is tilted at an angle greater than 40°.

► Tilt the appliance carefully.

Installation loca- Requirements tion

On a base



Secure the appliance with fixing brackets → Page 37.


On a wooden ioist floor



Place the appliance on a waterresistant wooden board which is screwed tightly to the floor. The wooden board should be at least 30 mm thick.

Installation loca- Requirements tion

In a kitchen unit




 A niche width of 60 cm is reauired.

Only install the appliance underneath a continuous worktop that is securely connected to adiacent cabinets.

Note: The use of sliding plates → "Accessories". Page 37 makes it easier to slide the appliance into the recess. Moisten the sliding plates with a mixture of water and washing-up liquid before pushing the appliance in. Do not use grease or oil to do this.

On a wall




Do not trap the hoses between the wall and the appliance.

4.4 Removing the transit bolts

The appliance is secured for transportation using transit bolts on the rear of the appliance.

Notes


- Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.
- Keep the transit bolts, screws and sleeves in a safe place for future transport → Page 62.
- 1. Pull the hoses out of the holders.




2. Unscrew 1 and remove 2 all four screws for the transit bolts with a WAF 13 wrench.



3. Pull the power cord out of the holder.




4. Remove the four sleeves.



5. Put on the four cover caps.



6. Press down on the four cover caps.



4.5 Tools for assembly


You require the following tools for the assembly:

- Spirit level
- Wrench, WAF 13
- Wrench, WAF 17
- Forstner 35 mm drill bit
- 2 mm twist drill
- Screwdriver


4.6 Installing the appliance

Preparing the appliance


 To make it easier to slide in the appliance, turn in the appliance's rear feet until the appliance is on the runners.



2. Measure the built-in niche.




- 3. Lay the power cord as well as the water inlet and water drain hose.
- 4. Slide the appliance in and, at the same time, pull through the power cord, water inlet and water drain hose.




- Connect the water inlet hose.
 → "Connecting the water inlet hose", Page 21
- Connect the water drain hose.
 → "Water outlet connection types",
 Page 21

7. Unscrew the rear appliance feet.




- 8. Align the appliance using a spirit level.
 - → "Aligning the appliance", Page 22




Installing the cabinet door

Note: Metal elements may impair the function of the control panel. Do not use any cabinet doors with metal elements in the area of the control panel.

1. Hold the cabinet door at the reguired height on the appliance and mark the upper edge of the appliance on the inside of the door.




Mark on the top edge of the appliance at the left-hand stop




Mark on the top edge of the appliance at the right-hand stop

2. Using the mark for the top edge of the appliance on the inside of the door as a basis, mark the drill holes as follows.




Mark for the holes at the left-hand stop




Mark for the holes at the right-hand stop

3. At the previously marked points, use a Forstner 35 mm drill to drill the holes for the hinges. At the previously marked points, use a 2 mm twist drill to drill holes for the screws.




4. Insert the hinges into the holes and screw them in.




5. Screw on the counter plates for the magnetic catches.

6. Insert the hinges into the appliance 1 - 2.




- 7. Slide in the covering rail 3 and screw it in 4.
- 8. Put the magnetic catches on the appliance.




Aligning the cabinet door

Vertically aligning the cabinet door




Horizontally aligning the cabinet door




Installing the base panel


1. Insert the spacers for the base panel.



2. Measure dimension Z and dimension Y.




3. Screw the spacers in as per the dimensions.




4. **Note:** When inserting the base panel, ensure that, if the base panel is protruding or the cabinet panel is flush-mounted, the time-Light is not visible.

Install the base panel.



- 5. Connect the appliance to the power supply
 - → "Connecting the appliance to the electricity supply". Page 22.



4.7 Connecting the appliance


Connecting the water inlet hose

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

- ► Do not immerse the electrical AguaStop valve in water.
- 1. Connect the water inlet hose to a tap (26.4 mm = 3/4").



2. Open the water tap carefully and check that the connection points are tight.

Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.


ATTENTION!

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

► Secure the water outlet hose against unintentional loosening.

Note: Observe the draining heights. The maximum draining height is 100 cm

Drainage into a siphon



Secure the connection point with a (24-40 mm) hose clamp.

Drainage into a washbasin




Fix and secure the water outlet using an elbow.

Drainage into a plastic pipe with rubber sleeve or into a gully.

Fix and secure the water outlet using an elbow.

en Installation and connection




4.8 Aligning the appliance


In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.

 Loosen the lock nuts using a WAF 17 wrench by turning it in a clockwise direction.




2. To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

Screw the lock nuts tightly against the housing using a WAF 17 wrench.



In doing so, hold the foot tight and do not adjust its height.

4.9 Connecting the appliance to the electricity supply

Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.


 Insert the mains plug of the appliance's power cable in a socket nearby.

- The connection details of the appliance can be found under Technical data \rightarrow *Page* 67.
- 2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance


You can find an overview of the parts of your appliance here.



On certain models, specific details such as the colour and shape may differ from those pictured.

1	Maintenance flap for the drain pump → Page 50
2	Door
3	Detergent drawer → Page 25
4	Controls → Page 25
5	Water outlet hose → Page 21
6	Power cord → Page 22
7	Transit bolts → Page 15


8	Water inlet hose → Page 21
9	Emergency release → Page 62
10	TimeLight → Page 47
11	Drain hose → Page 50



- Measuring aid for liquid deter-
 - → "Using a measuring aid for liquid detergent", Page 43
- Compartment II:
 - Detergent for main wash
 - Water softener
 - Bleach
 - Stain remover
- Compartment \&:
 - Fabric softener
 - Liquid starch
 - Waterproofing agent
- 4 Compartment I:
 - Detergent for prewash
 - Hygiene detergent

5.3 Controls


You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- → Page 42
- Display → Page 26
- **Buttons**

6 Display

The display shows the current settings, options or relevant information.



Display	Designation	Description
0:40 1	Programme duration/programme time remaining	Approximate expected programme duration or programme time remaining.
10h ¹	"Ready in" time	The programme end has been set and the remaining number of hours is displayed. → "Buttons", Page 28
8 kg ¹	Recommended load	The maximum load capacity for the selected programme in kg.
1400	Spin speed	Set spin speed in rpm. → "Buttons", Page 28 0= No final spin, only draining : Rinse Hold, no draining
70	Temperature	Set temperature in °C. → "Buttons", Page 28 (cold)
_	Start/Pause	Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be started or continued.
	Wash	Programme status
¹ Example		

Display	Designation	Description
(EE)	Rinse	Programme status
<u>©</u>	Spin	Programme status
	Rinse Hold	Programme status
End	End of pro- gramme	Programme status
B	Childproof lock	 Lights up: The childproof lock is activated. Flashes: The childproof lock is active and the programme selector has been adjusted. → "Deactivating the childproof lock", Page 46
= ₩	SpeedPerfect	Short wash activated. → "Buttons", Page 28
©	Reminder to clean the drum	Flashes: Drum is dirty. Run the
*** ****	Foam detection system	The appliance has detected too much foam.
©	Door	 Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened.
是	Тар	No water pressure.The water pressure is too low.
E:35 / -10 ¹	Error	Error code, error display, signal.
¹ Example		

7 Buttons

The selection of programme settings depends on the selected programme. You can see the selection options for each programme in the overview for \rightarrow "Programmes", Page 30.

Button	Selection	Description
Start/Reload DW	StartCancelPause	Start, cancel or pause the programme.
Speed Perfect	ActivateDeactivate	Activate or deactivate a short washing programme. Note: Energy consumption increases. The washing result is not affected by this.
Finished in (9	1-24 hours	Set the programme end. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
Temp. &	70 °C	Adjust the temperature in °C.
Spin 6	1400	Adjust the spin speed or activate – – (Rinse Hold). If – – is selected, the water is not drained at the end of the washing cycle and the spin cycle is deactivated. The laundry remains in the water used for rinsing.
C∞ 3 sec.	ActivateDeactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 46
Start/Reload DII	Basic settings	Change the basic settings for the appliance.
Prewash Ů	ActivateDeactivate	Activate or deactivate prewash, e.g. for washing heavily soiled laundry.

Button	Selection	Description
Water/Rinse + 🏖	ActivateDeactivate	Activate or deactivate a washing programme with more water and an additional rinse cycle. Recommended for particularly sensitive skin or in regions with very soft water.

8 Programmes

Below is an overview of the programmes. You can find information on the load and on the adjustable programme options.

Tip: The laundry's care labels provide you with additional information on programme selection. \rightarrow "Care symbols on the care labels", Page 40

Programme	Description	Ма		Progr	Programme settings	settin	gs	
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	Speed Perfect	Water/Rinse + ⊕	Spin © (Rinse Hold)	Prewash
Cottons 🖟	Wash hard-wearing items made from cotton, linen or blended fabrics. Also suitable as a short programme for normally soiled laundry when you activate Speed Perfect. If Speed Perfect is activated, the maximum load capacity is reduced to 5 kg.	8	70	1400	•	•	•	•
Eco 40-60		8	_	14 00	_	•	•	•
¹ Programme setting	٥١							

Programme	Description	Ма		Pro	Programme settings	e settir	sbı	
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	Speed Perfect	Water/Rinse + 🏝	Spin © (Rinse Hold)	Prewash
	Wash items made from cotton, linen or blended fabrics. Note: Textiles which can be washed from 40 °C var up to 60 °C var as per the care symbol can be washed together. The washing performance corresponds to the best possible washing performance class according to the legal requirements. For this programme, the washing temperature is automatically adjusted depending on the load size, in order to achieve the best possible energy efficiency with the best possible washing result. You cannot change the washing temperature.							
Easy Care 숀	Wash items made from synthetic or blended fabrics.	4	60	1200	•	•	•	•
¹ Programme setting	Вu							

Programme	Description	Ma		Progran	Programme settings	ngs	
		x. load (kg)	Max. spin speed (rpm) ¹ Max. temperature (°C)	Speed Perfect	Water/Rinse + ∰	Spin © (Rinse Hold)	Prewash ⊎
Quick Mix 夞M	Wash items made from cotton, linen, 4 or synthetic or blended fabrics. Suitable for lightly soiled laundry.		60	1400	•	•	•
the Delicates/Silk	Wash delicate, washable items made 2 from silk, viscose and synthetics. Use a detergent that is suitable for delicates or silk. Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag.		40	800	_	•	•
₩ Mool ₩	Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool.		40	800	_	•	_
¹ Programme setting	5						

Programme	Description	Ма		Proç	Programme settings	settin	gs	
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	Speed Perfect	Water/Rinse + 🏝	Spin © (Rinse Hold)	Prewash
Rinse 📨	Rinses and then spins the laundry, and then drains the water.	ı	_	1400	_	•	•	_
© Spin/Drain ∜	Spins and drains the water. If you only want to drain the water, activate 0. The laundry is not spun.	ı	_	1400	_	_	_	_
🌶 Dark Wash	Wash dark-coloured and colour-intense items made from cotton or easy-care fabric, e.g. jeans. Turn laundry inside-out before washing. Use liquid detergent.	4	40	1200	•	•	•	•
♣ Down	Wash pillows, duvets or clothing stuffed with down and fillings with synthetic fibres. Wash large items separately. Use a detergent that is suitable for down or delicates. Use sparingly. Do not use fabric softener.	1	60	1200	_	•	•	_
¹ Programme setting	<u>ق</u> ر							

Programme	Description	Ma	a	Programme settings	ne settir	sbu	
	An roud (Mg)	Max. temperature (°C) x. load (kg)	Max. spin speed (rpm) 1	Speed Perfect	Water/Rinse + ∰	Spin ⊚ – –– (Rinse Hold)	Prewash
	Note: To prevent excessive foaming, remove air from laundry items by rolling them up before you wash them.						
Orum Clean Orum Clean	Cleaning and caring for the drum. Use this programme in the following cases: Before using the appliance for the first time If you regularly wash at temperatures of 40 °C or lower After a prolonged period of nonuse Use washing powder or a detergent containing bleach. Halve the amount of detergent to avoid foaming. Do not use fabric softener.		1200	-	_	_	_
¹ Programme setting	D)						

Programme	Description	Ma		Prog	Programme settings	settin	sbi	
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	Speed Perfect	Water/Rinse + 🏝	Spin © (Rinse Hold)	Prewash
	Do not use liquid detergent or detergent that is intended for woollens or delicates.							
	Note: The drum cleaning indicator will flash to remind you if you have not used a programme at 60 °C or higher for a long time.							
[‡] € Night Wash Mix	Wash items made from cotton, linen, 4 or synthetic or blended fabrics. Suitable for quiet washing at night. The audible signal at the end of the programme is deactivated and a reduced final spin speed set by default.		60	1400	•	•	•	•
	Wash non-iron shirts and blouses 2 made from cotton, linen, synthetic or blended fabrics. Note: Use the the Delicates/Silkprogramme to wash shirts and blouses made from silk or delicate fabrics.		60	800	_	•	•	•
¹ Programme setting	0							

Programme	Description		Proé	Programme settings	e settin	gs	
	x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	Speed Perfect	Water/Rinse + 🏝	Spin © (Rinse Hold)	Prewash
	Wash sports and leisure items made 2 from synthetic fibres, microfibre or fleece. Use a detergent that is suitable for sports items. Do not use fabric softener. Tip: Use the Easy Care ��programme to wash heavily soiled laundry.	40	800	_	•	•	•
Su- per Quick 15/30' (Wash items made from cotton, syn- Thetic or blended fabrics. Short programme for small items of lightly soiled laundry. The programme duration is approx. The programme duration is approx. If you wish to reduce the programme duration to 15 minutes, activate Speed Perfect. The maximum load is reduced to 2 kg.	40	1200	•	•	•	_
¹ Programme setting	ĎL.						

9 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order number
Water inlet hose extension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Liquid detergent insert	Measure liquid detergent.	00605740
Slide sheets	Makes it easier to insert the appliance into the in- stallation recess.	00661827
Taller feet	Taller feet for installing the appliance under a high worktop.	WMZ20441

10 Before using for the first time


Prepare the appliance for use.

10.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.


1. Turn the programme selector to Prum Clean.




2. Close the door.

en Laundry


3. Pull out the detergent drawer.




4. Pour approx. 1 litre of tap water into compartment II.



5. Pour washing powder into compartment II.



To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates. 6. Push in the detergent drawer.



- **7.** Press **Start/Reload** D**1** to start the programme.
- The display shows the remaining programme duration.
- In each case, the TimeLight alternately shows the remaining programme duration and the current programme status on the floor.
- ✓ After the programme has ended, the display shows: "End".
- The TimeLight is projected onto the floor at the end of the programme.
- **8.** Start the first wash cycle or set the programme selector to **Off** to switch off the appliance.
 - → "Basic operation", Page 42

11 Laundry

11.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

- Remove all items from any pockets in your laundry before using the appliance.
- To protect your appliance and the laundry, prepare the laundry beforehand.
 - Empty all pockets

- Brush sand out of all collars and pockets
- Close bed covers and cushion covers
- Close all zips, Velcro fasteners, hooks and eyes
- Tie cloth belts and apron strings together or use a mesh laundry bag
- Remove curtain hooks and lead strips or use a mesh laundry bag
- Use a mesh laundry bag for small items of laundry such as children's socks
- Separate items of laundry and shake them out
- Wash large and small items of laundry together
- Dab fresh stains with soapy water (do not rub them)
- Some stubborn or dried-in stains can be removed by washing several times

11.2 Sorting laundry

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

- ▶ To improve washing results and prevent discolouration, sort the laundry according to the following criteria before washing.
 - Type of fabric and fibre type
 - Whites
 - Colours

Wash new coloured items separately the first time you wash them.

- Soiling → Page 39
- Care symbols on the care labels → Page 40

11.3 Degrees of soiling

Degree of soiling	Soiling	Examples
Light	No dirt or stains are visibleLaundry has absorbed odours	Light summer clothing or sports clothing that has been worn for a just a few hours
Normal	Dirt or light stains are visible	 T-shirts, shirts or blouses are sweat-soaked or have been worn a few times Towels or bedding that has been used for up to one week
Heavy	Dirt or stains are clearly visible	Tea towels, baby items or work clothing

11.4 Care symbols on the care labels

The symbols indicate the recommended programme and the numbers in the symbols indicate the maximum recommended washing temperature.

Symbol	Washing process	Recommended programme
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Normal	Cottons
<u> </u>	Gentle	Easy Care
<u> </u>	Particularly gentle	Delicates/Silk for washing by hand
5	Hand wash	Wool
**	Not suitable for machine-washing	_

Tip: You can find more information about care symbols at www.ginetex.ch.

12 Detergents and care products

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- only use liquid detergents that are self-flowing
- Do not mix different liquid deter-
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed.
- Do not use products containing solvents, caustic agents or volatile substances (e.g. bleach)
- Use dyes sparingly as salt may damage stainless steel
- Do not use bleaching agents in the appliance

12.1 Detergent recommendation

Detergent	Laundry	Pro- gramme	Temperature
Standard detergent with optical brighteners	Heat-resistant white fabrics made from cotton or linen	Cotton	From cold up to 90 °C
Detergent for colours without bleach or optical brighteners	Coloured fabrics made from linen or cotton	Cotton	From cold up to 60 °C

Detergent	Laundry	Pro- gramme	Temperature
Detergent for col- ours/delicates without optical brighteners	Coloured fabrics made from easy-care fabrics or synthetic materials	Easy Care	From cold up to 60 °C
Detergent for delicates	Delicate fine textiles, silk or viscose	Delicates/ Silk	From cold up to 40 °C
Detergent for woollens	Wool	Wool	From cold up to 40 °C

Tip: Visit www.cleanright.eu to find further information on detergents, care products and cleaning agents for domestic use.

12.2 Detergent dosage

The detergent dosage depends on:

- The amount of laundry
- Degree of soiling
- Water hardness

You can find out how hard your water is from your local water company or measure it yourself using a water hardness tester.

Water hardness

Hardness range	Total hardness in mmol/	German degrees in °dH
soft (I)	0–1.5	0-8.4
medium (II)	1.5- 2.5	8.4-14
hard (III)	over 2.5	over 14

Example of a manufacturer's instructions for detergent

These example values refer to a standard load of 4-5 kg.

Soiling	Light	Normal	Heavy
Water hardness: Soft/medium	40 ml	55 ml	80 ml
Water hardness: Hard/very hard	55 ml	80 ml	105 ml


The dosages can be found on the manufacturer's packaging.

 Adjust the dosage to the actual load.

13 Basic operation

13.1 Switching on the appliance


► Turn the programme selector to a programme.



Note: The drum is lit up after the door is opened and closed and once the programme has started. The light goes out automatically.

13.2 Setting a programme

1. Set the programme selector to the required programme → Page 30.



2. If necessary, adjust the programme settings → Page 42.

13.3 Adjusting the programme settings

Depending on the programme and programme progress, you can adjust or activate/deactivate the settings.

Note: Overview of all programme settings:

Requirement: A programme has been set.

 Adjust the programme settings. The programme settings are not saved permanently for the programme.


13.4 Loading laundry

Notes

- Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.
- To prevent creasing, take note of the maximum load for the relevant programme → Page 30.

Requirement: Prepare and sort the laundry.

- → "Laundry", Page 38
- 1. Open the door.



- 2. Ensure that the drum is empty.
- 3. Separate the laundry and place it in the drum


4. **Note:** Ensure that there is no laundry trapped in the door.

Close the door.


13.5 Using a measuring aid for liquid detergent

If you order the measuring aid as an accessory, you must use the measuring aid.


1. Pull out the detergent drawer.




2. Press down on the insert and remove the detergent drawer.



3. Insert the measuring aid.




4. Insert the detergent drawer.




13.6 Use the measuring aid for liquid detergent

To add liquid detergent, you can use a measuring aid in the detergent drawer.

- 1. Pull out the detergent drawer.
- 2. Slide the measuring aid forwards.



3. Fold the measuring aid down and click it into place.



4. Push in the detergent drawer.

13.7 Adding detergent and care product

Notes

- Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.
- Do not use the measuring aid for liquid detergent for gel detergents, washing powder, or if Prewash or "Ready in" time are activated.

Requirement: Find out the optimum dosage for detergent and care product. → *Page 40*

- 1. Pull out the detergent drawer.
- 2. Pour in detergent.
 - → "Detergent drawer", Page 25
- **3.** If required, add the care product.
- 4. Push in the detergent drawer.

13.8 Starting the programme

Note: If you want to change the time until the programme ends, set the "Ready in" time first.

▶ Press Start/Reload DM.

- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- The display shows either the programme duration or the "Ready in" time.
- In each case, the TimeLight alternately shows the remaining programme duration and the current programme status on the floor.
- After the programme has ended, the display shows: "End".
- The TimeLight is projected onto the floor at the end of the programme.

13.9 Adjusting the "Ready in" time before the programme starts

You can readjust the selected "Ready in" time before the programme starts.

- 1. Press Start/Reload DM.
- 2. Press **Finished in** ⁽¹⁾ repeatedly until the display indicates the desired "Ready in" time.
- 3. Press Start/Reload DII.

13.10 Soaking laundry

You can soak the laundry before washing in the appliance by pausing the programme.

Note: No additional detergent is required. The washing solution is then used for washing.

- 1. Start the programme.
- To pause the programme, after approx. 10 minutes, press Start/Reload DM.
- To resume the programme, after the desired soaking time, press Start/Reload DII.

13.11 Adding laundry

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safelv.

1. Press Start/Reload D.

The appliance is paused and checks whether it is possible to add or remove laundry. Take note of the programme status.

- 2. Add or remove laundry.
- 3. Close the door.
- 4. Press Start/Reload DM.

13.12 Cancelling the programme

Once the programme has started, vou can cancel it at any time.

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

- 1. Press Start/Reload DM.
- 2. Open the door.

The appliance door remains locked for safety reasons if the temperature and water levels are high.

- If the temperature is high, start the **Rinse** w programme.
- If the water level is high: Start the **Spin** or **Drain F** programme.
- 3. Remove the laundry.


13.13 Resuming the programme when the programme status is Rinse Hold

- 1. Set the Spin or Drain F programme.
- Press Start/Reload DM.

13.14 Unloading the laundry


Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

- 1. Open the door.
- 2. Remove the laundry.



13.15 Switching off the appliance

1. Turn the programme selector to **Off**.



2. Wipe the rubber gasket dry and remove any foreign objects.



Leave the door and detergent drawer open so that residual water can evaporate.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof lock

- ▶ Press and hold the two c→ 3 sec. buttons for approx. 3 seconds.

- ▼ The controls are locked.
- The childproof lock remains active even after the appliance has been switched off.

14.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.


- ▶ Press and hold the two c 3 sec. buttons for approx. 3 seconds.
- ✓ congoes out in the display.

15 Basic settings

You can configure the appliance to meet your needs.

15.1 Overview of the basic settings


Below is an overview of the basic settings on your appliance.



Basic setting	Programme position	Value	Description
End signal	2	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	Set the volume of the signal at the end of the programme.
Button signal	3	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	The volume of the audible signal emitted when the buttons are pressed.
Drum cleaning reminder	4	ON OFF	Activate or deactivate the reminder to clean the drum.
timeLight	5	ON OFF	Activate or deactivate timeLight (optical display for the programme information on the floor).

15.2 Changing the basic settings

Set the programme selector to position 1.



- 2. Press **Start/Reload** D**II** and, at the same time, turn the programme selector to position 2.
- The display shows the current value.
- **3.** Set the programme selector to the required position.
- **4.** To change the value, press **Finished in** ①.
- **5.** To save the changes, switch off the appliance.

16 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

16.1 Tips on appliance care

Follow the tips for appliance care to ensure your appliance works correctly in the long term.

Wipe down the housing and the control panel

The appliance parts remain clean and hygienic.

with nothing but water and a damp cloth.

Remove all detergent residue, spray residue or other residues immediately.

Fresh deposits are easier to remove without leaving any residue.

Keep the appliance door and detergent drawer open after use.

This allows the residual water to dry, reducing odours in the appliance.

16.2 Cleaning the drum

If you often wash at a washing temperature of 40 °C and lower or the appliance has not been used for a long period, clean the drum.

⚠ CAUTION Risk of injury!


Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.

- Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- Run the Drum Clean programme without laundry.
 Add washing powder.


16.3 Cleaning the detergent drawer

Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.


- **1.** Pull out the detergent drawer.
- 2. Press down on the insert and remove the detergent drawer.




3. Press out the insert upwards from below.



4. Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and lock it into place.



6. Cleaning the opening for the detergent drawer.



7. Push in the detergent drawer.

16.4 Descaling

If you add detergent correctly, you do not need to descale your appliance. If you still wish to use descaler, follow the manufacturer's instructions for use.

ATTENTION!

The use of unsuitable descaling agents, e.g. for coffee machines, may damage the appliance.

► For this appliance, only use descaling agents that are available from the manufacturer's website or our after-sales service.


16.5 Cleaning the drain pump

Clean the drain pump in the event of faults, e.g. blockages or rattling noises.


Emptying the drain pump

Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.


- 1. Turn off the water tap.
- 2. Switch off the appliance.
- **3.** Disconnect the appliance's mains plug from the power supply.
- **4.** Remove the base panel.



5. Slide a sufficiently large receptacle under the opening.




6. Take the drain hose out of the holder.




- 7. CAUTION Risk of scalding! When you wash at high temperatures, the detergent solution gets hot.
- ▶ Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



8. Firmly press on the sealing cap.



9. Insert the drain hose into the holder.




Cleaning the drain pump


Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

Requirement: The drain pump is empty.


- 1. Since water may remain in the drain pump, unscrew the pump cap carefully.
 - The filter insert in the pump housing may become stuck due to coarse particles of dirt. Loosen the dirt and remove the filter insert.



2. Clean the interior, the thread on the pump cap and the pump housing.



- 3. Make sure that the impeller in the drain pump can be rotated.
- 4. Insert the pump cap and screw it on.




The handle on the pump cap must be in a vertical position.

en Cleaning and servicing

5. Note: When inserting the base panel, ensure that, if the base panel is protruding or the cabinet panel is flush-mounted, the time-Light is not visible.

Install the base panel.



Before the next wash

To prevent unused detergent from flowing straight into the outlet in the next wash, run the **Drain** Forogramme after you have emptied the drain pump.


- 1. Turn on the tap.
- 2. Insert the mains plug.
- **3.** Switch on the appliance.
- Pour 1 litre of water into compartment II.
- **5.** Start the **Drain** \mathcal{F} programme.

16.6 Cleaning the water outlet hose at the siphon

If the water outlet hose at the siphon is dirty or the detergent solution is not being pumped out, you must clean these.


- 1. Switch off the appliance.
- 2. Disconnect the appliance's mains plug from the power supply.

3. Loosen the hose clamp and carefully remove the water outlet hose.




Residual water may leak out.

4. Clean the water outlet hose and siphon connecting piece.



5. Reattach the water outlet hose and secure the connection point using the hose clamp.



16.7 Cleaning the water inlet filter

Emptying the water inlet hose

In order to clean the filter, first empty the water inlet hose.


- 1. Turn off the tap.
- 2. Set a programme, except for Rinse , Spin or Drain .
- 3. Start the programme and leave it to run for approx. 40 seconds.
- 4. Switch off the appliance.
- 5. Disconnect the appliance's mains plug from the power supply.

Cleaning the filter on the tap


Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

Requirement: The water inlet hose is empty.


1. Remove the water inlet hose from the tap.



2. Clean the filter with a small brush.



3. Connect the water inlet hose and check for leaks.



17 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.



⚠ WARNING

Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting
The display goes out and Start/Reload D M flashes.	Energy-saving mode is active▶ Press any button.✔ The symbol lights up again.
"E:36 / -10"	Drain pipe or water outlet hose is blocked. • Clean the drain pipe and the water outlet hose.
	Drain pipe or water drain hose is caught or jammed.► Ensure that the drain pipe and water drain hose are not kinked or trapped.
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 50
	The water outlet hose is connected too high. ► Install the water outlet hose at a maximum height of 1 metre.
	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load.
	 Unapproved extension installed on the water drain hose. Remove any unapproved extensions from the water hose. Connecting the appliance
"E:36 / -25 / -26"	Drain pump is blocked. ► → "Cleaning the drain pump", Page 50

Fault	Cause and troubleshooting
是	The water pressure is low. No remedial action possible.
	The filter in the water inflow is blocked. ► Clean the water inflow filter → Page 53.
	The tap is turned off. ► Turn on the tap.
	The water inlet hose is kinked or jammed.Ensure that the water inlet hose is not kinked or jammed.
"E:35 / -10"	There is water in the base trough. ► Turn off the water tap. ► Call the after-sales service. → "Customer Service", Page 64
	The appliance is leaking. ► Turn off the water tap. ► Call the after-sales service. → "Customer Service", Page 64
~~~	<ul> <li>Detergent dosage is too high.</li> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down).</li> <li>Reduce the amount of detergent for the next washing cycle with the same load.</li> </ul>
C lights up.	The temperature is too high.  ► Wait until the temperature has dropped.  ► → "Cancelling the programme", Page 45
	Water level is too high.  ► Start the <b>Drain</b> ¥ programme.
	Laundry is caught in the door.  1. Open the door again.  2. Remove any trapped laundry.  3. Close the door.  4. Press Start/Reload DII to start the programme.
C flashes.	Door is not closed.  1. Close the door.  2. Press Start/Reload DII to start the programme.

#### en Troubleshooting

Fault	Cause and troubleshooting
All other error codes.	Malfunction  ► Call the after-sales service.  → "Customer Service", Page 64
The appliance is not working.	The mains plug of the power cord is not plugged in.  ▶ Connect the appliance to the power supply.
	The circuit breaker is faulty.  ► Check the circuit breaker in the fuse box.
	<ul><li>There has been a power cut.</li><li>► Check whether the lighting in your kitchen or other appliances are working.</li></ul>
The programme does not start.	You have not pressed <b>Start/Reload</b> D <b>I</b> II.  ▶ Press <b>Start/Reload</b> D <b>I</b> II.
	Door is not closed.  1. Close the door.  2. Press Start/Reload ▷ III to start the programme.
	Childproof lock is activated.  ► → "Deactivating the childproof lock", Page 46
	Finished in ⊕ is activated.  ► Check whether Finished in ⊕ is activated.  → "Buttons", Page 28
	Laundry is caught in the door.  1. Open the door again.  2. Remove any trapped laundry.  3. Close the door.  4. Press Start/Reload ▷ III to start the programme.
The door cannot be opened.	<ul> <li> is activated.</li> <li>Continue the programme by selecting ⑤ Spin or Drain ∜ and pressing Start/Reload ▷ ∅.</li> <li>→ "Resuming the programme when the programme status is Rinse Hold", Page 45</li> </ul>
	The temperature is too high.  ► Wait until the temperature has dropped.  ► → "Cancelling the programme", Page 45
	Water level is too high. ► Start the <b>Drain F</b> programme.
	Power failure.  ► Open the door using the emergency release.  → "Emergency release", Page 62

Foult	Course and troublesheating
Fault The water is not drain-	Drain pipe or water outlet hose is blocked.
ing.	► Clean the drain pipe and the water outlet hose.
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>
	Drain pump is blocked.  ► → "Cleaning the drain pump", Page 50
	<ul> <li> is activated.</li> <li>Continue the programme by selecting ⑤ Spin or Drain ♥ and pressing Start/Reload ▷ III.</li> <li>→ "Resuming the programme when the programme status is Rinse Hold", Page 45</li> </ul>
	The water outlet hose is connected too high.  ▶ Install the water outlet hose at a maximum height of 1 metre.
	<ul> <li>Detergent dosage is too high.</li> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down).</li> <li>Reduce the amount of detergent for the next washing cycle with the same load.</li> </ul>
	Unapproved extension installed on the water drain hose.  ▶ Remove any unapproved extensions from the water hose. Connecting the appliance
Water is not flowing in. Detergent is not	You have not pressed <b>Start/Reload</b> D <b>I</b> II.  ▶ Press <b>Start/Reload</b> D <b>I</b> II.
being dispensed.	The filter in the water inflow is blocked.  ► Clean the water inflow filter → Page 53.
	The tap is turned off.  ► Turn on the tap.
	The water inlet hose is kinked or jammed.  ► Ensure that the water inlet hose is not kinked or jammed.

Fault	Cause and troubleshooting		
The spin cycle runs several times.	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry.  Not a fault – no action required.		
	<b>Note:</b> When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
The programme duration changes during the wash cycle.	The programme operation is optimised electronically. This may change the programme duration.  ▶ Not a fault – no action required.		
	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry.  Not a fault – no action required.		
	<b>Note:</b> When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	Foam detection system switches on a rinse cycle if foam build-up is too high.  Not a fault – no action required.		
No water is visible in the drum.	<ul> <li>Water is below the visible area.</li> <li>Not a fault – no action required.</li> <li>Do not add any extra water to the appliance while it is operating.</li> </ul>		
Drum jerks after the programme starts.	This is caused by an internal motor test.  ▶ Not a fault – no action required.		
Residual water is present in the compartment %.	Insert in compartment ⊗ is blocked.  ► → "Cleaning the detergent drawer", Page 48		
Vibrations and movement of the appliance whilst spinning.	Appliance is not correctly aligned.  ▶ Aligning the appliance		
	The appliance feet are not fixed.  ▶ Secure the appliance feet. Aligning the appliance		
	Transit bolts have not been removed.  ▶ Removing the transit bolts		
Drum does not turn, water does not flow in.	Load detection is active.  ► Not a fault – no action required.		
	Note: The load detection can take up to two minutes.		

Fault	Cause and troubleshooting		
Heavy foam build-up	<ul> <li>Detergent dosage is too high.</li> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down).</li> <li>Reduce the amount of detergent for the next washing cycle with the same load.</li> </ul>		
timeLight does not light up.	timeLight deactivated in the basic settings.  ▶ → "Overview of the basic settings", Page 47		
	Energy-saving mode is active.  ▶ Press any button.  ✓ The symbol lights up again.		
High spin speed not reached.	<ul><li>A low spin speed is selected.</li><li>► The next time you run a wash cycle, set a higher spin speed.</li></ul>		
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.  Redistribute the laundry in the drum.		
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	► Start the <b>⑤ Spin</b> programme.		
The spin programme does not start.	<ul><li>Drain pipe or water outlet hose is blocked.</li><li>▶ Clean the drain pipe and the water outlet hose.</li></ul>		
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>► Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>		
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.  • Redistribute the laundry in the drum.		
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	Start the Spin programme.		
Rushing, hissing noise.	Water is flushed under pressure into the detergent drawer.  ► Not a fault – normal operating noise.		
Loud noises during the spin cycle.	Appliance is not correctly aligned.  ► Aligning the appliance		

#### en Troubleshooting

Fault	Cause and troubleshooting			
Loud noises during the spin cycle.	The appliance feet are not fixed.  ▶ Secure the appliance feet. Aligning the appliance			
	Transit bolts have not been removed.  ▶ Removing the transit bolts			
Banging noises, rat- tling in the drain pump.	Foreign bodies have got into the drain pump.  ▶ → "Cleaning the drain pump", Page 50			
Slurping, rhythmical suction noise.	The drain pump is active, the detergent solution is pumped out.  Not a fault – normal operating noise.			
Creasing.	The spin speed is too high.  ➤ The next time you run a wash cycle, set a lower spin speed.			
	<ul><li>The load is too large.</li><li>▶ The next time you run a wash cycle, reduce the amount of laundry being loaded.</li></ul>			
	The wrong programme is selected for the type of fabric.			
	<ul> <li>Select the programmes that are suitable for the type of fabric.</li> <li>→ "Programmes", Page 30</li> </ul>			
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	Too much detergent/fabric softener in the detergent drawer.  ➤ When dosing liquid detergent and fabric softener, observe the marking in the detergent drawer and do not dose above this.			
The spin result is not satisfactory. The laundry is too wet/too damp.	<ul> <li>A low spin speed is selected.</li> <li>► The next time you run a wash cycle, set a higher spin speed.</li> <li>► Start the ⑤ Spin programme.</li> </ul>			
	Drain pipe or water outlet hose is blocked.  ▶ Clean the drain pipe and the water outlet hose.			
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>► Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>			
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.  • Redistribute the laundry in the drum.			
	<ul><li>Redistribute the laundry in the drum.</li></ul>			

Fault	Cause and troubleshooting			
The spin result is not satisfactory. The laundry is too wet/too	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
damp.	► Start the <b>⑤ Spin</b> programme.			
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.  ▶ Redistribute the laundry in the drum.			
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
	► Start the <b>Spin</b> programme.			
Detergent residue on the damp washing.	Detergents may contain water-insoluble substances that deposit on the laundry.  Start the <b>Rinse</b> programme.			
Detergent residue on the dry laundry.	Detergents may contain water-insoluble substances that deposit on the laundry.  • Brush out the laundry after washing and drying.			
Water is leaking out at the water inlet hose.	<ul><li>Water inlet hose is not correctly/securely connected.</li><li>1. Connect the water supply hose correctly. Connecting the water inlet hose</li><li>2. Tighten the screw connection.</li></ul>			
Water is leaking out at the water outlet hose.	The water outlet hose is damaged.  ▶ Replace the damaged water outlet hose.			
	Water outlet hose is not connected correctly.  ► Connect the water outlet hose correctly. Water outlet connection types			
Odours have formed in the appliance.	Humidity and detergent residue may promote the formation of bacteria.  ► → "Cleaning the drum", Page 48  ► If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate.			


#### 17.1 Emergency release

#### Releasing the door

**Requirement:** The drain pump is empty.

- 1. **ATTENTION!** Escaping water may cause material damage.
- ▶ Do not open the door if you can see water through the glass.

Pull the emergency release downwards with a tool and release.



- The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

### 18 Transportation, storage and disposal

You can find out here how to prepare your appliance for transportation and storage. You will also find out how to dispose of old appliances.

### 18.1 Removing the appliance


- 1. Turn off the tap.
- 2. → "Emptying the water inlet hose", Page 53.
- 3. Switch off the appliance.
- 4. Unplug the appliance's mains plug.

- 5. Drain the remaining detergent solution.
  - → "Cleaning the drain pump". Page 50
- 6. Detach the hoses.

#### 18.2 Inserting the transit bolts


Secure the appliance for transportation using transit bolts in order to prevent damage.

- 1. Remove the four cover caps.
  - If necessary, use a screwdriver to remove the cover caps.




Keep the cover caps.


2. Insert the four sleeves.




3. Insert all screws into the four transit bolts and tighten slightly.



4. Insert the power cord into the holder 1 and tighten all four screws for the transit bolts with a WAF 13 wrench 2.



5. Insert the hose into holder.



### 18.3 Using the appliance again

1. Remove the transit bolts.

- 2. Pour approx. 1 litre of water into compartment II in the detergent drawer.
- 3. Start the **Drain** \$\mathbb{F}\$ programme.
- The unused detergent cannot flow straight into the outlet during the next wash.

## 18.4 Disposing of old appli-

Valuable raw materials can be reused by recycling.

#### WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ► With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- **2.** Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

#### 19 Customer Service

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service.

You can solve many problems yourself by consulting the information on troubleshooting in these instructions or on our website. If this is not the case, contact our after-sales service. With any warranty claims, we will make sure that your appliance is repaired by trained after-sales technicians using genuine spare parts, including after the manufacturer's warranty has expired.

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area

**Note:** Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

## 19.1 Product number (E-Nr.) and production number

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

#### 19.2 AQUA-STOP quarantee

In addition to warranty claims against the seller under the purchase agreement and in addition to our manufacturer's warranty, we offer compensation under the following conditions.

- If our Aqua-Stop system is defective and causes water damage, we will make good the damage for private users. To ensure protection from water damage, the appliance must be connected to the power vlagus.
- The liability guarantee is valid for the service life of the appliance.
- A claim can only be made under the guarantee if the appliance has been correctly installed and connected with Aqua-Stop according to our instructions; this also in-

- cludes correctly fitting the Aqua-Stop extension (genuine accessory). Our guarantee does not cover defective supply lines or fittings up to the Aqua-Stop connection on the tap.
- If your appliance is fitted with Aqua-Stop, you can in principle leave your appliance unattended during operation and the tap turned on afterwards. The tap only needs to be turned off if you are away from home for a long period, e.g. on holiday for several weeks.

## 20 Consumption values

The following information is provided in accordance with the EU Ecodesign Regulation. The values given for programs other than the **Eco 40-60** are indicative only and were determined in accordance with the applicable standard EN60456.

Programme	Load (kg)	Pro- gramm e dura- tion (hr:min	Energy con- sump- tion (kWh/ cycle) ¹	Water con- sump- tion (I/ cycle) ¹	Max- imum temper- ature (°C) 5 mins ¹	Spin speed (rpm) ¹	Residual moisture (%)1
Eco 40-60 ²	8,0	3:16	1,090	55,0	48	1393	53
Eco 40-60 ²	4,0	2:36	0,560	45,0	37	1400	53
Eco 40-60 ²	2,0	2:22	0,170	33,0	24	1400	53
Cottons 🛣 20 °C	8,0	3:16	0,290	84,0	23	1400	52
Cottons 🛣 40 °C	8,0	3:16	1,030	84,0	45	1400	52
Cottons 🛣 60 °C	8,0	3:16	1,200	84,0	53	1400	52
Cottons 1♣ 40 °C + Pre- wash ↓	8,0	3:45	1,130	89,0	45	1400	52
Easy Care 企 40 °C	4,0	2:30	0,740	62,0	44	1200	30
Quick Mix 🎎 🖟 40 °C	4,0	1:00	0,590	41,0	41	1400	55
	2,0	0:45	0,200	40,0	24	800	27

¹ Due to the influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions, the actual values may deviate from the stated values.

² Test programme in accordance with the EU Ecodesign Directive and the EU Energy Labelling Regulation with cold water (15 °C).

#### 21 Technical specifications

Appliance beight 010 cm

Facts and figures for your appliance can be found here.

Appliance height	81,8 cm
Appliance width	59,6 cm
Appliance depth	57,4 cm
Weight	72 - 76 kg ¹
Maximum load	8 kg
Mains voltage	220 - 240 V, 50 Hz
Minimum installation protection	10 A
Rated power	2300 W
Power consumption	<ul><li>Off mode: 0,12 W</li><li>Left-on mode: 0,50 W</li></ul>
Water pressure	<ul> <li>Minimum:     100 kPa     (1 bar)</li> <li>Maximum:     1000 kPa     (10 bar)</li> </ul>
Length of the wa-	220 cm
ter inlet hose	
Length of the water outlet hose	220 cm

cifications This product contains light sources

Depending on the appliance spe-

210 cm

Length of the

power cord

from energy efficiency class F. These light sources are available as a spare part and must only be replaced by trained specialist staff.

More information about your model can be found online at https://energylabel.bsh-group.com¹. This web address is linked to the official EU EPREL product database. At the time of printing its web address had not yet been published. Please then follow the instructions on searching for models. The model identifier is made up of the characters before the slash in the product number (E-Nr.) on the rating plate. Alternatively you can also find the model identifier in the first line of the EU energy label.

Only applies to countries in the European Economic Area



## Thank you for buying a **Bosch Home Appliance!**

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: www.bosch-home.com/welcome



## Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

Robert Bosch Hausgeräte GmbH

Carl-Werv-Straße 34 81739 München **GFRMANY** www.bosch-home.com



**9001525370** (001204)