



Washing machine

WAU28R90GB

[en]

User manual and installation instructions

For further information, please refer to the Digital User Guide.



Table of contents

1 S	afety	4
1.1	General information	4
	Intended use	
1.3	Restriction on user group	2
	Safe use	
	Safe cleaning and mainten-	
	ance	Ć
2 P	reventing material damage	1 (
3 E	nvironmental protection and aving energy	
3 1	Disposing of packaging	• • •
	Save energy and conserve	
	resources1	1 -
3.3	Energy saving mode	1
4 Ir	nstallation and connection	12
4.1	Unpacking the appliance 1	2
	Contents of package	2
4.3	Requirements for the installation location	1
4.4	Removing the transit bolts 1	3
4.5	Connecting the appliance 1	4
4.6	Aligning the appliance 1	
4.7	Connecting the appliance to	
	the electricity supply1	16
5 F	amiliarising yourself with	
y 5 1	our appliance1 Appliance1	1 / 1 /
	Detergent drawer	
	Control panel	
	Operating logic1	

6.1 Starting an empty washing cycle	
7 Display	
8 Buttons	
9 Programmes	24
10 Accessories	28
11 Laundry	28
11.1 Preparing the laundry	28
12 Detergents and care	
products	29
13 Basic operation 13.1 Switching on the appliance 13.2 Setting a programme	29
13.3 Adjusting the programme settings	
13.4 Saving the programme settings	29
13.6 Using a measuring aid for liquid detergent	
13.7 Use the measuring aid for liquid detergent	
13.8 Adding detergent and care product	
13.9 Starting the programme	
13.10 Adding laundry	
13.12 Unloading the laundry	
ance	21

14 Childproof lock	32
14.1 Activating the childproof lock	32
14.2 Deactivating the childproof lock	32
15 Basic settings	32
16 Clooping and convioing	20
16 Cleaning and servicing	
16.1 Cleaning the drum	32
16.2 Cleaning the detergent	
drawer	
16.3 Cleaning the drain pump	33
17 Troubleshooting	36
17.1 Emergency release	
18 Transportation, storage and	4.4
disposal	
18.1 Removing the appliance	
18.2 Inserting the transit bolts	
18.3 Using the appliance again	44
18.4 Disposing of old appliance	45
19 Customer Service	45
19.1 Product number (E-Nr.) and	
production number (FD)	45
20 Consumption values	47
21 Technical specifications	47
LI ICUIIIIUAI SPCUIIUAIIUIIS	7/



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- For washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- With tap water and commercially available detergents and care products suitable for washing machines.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Take note of the safety instructions when installing the appliance.

Improper installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ▶ When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ▶ If the power cord is too short, contact Customer Service.
- ▶ Only use adapters approved by the manufacturer.

⚠ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- ► Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- ➤ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

△ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

⚠ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ▶ Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- ► Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

▶ Do not touch the sharp edges on the appliance.

► Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer services. → Page 45

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

△ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ▶ Keep detergents and care products out of the reach of children.

△ WARNING – Risk of explosion!

Laundry that has been pretreated with cleaning agents that contain solvents may cause an explosion in the appliance.

► Rinse pretreated laundry thoroughly with water before washing.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

Wait for the drum to come to a complete stop before reaching inside.

△ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

▶ Do not touch the hot detergent solution.

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- ► Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

Take note of the safety instructions when cleaning and performing maintenance work on the appliance.

⚠ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

△ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

Follow these instructions to avoid material damage and damage to the appliance.

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

► Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 24 The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.
- ▶ Before starting up the appliance. remove the transit bolts completely and keep them in a safe place.
- ▶ Before transport, fit the transit bolts fully in order to prevent damage in

Material damage may be caused if the water inlet hose is connected incorrectly.

- ► Tighten the screw connections on the water inlet until they are handtight.
- ► Ideally, connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions, valves or similar.
- ► Ensure that the inner diameter of the water tap is at least 17 mm.

Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- ► Ensure that the water pressure in the water supply system is at least 100 kPa (1 bar) and max. 1000 kPa (10 bar).
- ▶ If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- ▶ Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- ▶ Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may lead to material damage and damage to the appliance.

Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- ▶ Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.

 Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

Choose programmes with low temperatures and longer wash times and use maximum load capacity.

 Energy consumption and water consumption is most efficient.

Use the economy programme settings.

✓ If you adjust the programme settings for a programme, the display shows the expected consumption.

Add detergent based on the laundry's degree of soiling.

 For light to normal soiling, a smaller amount of detergent is sufficient. Observe the dosage recommendation from the detergent manufacturer.

Reduce the washing temperature for lightly and normally soiled laundry.

✓ At lower temperatures, the appliance consumes less energy. For light to normal soiling, lower temperatures than indicated on the care label are also sufficient.

Set the maximum spin speed if you want to dry the laundry in the tumble dryer afterwards.

 ✓ The drier the laundry, the shorter the programme duration when drving which, in turn, reduces energy consumption. A higher spin speed reduces the residual moisture in the laundry and increases the volume of the spin noise.

Wash the laundry without prewash.

Washing with prewash increases the programme duration and increases energy and water consumption.

The appliance has a continuous automatic load adjustment function.

✓ Depending on the type of fabric and load capacity, the continuous automatic load adjustment function optimally adjusts the water consumption and programme duration.

3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. Energy-saving mode ends when you use the appliance again.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- 1. Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 11.
- 2. Check the appliance for visible damage.
- 3. Open the appliance door. → "Basic operation", Page 29
- 4. Remove any accessories from the drum.
- 5. Close the appliance door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

▶ Do not operate the appliance with incomplete or defective accessories.

- ► Replace the accessories in question before operating the appliance.
 - → "Accessories", Page 28

Note: The appliance has been tested at the factory to check it is in working order. As a result, water stains may remain in the appliance. These marks will disappear after the first wash cycle.

The delivery consists of the following:

- Washing machine
- Accompanying documents
- Transit bolts
 - → "Removing the transit bolts", Page 13
- Cover caps
- Water inlet hose
 - → "Connecting the water inlet hose", Page 14

4.3 Requirements for the installation location

⚠ WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

Do not operate the appliance without a cover cap.

⚠ WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

► Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 28 before using the appliance for the first time.

ATTENTION!

The appliance may contain residual water. If you tilt the appliance beyond 40°, this residual water may leak out.

► Tilt the appliance carefully.

Installation loca- Requirements tion Base Secure the appliance with fixing brackets → Page 28. Wooden joist Place the applifloor



ance on a waterresistant wooden board (minimum thickness of 30 mm) which is screwed tightly to the floor.



Only install the appliance underneath a continuous worktop that is securely connected to adjacent cabinets. Required niche width: 60 cm.



Do not trap the hoses between the wall and the appliance.

ATTENTION!

Residual water may freeze. Freezing residual water may damage the appliance and frozen hoses may burst.


▶ Do not install the appliance outdoors or in areas where there is a risk of frost.

4.4 Removing the transit bolts


The appliance is secured for transportation using transit bolts on the rear of the appliance.

Note: Keep the transit bolt screws and the sleeves in a safe place for future transport → Page 44.

1. Pull the hoses out of the holders.



2. Unscrew 1 and remove 2 all 4 screws for the transit bolts with a WAF 13 wrench.




en Installation and connection


3. Pull the power cable out of the holder.




4. Remove the 4 sleeves.



5. Put on the 4 cover caps.




6. Press down on the 4 cover caps.




4.5 Connecting the appliance

Connecting the water inlet hose

1. Connect the water inlet hose.



2. Connect the water inlet hose to a tap (26.4 mm = 3/4").



3. Open the water tap carefully and check that the connection points are tight.

Water outlet connection types

This information is intended to help vou to connect this appliance to the water outlet.


ATTENTION!

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

Secure the water outlet hose against unintentional loosening.


Note: Observe the draining heights. The maximum draining height is 100 cm.

Siphon



Secure the connection point with a (24-40 mm) hose clamp.


Sink



Fix and secure the water outlet hose with an elhow

→ Page 28.

Plastic pipe with rubber sleeve or qully




Fix and secure the water outlet hose with an elbow

→ Page 28.


4.6 Aligning the appliance

In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

1. Loosen the lock nuts using a WAF 17 wrench by turning it in a clockwise direction.




2. To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

Screw the lock nuts tightly against the housing using a WAF 17 wrench.



In doing so, hold the foot tight and do not adjust its height.

4.7 Connecting the appliance to the electricity supply

 Insert the mains plug of the appliance's power cable in a socket nearby.


The connection details of the appliance can be found under Technical data \rightarrow *Page 47*.

2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance


You can find an overview of the parts of your appliance here.



On certain models, specific details such as the colour and shape may differ from those pictured.

1	Maintenance flap for the drain pump → Page 33
2	Door
3	Detergent drawer → Page 18
4	Control panel → Page 18
5	Water outlet hose → Page 15
6	Power cord → Page 16
7	Transit bolts → Page 13


5.2 Detergent drawer



- Measuring aid for liquid detergent
 - → "Using a measuring aid for liquid detergent", Page 30
- Compartment II:
 - Detergent for main wash
 - Water softener
 - Bleach
 - Stain remover
 - 3 Compartment \%:
 - Fabric softener
 - Liquid starch
 - Waterproofing agent
- 4 Compartment I:
 - Detergent for prewash
 - Hygiene detergent

5.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- 1 Programmes
- Programme selector


 → Page 29
- Buttons → Page 22 and display → Page 20

5.4 Operating logic

ATTENTION!

Pressing on the display with force may cause damage.

▶ Do not apply heavy pressure on the display. ► Do not press on the display using pointed or sharp objects.



6 Before using for the first time


Prepare the appliance for use.

6.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

- 1. Press ①.
 - The switch-on process takes a few seconds.
- 2. Set the **Drum Clean** programme.
- 3. Close the door.
- 4. Pull out the detergent drawer.

5. Pour standard washing powder into compartment II.




To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

- 6. Push in the detergent drawer.
- 7. Press DIII (Start/Pause) to start the programme.
- ✓ The display shows the remaining. programme duration.
- ✓ After the programme has ended, the display shows: End.
- 8. Start the first wash cycle or press ① to switch off the appliance.
 - → "Basic operation", Page 29

7 Display

The display shows the current settings, options or relevant information.



Example: Display

Display	Designation	More information
0:40 1	Programme duration/programme time remaining	Approximate expected programme duration or programme time remaining.
©10 ¹	"Ready in" time	→ "Buttons", Page 22
9,0 kg ¹	Recommended load	The maximum load capacity for the selected programme in kg.
	Prewash	Programme status
	Wash	Programme status
(555)	Rinse	Programme status
<u>©</u>	Spin	Programme status
End	End of pro- gramme	Programme status
+1 +2 +3	Additional rinse	Additional rinse cycles are activated. → "Buttons", Page 23
₹	Energy consumption	Energy consumption for the selected programme. - : Low energy consumption - : High energy consumption
¹ Example		

Display	Designation	More information
Ċ	Water consumption	Water consumption for the selected programme. — : Low water consumption — — : High water consumption
Q	End signal	Basic setting
(1))	Button signal	Basic setting
- A -	Display brightness	Basic setting
<u></u> ©	Reminder to clean the drum	Flashes: Drum is dirty. Run the Drum Clean programme for cleaning and caring for the drum and the outer tub. → "Cleaning the drum", Page 32
:	Voltage control system	Flashes: The automatic voltage control system detects impermissible voltage drops. This will pause the programme. Note: The programme will continue when the voltage is permissible again.
•	Voltage control system	Flashes: The programme has been paused because of impermissible voltage drops. The voltage is permissible again and the programme will continue. Note: The programme duration is extended.
#8009	Foam detection system	The appliance has detected too much foam.
©	Door	 Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened.
<u></u>	Тар	No water pressure.The water pressure is too low.
E:35 / -10 ¹	Error	Error code, error display, signal.
¹ Example		

8 Buttons

The selection of programme settings depends on the programme that is set. You can see the selection options for each programme in the overview for .

Button	Selection	More information
DIII (Start/Pause)	StartCancelPause	Start, cancel or pause the programme.
Speed	ActivateDeactivate	Activate or deactivate a shorter programme duration. Note: Energy consumption increases. The washing result is not affected by this.
♥ (Oil) P (Red wine) P (Blood) Grass)	Multiple selection	Select the type of stain. The temperature, drum movement and soaking time are all adjusted to suit the type of stain.
一/十(Ready in)	Up to 24 hours	Set the programme end. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed. Note: Use the buttons to set the setting values.
★ - 90° (Temper- ature)	* − 90 °C	Adjust the temperature in °C.
Ø - 1400 (SpinSpeed)	Ø - 1400 rpm	Adjust the spin speed or deactivate the spin cycle. If \mathscr{O} is selected, the water is not drained and the spin cycle is deactivated. The laundry stays wet inside the drum.
① (mains switch)	Switch onSwitch off	Switch the appliance on or off.
c⇒3s (Prog 3 sec.)	ActivateDeactivate	→ "Childproof lock", Page 32
& (Settings)	Multiple selection	Basic settings
	ActivateDeactivate	Activate or deactivate prewash, e.g. for washing heavily soiled laundry.

9 Programmes

Note: The laundry's care labels provide you with additional information about programme selection. Care symbols on the care labels

Programme	Description	Max. load (kg)
Cottons	Wash hard-wearing items made from cotton, linen or blended fabrics. Also suitable as a short programme for normally soiled laundry when you activate Speed. Programme setting: Max. 90 °C Max. 1400 rpm	9,0 5,0 ¹
Eco 40-60	Wash items made from cotton, linen or blended fabrics. Note: Fabrics which can be washed from 40 °C vary up to 60 °C vary as per the care symbol can be washed together. The washing performance corresponds to the best possible washing performance class according to the legal requirements. For this programme, the washing temperature is automatically adjusted depending on the load size, in order to achieve the best possible energy efficiency with the best possible washing result. You cannot change the washing temperature. Programme setting: Note: The temperature cannot be adjusted in this programme and is set automatically. Max °C Max. 1400 rpm	9,0
Cotton Colour 1 Speed activate	Wash hard-wearing items made from cotton, linen or blended fabrics. Energy-saving programme. Note: To save energy, the actual washing temperature may deviate from the set washing temperature. The washing performance meets legal requirements. Programme setting: Max. 90 °C Max. 1400 rpm	9,0

Programme	Description	Max. load (kg)
Easy Care	Wash items made from synthetic or blended fabrics. Programme setting: Max. 60 °C Max. 1200 rpm	4,0
Mixed Load	Wash items made from cotton, linen, or synthetic or blended fabrics. Suitable for lightly soiled laundry. Programme setting: Max. 60 °C Max. 1400 rpm	4,0
Delicates/Silk	Wash delicate, washable items made from silk, viscose and synthetic fabrics. Use a detergent that is suitable for delicates or silk. Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag. Programme setting: Max. 40 °C Max. 800 rpm	2,0
₩ Wool	Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool. Programme setting: Max. 40 °C Max. 800 rpm	2,0
Rinse	Rinse and then spin the laundry, and drain the water. Programme setting: Max. 1400 rpm	_
Spin/Drain	Spin and drain the water. If you only want to drain the water, activate 6 . The laundry is not spun. Programme setting: Max. 1400 rpm	_
Speed activat	ed	

Programme	Description	Max. load (kg)
Shirts	Wash non-iron shirts and blouses made from cotton, linen, or synthetic or blended fabrics.	2,0
	Tip: In order to avoid creasing in your laundry, you can activate . The laundry is only given a short spin and can be removed while still dripping wet. Hang out shirts and blouses while they are still dripping wet so that they drip dry. Note: Use the Delicates/Silk programme to wash shirts and blouses made from silk or delicate fab-	
	rics. Programme setting: ■ Max. 60 °C ■ Max. 800 rpm	
Sportswear	Wash sports and leisure items made from synthetic fibres, microfibre or fleece. Use a detergent that is suitable for sports items. Do not use fabric softener. Tip: Use the Easy Care programme to wash heavily soiled laundry.	2,0
	Programme setting: ■ Max. 40 °C ■ Max. 800 rpm	
Dark Wash	Wash dark-coloured and colour-intense items made from cotton or easy-care fabric, e.g. jeans. Turn laundry inside-out before washing. Use liquid detergent. Programme setting: Max. 40 °C Max. 1200 rpm	4,0
Drum Clean	Cleaning and caring for the drum. Use this programme in the following cases: Before using the appliance for the first time If you regularly wash at temperatures of 40 °C or lower After a prolonged period of non-use	-
	Use washing powder or a detergent that contains bleach. Halve the amount of detergent to avoid foaming. Do not use fabric softener. Do not use liquid detergent or detergent that is intended for woollens or delicates.	

Programme	Description	Max. load (kg)
	Note: The drum cleaning indicator will flash to remind you if you have not used a programme at 60 °C or higher for a long time.	
Super Quick 15'/30'	Super Quick Wash items made from cotton, or synthetic or blen	

¹ Speed activated

10 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order number
Water inlet hose extension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Elbow	Secure the water outlet hose in place.	00655300
Liquid detergent insert	Measure liquid detergent.	00605740
Platform	Install the appliance at a raised height so that it can be easily loaded and unloaded.	WMZ20490

11 Laundry

Note: More detailed instructions for use can be found on www.boschhome.com or by scanning the QR code on the title page of this user manual.

11.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

- Remove all items from any pockets in your laundry before using the appliance.
- To protect your appliance and the laundry, prepare the laundry beforehand.
 - Empty any pockets
 - Brush sand out of all collars and pockets

- Close bed covers and cushion covers
- Close all zips, Velcro fasteners, hooks and eves
- Tie cloth belts, apron strings, etc. together or use a laundry bag.
- Tie together longer drawstrings, and tie cords with solid endpieces in hoods or trousers
- Remove curtain hooks and lead strips or use a mesh laundry bag
- Use a mesh laundry bag for small items of laundry, such as children's socks
- Some stubborn or dried-in stains can be removed by washing several times
- Wash large and small items of laundry together
- Do not rub fresh stains but dab them with soapy water

- Separate items of laundry and shake them out, or observe the programme description

12 Detergents and care products

Notes

- More detailed instructions for use can be found on www.boschhome.com or by scanning the QR code on the title page of this user manual.
- Observe the information on safety → Page 4 and preventing material damage → Page 10.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- Only use liquid detergents that are self-flowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances (e.g. bleach)
- Use dyes sparingly as salt may damage stainless steel
- Do not use bleaching agents in the appliance

13 Basic operation

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

13.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected.

- → "Installation and connection", Page 12
- ► Press ①.

The switch-on process takes a few seconds.

13.2 Setting a programme

- 1. Turn the programme selector and set the required programme. → "Programmes", Page 24
- 2. If necessary, adjust the pro-

gramme settings → Page 29.

13.3 Adjusting the programme settings

Requirement: A programme has been set.

- → "Setting a programme", Page 29
- ► Adjust the programme settings. → "Buttons", Page 22

Observe the information about operating logic.

Note: The programme settings are not saved permanently for the programme.

13.4 Saving the programme settings

You can save your individual programme settings as favourites.

Requirements

- A programme has been set.
- The programme settings have been adjusted.
- ▶ Press and hold ☆ for approx. 3 seconds.

en Basic operation

Press \triangle to call up the saved programme.

Note: To overwrite the saved programme, repeat the steps above.

13.5 Loading laundry

Note: To prevent creasing, take note of the maximum load for the → "Programmes", Page 24.


Requirement: The laundry is prepared.

- → "Laundry", Page 28
- Open the door.
 Make sure that the drum is empty.
- 2. Place the laundry in the drum.
- Close the door.Ensure that there is no laundry trapped in the door.


13.6 Using a measuring aid for liquid detergent

If you order the measuring aid as an accessory, you must use the measuring aid.

- 1. Pull out the detergent drawer.
- **2.** Press down on the insert and remove the detergent drawer.



3. Insert the measuring aid.




4. Insert the detergent drawer.


13.7 Use the measuring aid for liquid detergent

To add liquid detergent, you can use a measuring aid in the detergent drawer.

- **1.** Pull out the detergent drawer.
- 2. Slide the measuring aid forwards.



3. Fold the measuring aid down and click it into place.



4. Push in the detergent drawer.

13.8 Adding detergent and care product

Notes

- Do not use the measuring aid for liquid detergent for gel detergents, washing powder, or if Prewash or "Ready in" time are activated.
- Observe the information about detergents and care products → Page 29.
- 1. Pull out the detergent drawer.
- 2. Pour in deteraent.
 - → "Detergent drawer", Page 18
- 3. If required, add the care product.
- **4.** Push in the detergent drawer.

13.9 Starting the programme

Note: If you want to change the time until the programme ends, set the "Ready in" time first.

- ► Press DII.
- ✓ The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- ▼ The display shows either the programme duration or the "Ready in" time.

13.10 Adding laundry

1. Press DM

The appliance pauses.

Note: If @ appears, it is not possible to add laundry. When @ goes out, it is possible to add laundry.

- 2. Open the appliance door.
- 3. Add or remove laundry.
- 4. Close the appliance door.
- 5. Press DM.

13.11 Cancelling the programme

- 1. Press DM.
- 2. Open the appliance door.

The appliance door remains locked for safety reasons if the temperature and water levels are hiah.

- If the temperature is high, start the **Rinse** programme.
- If the water level is high, start the **Spin** programme or select a suitable programme for draining. → "Programmes", Page 24
- 3. Remove the laundry → Page 31.

13.12 Unloading the laundry

- 1. Open the appliance door.
- 2. Remove the laundry.

13.13 Switching off the appliance

- 1. Press (1).
- 2. Turn off the tap.

3. Wipe the rubber gasket dry and remove any foreign objects.



 Leave the appliance door and detergent drawer open so that residual water can evaporate.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof lock

- ▶ Press and hold C→3s for approx. 3 seconds.
- The controls are locked.
- The childproof lock remains active even after the appliance has been switched off

14.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

▶ Press and hold c→3s for approx. 3 seconds.

15 Basic settings

You can configure the appliance to meet your needs.

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

16 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

16.1 Cleaning the drum


⚠ CAUTION Risk of injury!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.


- Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- ► Run the **Drum Clean** programme without laundry and using all-purpose washing powder.

16.2 Cleaning the detergent drawer


- 1. Pull out the detergent drawer.
- 2. Press down on the insert and remove the detergent drawer.




3. Pull out the insert upwards.



4. Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and click it into place.



6. Clean the opening for the detergent drawer.



7. Push in the detergent drawer.

16.3 Cleaning the drain pump


Clean the drain pump in the event of faults, e.g. blockages or rattling noises.

Emptying the drain pump


- 1. Turn off the water tap.
- 2. Switch off the appliance.
- 3. Disconnect the appliance's mains plug from the power supply.

en Cleaning and servicing


4. Open and remove the service flap.



5. Slide a sufficiently large container under the opening.




6. Take the drain hose out of the holder.




- 7. CAUTION Risk of scalding!
 When you wash at high temperatures, the detergent solution gets hot.
- ► Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



8. Firmly press on the sealing cap.




9. Insert the drain hose into the holder.




Cleaning the drain pump

Requirement: The drain pump is empty. → Page 33


1. Since water may remain in the drain pump, unscrew the pump cap carefully.




2. Clean the interior, the thread on the pump cap and the pump housing.



3. Insert the pump cap.




4. Screw the pump cap as far as it will go.



The handle on the pump cap must be in a vertical position.

5. Insert and close the service flap.



17 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.



⚠ WARNING

Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified

person in order to prevent any risk.	
Fault	Cause and troubleshooting
The display goes out and DII flashes.	Energy-saving mode is active ► Press any button. ✓ The symbol lights up again.
"E:36 / -10"	Drain pipe or water outlet hose is blocked. ► Clean the drain pipe and the water outlet hose.
	 Drain pipe or water drain hose is caught or jammed. ► Ensure that the drain pipe and water drain hose are not kinked or trapped.
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 33
	The water outlet hose is connected too high. ► Install the water outlet hose at a maximum height of 1 metre.
	Detergent dosage is too high. ► Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down). ► Reduce the amount of detergent for the next washing cycle with the same load.
	Unapproved extension installed on the water drain hose. ▶ Remove any unapproved extensions from the water hose. Connecting the appliance

The pump cap is not fully screwed in.

Fault	Cause and troubleshooting	
"E:36 / -10"	 Ensure that the pump cap is screwed in all the way into the appliance. The handle on the pump cap must be in a vertical position. → "Cleaning the drain pump", Page 35 	
"E:36 / -25 / -26"	Drain pump is blocked. ► → "Cleaning the drain pump", Page 33	
문 ·	The water pressure is low. No remedial action possible.	
	The filters in the water inflow are blocked. ▶ Clean the filters in the water inflow.	
	The tap is turned off. ► Turn on the tap.	
	The water inlet hose is kinked or jammed.▶ Ensure that the water inlet hose is not kinked or jammed.	
: flashes.	The automatic voltage control system detects an unauthorised voltage under-usage. No remedial action possible.	
	Note: If the power supply is stable, the programme continues to run as normal.	
	Voltage under-usage may cause extension of a programme. No remedial action possible.	
~~************************************	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load. 	
C lights up.	The temperature is too high. ► Wait until the temperature has dropped. ► → "Cancelling the programme", Page 31	
	Water level is too high. ► Start the Drain programme.	
	Laundry is caught in the door. 1. Open the door again. 2. Remove any trapped laundry. 3. Close the door. 4. Press DII to start the programme.	

en Troubleshooting

Fault	Cause and troubleshooting
C flashes.	Door is not closed. 1. Close the door. 2. Press DII to start the programme.
All other error codes.	Malfunction ► Call the after-sales service. → "Customer Service", Page 45
"E:30/-20"	Solenoid valve defective. ► Call the after-sales service. → "Customer Service", Page 45
	Detergent dosage is too high. ➤ Reduce the amount of detergent for the next washing cycle with the same load.
	Additional water is added. ➤ Do not add any extra water to the appliance while it is operating.
The appliance is not working.	The mains plug of the power cord is not plugged in. ▶ Connect the appliance to the power supply.
	The circuit breaker is faulty. ► Check the circuit breaker in the fuse box.
	There has been a power cut. ➤ Check whether the lighting in your kitchen or other appliances are working.
The programme does not start.	You have not pressed D. Press D
	Door is not closed. 1. Close the door. 2. Press DII to start the programme.
	Childproof lock is activated. ► → "Deactivating the childproof lock", Page 32
	 - / + is activated. ► Check whether - / + is activated. → "Buttons", Page 22
	Laundry is caught in the door. 1. Open the door again. 2. Remove any trapped laundry. 3. Close the door. 4. Press DII to start the programme.

	roubleshooting en
Fault	Cause and troubleshooting
The door cannot be opened.	 is activated. Continue the programme by selecting Spin or Drain and pressing DII.
	The temperature is too high. ► Wait until the temperature has dropped. ► → "Cancelling the programme", Page 31
	Water level is too high. ► Start the Drain programme.
	Power failure. ► Open the door using the emergency release. → "Emergency release", Page 44
The water is not draining.	Drain pipe or water outlet hose is blocked. ➤ Clean the drain pipe and the water outlet hose.
	Drain pipe or water drain hose is caught or jammed. ► Ensure that the drain pipe and water drain hose are not kinked or trapped.
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 33
	 is activated. Continue the programme by selecting Spin or Drain and pressing D
	The water outlet hose is connected too high. ► Install the water outlet hose at a maximum height of 1 metre.
	Detergent dosage is too high. ► Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down). ► Reduce the amount of detergent for the next washing cycle with the same load.
	Unapproved extension installed on the water drain hose. ▶ Remove any unapproved extensions from the water hose. Connecting the appliance
Water is not flowing in. Detergent is not	You have not pressed DII. ▶ Press DII.
being dispensed.	The filters in the water inflow are blocked.

► Clean the filters in the water inflow.

Fault	Cause and troubleshooting		
Water is not flowing in. Detergent is not	The tap is turned off. ► Turn on the tap.		
being dispensed.	The water inlet hose is kinked or jammed. ► Ensure that the water inlet hose is not kinked or jammed.		
The spin cycle runs several times.	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. Not a fault – no action required.		
	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
The programme duration changes during the wash cycle.	The programme operation is optimised electronically. This may change the programme duration. ▶ Not a fault – no action required.		
	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. ▶ Not a fault – no action required.		
	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	Foam detection system switches on a rinse cycle if foam build-up is too high. ▶ Not a fault – no action required.		
No water is visible in the drum.	 Water is below the visible area. ▶ Not a fault – no action required. ▶ Do not add any extra water to the appliance while it is operating. 		
Drum jerks after the programme starts.	This is caused by an internal motor test. ▶ Not a fault – no action required.		
Residual water is present in the compartment %.	Insert in compartment ⊗ is blocked. ► → "Cleaning the detergent drawer", Page 33		
Vibrations and movement of the appliance whilst spinning.	Appliance is not correctly aligned. ► Aligning the appliance		
	The appliance feet are not fixed. ▶ Secure the appliance feet. Aligning the appliance		
	Transit bolts have not been removed. ▶ Removing the transit bolts		

Fault	Cause and troubleshooting		
Drum rotates, water	Load detection is active.		
does not flow in.	Not a fault – no action required.		
	Note: The load detection can take up to two minutes.		
Heavy foam build-up	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load. 		
High spin speed not reached.	A low spin speed is selected.► The next time you run a wash cycle, set a higher spin speed.		
	☐ is activated.► Select the programmes that are suitable for the type of fabric.		
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance. ▶ Redistribute the laundry in the drum.		
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	► Start the Spin programme.		
The spin programme does not start.	Drain pipe or water outlet hose is blocked. • Clean the drain pipe and the water outlet hose.		
	 Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped. 		
	not kinked of trapped.		
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. • Redistribute the laundry in the drum.		
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. • Redistribute the laundry in the drum. Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. ► Redistribute the laundry in the drum. Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle. ► Start the Spin programme.		
Rushing, hissing noise.	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. • Redistribute the laundry in the drum. Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		

en Troubleshooting

Fault	Cause and troubleshooting			
Loud noises during the spin cycle.	Appliance is not correctly aligned. ► Aligning the appliance			
	The appliance feet are not fixed. ▶ Secure the appliance feet. Aligning the appliance			
	Transit bolts have not been removed. ▶ Removing the transit bolts			
Banging noises, rattling in the drain pump.	Foreign bodies have got into the drain pump. ▶ → "Cleaning the drain pump", Page 33			
Slurping, rhythmical suction noise.	The drain pump is active, the detergent solution is pumped out. Not a fault – normal operating noise.			
Creasing.	The spin speed is too high. ➤ The next time you run a wash cycle, set a lower spin speed.			
	The load is too large. ➤ The next time you run a wash cycle, reduce the amount of laundry being loaded.			
	The wrong programme is selected for the type of fabric.▶ Select the programmes that are suitable for the type of fabric.			
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	Too much detergent/fabric softener in the detergent drawer. ➤ When dosing liquid detergent and fabric softener, observe the marking in the detergent drawer and do not dose above this.			
The spin result is not satisfactory. The laundry is too wet/too damp.	 A low spin speed is selected. ► The next time you run a wash cycle, set a higher spin speed. ► Start the Spin programme. 			
	 is activated. Select the programmes that are suitable for the type of fabric.			
	Drain pipe or water outlet hose is blocked. ► Clean the drain pipe and the water outlet hose.			
	Drain pipe or water drain hose is caught or jammed. ► Ensure that the drain pipe and water drain hose are not kinked or trapped.			


Fault	Cause and troubleshooting
The spin result is not satisfactory. The laundry is too wet/too	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.
damp.	Redistribute the laundry in the drum.
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
	► Start the Spin programme.
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance. ▶ Redistribute the laundry in the drum.
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
	Start the Spin programme.
Detergent residue on the damp washing.	Detergents may contain water-insoluble substances that deposit on the laundry. Start the Rinse programme.
Detergent residue on the dry laundry.	Detergents may contain water-insoluble substances that deposit on the laundry. • Brush out the laundry after washing and drying.
Water is leaking out at the water inlet hose.	Water inlet hose is not correctly/securely connected.1. Connect the water supply hose correctly. Connecting the water inlet hose2. Tighten the screw connection.
Water is leaking out at the water outlet hose.	The water outlet hose is damaged. ▶ Replace the damaged water outlet hose.
	Water outlet hose is not connected correctly. ► Connect the water outlet hose correctly. Water outlet connection types
Odours have formed in the appliance.	Humidity and detergent residue may promote the formation of bacteria. ► → "Cleaning the drum", Page 32 ► If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate.

17.1 Emergency release

Releasing the door

Requirement: The drain pump is empty. → Page 33

- 1. **ATTENTION!** Escaping water may cause material damage.
- ▶ Do not open the door if you can see water through the glass. Pull the emergency release downwards with a tool and release.



- The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

18 Transportation, storage and disposal

You can find out here how to prepare your appliance for transportation and storage. You will also find out how to dispose of old appliances.

18.1 Removing the appliance

Note: More detailed instructions for use can be found on www.boschhome.com or by scanning the QR code on the title page of this user manual.


- 1. Turn off the water tap.
- 2. Empty the water inlet hose.

- 3. Switch off the appliance.
- 4. Unplug the appliance's mains plug.
- 5. Drain the water.
 - → "Cleaning the drain pump". Page 33
- 6. Detach the hoses.

18.2 Inserting the transit **bolts**

Secure the appliance for transportation using transit bolts in order to prevent damage.

1. Use a screwdriver to remove the 4 cover caps.



Keep the cover caps.

2. Install the 4 transit bolts. Refer to the description Removing the transit bolts for this and proceed in reverse order.

18.3 Using the appliance again

- ► For further information, see → "Installation and connection". Page 12 and
 - → "Before using for the first time", Page 19.

18.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ► With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

19 Customer Service

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service.

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

19.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance
- On the rear of the appliance.

en Customer Service

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

20 Consumption values

The following information is provided in accordance with the EU Ecodesign Regulation. The values given for programs other than the Eco 40-60 are indicative only and were determined in accordance with the applicable standard FN60456

Programme	Load (kg)	Pro- gramm e dura- tion (h:min) ¹	Energy con- sump- tion (kWh/ cycle) ¹	Water con- sump- tion (I/ cycle) ¹	Max- imum temper- ature (°C) 5 mins ¹	Spin speed (rpm) ¹	Residual moisture (%)1
Eco 40-60 ²	9,0	3:37	1,250	61,0	50	1400	50,00
Eco 40-60 ²	4,5	2:52	0,610	45,0	36	1400	50,00
Eco 40-60 ²	2,5	2:30	0,180	30,0	24	1400	54,00
Cot- tons 20 °C	9,0	3:28	0,370	90,0	23	1400	52,00
Cot- tons 40 °C	9,0	3:28	1,350	90,0	45	1400	52,00
Cot- tons 60 °C	9,0	3:28	1,450	90,0	55	1400	52,00
Easy Care 40 °C	4,0	2:28	0,780	61,0	44	1200	27,00
Mixed Load 40 °C	4,0	0:59	0,620	44,0	41	1400	53,00
₩ Wool 30 °C	2,0	0:40	0,200	40,0	22	800	25,00

Due to the influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions, the actual values may deviate from the stated values.

21 Technical specifications

Appliance height 84,8 cm

Depending on the appliance specifications

Appliance width	59,8 cm
Appliance depth	63,2 cm
Weight	72,2 kg ¹
Maximum load	9,0 kg

Depending on the appliance specifications

² Test programme in accordance with the EU Ecodesign Directive and the EU Energy Labelling Regulation with cold water (15 °C).

en Technical specifications

,	
Mains voltage	220-240 V, 50 Hz
Minimum installation protection	10 A
Nominal power	2300 W
Power consumption	Off mode: 0,10 WLeft-on mode: 0,50 W
Water pressure	Minimum: 100 kPa (1 bar)Maximum: 1000 kPa (10 bar)
Length of the water inlet hose	150 cm
Length of the water outlet hose	150 cm
Length of the power cable	210 cm
Depending on the cifications	ne appliance spe-

You can find more information about your model online at https://eprel.ec.europa.eu/1. This web address is linked to the official EU EPREL product database. Please then follow the instructions on searching for models. The model identifier is made up of the characters before the slash in the product number (E-Nr.) on the rating plate. Alternatively, you can also find the model identifier in the first line of the EU energy label.

¹ Only applies to countries in the European Economic Area









Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- · Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome**



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: **www.bosch-home.com/service**

Contact data of all countries are listed in the attached service directory.

Robert Bosch Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München GERMANY www.bosch-home.com



Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom