



# Washing machine

WAX32KH2BY

[en]

User manual and installation instructions

# **Table of contents**

1 Safety 4	10 Before using for the	20
1.1 General information	first time	. ა
1.2 Intended use 4 1.3 Restriction on user group 4	cycle	. 36
1.4 Safe installation 5	•	
1.5 Safe use 7	11 Laundry	
1.6 Safe cleaning and mainten-	11.1 Preparing the laundry	
ance9	11.2 Sorting laundry	
	11.3 Degrees of soiling	. 38
2 Preventing material damage 10	11.4 Care symbols on the care labels	38
3 Environmental protection and		. 00
saving energy11	12 Detergents and care	-
3.1 Disposing of packaging 11	products	. 39
3.2 Save energy and conserve	12.1 Detergent recommendation	
resources	12.2 Detergent dosage	. 40
3.3 Energy saving mode 12	13 Basic operation	. 41
4 Installation and connection 12	13.1 Switching on the appliance	
4.1 Unpacking the appliance 12	13.2 Setting a programme	. 41
4.2 Contents of package13	13.3 Adjusting the programme	
4.3 Requirements for the install-	settings	
ation location13	13.4 Loading laundry	. 41
4.4 Removing the transit bolts 14	13.5 Adding detergent and care product	10
4.5 Removing the transport	13.6 Starting the programme	
struts	13.7 Soaking laundry	
4.7 Aligning the appliance	13.8 Adding laundry	
4.8 Connecting the appliance to	13.9 Cancelling the programme	
the electricity supply18	13.10 Resuming the programme	
	when the programme	
5 Familiarising yourself with your appliance19	status is Rinse Hold	
5.1 Appliance	13.11 Unloading the laundry	. 43
5.2 Detergent drawer20	13.12 Switching off the appli-	40
5.3 Controls	ance	
	14 Childproof lock	. 43
6 Display 21	14.1 Activating the childproof	
7 Buttons 24	lock	. 43
	14.2 Deactivating the childproof	11
8 Programmes 27	lock	. 44
9 Accessories 36	<b>15 Intelligent dosing system</b> 15.1 Filling the dispenser	
	To. I I miling the dispenser	

	Basic dosage	
16 H	ome Connect	45
	Connecting the appliance to a WLAN home network (Wi-Fi) with WPS function Connecting the appliance to a WLAN home network (Wi-Fi) without WPS func-	
16.3	Connecting the appliance	
16.4	to the Home Connect app Connecting the appliance	
16.5	to the energy manager	
16.6	Deactivating Wi-Fi on the	
	Software update	48
16.9	network settings	49
17.1	Overview of basic settings Changing the basic set-	50
	tings	51
18.1 18.2	Tips on appliance care	51 51
18.5	DescalingCleaning the drain pump	53
	Cleaning the intake opening in the rubber gasket Cleaning the water outlet	56
	hose at the siphon	56
. 0.0		57

19 Troubleshooting	. 59
20 Transportation, storage and disposal	. 70
20.1 Removing the appliance 20.2 Inserting the transit bolts 20.3 Using the appliance again 20.4 Disposing of old appliance	. 70 . 70 . 71
21 Customer Service	. 72
22 Consumption values	. 73
23 Technical specifications	. 74
24 Declaration of Conformity	. 74



# 1 Safety

Observe the following safety instructions.

#### 1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

#### 1.2 Intended use

Only use this appliance:

- For washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- With tap water and commercially available detergents and care products suitable for washing machines.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

#### 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

#### 1.4 Safe installation

Take note of the safety instructions when installing the appliance.

#### 

Improper installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ▶ When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

#### 

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ▶ If the power cord is too short, contact Customer Service.
- ▶ Only use adapters approved by the manufacturer.

# **⚠** WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- ► Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- ➤ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

#### **△** WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

# **⚠** CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ▶ Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- ► Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

# **△** CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

▶ Do not touch the sharp edges on the appliance.

► Wear protective gloves when installing and transporting the appliance.

#### 1.5 Safe use

#### 

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer services. → Page 72

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

#### **⚠** WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

#### **⚠** WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

# **△** WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

# **⚠** WARNING – Risk of explosion!

Laundry that has been pretreated with cleaning agents that contain solvents may cause an explosion in the appliance.

► Rinse pretreated laundry thoroughly with water before washing.

# **△** CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

▶ Wait for the drum to come to a complete stop before reaching inside.

#### **⚠** CAUTION – Risk of burns!

When washing at high temperatures, the glass in the appliance door becomes hot.

- ▶ Do not touch the appliance door when it is hot.
- ► Keep children away from the appliance door when it is hot.

#### **△** CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

▶ Do not touch the hot detergent solution.

#### **△** CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- ► Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

#### 1.6 Safe cleaning and maintenance

Take note of the safety instructions when cleaning and performing maintenance work on the appliance.

#### 

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

#### **△** WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

# **△** WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

# 2 Preventing material damage

Follow these instructions to avoid material damage and damage to the appliance.

#### **ATTENTION!**

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 27 The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.
- ► Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- ▶ Before transport, fit the transit bolts fully in order to prevent damage in

Material damage may be caused if the water inlet hose is connected incorrectly.

- ► Tighten the screw connections on the water inlet until they are handtight.
- Ideally, connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions, valves or similar.

- Make sure that the valve housing for the water inlet hose does not come into contact with its surroundings and is not subjected to any external forces.
- Ensure that the inner diameter of the water tap is at least 17 mm.
- Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- ► Ensure that the water pressure in the water supply system is at least 100 kPa (1 bar) and max. 1000 kPa (10 bar).
- If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may cause material damage.

► Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- ▶ Do not use harsh or abrasive detergents.
- ▶ Do not use cleaning products with a high alcohol content.

- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

## 3 Environmental protection and saving energy

#### 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

#### 3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

Choose programmes with low temperatures and longer wash times and use maximum load capacity

- → Page 27.
- Energy consumption and water consumption is most efficient.

Use the economy programme settings.

✓ If you adjust the programme settings for a programme, the display shows the expected consumption.

Add → Page 40 detergent based on the laundry's degree of soiling.

✓ For light to normal soiling, a smaller amount of detergent is sufficient. Observe the dosage recommendation from the detergent manufacturer.

Reduce the washing temperature for lightly and normally soiled laundry.

✓ At low temperatures, the appliance consumes less energy. For light to normal soiling, lower temperatures than indicated on the care label are also sufficient.

Set the maximum spin speed if you want to dry the laundry in a tumble drver afterwards.

 ✓ The drier the laundry, the shorter the programme duration when drying which, in turn, reduces energy consumption. A higher spin speed reduces the residual moisture in the laundry and increases the volume of the spin noise.

Wash the laundry without prewash.

Washing with prewash increases the programme duration and increases energy and water consumption.

The appliance has a continuous automatic load adjustment function.

 Depending on the type of fabric and load capacity, the continuous automatic load adjustment function optimally adjusts the water consumption and programme duration.

The appliance comes with an Aqua-Sensor.

 During the rinse cycle, the Aqua-Sensor checks the degree of turbidity of the rinsing water, and adjusts the duration and number of rinse cycles accordingly.

#### 3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. All displays go out and **Start/Reload** DIII flashes.

Energy-saving mode ends when you use the appliance again, e.g. if you open or close the door.

If you do not use the appliance for an extended period, the appliance switches off automatically.

**Note:** If Wi-Fi is activated, the appliance will not switch itself off automatically.

#### 4 Installation and connection

#### 4.1 Unpacking the appliance

**Note:** Please read the information in the Safety  $\rightarrow$  *Page 4* and Preventing material damage  $\rightarrow$  *Page 10* sections to ensure that you use the appliance safely.

#### **ATTENTION!**

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.


- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- Remove any packaging and protective covers completely from the appliance.

For the environmentally friendly disposal of the packaging materials, observe the information on the topic of

- → "Disposing of packaging", Page 11.
- 2. Check the appliance for visible damage.
- Open the door.
   → "Basic operation", Page 41
- **4.** Remove the accessory from the drum.
- 5. Close the door.

#### 4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.



- Washing machine
- Accompanying documents
- Elbow for fixing the water outlet hose
- Cover caps

#### 4.3 Requirements for the installation location

**Note:** Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

#### **WARNING** Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

▶ Do not operate the appliance without a cover cap.

#### WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

► Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 36 before using the appliance for the first time.

#### **ATTENTION!**

If the appliance is installed in areas exposed to frost or outdoors, frozen residual water may damage the appliance and frozen hoses may crack or split.

▶ Do not install or operate this appliance anywhere that is liable to experience frost and/or outdoors.

The appliance underwent a function test before leaving the factory and may, therefore, contain residual water. This residual water may leak out if the appliance is tilted at an angle greater than 40°.

Tilt the appliance carefully.

#### Installation loca- Requirements tion

On a base



Secure the appliance with fixing brackets → Page 36.

#### On a wooden ioist floor



Place the appliance on a waterresistant wooden board which is screwed tightly to the floor. The wooden board should be at least 30 mm thick.


#### In a kitchen unit



- A niche width of 60 cm is reauired.
- Only install the appliance underneath a continuous worktop that is securely connected to adiacent cabinets.

#### Installation loca- Requirements tion

On a wall




Do not trap the hoses between the wall and the appliance.

#### 4.4 Removing the transit bolts


The appliance is secured for transportation using transit bolts on the rear of the appliance.

#### **Notes**


- Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.
- Keep the transit bolts, screws and sleeves in a safe place for future transport → Page 70.
- 1. Pull the hoses out of the holders.




2. Unscrew ① and remove ② all four screws for the transit bolts with a WAF 13 wrench.




3. Pull the power cord out of the holder.




4. Remove the four sleeves.



5. Put on the four cover caps.




6. Press down on the four cover caps.




#### 4.5 Removing the transport struts

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.


 Unscrew and remove the screws in the vertical transport struts using a T20 screwdriver.




2. Remove the transport struts.



Undo and remove the screws in the horizontal transport strut using a T20 screwdriver.



**4.** Remove the transport strut.



#### 4.6 Connecting the appliance


#### Connecting the water inlet hose

**Note:** Please read the information in the Safety  $\rightarrow$  *Page 4* and Preventing material damage  $\rightarrow$  *Page 10* sections to ensure that you use the appliance safely.

# MARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

- ► Do not immerse the electrical AquaStop valve in water.
- 1. Connect the water inlet hose to a tap (26.4 mm = 3/4").



Open the water tap carefully and check that the connection points are tight.

#### Water outlet connection types

This information is intended to help vou to connect this appliance to the water outlet.

**Note:** Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.


#### **ATTENTION!**

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

Secure the water outlet hose against unintentional loosening.

**Note:** Observe the draining heights. The maximum draining height is 100 cm.

Drainage into a siphon



Secure the connection point with a (24-40 mm) hose clamp.


Drainage into a washbasin



Fix and secure the water outlet using an elbow.

Drainage into a plastic pipe with rubber sleeve or into a gully.

Fix and secure the water outlet using an elbow.




#### 4.7 Aligning the appliance


In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

**Note:** Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

1. Loosen the lock nuts using a WAF 17 wrench by turning it in a clockwise direction.




2. To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the around.

Screw the lock nuts tightly against the housing using a WAF 17 wrench.



In doing so, hold the foot tight and do not adjust its height.

# 4.8 Connecting the appliance to the electricity supply


**Note:** Please read the information in the Safety  $\rightarrow$  *Page 4* and Preventing material damage  $\rightarrow$  *Page 10* sections to ensure that you use the appliance safely.

- Insert the mains plug of the appliance's power cable in a socket nearby.
  - The connection details of the appliance can be found under Technical data  $\rightarrow$  *Page 74*.
- **2.** Check the mains plug is inserted properly.

# 5 Familiarising yourself with your appliance

#### 5.1 Appliance

You can find an overview of the parts of your appliance here.





On certain models, specific details such as the colour and shape may differ from those pictured.

- Maintenance flap for the drain pump → Page 53
- Door
- 3 Detergent drawer → Page 20
- 4 Controls → Page 20
- 5 Water outlet hose → Page 17
- Transport struts → Page 15
- Power cord → Page 18

- Transit bolts → Page 14
- Water inlet hose → Page 16








3 O: Dispenser for detergent

#### 5.3 Controls

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.




- 1 Programmes → Page 27
- Programme selector

  → Page 41
- 3 Buttons → Page 24
- 4 Display → Page 21

# 6 Display

The display shows the current settings, options or relevant information.



Display	Designation	Description
0:40 1	Programme dura- tion/programme time remaining	Approximate expected programme duration or programme time remaining.
10h <sup>1</sup>	"Ready in" time	The programme end has been set and the remaining number of hours is displayed.  → "Buttons", Page 24
10 kg <sup>1</sup>	Recommended load	The maximum load capacity for the selected programme in kg.
<b>□</b> - 1600	Spin speed	Set spin speed in rpm.  → "Buttons", Page 25 0= No final spin, only draining  □: Rinse Hold, no draining
<b>*</b> - 90	Temperature	Set temperature in °C.  → "Buttons", Page 24  It (cold)
<u></u>	Prewash	Programme status
	Wash	Programme status
###Y	Rinse	Programme status
©	Spin	Programme status
-P-	Pause	Programme status
<sup>1</sup> Example		

#### en Display

Display	Designation	Description
-0-	End of programme	Programme status
(m)	Childproof lock	<ul> <li>lights up: The childproof lock is activated.</li> <li>flashes: The childproof lock is activated and the appliance has been operated.</li> <li>→ "Deactivating the childproof lock", Page 44</li> </ul>
705	Energy consumption	Energy consumption for the selected programme.  - : Low energy consumption - : High energy consumption
<b>O</b>	Water consumption	Water consumption for the selected programme.  - : Low water consumption - : High water consumption
<u></u>	Wi-Fi	<ul> <li>Lights up: The appliance is connected to your home network.</li> <li>Flashes: The appliance is trying to connect to your home network.</li> </ul>
		→ "Home Connect ", Page 45
ਚੰ	Energy manager	The appliance is connected to the smart energy system (energy manager).  → "Connecting the appliance to the energy manager", Page 47
<b>⋄</b>	Dispenser for liquid detergent	<ul> <li>Lights up: The intelligent dosing system for liquid detergent is activated.</li> <li>Flashes: The fill level of the dispenser is below the minimum level.</li> <li>→ "Intelligent dosing system", Page 44</li> </ul>
		♦ (liquid detergent)
<b>⋄</b>	Dispenser for liquid detergent or fabric softener.	<ul> <li>Lights up: The intelligent dosing system for liquid detergent or fabric softener is activated.</li> <li>Flashes: The fill level of the dispenser is below the minimum level.</li> <li>→ "Intelligent dosing system", Page 44</li> </ul>
		<ul><li>Ó (liquid detergent)</li><li>※ (fabric softener)</li></ul>
<sup>1</sup> Example		

Display	Designation	Description
50 ml <sup>1</sup>	Basic dosage	Basic dosage for detergent or fabric softener.  → "Basic dosage", Page 45
<del>4800</del>	Foam detection system	The appliance has detected too much foam.
<b>(</b>	Door	The door is unlocked and can be opened.
<sub></sub>	Tap	<ul><li>No water pressure.</li><li>The water pressure is too low.</li></ul>
	Detergent drawer	The detergent drawer has not been pushed in fully.
E:35 / -10 <sup>1</sup>	Error	Error code, error display, signal.
<sup>1</sup> Example		

### 7 Buttons

The selection of programme settings depends on the programme that is set. You can see the selection options for each programme in the overview for → "Programmes", Page 27.

Button	Selection	Description
Start/Reload ▷W	<ul><li>Start</li><li>Cancel</li><li>Pause</li></ul>	Start, cancel or pause the programme.
SpeedPerfect =①	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate a short washing programme.  Note: Energy consumption increases. The washing result is not affected by this.
Intensive Plus ®	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate an extended washing programme. The programme duration is extended by up to 30 minutes. Suitable for heavily soiled laundry.
1 i-DOS	<ul><li>Activate</li><li>Deactivate</li><li>Basic dosage</li></ul>	Briefly press the button to activate or deactivate the intelligent dosing system for liquid detergent O.  Press the button for approx. 3 seconds to set the basic dosage.  → "Intelligent dosing system", Page 44
2 i-DOS	<ul><li>Activate</li><li>Deactivate</li><li>Dispenser contents</li><li>Basic dosage</li></ul>	Briefly press the button to activate or deactivate the intelligent dosing system for fabric softener ⊗ or liquid detergent o.  Press the button for approx. 3 seconds to specify the contents of the dispenser or set the basic dosage.  → "Intelligent dosing system", Page 44
- Finished in + ©	1-24 hours	Set the programme end. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
Temperature Selction &	<b>*</b> − 90 °C	Adjust the temperature in °C.

Button	Selection	Description
Spin Speed Re- duction ලි	<b>□</b> - 1600	Adjust the spin speed or activate (Rinse Hold).  If is selected, the water is not drained at the end of the washing cycle and the spin cycle is deactivated. The laundry remains in the water used for rinsing.
① (mains switch)	<ul><li>Switch on</li><li>Switch off</li></ul>	Switch the appliance on or off.
Remote Start □	<ul> <li>Activate</li> <li>Deactivate</li> <li>Open the Home Connect menu</li> </ul>	If you briefly press the button, the appliance will be enabled for remote start via the Home Connect app If you press the button for approx. 3 seconds, the Home Connect menu opens.  Notes  Remote start cannot be activated for safety reasons in the following circumstances:  The door is open.  The detergent drawer has not been pushed in fully.  Remote start is deactivated for safety reasons in the following circumstances:  Open the door.  Press Start/Reload ▷ ■.  Press Remote Start □ .  Switch off the appliance.  Following a power cut.
Child Lock 3 sec.	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated.  → "Childproof lock", Page 43
Spin Speed Reduction ©	Basic settings	Change the basic settings for the appliance.  → "Changing the basic settings", Page 51

#### en Buttons

Button	Selection	Description
Prewash <b></b>	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate prewash, e.g. for washing heavily soiled laundry.  Note: If the intelligent dosing system is activated, the detergent will be dispensed automatically for the prewash and the main wash.  If the intelligent dosing system is deactivated, place the detergent for the prewash directly in the drum.
Water plus &	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate a washing programme with more water and an additional rinse cycle.  Recommended for particularly sensitive skin or in regions with very soft water.

# 8 Programmes

Below is an overview of the programmes. You can find information on the load and on the adjustable programme options.

**Tip:** The laundry's care labels provide you with additional information on programme selection. → "Care symbols on the care labels", Page 38

Programme	Description	Ма			Progra	Programme settings	ettings			
		x. load (kg)	Max. temperature (°C)	SpeedPerfect =①  Max. spin speed (rpm) 1	Water plus <b>2</b>	Spin Speed Reduction ⊚  ☐ (Rinse Hold)	Prewash ⊎	ப்i-DOS ்	ப்-DOS ⊛	Intensive Plus ⊕ <sup>⁺</sup>
Cottons 🏗	Wash hard-wearing items made from cotton, linen or blended fabrics. Also suitable as a short programme for normally soiled laundry when you activate SpeedPerfect =Û. If SpeedPerfect =Û is activated, the maximum load capacity is reduced to 5 kg.	10	90	1600	•	•	•	•	•	•
1 Programme setting	etting									

Programme	Description	Ма			ā	ogral	Programme settings	tting	ေ		
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) <sup>1</sup>	SpeedPerfect =①	Water plus 🏝	Spin Speed Reduction ⊚  ☐ (Rinse Hold)	Prewash ⊎	ப்i-DOS ்	i-DOS ⊛	Intensive Plus ∰
Cottons Colour &	Wash hard-wearing items made from cotton, linen or blended fabrics. Energy-saving programme.  Note: To save energy, the actual washing temperature may deviate from the set washing temperature. The washing performance meets legal requirements.	10	90	1600	_	•	•	•	•	•	_
Eco 40-60	Wash items made from cotton, linen or blended fabrics.  Note: Textiles which can be washed from 40 °C var up to 60 °C var as per the care symbol can be washed together.	10	_	1600	_	•	•	•	•	•	_
<sup>1</sup> Programme setting	etting										

Programme	Description	Ма			4	rogra	Programme settings	etting	<u>s</u>		
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	SpeedPerfect =①	Water plus 🏝	Spin Speed Reduction ⊚  ☐ (Rinse Hold)	Prewash <b></b>	ப்i-DOS ◊	② i-DOS ↔	Intensive Plus ₫
	The washing performance corresponds to the best possible washing performance class according to the legal requirements.  For this programme, the washing temperature is automatically adjusted depending on the load size, in order to achieve the best possible energy efficiency with the best possible washing result. You cannot change the washing temperature.										
Easy-Care 企	Wash items made from synthetic or blended fabrics.	4	60	1200	•	•	•	•	•	•	•
<sup>1</sup> Programme setting	etting										

Programme	Description	Ма			P	ogra	Programme settings	tting	S		
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) <sup>1</sup>	SpeedPerfect =①	Water plus 🏝	Spin Speed Reduction ⊚  ☐ (Rinse Hold)	Prewash ⊍	ப்i-DOS ்	i-DOS ⊛	Intensive Plus ⊕
Quick Mix Man	Wash items made from cotton, linen, or synthetic or blended fabrics. Suitable for lightly soiled laundry.	4	60	1600	•	•	•	•	•	•	•
Delicates/ Silk 🗞	Wash delicate, washable items made from silk, viscose and synthetics. Use a detergent that is suitable for delicates or silk.  Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag.	2	40	800	_	•	•	•	•	•	_
<sup>1</sup> Programme se	setting										

Programme	Description	Ма			ď	ograi	Programme settings	tting	ဖ		
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	SpeedPerfect =①	Water plus 🏝	Spin Speed Reduction ⊚  ☐ (Rinse Hold)	Prewash ⊎	ப்i-DOS ்	② i-DOS ↔	Intensive Plus ⊕ <sup>†</sup>
® (00) №	Hand- or machine-washable items that are made from wool or contain wool.  To prevent the laundry from shrinking, the drum moves the items very gently with long pauses.  Use a detergent that is suitable for wool.	S	40	800	_	_	•	_	_	•	_
æ⁄ Rinse	Rinses and then spins the laundry, and then drains the water.	ı	_	1600	_	•	•	_	_	•	_
⑥ ∜ Spin/ Drain	Spins and drains the water. If you only want to drain the water, activate 0. The laundry is not spun.	1	_	1600	_	_	_	_	_	_	_
<sup>1</sup> Programme setting	etting										

Programme	Description	Ма			Pro	gran	Programme settings	tings			
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) <sup>1</sup>	SpeedPerfect =①	Water plus 🏝	Spin Speed Reduction ⊚  ☐ (Rinse Hold)	Prewash <u></u>	ப்i-DOS ்	ப்-DOS ⊛	Intensive Plus ∰
△ Automatic 30°	Wash delicate items made from cotton, synthetic or blended fabrics. Gentle laundry care. The degree of soiling and the type of fabric are automatically detected. The washing process is adapted.	3,5	_	_	_	_	•	_	•	•	_
♣ Jeans/Dark Wash	Wash dark-coloured and colour-intense items made from cotton or easy-care fabric, e.g. jeans.  Turn laundry inside-out before washing.	4	40	1200	•	•	•	•	•	•	•
<sup>1</sup> Programme setting	ətting										

Programme	Description	Ма			P	ogra	Programme settings	tting	S		
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	SpeedPerfect =①	Water plus 🏝	Spin Speed Reduction ⊚  ☐ (Rinse Hold)	Prewash	ப்i-DOS ்	② i-DOS ↔	Intensive Plus ∰
⊙ Drum Clean	Cleaning and caring for the drum. Use this programme in the following cases:  Before using the appliance for the first time If you regularly wash at temperatures of 40 °C or lower non-use After a prolonged period of non-use Use washing powder or a detergent containing bleach. Halve the amount of detergent to avoid foaming. Do not use fabric softener. Do not use liquid detergent or detergent that is intended for woollens or delicates.	1	_	1200	_	_	_	_	_	_	_
1 Programme se	setting										

Programme	Description	Ма			P	ogra	Programme settings	tting	S		
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) <sup>1</sup>	SpeedPerfect =①	Water plus 🏝	Spin Speed Reduction ⊚  ☐ (Rinse Hold)	Prewash <b></b> ⊎	ப்i-DOS ்	② i-DOS ↔	Intensive Plus 🎳
	Note: The drum cleaning indicator will flash to remind you if you have not used a programme at 60 °C or higher for a long time.										
₹N Outdoor	Wash all-weather and outdoor clothing with membrane technology and water-resistant equipment. Use a detergent for outdoor fabrics. Do not use fabric softener.	2	40	800	  -	•	•	_	_	_	•
Ø/® Super Quick 15/30'	Wash items made from cotton, synthetic or blended fabrics. Short programme for small items of lightly soiled laundry. The programme duration is approx. 30 minutes.	4	40	1200	•	•	•	_	•	•	_
<sup>1</sup> Programme setting	etting										

#### 9 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order number
Water inlet hose extension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Fixing brackets	Improves the stability of the appliance.	WMZ2200

# 10 Before using for the first time


Prepare the appliance for use.

# 10.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.


**Note:** Please read the information in the Safety  $\rightarrow$  *Page 4* and Preventing material damage  $\rightarrow$  *Page 10* sections to ensure that you use the appliance safely.

1. Press ①.




It may take a few seconds for the appliance to switch on.

- 2. Set the **ODrum Clean** programme.
- 3. Close the door.
- 4. Pull out the detergent drawer.




5. Add washing powder to the manual dosing compartment.



To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

6. Push in the detergent drawer.



- 7. Press Start/Reload DII to start the programme.
- ✓ The display shows the remaining. programme duration.
- After the programme has ended, the display shows: -0-.
- 8. Start the first wash cycle or press ① to switch off the appliance.
  - → "Basic operation", Page 41

#### 11 Laundry

#### 11.1 Preparing the laundry

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

#### ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

- ► Remove all items from any pockets in your laundry before using the appliance.
- ► To protect your appliance and the laundry, prepare the laundry beforehand.
  - Empty any pockets
  - Brush sand out of all collars and pockets
  - Close bed covers and cushion covers
  - Close all zips, Velcro fasteners, hooks and eyes
  - Tie cloth belts, apron strings, etc. together or use a laundry bag.
  - Tie together longer drawstrings, and tie cords with solid endpieces in hoods or trousers
  - Remove curtain hooks and lead strips or use a mesh laundry baa
  - Use a mesh laundry bag for small items of laundry, such as children's socks
  - Some stubborn or dried-in stains can be removed by washing several times
  - Wash large and small items of laundry together
  - Do not rub fresh stains but dab them with soapy water

#### **en** Laundry

 Separate items of laundry and shake them out, or observe the programme description

#### 11.2 Sorting laundry

**Note:** Please read the information in the Safety → *Page 4* and Preventing material damage → *Page 10* sections to ensure that you use the appliance safely.

To improve washing results and prevent discolouration, sort the laundry according to the following criteria before washing.

- Type of fabric and fibre Wash laundry of the same type of fabric and fibre together.
- Care symbols on the care labels
   → Page 38
- Description of the programmes
   → Page 27
- Whites
- Colours

Wash new coloured items separately the first time you wash them.

#### 11.3 Degrees of soiling

Degree of soiling	Soiling	Examples
Light	<ul><li>No dirt or stains are visible</li><li>Laundry has absorbed odours</li></ul>	Light summer clothing or sports clothing that has been worn for a just a few hours
Normal	Dirt or light stains are visible	<ul> <li>T-shirts, shirts or blouses are sweat-soaked or have been worn a few times</li> <li>Towels or bedding that has been used for up to one week</li> </ul>
Heavy	Dirt or stains are clearly visible	Tea towels, baby items or work clothing

#### 11.4 Care symbols on the care labels

#### Washing care symbols

Symbol	Washing process	Recommended programme
<b>L L L L L L L L L L</b>	Normal	Cotton
<u> </u>	Gentle	Easy-Care
<u> </u>	Particularly gentle	Delicates/Silk for washing by hand
<b>E</b>	Hand wash	Wool

Symbol	Washing process	Recommended programme
***	Not suitable for machine-washing	_

#### 12 Detergents and care products

**Note:** Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

The manufacturer's instructions for use and dosage can be found on the packaging.

#### **Notes**

 Only use liquid detergents that are self-flowing

- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances (e.g. bleach)
- Use dyes sparingly as salt may damage stainless steel
- Do not use bleaching agents in the appliance
- Do not use laundry vinegar

#### 12.1 Detergent recommendation

Detergent	Fabrics	Pro- gramme	Temperature
Standard detergent with optical brighteners	Heat-resistant white fabrics made from cotton or linen	Cotton	From cold up to 90 °C
Detergent for colours without bleach or optical brighteners	Coloured fabrics made from linen or cotton	Cotton	From cold up to 60 °C
Detergent for col- ours/delicates without optical brighteners	Coloured fabrics made from easy-care fabrics or synthetic materials	Easy-Care	From cold up to 60 °C
Detergent for delicates	Delicate fine textiles, silk or viscose	Delicates/ Silk	From cold up to 40 °C
Detergent for woollens	Wool	Wool	From cold up to 40 °C

Tip: Visit www.cleanright.eu to find further information on detergents. care products and cleaning agents for domestic use.

#### 12.2 Detergent dosage

The detergent dosage depends on:

- The amount of laundry
- Degree of soiling
- Water hardness

You can find out how hard your water is from your local water company or measure it yourself using a water hardness tester.

#### Water hardness

Hardness range	Total hardness in mmol/	German degrees in °dH
soft (I)	0-1.5	0-8.4
medium (II)	1.5- 2.5	8.4-14
hard (III)	over 2.5	over 14

### Example of a manufacturer's instructions for detergent

These example values refer to a standard load of 4–5 kg.

Soiling	Light	Normal	Heavy
Water hardness: Soft/medium	40 ml	55 ml	80 ml
Water hardness: Hard/very hard	55 ml	80 ml	105 ml


The dosages can be found on the manufacturer's packaging.

- If you are not using manual dosage, adjust the dosage to the actual load.
- If intelligent dosing is activated, do not adjust the dosage to the actual load capacity. The quantity of detergent and fabric softener is automatically calculated via the basic dosage → Page 45 and the amount of laundry detected. The basic dosage setting must always comply with the dosage for a load of 4.5 kg.

#### 13 Basic operation

#### 13.1 Switching on the appliance

▶ Press ①.



It may take a few seconds for the appliance to switch on.


 ▼ The appliance performs an audible function test in the detergent drawer.

**Note:** The drum is lit up after the door is opened and closed and once the programme has started. The light goes out automatically.

#### 13.2 Setting a programme

1. Set the programme selector to the required programme.

→ "Programmes", Page 27



2. If necessary, adjust the programme settings → Page 41.

#### 13.3 Adjusting the programme settings

Requirement: A programme has been set.

- → "Setting a programme", Page 41
- Adjust the programme settings. → "Programmes", Page 27

#### **Notes**

- The programme settings are not saved permanently for the programme.
- The setting is saved if you activate or deactivate the intelligent dosing system.

#### 13.4 Loading laundry


#### **Notes**

- Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.
- To prevent creasing, take note of the maximum load for the

→ "Programmes", Page 27.

**Requirement:** The laundry is prepared and sorted.

- → "Laundry", Page 37
- 1. Open the door.



Make sure that the drum is empty.

- 2. Load the laundry unfolded into the drum.
- 3. Close the door.

Ensure that there is no laundry trapped in the door.

### 13.5 Adding detergent and care product

For programmes in which intelligent dosing is not possible or desirable, you can add detergent to the manual dosing compartment.

**Note:** Please read the information in the Safety  $\rightarrow$  *Page 4* and Preventing material damage  $\rightarrow$  *Page 10* sections to ensure that you use the appliance safely.

**Tip:** In addition to intelligent dosing, you can also add additional care product for laundry, e.g. stain remover, starch or bleach, to the manual dosing compartment. Do not add any additional detergent to the manual dosing compartment to avoid overdosage and/or foaming.

**Requirement:** Find out the optimum dosage for detergent and care product. → *Page 39* 

- 1. Pull out the detergent drawer.
- 2. Pour in detergent.
  - → "Detergent drawer", Page 20
- 3. If required, add the care product.
- 4. Push in the detergent drawer.

#### 13.6 Starting the programme

**Note:** If you want to change the time until the programme ends, set the "Ready in" time first.

- Press Start/Reload DII.
- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- The display shows either the programme duration or the "Ready in" time.

✓ After the programme has ended, the display shows: -0-.

#### 13.7 Soaking laundry

**Note:** No additional detergent is required. The washing solution is then used for washing.

- **1.** Start the programme.
- To pause the programme, after approx. 10 minutes, press Start/Reload DM.
- To resume the programme, after the desired soaking time, press Start/Reload DM.

#### 13.8 Adding laundry

**Note:** Please read the information in the Safety → *Page 4* and Preventing material damage → *Page 10* sections to ensure that you use the appliance safely.

1. Press Start/Reload DM.

The appliance is paused and checks whether it is possible to add or remove laundry. Take note of the programme status.

- 2. Add or remove laundry.
- 3. Close the door.
- 4. Press Start/Reload DII.

### 13.9 Cancelling the programme

Once the programme has started, you can cancel it at any time.

**Note:** Please read the information in the Safety  $\rightarrow$  *Page 4* and Preventing material damage  $\rightarrow$  *Page 10* sections to ensure that you use the appliance safely.

- 1. Press Start/Reload DM.
- 2. Open the door.

The appliance door remains locked for safety reasons if the temperature and water levels are high.

- If the temperature is high, start the **Rinse** programme.
- If the water level is high: Start the **Spin** or **Tonain** programme.
- 3. Remove the laundry.


#### 13.10 Resuming the programme when the programme status is Rinse Hold

- 1. Set the Spin or Train programme.
- 2. Press Start/Reload DM.

#### 13.11 Unloading the laundry


**Note:** Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

- 1. Open the door.
- 2. Remove the laundry.



#### 13.12 Switching off the appliance

1. Press (I)



2. Wipe the rubber gasket dry and remove any foreign objects.



3. Leave the door and detergent drawer open so that residual water can evaporate.

#### 14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

#### 14.1 Activating the childproof lock

- Press and hold the two Child Lock **3 sec.** buttons for approx. 3 seconds.

- ▼ The controls are locked.
- The childproof lock remains active even after the appliance has been switched off.

#### 14.2 Deactivating the childproof lock

**Requirement:** To deactivate the childproof lock, the appliance must be switched on.

Press and hold the two Child Lock
 3 sec. buttons for approx.
 3 seconds.

So that the programme currently running is not cancelled, the programme selector must be set to the initial programme.

✓ come goes out in the display.

### 15 Intelligent dosing system

The optimum quantities of liquid detergent and fabric softener are dispensed automatically depending on the programme and settings.

#### 15.1 Filling the dispenser


#### Note

In order to use intelligent dosing, fill the dispenser.


- Fill the dispenser only with suitable detergent and care products
   → Page 39.
- If you change the liquid detergent or fabric softener, empty and clean the dispenser beforehand.
  - → "Cleaning the detergent drawer", Page 51
- If you want to use both dispensers for liquid detergent, adjust the contents of the dispenser → Page 44.

**Requirement:**  $\lozenge/ \otimes$  flashes.

- 1. Pull out the detergent drawer.
- 2. Open the dispenser lid.



- Pour liquid detergent ◊ and fabric softener ⊗ into the relevant dispensers.
  - → "Detergent drawer", Page 20



4. Close the dispenser lid.

**Note:** To prevent the detergent from drying out or drying up, do not leave the dispenser lid open for a long period of time.

- 5. Push in the detergent drawer.
- 6. Adjust the basic dosage → Page 45.

#### 15.2 Dispenser contents

#### Notes

 If you change the content of the dispenser, the basic dosage for this dispenser is reset. If you use both dispensers for liquid detergent, you must select a dispenser which is to be used during washing.

#### Adjusting the dispenser contents

- 1. Press and hold 2 i-DOS for approx. 3 seconds.
- 2. To set  $\Diamond$ , press  $\supseteq$  i-DOS.
- ✓ The display shows δ.
- 3. To set ⊗, press 2 i-DOS again.
- **4.** To end the setting process, wait briefly.

#### 15.3 Basic dosage

The basic dosage depends on the manufacturer's instructions for the detergent, the water hardness and the degree of soiling of the laundry. Always set a basic dosage that corresponds to the dosage for a standard load of 4.5 kg.

→ "Detergent dosage", Page 40

#### Adjusting the basic dosage

- Press and hold i-DOS for approx. 3 seconds.
- The display shows the basic dosage set for δ.
- 2. To adjust the setting, press / +.
- 3. To end the setting process, wait briefly.

**Note:** To adjust the basic dosage for ⊕, repeat the steps with ② **i-DOS**.

#### 16 Home Connect

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: www.home-connect.com.

- → "Connecting the appliance to a WLAN home network (Wi-Fi) with WPS function", Page 45
- → "Connecting the appliance to a WLAN home network (Wi-Fi) without WPS function", Page 46
  The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

#### **Tips**

- Please consult the documents supplied by Home Connect.
- Please also follow the instructions in the Home Connect app.

#### Notes

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app. → "Safety", Page 4
- Operating the appliance on the appliance itself always takes priority.
   During this time it is not possible to operate the appliance using the Home Connect app.


#### 16.1 Connecting the appliance to a WLAN home network (Wi-Fi) with WPS function

**Requirement:** If your router has a WPS function, you can connect the appliance to your WLAN home network (Wi-Fi) automatically.

#### en Home Connect

- Press and hold Remote Start 

   <sup>↑</sup> for approx. 3 seconds.
- ✓ The display shows Aut.
- 2. Press Start/Reload DII.
- Press the WPS button on the router within the next 2 minutes.
   Take note of the information in the documents for your router.
- flashes in the display.
- The appliance attempts to connect to your WLAN home network.
- If the display shows con and lights up permanently, the appliance is connected to the home network.



- If the display shows Err, the appliance is not connected to the home network.
  - Check whether your appliance is in range of your home network.
  - Reconnect the appliance to the WLAN home network (Wi-Fi) with WPS function.
- 5. Connect your appliance to the Home Connect app. → Page 47

# 16.2 Connecting the appliance to a WLAN home network (Wi-Fi) without WPS function

If your router does not have a WPS function, you can connect the appliance to your WLAN home network

(Wi-Fi) manually. The appliance briefly sets up its own Wi-Fi network. You can connect a mobile device to the WLAN network and transfer the network information for the WLAN home network (Wi-Fi) to your appliance.


**Requirement:** The Home Connect app is open and you have logged on.

- Press and hold Remote Start 

   <sup>↑</sup> for at least 3 seconds.
- ✓ The display shows Aut.
- **2.** Set the programme to position 2.
- ✓ The display shows SAP.
- 3. Press Start/Reload DM.
- The appliance now sets up its own Wi-Fi network with the name (SSID) HomeConnect.



- **4.** Call up the Wi-Fi settings on the mobile device.
  - Connect the mobile device to the HomeConnect Wi-Fi network and enter the password (key) Home-Connect.
- Your mobile device now connects to the appliance. The connection process may take up to 60 seconds.



- 5. Open the Home Connect app on your mobile device and carry out the steps in the app.
- In the Home Connect app, enter the network name (SSID) and password (key) for your home network.
- Carry out the steps in the Home Connect app to connect the appliance.
- If the display shows con and lights up permanently, the appliance is connected to the home network.
- If the display shows Err, the appliance is not connected to the home network.
  - Check whether your appliance is in range of your home network.
  - Reconnect the appliance to the WLAN home network (Wi-Fi) with WPS function.
- Connect your appliance to the Home Connect app → Page 47.

## 16.3 Connecting the appliance to the Home Connect app

#### Requirements

- The appliance is connected to the WLAN home network (Wi-Fi).
- The Home Connect app is open and you have logged on.

- 1. Set the programme to position 3.
- ✓ The display shows APP.
- 2. Press Start/Reload DM.
- ▼ The appliance connects to the Home Connect app.
- 3. Once your appliance is displayed in the Home Connect app, carry out the last steps in the Home Connect app.
- If the display shows con, the appliance is connected to the Home Connect app.

#### 16.4 Connecting the appliance to the energy manager

If you connect the appliance to the smart energy system (energy manager), you will optimise your energy consumption. The appliance starts only when your home photovoltaic system can provide sufficient energy or the energy tariff is good.

#### Requirements

- The smart energy system (energy manager) must use the EEBus Initiative communications standard.
- You have read about how to connect your appliance to the smart energy system (energy manager) in the instruction manual for the smart energy system (energy manager).
- Press and hold Remote Start □ for approx. 3 seconds.
- The display shows Aut.
- **2.** Set the programme to position 7.
- The display shows EnG.
- 3. Press Start/Reload DII.
- The appliance is connected to the smart energy system (energy manager).

- If the appliance has connected to the energy manager successfully, the display shows con and e<sup>n</sup>.
- Activate Flex Start if you want the smart energy system (energy manager) to start up your appliance.
   → "Activate Flex Start", Page 48

#### **Activate Flex Start**

Activate Flex Start to allow your smart energy system (energy manager) to start your appliance once your home photovoltaic system is able to provide sufficient energy or the energy tariff is good.

**Requirement:** The smart energy system (energy manager) cannot start your appliance until it is connected to the appliance.

- 1. Set the programme you require.
- 2. Press Finished in + (9) to set the required time.
- 3. Press Start/Reload DII.
- 4. Press Remote Start ⊓.
- ✓ The display shows e<sup>®</sup> and Flex Start is activated. The appliance waits to be started by the smart energy system (energy manager).
- If the time changes on the display, e.g. to 8 h, the smart energy system (energy manager) has established a time at which your appliance can start.
- If the smart energy system (energy manager) does not start the appliance within the set time, the appliance will start the programme itself before the set time period ends. The programme ends when the time period ends.

#### Note

Flex Start is deactivated for safety reasons in the following circumstances:

- Press Start/Reload DM.
- Open the door.

- Switch off the appliance.
- Power failure.

### 16.5 Activating Wi-Fi on the appliance

**Note:** When Wi-Fi is activated, the energy consumption increases in comparison to the values specified in the consumption value table.

- Press and hold Remote Start □ for approx. 3 seconds.
- 2. Set the programme to position 4.
- ✓ The display shows Con.
- 3. Press **Start/Reload DII** repeatedly until the display shows **On**.
- ✓ Wi-Fi is activated.

**Note:** If Wi-Fi is activated, the appliance will not switch itself off automatically.

### 16.6 Deactivating Wi-Fi on the appliance

- **2.** Set the programme to position 4.
- ✓ The display shows Con.
- Press Start/Reload D repeatedly until the display shows OFF.
- Wi-Fi is deactivated.

**Note:** If Wi-Fi is switched off and your appliance was previously connected to your home network, this connection will be re-established automatically when Wi-Fi is switched back on.

#### 16.7 Software update

**Requirement:** The display shows **UPd**.

 Press and hold Remote Start ☐ for approx. 3 seconds.

- 2. Set the programme to position 6.
- UPd appears on the display.
- 3. Press Start/Reload DM.
- The software update is installed.
- If End is shown on the display, the software update is installed.

**Note:** The software update may take several minutes. Do not switch off the appliance while the software update is in progress.

### 16.8 Resetting the appliance network settings

- 2. Set the programme to position 5.
- ✓ The display shows rES.
- 3. Press Start/Reload DII.
- ✓ The display shows YES.
- 4. Press Start/Reload DII.
- The network settings are reset.
- If End is shown on the display, the network settings are reset.

**Tip:** If you wish to operate your appliance again via the Home Connect app, you will need to reconnect it to the Wi-Fi and to the Home Connect app.

#### 16.9 Remote diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance.

**Tip:** For further information and details about the availability of Remote Diagnostics in your country, please visit the service/support section of your local website: www.home-connect.com

#### 16.10 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the Wi-Fi communication module installed).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous reset to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time


**Note:** Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

#### 17 Basic settings

You can configure the appliance to meet your needs.

#### 17.1 Overview of basic settings


Below is an overview of the basic settings on your appliance.



Basic setting	Programme position	Value	Description
End signal	2	0 (off) 1 (quiet) 2 (medium) 3 (loud) 4 (very loud)	Set the volume of the signal at the end of the pro- gramme.
Button signal	3	0 (off) 1 (quiet) 2 (medium) 3 (loud) 4 (very loud)	The volume of the audible signal emitted when the buttons are pressed.
Drum cleaning reminder	4	ON OFF	Activate or deactivate the reminder to clean the drum.

#### 17.2 Changing the basic settings

1. Set the programme selector to position 1



- 2. Press Spin Speed Reduction © and, at the same time, turn the programme selector to position 2.
- The display shows the current value.
- 3. Set the programme selector to the required position.
- 4. To change the value, press / +.
- 5. To save the changes, switch off the appliance.

#### 18 Cleaning and servicina

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

#### 18.1 Tips on appliance care

Wipe down the housing and the control panel with nothing but water and a damp cloth.

This ensures the parts of the appliance will remain clean and hygienic.

Remove all de-	Fresh c
tergent residue,	are eas
spray residue or	move v
other residues	leaving
immediately.	residue
Keep the appli-	This all
ance door and	residua

deposits sier to rewithout any

lows the sidual water to dry, reducing detergent drawer odours in the appliance.

#### 18.2 Cleaning the drum

#### ⚠ CAUTION Risk of injury!

open after use.

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.

- ► Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- ▶ Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- ► Run the **OP** Drum Clean programme without laundry. Add washing powder.


#### 18.3 Cleaning the detergent drawer

If you change detergent or the detergent drawer is dirty, clean the detergent drawer and the pump unit of the intelligent dosing system.


**Note:** Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

- **1.** Switch off the appliance.
- **2.** Pull out the detergent drawer.


- en Cleaning and servicing
- **3.** Press down on the insert and remove the detergent drawer.




4. Remove the pump unit.




**5.** Unclip the detergent drawer lid and remove it.




6. Empty the detergent drawer.




- **7. ATTENTION!** The pump unit contains electrical components.
- ► Do not clean the pump unit in the dishwasher and do not immerse it in water.
- Protect the electrical connection on the rear against water, detergent and fabric softener residue.
   Clean the pump unit with a damp cloth.




8. Clean the detergent drawer and the lid with a soft, damp cloth or hand shower




9. Dry the detergent drawer, lid and pump unit and reinsert them.





10. Clean the inside of the detergent drawer housing.



11. Push in the detergent drawer.

#### 18.4 Descaling

#### ATTENTION!

The use of unsuitable descaling agents, e.g. for coffee machines, may damage the appliance.

► For this appliance, only use descaling agents that are available from the manufacturer's website or our after-sales service.

#### 18.5 Cleaning the drain pump


Clean the drain pump in the event of faults, e.g. blockages or rattling noises.

#### **Emptying the drain pump**


Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

- 1. Turn off the water tap.
- 2. Switch off the appliance.
- 3. Disconnect the appliance's mains plug from the power supply.


4. Open the maintenance flap.




5. Remove the maintenance flap.



**6.** Slide a sufficiently large receptacle under the opening.




**7.** Take the drain hose out of the holder.




- 8. A CAUTION Risk of scalding!
  When you wash at high temperatures, the detergent solution gets
- ► Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



9. Firmly press on the sealing cap.



10. Insert the drain hose into the holder.




#### Cleaning the drain pump


**Note:** Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

Requirement: The drain pump is empty. → Page 53

- 1. Since water may remain in the drain pump, remove the pump cap carefully.
  - The filter insert in the pump housing may become stuck due to coarse particles of dirt. Loosen the dirt and remove the filter insert.




2. Clean the interior, the thread on the pump cap and the pump housing.




The pump cap is comprised of two parts which can be taken apart for cleaning.

3. Ensure that both impellers can turn.




- 4. Insert the pump cap.
  - Ensure that the parts of the pump cap are correctly assembled.




#### en Cleaning and servicing

5. Insert the pump cap and screw it on as far as it will go.



The handle on the pump cap must be in a vertical position.

**6.** Insert the maintenance flap and lock it into place.




7. Close the maintenance flap.

## 18.6 Cleaning the intake opening in the rubber gasket

Regularly check the intake opening in the rubber gasket for any blockages and clean the intake opening.

1. Open the door.


Check the intake opening for blockages and remove any blockages.



**Note:** Do not use any sharp or pointed objects.


### 18.7 Cleaning the water outlet hose at the siphon

- **1.** Switch off the appliance.
- 2. Disconnect the appliance's mains plug from the power supply.
- 3. Loosen the hose clamp and carefully remove the water outlet hose.




Residual water may leak out.

4. Clean the water outlet hose and siphon connecting piece.



5. Reattach the water outlet hose and secure the connection point using the hose clamp.



#### 18.8 Cleaning the water inlet filter

#### Emptying the water inlet hose

In order to clean the filter, first empty the water inlet hose.


- 1. Turn off the tap.
- **2.** Set the **Cottons 1** programme.
- 3. Start the programme and leave it to run for approx. 70 seconds.
- 4. Switch off the appliance.
- 5. Disconnect the appliance's mains plug from the power supply.

#### Cleaning the filter on the tap


**Note:** Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

Requirement: The water inlet hose is emptv.


1. Remove the water inlet hose from the tap.



Clean the filter with a small brush.



- en Cleaning and servicing
- **3.** Connect the water inlet hose and check for leaks.



#### 19 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.



#### 🗥 WARNING

#### Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

porcon in order to provent any note.	
Fault	Cause and troubleshooting
The display goes out and <b>Start/Reload</b> DIII flashes.	Energy-saving mode is active  ▶ Press any button.  ✓ The symbol lights up again.
"E:30 / -80"	Drain pipe or water outlet hose is blocked.  • Clean the drain pipe and the water outlet hose.
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>► Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>
	Drain pump is blocked.  ► → "Cleaning the drain pump", Page 53
	The water outlet hose is connected too high.  ► Install the water outlet hose at a maximum height of 1 metre.
	Pump cover is not correctly assembled.  Correctly assemble the pump cover.
	Detergent dosage is too high.  ► Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed

If intelligent dosing is activated, reduce the basic

▶ If you dose manually, reduce the amount of detergent for the next washing cycle with the same load.

with down).

dosage → Page 45.

Fault	Cause and troubleshooting
"E:30 / -80"	Unapproved extension installed on the water drain hose.  • Remove any unapproved extensions from the water
	hose. Connecting the appliance
"E:36 / -25 / -26"	Drain pump is blocked.  ► → "Cleaning the drain pump", Page 53
"E:38 / -25 / -26"	Drain pump is blocked.  ► → "Cleaning the drum", Page 51
	if the fault is displayed again,  ► → "Cleaning the drain pump", Page 53
	<ul> <li>Inlet opening of the rubber gasket is blocked.</li> <li>→ "Cleaning the intake opening in the rubber gasket", Page 56</li> </ul>
"E:10 / -00 / -10 / -20"	<ul> <li>The pump for the intelligent dosing system is blocked.</li> <li>1. Switch off the appliance.</li> <li>2. Clean the pump unit.  → "Cleaning the detergent drawer", Page 51</li> <li>3. If this indicator appears again, call our after-sales service.  → "Customer Service", Page 72</li> </ul>
	<b>Note:</b> You can start the washing programme if you deactivate the intelligent dosing system and dose manually.  → "Buttons", Page 24
足	The water pressure is low. No remedial action possible. The filter in the water inflow is blocked.
	<ul> <li>Clean the water inflow filter → Page 57.</li> <li>The tap is turned off.</li> <li>Turn on the tap.</li> </ul>
	The water inlet hose is kinked or jammed.  ► Ensure that the water inlet hose is not kinked or jammed.
"E:35 / -10"	There is water in the base trough.  ► Turn off the water tap.  ► Call the after-sales service.  → "Customer Service", Page 72
	The appliance is leaking. ► Turn off the water tap.

Fault	Cause and troubleshooting
"E:35 / -10"	► Call the after-sales service.  → "Customer Service", Page 72
	The detergent drawer has not been pushed in as far as it can go.  Push the detergent drawer in as far as it will go.
	<ul> <li>The pump unit is not inserted.</li> <li>1. Insert the pump unit into the detergent drawer.  → "Cleaning the detergent drawer", Page 51</li> <li>2. Push the detergent drawer in as far as it will go.</li> </ul>
****	<ul> <li>Detergent dosage is too high.</li> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down).</li> <li>If intelligent dosing is activated, reduce the basic dosage → Page 45.</li> <li>If you dose manually, reduce the amount of detergent for the next washing cycle with the same load.</li> </ul>
(1) lights up.	The temperature is too high.  ► Wait until the temperature has dropped.  ► → "Cancelling the programme", Page 42
	Water level is too high. ► Start the <b>Train</b> programme.
	<ol> <li>Laundry is caught in the door.</li> <li>Open the door again.</li> <li>Remove any trapped laundry.</li> <li>Close the door.</li> <li>Press Start/Reload DI to start the programme.</li> </ol>
(D) flashes.	Door is not closed.  1. Close the door.  2. Press Start/Reload DII to start the programme.
All other error codes.	Malfunction ► Call the after-sales service. → "Customer Service", Page 72
The appliance is not working.	The mains plug of the power cord is not plugged in.  ► Connect the appliance to the power supply.
	The circuit breaker is faulty.  ► Check the circuit breaker in the fuse box.

#### en Troubleshooting

Fault	Cause and troubleshooting
The appliance is not working.	<ul><li>There has been a power cut.</li><li>Check whether the lighting in your kitchen or other appliances are working.</li></ul>
The programme does not start.	You have not pressed <b>Start/Reload DII</b> . ▶ Press <b>Start/Reload DII</b> .
	Door is not closed.  1. Close the door.  2. Press Start/Reload ▷ II to start the programme.
	Childproof lock is activated.  ► → "Deactivating the childproof lock", Page 44
	- Finished in + ⊕ is activated.  ► Check whether - Finished in + ⊕ is activated.  → "Buttons", Page 24
	Laundry is caught in the door.  1. Open the door again.  2. Remove any trapped laundry.  3. Close the door.  4. Press Start/Reload ▷ II to start the programme.
	The detergent drawer has not been pushed in as far as it can go.  Push the detergent drawer in as far as it will go.
	<ul> <li>The pump for the intelligent dosing system is blocked.</li> <li>1. Switch off the appliance.</li> <li>2. Clean the pump unit.  → "Cleaning the detergent drawer", Page 51</li> <li>3. If this indicator appears again, call our after-sales service.  → "Customer Service", Page 72</li> </ul>
	Note: You can start the washing programme if you deactivate the intelligent dosing system and dose manually.  → "Buttons", Page 24
The door cannot be opened.	<ul> <li>         is activated.     </li> <li>Continue the programme by selecting</li></ul>
	The temperature is too high.  ► Wait until the temperature has dropped.  ► → "Cancelling the programme", Page 42

Fault	Cause and troubleshooting			
The door cannot be opened.	Water level is too high.  ► Start the <b>Train</b> programme.			
	Power failure.  ► Open the door using the emergency release.  → "Emergency release", Page 70			
The water is not draining.	Drain pipe or water outlet hose is blocked.  ► Clean the drain pipe and the water outlet hose.			
	<ul><li>Drain pipe or water drain hose is caught or jammed.</li><li>► Ensure that the drain pipe and water drain hose are not kinked or trapped.</li></ul>			
	Drain pump is blocked.  ► → "Cleaning the drain pump", Page 53			
	<ul> <li>         is activated.     </li> <li>Continue the programme by selecting ⑤ Spin or ௵ Drain and pressing Start/Reload ▷ III.     </li> <li>         i''Resuming the programme when the programme status is Rinse Hold", Page 43     </li> </ul>			
	The water outlet hose is connected too high.  ▶ Install the water outlet hose at a maximum height of 1 metre.			
	Pump cover is not correctly assembled.  Correctly assemble the pump cover.			
	<ul> <li>Detergent dosage is too high.</li> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down).</li> <li>If intelligent dosing is activated, reduce the basic dosage → Page 45.</li> </ul>			
	<ul> <li>If you dose manually, reduce the amount of detergent for the next washing cycle with the same load.</li> </ul>			
	Unapproved extension installed on the water drain hose.  ▶ Remove any unapproved extensions from the water hose. Connecting the appliance			
Water is not flowing in. Detergent is not	You have not pressed <b>Start/Reload DII</b> .  ▶ Press <b>Start/Reload DII</b> .			
being dispensed.	The filter in the water inflow is blocked.  ► Clean the water inflow filter → Page 57.			

#### en Troubleshooting

Fault	Cause and troubleshooting			
Water is not flowing in. Detergent is not	The tap is turned off.  ► Turn on the tap.			
being dispensed.	The water inlet hose is kinked or jammed.  ► Ensure that the water inlet hose is not kinked or jammed.			
The spin cycle runs several times.	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry.  ▶ Not a fault – no action required.			
	<b>Note:</b> When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
The programme duration changes during the wash cycle.	The programme operation is optimised electronically. This may change the programme duration.  Not a fault – no action required.			
	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry.  ▶ Not a fault – no action required.			
	<b>Note:</b> When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
	Foam detection system switches on a rinse cycle if foam build-up is too high.  Not a fault – no action required.			
No water is visible in the drum.	<ul> <li>Water is below the visible area.</li> <li>▶ Not a fault – no action required.</li> <li>▶ Do not add any extra water to the appliance while it is operating.</li> </ul>			
Drum jerks after the programme starts.	This is caused by an internal motor test.  ▶ Not a fault – no action required.			
Vibrations and movement of the appliance	Appliance is not correctly aligned. ► Aligning the appliance			
whilst spinning.	The appliance feet are not fixed. ► Secure the appliance feet. Aligning the appliance			
	Transit bolts have not been removed.  ▶ Removing the transit bolts			

	Troubleshooting Cit			
Fault	Cause and troubleshooting			
Drum does not turn, water does not flow in.	Load detection is active.  ► Not a fault – no action required.			
	Note: The load detection can take up to two minutes.			
Heavy foam build-up	<ul> <li>Detergent dosage is too high.</li> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down).</li> <li>If intelligent dosing is activated, reduce the basic dosage → Page 45.</li> </ul>			
	If you dose manually, reduce the amount of detergent for the next washing cycle with the same load.			
i-DOS 2 i-DOS cannot be actuated.	Intelligent dosing is not intended for this programme.  ▶ Not a fault – no action required.			
	Programme progress does not allow intelligent dosing.  No remedial action possible.			
High spin speed not reached.	<ul><li>A low spin speed is selected.</li><li>▶ The next time you run a wash cycle, set a higher spin speed.</li></ul>			
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.  ▶ Redistribute the laundry in the drum.			
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
	► Start the ⑤ Spin programme.			
The spin programme does not start.	Drain pipe or water outlet hose is blocked.  Clean the drain pipe and the water outlet hose.			
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>► Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>			
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.  • Redistribute the laundry in the drum.			
	Trodiction in lauriary in the drain.			

**Note:** Where possible, mix large and small items in the drum. Different sized items of laundry distribute

themselves better during the spin cycle.

#### en Troubleshooting

Fault	Cause and troubleshooting
The spin programme does not start.	► Start the <b>Spin</b> programme.
Rushing, hissing noise.	Water is flushed under pressure into the detergent drawer.
	► Not a fault – normal operating noise.
Longer, whirring noise before the start of the wash cycle or fabric softening.	Intelligent dosing system dispenses detergent or care products.  ► Not a fault – normal operating noise.
Brief whirring noise after switching on the appliance.	Intelligent dosing system carries out a function test.  Not a fault – normal operating noise.
Loud noises during the spin cycle.	Appliance is not correctly aligned.  ► Aligning the appliance
	The appliance feet are not fixed.  ▶ Secure the appliance feet. Aligning the appliance
	Transit bolts have not been removed.  ▶ Removing the transit bolts
Banging noises, rattling in the drain pump.	Foreign bodies have got into the drain pump.  ▶ → "Cleaning the drain pump", Page 53
Slurping, rhythmical suction noise.	The drain pump is active, the detergent solution is pumped out.  ▶ Not a fault – normal operating noise.
Creasing.	The spin speed is too high.  ➤ The next time you run a wash cycle, set a lower spin speed.
	The load is too large.  ► The next time you run a wash cycle, reduce the amount of laundry being loaded.
	The wrong programme is selected for the type of fabric.
	<ul> <li>Select the programmes that are suitable for the type of fabric.</li> <li>→ "Programmes", Page 27</li> </ul>
The spin result is not satisfactory. The laundry is too wet/too damp.	<ul> <li>A low spin speed is selected.</li> <li>► The next time you run a wash cycle, set a higher spin speed.</li> <li>► Start the ⑤ Spin programme.</li> </ul>
	Drain pipe or water outlet hose is blocked.

	٠	. 14
Н	aι	ш

#### The spin result is not satisfactory. The laundry is too wet/too damp.

#### Cause and troubleshooting

► Clean the drain pipe and the water outlet hose.

Drain pipe or water drain hose is caught or jammed.

► Ensure that the drain pipe and water drain hose are not kinked or trapped.

The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.

Redistribute the laundry in the drum.

**Note:** Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.

▶ Start the ⑤ **Spin** programme.

Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.

Redistribute the laundry in the drum.

**Note:** Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.

Start the Spin programme.

#### Detergent residue on the damp washing.

Detergents may contain water-insoluble substances that deposit on the laundry.

▶ Start the **r** Rinse programme.

Unsuitable detergent added to the dispenser of the intelligent dosing system.

- 1. Check whether the detergent used is suitable. → "Detergents and care products", Page 39
- 2. Drain the dispenser.
  - → "Cleaning the detergent drawer", Page 51
- **3.** Clean the dispenser.
- **4.** Refill the dispenser.
  - → "Filling the dispenser", Page 44

Basic dosage is not correctly adjusted.

▶ If intelligent dosing is activated, reduce the basic dosage → Page 45.

#### Detergent residue on the dry laundry.

Detergents may contain water-insoluble substances that deposit on the laundry.

Brush out the laundry after washing and drying.

Unsuitable detergent added to the dispenser of the intelligent dosing system.

Fault	Occupa and treathlesh action
Fault	Cause and troubleshooting
Detergent residue on the dry laundry.	<ol> <li>Check whether the detergent used is suitable.         → "Detergents and care products", Page 39</li> <li>Drain the dispenser.         → "Cleaning the detergent drawer", Page 51</li> <li>Clean the dispenser.</li> </ol>
	<ol> <li>Refill the dispenser.</li> <li>→ "Filling the dispenser", Page 44</li> </ol>
	<ul> <li>Basic dosage is not correctly adjusted.</li> <li>▶ If intelligent dosing is activated, reduce the basic dosage → Page 45.</li> </ul>
Insufficient cleaning.	<ul> <li>Basic dosage is not correctly adjusted.</li> <li>▶ If intelligent dosing is activated, adjust the basic dosage → Page 45 correctly.</li> </ul>
	Detergent or care products have congealed in dispensers of the intelligent dosing system.  1. Check whether the detergent used is suitable.  → "Detergents and care products", Page 39  2. Drain the dispenser.  → "Cleaning the detergent drawer", Page 51  3. Clean the dispenser.  4. Refill the dispenser.  → "Filling the dispenser", Page 44
	Unsuitable detergent added to the dispenser of the intelligent dosing system.  1. Check whether the detergent used is suitable.  → "Detergents and care products", Page 39  2. Drain the dispenser.  → "Cleaning the detergent drawer", Page 51  3. Clean the dispenser.  4. Refill the dispenser.  → "Filling the dispenser", Page 44
HomeConnect is not working correctly.	Different causes are possible.  ► Go to www.home-connect.com.
No connection to the home network.	Wi-Fi is switched off.  ► → "Activating Wi-Fi on the appliance", Page 48
	Wi-Fi is activated but a connection to your home network cannot be established.  1. Ensure that the home network is available.

Fault	Cause and troubleshooting			
No connection to the home network.	2 Reconnect the appliance to the home network.  → "Connecting the appliance to a WLAN home network (Wi-Fi) with WPS function", Page 45  → "Connecting the appliance to a WLAN home network (Wi-Fi) without WPS function", Page 46			
Water is leaking out at the water inlet hose.	<ul><li>Water inlet hose is not correctly/securely connected.</li><li>1. Connect the water supply hose correctly. Connecting the water inlet hose</li><li>2. Tighten the screw connection.</li></ul>			
Water is leaking out at the water outlet hose.	The water outlet hose is damaged.  ▶ Replace the damaged water outlet hose.			
	Water outlet hose is not connected correctly.  ► Connect the water outlet hose correctly. Water outlet connection types			
Odours have formed in the appliance.	<ul> <li>Humidity and detergent residue may promote the formation of bacteria.</li> <li>► → "Cleaning the drum", Page 51</li> <li>► If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate.</li> </ul>			


#### 19.1 Emergency release

#### Releasing the door

**Requirement:** The drain pump is empty. → Page 53

- 1. **ATTENTION!** Escaping water may cause material damage.
- ▶ Do not open the door if you can see water through the glass. Pull the emergency release down-

wards with a tool and release.



- The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

#### 20 Transportation, storage and disposal

You can find out here how to prepare your appliance for transportation and storage. You will also find out how to dispose of old appliances.

#### 20.1 Removing the appliance


- 1. Turn off the tap.
- 2. → "Emptying the water inlet hose", Page 57.
- 3. Switch off the appliance.
- 4. Unplug the appliance's mains plug.

- 5. Drain the remaining detergent solution.
  - → "Cleaning the drain pump". Page 53
- 6. Detach the hoses.
- 7. Empty the dispensers.

#### 20.2 Inserting the transit **bolts**


Secure the appliance for transportation using transit bolts in order to prevent damage.

- 1. Remove the four cover caps.
  - If necessary, use a screwdriver to remove the cover caps.




Keep the cover caps.


2. Insert the four sleeves.




3. Insert all screws into the four transit bolts and tighten slightly.



4. Insert the power cord into the holder 1 and tighten all four screws for the transit bolts with a WAF 13 wrench 2.



5. Insert the hose into holder.



#### 20.3 Using the appliance again

Remove the transit bolts.

#### 20.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

#### ⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

#### 21 Customer Service

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service.

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

**Note:** Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

#### 21.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

#### 21.2 AQUA-STOP quarantee

In addition to warranty claims against the seller under the purchase agreement and in addition to our manufacturer's warranty, we offer compensation under the following conditions.

- If our Aqua-Stop system is defective and causes water damage, we will make good the damage for private users. To ensure protection from water damage, the appliance must be connected to the power vlagus.
- The liability guarantee is valid for the service life of the appliance.
- A claim can only be made under the guarantee if the appliance has been correctly installed and connected with Agua-Stop according to our instructions: this also includes correctly fitting the Aqua-Stop extension (genuine accessory). Our guarantee does not cover defective supply lines or fittings up to the Agua-Stop connection on the tap.
- If your appliance is fitted with Aqua-Stop, you can in principle leave your appliance unattended during operation and the tap turned on afterwards. The tap only needs to be turned off if you are away from home for a long period, e.g. on holiday for several weeks.

#### 22 Consumption values

The following information is provided in accordance with the EU Ecodesign Regulation. The values given for programs other than the **Eco 40-60** are indicative only and were determined in accordance with the applicable standard EN60456. The automatic dosing function has been deactivated for this purpose.

Note on the comparison test: Deactivate the automatic dosing function unless this function is the object of the test.

Programme	Load (kg)	Pro- gramm e dura- tion (hr:min	Energy con- sump- tion (kWh/ cycle) <sup>1</sup>	Water con- sump- tion (I/ cycle) <sup>1</sup>	Max- imum temper- ature (°C) 5 mins <sup>1</sup>	Spin speed (rpm) <sup>1</sup>	Residual moisture (%)1
Eco 40-60 <sup>2</sup>	10,0	3:55	1,200	70,0	40	1600	44,00
Eco 40-60 <sup>2</sup>	5,0	2:55	0,650	48,0	33	1600	44,00
Eco 40-60 <sup>2</sup>	2,5	2:45	0,330	36,0	25	1600	44,00
Cottons 🛣 20 °C	10,0	3:15	0,500	95,0	24	1600	46,00
Cottons 🛣 40 °C	10,0	3:36	1,400	95,0	42	1600	46,00
Cottons 🛣 60 °C	10,0	3:32	2,150	95,0	60	1600	46,00
Cottons 🛣 40 °C + Prewash 🕹	10,0	4:14	1,450	105,0	42	1600	46,00
Easy-Care 企 40 °C	4,0	2:29	0,780	58,0	43	1200	30,00
Quick Mix >>> 12/10 40 °C	4,0	1:00	0,650	44,0	41	1600	52,00
	2,0	0:41	0,200	40,0	25	800	25,00

Due to the influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions, the actual values may deviate from the stated values.

Test programme in accordance with the EU Ecodesign Directive and the EU Energy Labelling Regulation with cold water (15 °C).

#### 23 Technical specifications

Appliance height	85,0 cm
Appliance width	60,0 cm
Appliance depth	64,0 cm
Weight	73 kg <sup>1</sup>
Maximum load	10,0 kg
Mains voltage	220 - 240 V, 50 Hz
Minimum installation protection	10 A
Rated power	2300 W
Power consumption	<ul> <li>Off mode: 0,10 W</li> <li>Left-on mode: 0,50 W</li> <li>Time until the networked standby mode is set (Wi-Fi): 5 Min.</li> <li>Networked standby mode (Wi-Fi): 1,50 W</li> </ul>
Water pressure	<ul> <li>Minimum:         <ul> <li>100 kPa</li> <li>(1 bar)</li> </ul> </li> <li>Maximum:         <ul> <li>1000 kPa</li> <li>(10 bar)</li> </ul> </li> </ul>
Length of the water inlet hose	150 cm
Length of the water outlet hose	150 cm
4	

Depending on the appliance spe-

Length of the	160 cm	
power cord		

Depending on the appliance specifications

This product contains light sources from energy efficiency class F. These light sources are available as a spare part and must only be replaced by trained specialist staff.

You can find more information about your model online at https:// eprel.ec.europa.eu/1. This web address is linked to the official EU EPREL product database. At the time of printing, its web address had not vet been published. Please then follow the instructions on searching for models. The model identifier is made up of the characters before the slash in the product number (E-Nr.) on the rating plate. Alternatively, you can also find the model identifier in the first line of the EU energy label.

#### 24 Declaration of Conformity

Robert Bosch Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality meets the essential requirements and other relevant provisions of the Directive 2014/53/FU.

A detailed RED Declaration of Conformity can be found online at www.bosch-home.com among the additional documents on the product page for your appliance.



2.4 GHz band: 100 mW max. 5 GHz band: 100 mW max.

cifications

Only applies to countries in the European Economic Area



BE	BG	CZ	DK	DE	EE	ΙE	EL	
ES	FR	HR	IT	CY	LV	LT	LU	
HU	MT	NL	AT	PL	PT	RO	SI	
SK	FI	SE	UK	NO	СН	TR	'	

5 GHz WLAN (Wi-Fi): For indoor use only.



### Thank you for buying a **Bosch Home Appliance!**

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration - also on mobile phones: www.bosch-home.com/welcome



### Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

#### Robert Bosch Hausgeräte GmbH

Carl-Werv-Straße 34 81739 München **GFRMANY** www.bosch-home.com

9001557156 (010330)

Wolverton, Milton Keynes MK12 5PT

United Kingdom

Grand Union House

Old Wolverton Road

Valid within Great Britain:

Imported to Great Britain by

BSH Home Appliances Ltd.