

Register your new device on MyBosch now and get free benefits: bosch-home.com/ welcome



Washing machine

WAU28S80GB

[en] User manual and installation instructions

For further information, please refer to the Digital User Guide.



Table of contents

1 S	afety	. 4
1.1	General information	. 4
	Intended use	
1.3	Restriction on user group	. 4
	Safe installation	
1.5	Safe use	. 7
1.6	Safe cleaning and mainten-	
	ance	. 9
2 P	reventing material damage	10
	nvironmental protection and	
	aving energy	
	Disposing of packaging	11
3.2	Save energy and conserve	1 1
<u></u>	resources Energy saving mode	
0.0	Energy saving mode	12
4 Ir	nstallation and connection	12
	Unpacking the appliance	
	Contents of package	12
4.3	Requirements for the install-	
	ation location	
	Removing the transit bolts	
	Connecting the appliance	
	Aligning the appliance	15
4./	Connecting the appliance to	10
	the electricity supply	10
	amiliarising yourself with	. –
	our appliance	
	Appliance	
	Detergent drawer	
5.3	Control panel	18
6 B	efore using for the first time	19
6.1	Starting an empty washing	
	cycle	19

7 Display 2	0
8 Buttons 2	3
9 Programmes 2	5
10 Accessories 2	9
11 Laundry2 11.1 Preparing the laundry	
12 Detergents and care products 3	0
13 Basic operation	0 0
settings	
 13.5 Adding detergent and care product	
 13.7 Changing the activated "Ready in" time	1
 13.10 Cancening the pro- gramme	
13.12 Unloading the laundry	2

14 Childproof lock	. 32
14.1 Activating the childproof	00
14.2 Deactivating the childproof	. 32
lock	. 32
15 Intelligent dosing system	33
15.1 Starting the programme	
with intelligent dosing sys-	00
15.2 Filling the dispensers	
15.3 Basic dosage	
16 Basic settings	
-	
17 Cleaning and servicing	. 35
17.1 Cleaning the drum17.2 Cleaning the detergent	. 35
drawer	. 35
17.3 Cleaning the drain pump	. 37
18 Troubleshooting	. 40
18.1 Emergency release	. 50
19 Transportation, storage and	
disposal	
19.1 Removing the appliance19.2 Inserting the transit bolts	
19.3 Using the appliance again	. 50
19.4 Disposing of old appliance	
20 Customer Service	51
20.1 Product number (E-Nr.) and	
production number (FD)	. 51
21 Consumption values	. 53
22 Technical data	. 54

1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- For washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- With tap water and commercially available detergents and care products suitable for washing machines.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Take note of the safety instructions when installing the appliance.

▲ WARNING – Risk of electric shock!

Improper installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ► When using a residual current circuit breaker, only use a type with the mtext{mark}.
- Never equip the appliance with an external switching device, e.g. a timer or remote control.
- When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- When installing the appliance, check that the power cable is not trapped or damaged.
- If the insulation of the power cord is damaged, this is dangerous.
- Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ► Never kink, crush or modify the power cord.

▲ WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ► Do not use extension cables or multiple socket strips.
- ► If the power cord is too short, contact Customer Service.
- Only use adapters approved by the manufacturer.

▲ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

► Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- Do not install a washer-dryer stack on a platform; the appliances may tip over.

▲ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material.

▲ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level.

If hoses and power cords have been laid incorrectly, this causes a tripping hazard.

Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

► Do not move the appliance by holding onto protruding parts.

▲ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

► Do not touch the sharp edges on the appliance.

Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

▲ WARNING – Risk of electric shock!

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer services. → Page 51

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

▲ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

▲ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

▲ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

► If accidentally swallowed, seek medical advice.

► Keep detergents and care products out of the reach of children.

▲ WARNING – Risk of explosion!

Laundry that has been pretreated with cleaning agents that contain solvents may cause an explosion in the appliance.

Rinse pretreated laundry thoroughly with water before washing.

▲ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

► Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ► Do not sit on or lean against the appliance door.
- ► Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

Wait for the drum to come to a complete stop before reaching inside.

▲ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

► Do not touch the hot detergent solution.

▲ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ► If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

Take note of the safety instructions when cleaning and performing maintenance work on the appliance.

▲ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk. An ingress of moisture can cause an electric shock.
- Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

▲ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

Only use the manufacturer's original spare parts and original accessories.

▲ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

► Do not use cleaning agents that contain solvents.

2 Preventing material damage

Follow these instructions to avoid material damage and damage to the appliance.

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

► Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

 Observe the maximum load capacity for each programme and do not exceed it.

→ "Programmes", Page 25 The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.

- Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- Before transport, fit the transit bolts fully in order to prevent damage in transit.

Material damage may be caused if the water inlet hose is connected incorrectly.

- Tighten the screw connections on the water inlet until they are handtight.
- Ideally, connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions, valves or similar.
- Ensure that the inner diameter of the water tap is at least 17 mm.

Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- Ensure that the water pressure in the water supply system is at least 100 kPa (1 bar) and max.
 1000 kPa (10 bar).
- If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may lead to material damage and damage to the appliance.

 Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.

 Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

Choose programmes with low temperatures and longer wash times and use maximum load capacity.

 Energy consumption and water consumption is most efficient.

Use the economy programme settings.

 If you adjust the programme settings for a programme, the display shows the expected consumption.

Add detergent based on the laundry's degree of soiling.

For light to normal soiling, a smaller amount of detergent is sufficient. Observe the dosage recommendation from the detergent manufacturer.

Reduce the washing temperature for lightly and normally soiled laundry.

 At lower temperatures, the appliance consumes less energy. For light to normal soiling, lower temperatures than indicated on the care label are also sufficient.

Set the maximum spin speed if you want to dry the laundry in the tumble dryer afterwards.

 The drier the laundry, the shorter the programme duration when drying which, in turn, reduces energy consumption. A higher spin speed reduces the residual moisture in the laundry and increases the volume of the spin noise.

Wash the laundry without prewash.

 Washing with prewash increases the programme duration and increases energy and water consumption.

The appliance has a continuous automatic load adjustment function.

 Depending on the type of fabric and load capacity, the continuous automatic load adjustment function optimally adjusts the water consumption and programme duration.

The appliance comes with an Aqua-Sensor.

 During the rinse cycle, the Aqua-Sensor checks the degree of turbidity of the rinsing water, and adjusts the duration and number of rinse cycles accordingly.

3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. Energy-saving mode ends when you use the appliance again.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- 1. Remove any packaging and protective covers completely from the appliance.

→ "Disposing of packaging", Page 11.

- 2. Check the appliance for visible damage.
- Open the appliance door.
 → "Basic operation", Page 30
- 4. Remove any accessories from the drum.
- 5. Close the appliance door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- Do not operate the appliance with incomplete or defective accessories.
- Replace the accessories in question before operating the appliance.

→ "Accessories", Page 29

Note: The appliance has been tested at the factory to check it is in working order. As a result, water stains may remain in the appliance. These marks will disappear after the first wash cycle.

The delivery consists of the following:

- Washing machine
- Accompanying documents
- Transit bolts

 → "Removing the transit bolts", Page 13
- Cover caps
- Water inlet hose
 → "Connecting the water inlet
 hose", Page 14

4.3 Requirements for the installation location

MARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

 Do not operate the appliance without a cover cap.

A WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 29 before using the appliance for the first time.

ATTENTION!


If residual water in the appliance freezes, this may cause damage to the appliance.

Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- Tilt the appliance carefully.
- Transport the appliance in an upright position.

Installation loca- Requirements tion



width: 60 cm.

Installation loca- Requirements tion

Against a wall




Do not trap the hoses between the wall and the appliance.

4.4 Removing the transit bolts


The appliance is secured for transportation using transit bolts on the rear of the appliance.

Note: Keep the transit bolt screws and the sleeves in a safe place for future transport \rightarrow *Page 50*.

1. Pull the hoses out of the holders.




2 Unscrew ① and remove ② all 4 screws for the transit bolts with a WAF 13 wrench.




- en Installation and connection
- **3.** Pull the power cable out of the holder.




4. Remove the 4 sleeves.



5. Put on the 4 cover caps.




6. Press down on the 4 cover caps.




4.5 Connecting the appliance

Connecting the water inlet hose

1. Connect the water inlet hose.



2. Connect the water inlet hose to a tap (26.4 mm = 3/4").



3. Open the water tap carefully and check that the connection points are tight.

Water outlet connection types


This information is intended to help you to connect this appliance to the water outlet.

ATTENTION!

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

 Secure the water outlet hose against unintentional loosening.


Note: Observe the draining heights. The maximum draining height is 100 cm.




4.6 Aligning the appliance

In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

 Loosen the lock nuts using a WAF 17 wrench by turning it in a clockwise direction.




2 To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

- en Installation and connection
- **3.** Screw the lock nuts tightly against the housing using a WAF 17 wrench.



In doing so, hold the foot tight and do not adjust its height.

4.7 Connecting the appliance to the electricity supply

 Insert the mains plug of the appliance's power cable in a socket nearby.


The connection details of the appliance can be found under Technical data $\rightarrow Page 54$.

2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance


You can find an overview of the parts of your appliance here.



On certain models, specific details such as the colour and shape may differ from those pictured.

1	Maintenance flap for the drain pump \rightarrow Page 37
2	Door
3	Detergent drawer → Page 18
4	Control panel → Page 18
5	Water outlet hose \rightarrow Page 15
6	Power cord → Page 16
7	Transit bolts \rightarrow Page 13


5.2 Detergent drawer



1	Manual dosing compartment
2	88: Dispenser for fabric softener
3	Ô: Dispenser for detergent

5.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



1	Programmes
2	Programme selector → Page 30
3	Display → Page 20
4	Buttons → Page 23


6 Before using for the first time

Prepare the appliance for use.


6.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

- 1. Turn the programme selector to **Drum Clean**.
- 2. Close the door.
- 3. Pull out the detergent drawer.
- **4.** Pour approx. 1 litre of water into the manual dosing compartment.



5. Add washing powder to the manual dosing compartment.




To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

- 6. Push in the detergent drawer.
- 7. Press **Start/Reload** to start the programme.
- The display shows the remaining programme duration.
- After the programme has ended, the display shows: End.
- 8. Start the first wash cycle or set the programme selector to **Off** to switch off the appliance.
 - → "Basic operation", Page 30

7 Display

The display shows the current settings, options or relevant information.



Display	Designation	More information
0:40 1	Programme dura- tion/programme time remaining	Approximate expected programme dura- tion or programme time remaining.
8,0 kg ¹	Recommended load	The maximum load capacity for the selec- ted programme in kg.
1400	Spin speed	Set spin speed in rpm. → "Buttons", Page 23 0= No final spin, only draining : Rinse Hold, no draining
₩ - 90	Temperature	Set temperature in °C. → <i>"Buttons", Page 23</i> 黎 (cold)
	Start/Pause	 Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be star- ted or continued.
\	Wash	Programme status
	Rinse	Programme status
6	Spin	Programme status
¹ Example		

Display	Designation	More information
	Rinse Hold	Programme status
End	End of pro- gramme	Programme status
س ر)	Childproof lock	 lights up: The childproof lock is activated. flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 32
—	Prewash	Prewash is activated. → "Buttons", Page 24
=0	SpeedPerfect	Short wash activated. → "Buttons", Page 23
1	Energy consump- tion ≩	Energy consumption for the selected pro- gramme. — . Low energy consumption
¢	Reminder to clean the drum	Flashes: Drum is dirty. Run the Drum Clean programme for cleaning and caring for the drum and the outer tub. → "Cleaning the drum", Page 35
0	Dispenser for li- quid detergent	 Lights up: The intelligent dosing system for liquid detergent is activated. Flashes: The fill level of the dispenser is below the minimum level. → "Intelligent dosing system", Page 33
8	Dispenser for fab- ric softener.	 Lights up: The intelligent dosing system for fabric softener is activated. Flashes: The fill level of the dispenser is below the minimum level. → "Intelligent dosing system", Page 33
FO mol 1	Desis deserve	8 (fabric softener)
50 ml ¹	Basic dosage	Basic dosage for detergent or fabric softener. → "Basic dosage", Page 34
:	Voltage control system	Flashes: The automatic voltage control system detects impermissible voltage drops. This will pause the programme. Note: The programme will continue when the voltage is permissible again.
¹ Example		

Display	Designation	More information
•	Voltage control system	Flashes: The programme has been paused because of impermissible voltage drops. The voltage is permissible again and the programme will continue. Note: The programme duration is exten- ded.
¢	Door	 Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened.
<u>گ</u>	Тар	No water pressure.The water pressure is too low.
	Detergent drawer	The detergent drawer has not been pushed in fully.
E:35 / -10 ¹	Error	Error code, error display, signal.
¹ Example		

8 Buttons

The selection of programme settings depends on the programme that is set. You can see the selection options for each programme in the overview for .

Button	Selection	More information
Start/Reload	StartCancelPause	Start, cancel or pause the pro- gramme.
SpeedPerfect	ActivateDeactivate	Activate or deactivate a shorter pro- gramme duration. Note: Energy consumption increases. The washing result is not affected by this.
i-DOS ê	ActivateDeactivateBasic dosage	Briefly press the button to activate or deactivate the intelligent dosing sys- tem for fabric softener & or liquid de- tergent Ô. Press the button for approx. three seconds to set the basic dosage. → "Intelligent dosing system", Page 33
Finish in	Up to 24 hours	Set the programme end. The programme duration is already in- cluded in the set number of hours. Once the programme has started, the programme duration is displayed. Note: Use the button to adjust the ba- sic dosage. → "Adjusting the basic dosage", Page 34
Temp. °C	卷 – 90 °C	Adjust the temperature in °C.
Spin Speed	1400	Adjust the spin speed or activate

Button	Selection	More information
C∞ 3 sec.	ActivateDeactivate	→ "Childproof lock", Page 32
Prewash	ActivateDeactivate	Activate or deactivate prewash, e.g. for washing heavily soiled laundry. Note: If the intelligent dosing system is activated, the detergent will be dis- pensed automatically for the prewash and the main wash. If the intelligent dosing system is de- activated, place the detergent for the prewash directly in the drum.

9 Programmes

Note: The laundry's care labels provide you with additional information about programme selection. Care symbols on the care labels

Programme	Description	Max. load (kg)
Cottons	 Wash hard-wearing items made from cotton, linen or blended fabrics. Also suitable as a short programme for normally soiled laundry when you activate SpeedPerfect. Programme setting: Max. 90 °C Max. 1400 rpm 	8,0 5,0 ¹
Eco 40-60	 Wash items made from cotton, linen or blended fabrics. Note: Fabrics which can be washed from 40 °C var up to 60 °C var as per the care symbol can be washed together. The washing performance corresponds to the best possible washing performance class according to the legal requirements. For this programme, the washing temperature is automatically adjusted depending on the load size, in order to achieve the best possible energy efficiency with the best possible washing result. You cannot change the washing temperature. Programme setting: Note: The temperature cannot be adjusted in this programme and is set automatically. Max °C Max. 1400 rpm 	8,0
Cottons Colour	 Wash hard-wearing items made from cotton, linen or blended fabrics. Energy-saving programme. Note: To save energy, the actual washing temperature may deviate from the set washing temperature. The washing performance meets legal requirements. Programme setting: Max. 90 °C Max. 1400 rpm 	8,0
¹ SpeedPerfect	activated	

Programme	Description	Max. load (kg)	
Easy Care	Wash items made from synthetic or blended fab- rics. Programme setting: Max. 60 °C Max. 1200 rpm	4,0	
Mixed Load	 Wash items made from cotton, linen, or synthetic or blended fabrics. Suitable for lightly soiled laundry. Programme setting: Max. 60 °C Max. 1400 rpm 	4,0	
Delicates/Silk	 Wash delicate, washable items made from silk, viscose and synthetic fabrics. Use a detergent that is suitable for delicates or silk. Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag. Programme setting: Max. 40 °C Max. 800 rpm 	2,0	
[®] Wool	 Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool. Programme setting: Max. 40 °C Max. 800 rpm 	2,0	
Rinse	Rinse and then spin the laundry, and drain the wa- ter. Programme setting: Max. 1400 rpm	-	
Spin/Drain	Spin and drain the water. If you only want to drain the water, activate 0. The laundry is not spun. Programme setting: Max. 1400 rpm	-	
Shirts	Wash non-iron shirts and blouses made from cot- ton, linen, or synthetic or blended fabrics. Note: Use the Delicates/Silk programme to wash shirts and blouses made from silk or delicate fab- rics.	2,0	
¹ SpeedPerfect activated			

Programme	Description	Max. load (kg)
	Programme setting: Max. 60 °C Max. 800 rpm	
Sportswear	 Wash sports and leisure items made from synthetic fibres, microfibre or fleece. Use a detergent that is suitable for sports items. Do not use fabric softener. Tip: Use the Easy Care programme to wash heavily soiled laundry. Programme setting: Max. 40 °C Max. 800 rpm 	2,0
Auto Soft	Wash delicate items made from cotton, or synthetic or blended fabrics. Gentle laundry care. The degree of soiling and the type of fabric are automatically detected. The washing process is ad- apted. Note: The temperature and spin speed cannot be adjusted in this programme and are set automatic- ally. The maximum temperature is 30 °C. The maximum spin speed is 800 rpm.	3,5
Easy Care Plus	Wash dark-coloured and colour-intense items made from cotton or easy-care fabric, e.g. jeans. Turn laundry inside-out before washing. Use liquid detergent. Programme setting: Max. 40 °C Max. 1200 rpm	4,0
Drum Clean	 Cleaning and caring for the drum. Use this programme in the following cases: Before using the appliance for the first time If you regularly wash at temperatures of 40 °C or lower After a prolonged period of non-use Use washing powder or a detergent that contains bleach. Halve the amount of detergent to avoid foaming. 	_
¹ SpeedPerfect :	Do not use fabric softener.	

Programme	Description	Max. load (kg)	
	Do not use liquid detergent or detergent that is in- tended for woollens or delicates.		
	Note: The drum cleaning indicator will flash to re- mind you if you have not used a programme at 60 °C or higher for a long time.		
Super Quick 15'/30'	 Wash items made from cotton, or synthetic or blended fabrics. Short programme for small items of lightly soiled laundry. The programme duration is approx. 30 minutes. If you wish to reduce the programme duration to 15 minutes, activate SpeedPerfect. The maximum load is reduced to 2,0 kg. Programme setting: Max. 40 °C Max. 1200 rpm 	4,0	
¹ SpeedPerfect activated			

10 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order number
Water inlet hose exten- sion	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Longer water inlet hose	Replace the standard water inlet hose with a longer hose (2.20 m).	00353925
Elbow	Secure the water outlet hose in place.	00655300
Platform	Install the appliance at a raised height so that it can be easily loaded and unloaded.	WMZPW20W

11 Laundry

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

11.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

- Remove all items from any pockets in your laundry before using the appliance.
- To protect your appliance and the laundry, prepare the laundry beforehand.
 - Empty any pockets
 - Brush sand out of all collars and pockets

- Close bed covers and cushion covers
- Close all zips, Velcro fasteners, hooks and eyes
- Tie cloth belts, apron strings, etc. together or use a laundry bag.
- Tie together longer drawstrings, and tie cords with solid endpieces in hoods or trousers
- Remove curtain hooks and lead strips or use a mesh laundry bag
- Use a mesh laundry bag for small items of laundry, such as children's socks
- Some stubborn or dried-in stains can be removed by washing several times
- Wash large and small items of laundry together
- Do not rub fresh stains but dab them with soapy water

 Separate items of laundry and shake them out, or observe the programme description

12 Detergents and care products

Notes

- More detailed instructions for use can be found on www.boschhome.com or by scanning the QR code on the title page of this user manual.
- Observe the information on safety
 → Page 4 and preventing material
 damage → Page 10.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- Only use liquid detergents that are self-flowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances (e.g. bleach)
- Use dyes sparingly as salt may damage stainless steel
- Do not use bleaching agents in the appliance
- Do not pour vinegar into the dispensers → Page 33 of the intelligent dosing system

13 Basic operation

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

13.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected.

 \rightarrow "Installation and connection", Page 12

- Turn the programme selector to a programme.
- An audible function test is carried out.

13.2 Setting a programme

- Turn the programme selector and set the required programme.
 → "Programmes", Page 25
- If necessary, adjust the programme settings → Page 30.

13.3 Adjusting the programme settings

Requirement: A programme has been set.

- → "Setting a programme", Page 30
- Adjust the programme settings.
 → "Buttons", Page 23

Notes

- The programme settings are not saved permanently for the programme.
- The setting is saved if you activate or deactivate the intelligent dosing system.

13.4 Loading laundry

Note: To prevent creasing, take note of the maximum load for the → "Programmes", Page 25.

Requirement: The laundry is prepared.

- → "Laundry", Page 29
- 1. Open the door.

Make sure that the drum is empty.

- 2. Place the laundry in the drum.
- 3. Close the door.

Ensure that there is no laundry trapped in the door.

13.5 Adding detergent and care product

For programmes in which intelligent dosing is not possible or desirable, you can add detergent manually.

Tip: In addition to intelligent dosing, you can also add additional care product for laundry, e.g. stain remover, starch or bleach, to the manual dosing compartment. Do not add any additional detergent to the manual dosing compartment to avoid overdosage and/or foaming.

Note: Observe the information about detergents and care products \rightarrow *Page 30*.

- 1. Pull out the detergent drawer.
- 2. Pour in detergent. → "Detergent drawer" Page
 - → "Detergent drawer", Page 18
- **3.** If required, add the care product.
- 4. Push in the detergent drawer.

13.6 Starting the programme

Note: If you want to change the time until the programme ends, set the "Ready in" time first.

Press Start/Reload.

- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- The display shows either the programme duration or the "Ready in" time.
- After the programme has ended, the display shows: End.

13.7 Changing the activated "Ready in" time

If you have set and activated a "Ready in" time for a delayed programme start, you can change the "Ready in" time again before the programme starts.

Requirements

- The programme is set.
 → "Setting a programme", Page 30
- The "Ready in" time is set and activated.

→ "Buttons", Page 23

1. Press Start/Reload.

The activated "Ready in" time is paused.

- 2. Press **Finish in** repeatedly until the display indicates the desired "Ready in" time.
- 3. Press Start/Reload.

The changed "Ready in" time is activated.

13.8 Soaking laundry

Note: No additional detergent is required. The washing solution is then used for washing.

- 1. Start the programme.
- To pause the programme, after approx. 10 minutes, press Start/Reload.
- To resume the programme, after the desired soaking time, press Start/Reload.

13.9 Adding laundry

1. Press Start/Reload.

The appliance pauses.

Note: If [©] appears, it is not possible to add laundry. When [©] goes out, it is possible to add laundry.

- 2. Open the appliance door.
- 3. Add or remove laundry.
- 4. Close the appliance door.
- 5. Press Start/Reload.

13.10 Cancelling the programme

1. Press Start/Reload.

2. Open the appliance door.

The appliance door remains locked for safety reasons if the temperature and water levels are high.

- If the temperature is high, start the **Rinse** programme.
- If the water level is high, start the **Spin** programme or select a suitable programme for draining.
 → "Programmes", Page 25
- **3.** Remove the laundry \rightarrow Page 32.

13.11 Resuming the programme when the programme status is Rinse Hold

1. Start the **Spin** programme or select a suitable programme for draining.

→ "Programmes", Page 25

2. Press Start/Reload.

13.12 Unloading the laundry

- 1. Open the appliance door.
- 2. Remove the laundry.

13.13 Switching off the appliance

- 1. Turn the programme selector to **Off**.
- 2. Turn off the tap.
- **3.** Wipe the rubber gasket dry and remove any foreign objects.



4. Leave the appliance door and detergent drawer open so that residual water can evaporate.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof lock

- Press and hold the two C 3 sec. buttons for approx. 3 seconds.
- The display shows Cm.
- ✓ The controls are locked.
- The childproof lock remains active even after the appliance has been switched off.

14.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

- Press and hold the two C 3 sec. buttons for approx. 3 seconds.
- ✓ C∞ goes out in the display.

15 Intelligent dosing system

The optimum quantities of liquid detergent and fabric softener are dispensed automatically depending on the programme and settings.

15.1 Starting the programme with intelligent dosing system

If you do not want to dose liquid detergent and fabric softener manually, use the intelligent dosing system. This function is available depending on the selected programme and is activated automatically.

Note

If you are using the intelligent dosing system, do not add additional detergent or fabric softener into the compartment for manual dosing. \rightarrow "Adding detergent and care

product", Page 31

If you want to dose manually for a set programme, observe the following information:

- Deactivate the intelligent dosing system before starting the programme. The selected settings are retained even after the appliance has been switched off.
 → "Buttons", Page 23
- Pour detergent or fabric softener into the compartment for manual dosing.

→ "Adding detergent and care product", Page 31

- Activate the intelligent dosing system once the programme has ended.
 - → "Buttons", Page 23

Requirements

- The laundry is prepared.
 → "Preparing the laundry", Page 29
- The laundry is sorted. Sorting laundry
- The laundry is placed in the appliance.
 - → "Loading laundry", Page 31
- The programme is set.
 → "Setting a programme", Page 30
- The intelligent dosing system is activated.
 - → "Display", Page 21
 - → "Display", Page 21
- Fill the dispensers → Page 33. To replace the contents of the dispenser with another product, clean the detergent drawer → Page 35.
- If required, adjust the basic dosage → Page 34.
- If required, adjust the programme settings → Page 30.
- **4.** Start the programme \rightarrow *Page 31*.
- After the programme has ended, the display shows: End.
- 5. The

 \rightarrow "Unloading the laundry", Page 32.

15.2 Filling the dispensers

If you want to use the intelligent dosing system or if the appliance displays an indication during operation of the appliance, fill the dispensers.

Note: Fill the dispensers only with suitable detergent and care products \rightarrow *Page 30*.

If you want to add more liquid detergent or fabric softener in the dispenser, use the same product.


en Basic settings

If you want to replace the liquid detergent or fabric softener in the dispenser with another product, clean the detergent drawer beforehand. → "Cleaning the detergent drawer", Page 35

- 1. Pull out the detergent drawer.
- 2. Open the dispenser cover.



- Pour liquid detergent ◊ and fabric softener ⊗ into the relevant dispensers.
 - → "Detergent drawer", Page 18



Do not exceed the marking for the maximum filling level when filling.

4. Close the dispenser cover.

Note: To prevent the liquid detergent or fabric softener from drying out, close the dispenser cover immediately after filling.

5. If required, add cleaning aids such as stain remover, water softener or bleach into the compartment for

manual dosing. → "Adding detergent and care product", Page 31

- 6. Push in the detergent drawer.
- 7. Adjust the basic dosage \rightarrow Page 34.

15.3 Basic dosage

The basic dosage depends on the manufacturer's instructions for the detergent, the water hardness and the degree of soiling of the laundry. Always set a basic dosage that corresponds to the dosage for a standard load of 4.5 kg. Detergent dosage

Adjusting the basic dosage

- Press and hold i-DOS^(a) for approx. 3 seconds.
- ✓ The display shows the basic dosage set for Ô.
- To adjust the basic dosage for [&], press i-DOS[⊕].
- 3. To adjust the setting, press i-DOS +.
- 4. To end the setting process, wait briefly.

16 Basic settings

You can configure the appliance to meet your needs.

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

17 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

17.1 Cleaning the drum

CAUTION Risk of injury!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.

- Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- Run the Drum Clean programme without laundry and using all-purpose washing powder.

17.2 Cleaning the detergent drawer


If you want to replace the liquid detergent or fabric softener in the dispenser with another product or if the detergent drawer is dirty, clean the detergent dispenser.

ATTENTION!


The pump unit contains electrical components. Electrical components may be damaged if they come into contact with liquids.

- Do not clean the pump unit in the dishwasher and do not immerse it in water.
- Protect the electrical connection on the rear against water, detergent and fabric softener residue.
- Switch off the appliance.


 → "Switching off the appliance", Page 32
- 2. Pull out the detergent drawer.
- **3.** Press down on the insert and remove the detergent drawer.




- en Cleaning and servicing
- 4. Remove the pump unit.




5. Unclip the detergent drawer cover and remove it.




6. Empty the detergent drawer.




7. Clean the pump unit with a damp cloth.




8. Clean the detergent drawer and the cover with a soft, damp cloth or hand shower.



9. Dry the detergent drawer, cover and pump unit and reinsert them.





10. Clean the housing of the detergent drawer in the appliance.



11. Push in the detergent drawer.


17.3 Cleaning the drain pump

Clean the drain pump in the event of faults, e.g. blockages or rattling noises.


Emptying the drain pump

- 1. Turn off the water tap.
- 2. Switch off the appliance.
- **3.** Disconnect the appliance's mains plug from the power supply.


4. Open and remove the service flap.



5. Slide a sufficiently large container under the opening.




6. Take the drain hose out of the holder.




- 7. A CAUTION Risk of scalding! When you wash at high temperatures, the detergent solution gets hot.
- Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



8. Firmly press on the sealing cap.




9. Insert the drain hose into the holder.




Cleaning the drain pump

Requirement: The drain pump is empty. \rightarrow *Page 37*

- 1. Since water may remain in the drain pump, unscrew the pump cap carefully.
- 2 Clean the interior, the thread on the pump cap and the pump housing.




- **3.** Ensure that the impeller in the drain pump can rotate.
- 4. Insert the pump cap.
- 5. Screw the pump cap as far as it will go.



The handle on the pump cap must be in a vertical position.

6. Insert and close the service flap.



Before the next wash

To prevent unused detergent from flowing straight into the outlet in the next wash, run the **Drain** programme after you have emptied the drain pump.

- **1.** Turn on the water tap.
- 2. Insert the mains plug.
- 3. Switch on the appliance.
- 4. Pour 1 litre of water into the manual dosing compartment.
- **5.** Select a suitable programme for draining.
 - → "Programmes", Page 25

18 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting		
The display goes out and Start/Reload flashes.	Energy-saving mode is active ► Press any button. ► The symbol lights up again.		
"E:36 / -10"	Drain pipe or water outlet hose is blocked.Clean the drain pipe and the water outlet hose.		
	 Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped. 		
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 37		
	 The water outlet hose is connected too high. Install the water outlet hose at a maximum height of 1 metre. 		
	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down). If intelligent dosing is activated, reduce the basic dosage → Page 34. 		
	If you dose manually, reduce the amount of deter- gent for the next washing cycle with the same load.		
	Unapproved extension installed on the water drain hose.		

Fault	Cause and troubleshooting			
"E:36 / -10"	 Remove any unapproved extensions from the water hose. Connecting the appliance 			
	 The pump cap is not fully screwed in. Ensure that the pump cap is screwed in all the way into the appliance. The handle on the pump cap must be in a vertical position. → "Cleaning the drain pump", Page 38 			
"E:10 / -00 / -10 / -20"	 The pump for the intelligent dosing system is blocked. 1. Switch off the appliance. 2. Clean the pump unit. → "Cleaning the detergent drawer", Page 35 3. If this display appears again, call customer service. → "Customer Service", Page 51 			
	Note: You can start the washing programme if you de- activate the intelligent dosing system and dose manu- ally.			
	→ "Buttons", Page 23			
产	The water pressure is low. No remedial action possible.			
	The filters in the water inflow are blocked.Clean the filters in the water inflow.			
	The tap is turned off. ► Turn on the tap.			
	 The water inlet hose is kinked or jammed. Ensure that the water inlet hose is not kinked or jammed. 			
	The detergent drawer has not been pushed in as far as it can go.Push the detergent drawer in as far as it will go.			
	 The pump unit is not inserted. 1. Insert the pump unit into the detergent drawer. → "Cleaning the detergent drawer", Page 35 2. Push the detergent drawer in as far as it will go. 			
Voltage under-usage symbol (double point).	The automatic voltage control system detects an un- authorised voltage under-usage.No remedial action possible.			
	Note: If the power supply is stable, the programme continues to run as normal.			
	Voltage under-usage may cause extension of a pro- gramme.			

Fault	Cause and troubleshooting		
Voltage under-usage symbol (double point).	No remedial action possible.		
flashes.	Voltage under-usage may cause extension of a pro- gramme. No remedial action possible.		
© lights up.	 The temperature is too high. ► Wait until the temperature has dropped. ► → "Cancelling the programme", Page 32 		
	 Water level is too high. Select a suitable programme for draining. → "Programmes", Page 25 		
	 Laundry is caught in the door. 1. Open the door again. 2. Remove any trapped laundry. 3. Close the door. 4. Press Start/Reload to start the programme. 		
© flashes.	Door is not closed. 1. Close the door. 2. Press Start/Reload to start the programme.		
All other error codes.	Malfunction Call the after-sales service. → "Customer Service", Page 51 		
"E:30/-20"	Solenoid valve defective. ► Call the after-sales service. → "Customer Service", Page 51		
	 Detergent dosage is too high. If you dose manually, reduce the amount of detergent for the next washing cycle with the same load. 		
	Additional water is added.Do not add any extra water to the appliance while it is operating.		
The appliance is not working.	The mains plug of the power cord is not plugged in.Connect the appliance to the power supply.		
	The circuit breaker in the fuse box has tripped.Check the circuit breaker in the fuse box.		
	 There has been a power cut. Check whether the lighting in your kitchen or other appliances are working. 		

Fault	Cause and troubleshooting		
The programme does not start.	You have not pressed Start/Reload . ► Press Start/Reload .		
	Door is not closed.1. Close the door.2. Press Start/Reload to start the programme.		
	Childproof lock is activated. ► → "Deactivating the childproof lock", Page 32		
	 Finish in is activated. Check whether Finish in is activated. → "Buttons", Page 23 		
	 Laundry is caught in the door. 1. Open the door again. 2. Remove any trapped laundry. 3. Close the door. 4. Press Start/Reload to start the programme. 		
	The detergent drawer has not been pushed in as far as it can go.▶ Push the detergent drawer in as far as it will go.		
	 The pump for the intelligent dosing system is blocked. 1. Switch off the appliance. 2. Clean the pump unit. → "Cleaning the detergent drawer", Page 35 3. If this display appears again, call customer service. → "Customer Service", Page 51 		
	Note: You can start the washing programme if you de- activate the intelligent dosing system and dose manu- ally. → "Buttons", Page 23		
The door cannot be opened.	 is activated. Continue the programme by selecting Spin or Drain and pressing Start/Reload. → "Resuming the programme when the programme status is Rinse Hold", Page 32 		
	 The temperature is too high. Wait until the temperature has dropped. → "Cancelling the programme", Page 32 		
	 Water level is too high. ► Select a suitable programme for draining. → "Programmes", Page 25 		

Power failure.

Fault	Cause and troubleshooting			
The door cannot be opened.	 Open the door using the emergency release. → "Emergency release", Page 50 			
The water is not drain- ing.	Drain pipe or water outlet hose is blocked.Clean the drain pipe and the water outlet hose.			
	 Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped. 			
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 37			
	 is activated. Continue the programme by selecting Spin or Drain and pressing Start/Reload. → "Resuming the programme when the programme status is Rinse Hold", Page 32 			
	 The water outlet hose is connected too high. Install the water outlet hose at a maximum height of 1 metre. 			
	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down). If intelligent dosing is activated, reduce the basic dosage → Page 34. If you dose manually, reduce the amount of deter- 			
	gent for the next washing cycle with the same load.			
	 Unapproved extension installed on the water drain hose. Remove any unapproved extensions from the water hose. Connecting the appliance 			
Water is not flowing in. Detergent is not	You have not pressed Start/Reload . ▶ Press Start/Reload .			
being dispensed.	The filters in the water inflow are blocked.Clean the filters in the water inflow.			
	The tap is turned off. ► Turn on the tap.			
	The water inlet hose is kinked or jammed.Ensure that the water inlet hose is not kinked or jammed.			

Fault	Cause and troubleshooting			
The spin cycle runs several times.	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. ► Not a fault – no action required.			
	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
The programme dura- tion changes during the wash cycle.	 The programme operation is optimised electronically. This may change the programme duration. Not a fault – no action required. 			
	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. ► Not a fault – no action required.			
	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
	Foam detection system switches on a rinse cycle if foam build-up is too high. ► Not a fault – no action required.			
No water is visible in the drum.	 Water is below the visible area. Not a fault – no action required. Do not add any extra water to the appliance while it is operating. 			
Drum jerks after the programme starts.	This is caused by an internal motor test. ► Not a fault – no action required.			
Vibrations and move- ment of the appliance	Appliance is not correctly aligned.Aligning the appliance			
whilst spinning.	The appliance feet are not fixed.Secure the appliance feet. Aligning the appliance			
	Transit bolts have not been removed.Removing the transit bolts			
Drum rotates, water does not flow in.	Load detection is active.Not a fault – no action required.			
	Note: The load detection can take up to two minutes.			

Fault	Cause and troubleshooting
Heavy foam build-up	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down). If intelligent dosing is activated, reduce the basic dosage → Page 34. If you dose manually, reduce the amount of detergent for the next washing cycle with the same load.
i-DOS [®] cannot be ac- tuated.	Intelligent dosing is not intended for this programme.Not a fault – no action required.
	Programme progress does not allow intelligent dos- ing. No remedial action possible.
High spin speed not reached.	A low spin speed is selected.The next time you run a wash cycle, set a higher spin speed.
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.▶ Redistribute the laundry in the drum.
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
	 Start the Spin programme.
The spin programme does not start.	Drain pipe or water outlet hose is blocked.Clean the drain pipe and the water outlet hose.
	 Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped.
	 The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. Redistribute the laundry in the drum.
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
	 Start the Spin programme.

Fault	Cause and troubleshooting			
Rushing, hissing noise.	Water is flushed under pressure into the detergent drawer. ► Not a fault – normal operating noise.			
Longer, whirring noise before the start of the wash cycle or fabric softening.	 Intelligent dosing system dispenses detergent or care products. ▶ Not a fault – normal operating noise. 			
Brief whirring noise after switching on the appliance.	Intelligent dosing system carries out a function test.Not a fault – normal operating noise.			
Loud noises during the spin cycle.	Appliance is not correctly aligned.► Aligning the appliance			
	The appliance feet are not fixed.Secure the appliance feet. Aligning the appliance			
	Transit bolts have not been removed.Removing the transit bolts			
Banging noises, rat- tling in the drain pump.	 Foreign bodies have got into the drain pump. → "Cleaning the drain pump", Page 37 			
Slurping, rhythmical suction noise.	The drain pump is active, the detergent solution is pumped out. ► Not a fault – normal operating noise.			
Creasing.	The spin speed is too high.The next time you run a wash cycle, set a lower spin speed.			
	The load is too large.The next time you run a wash cycle, reduce the amount of laundry being loaded.			
	 Unsuitable programme for the type of fabric. Select the programmes that are suitable for the type of fabric. 			
The spin result is not satisfactory. The laun- dry is too wet/too damp.	 A low spin speed is selected. The next time you run a wash cycle, set a higher spin speed. Start the Spin programme. 			
	Drain pipe or water outlet hose is blocked.Clean the drain pipe and the water outlet hose.			
	 Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped. 			

Fault	Cause and troubleshooting			
The spin result is not satisfactory. The laun- dry is too wet/too	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distrib- uted.			
damp.	 Redistribute the laundry in the drum. 			
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
	 Start the Spin programme. 			
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.Redistribute the laundry in the drum.			
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
	 Start the Spin programme. 			
Detergent residue on the damp washing.	Detergents may contain water-insoluble substances that deposit on the laundry. Start the Rinse programme. 			
	 Unsuitable detergent added to the dispenser of the intelligent dosing system. 1. Check whether the detergent used is suitable. → "Detergents and care products", Page 30 2. Drain the dispenser. → "Cleaning the detergent drawer", Page 35 			
	3. Clean the dispenser.			
	 4. Refill the dispenser. → "Filling the dispensers", Page 33 			
	 Basic dosage is not correctly adjusted. If intelligent dosing is activated, reduce the basic dosage → Page 34. 			
Detergent residue on the dry laundry.	 Detergents may contain water-insoluble substances that deposit on the laundry. Brush out the laundry after washing and drying. 			
	 Unsuitable detergent added to the dispenser of the intelligent dosing system. 1. Check whether the detergent used is suitable. → "Detergents and care products", Page 30 2. Drain the dispenser. → "Cleaning the detergent drawer", Page 35 3. Clean the dispenser. 			

Fault	Cause and troubleshooting			
Detergent residue on the dry laundry.	 4. Refill the dispenser. → "Filling the dispensers", Page 33 			
	 Basic dosage is not correctly adjusted. If intelligent dosing is activated, reduce the basic dosage → Page 34. 			
Insufficient cleaning.	 Basic dosage is not correctly adjusted. If intelligent dosing is activated, adjust the basic dosage → Page 34 correctly. 			
	 Detergent or care products have congealed in dispensers of the intelligent dosing system. 1. Check whether the detergent used is suitable. → "Detergents and care products", Page 30 2. Drain the dispenser. → "Cleaning the detergent drawer", Page 35 3. Clean the dispenser. → "Filling the dispensers", Page 33 			
	 Unsuitable detergent added to the dispenser of the intelligent dosing system. 1. Check whether the detergent used is suitable. → "Detergents and care products", Page 30 2. Drain the dispenser. → "Cleaning the detergent drawer", Page 35 3. Clean the dispenser. → "Filling the dispenser. → "Filling the dispenser." 			
Water is leaking out at the water inlet hose.	Water inlet hose is not correctly/securely connected.1. Connect the water supply hose correctly. Connecting the water inlet hose2. Tighten the screw connection.			
Water is leaking out at the water outlet hose.	The water outlet hose is damaged.Replace the damaged water outlet hose.			
	 Water outlet hose is not connected correctly. Connect the water outlet hose correctly. Water outlet connection types 			
Odours have formed in the appliance.	Humidity and detergent residue may promote the formation of bacteria. ► → "Cleaning the drum", Page 35			
	 If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate. 			


18.1 Emergency release

Releasing the door

Requirement: The drain pump is empty. \rightarrow *Page* 37

- 1. **ATTENTION!** Escaping water may cause material damage.
- Do not open the door if you can see water through the glass.

Pull the emergency release downwards with a tool and release.



- ✓ The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

19 Transportation, storage and disposal

You can find out here how to prepare your appliance for transportation and storage. You will also find out how to dispose of old appliances.

19.1 Removing the appliance

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

- 1. Turn off the water tap.
- 2. Empty the water inlet hose.

- **3.** Switch off the appliance.
- 4. Unplug the appliance's mains plug.
- 5. Drain the water.
 → "Cleaning the drain pump", Page 37
- 6. Detach the hoses.
- 7. Empty the dispensers.

19.2 Inserting the transit bolts

Secure the appliance for transportation using transit bolts in order to prevent damage.

1. Use a screwdriver to remove the 4 cover caps.



Keep the cover caps.

2. Install the 4 transit bolts. Refer to the description Removing the transit bolts for this and proceed in reverse order.

19.3 Using the appliance again

For further information, see
 → "Installation and connection",
 Page 12 and
 → "Before using for the first time",
 Page 19.

19.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

MARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- Dispose of the appliance in an environmentally friendly manner.
 Information about current disposal methods are available from your specialist dealer or local authority.

This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

20 Customer Service

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service.

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

20.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

en Customer Service

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

21 Consumption values

The following information is provided in accordance with the EU Ecodesign Regulation. The values given for programs other than the **Eco 40-60** are indicative only and were determined in accordance with the applicable standard EN60456. The automatic dosing function has been deactivated for this purpose.

Note on the comparison test: Deactivate the automatic dosing function unless this function is the object of the test.

Programme	Load (kg)	Pro- gramm e dura- tion (h:min) ¹	Energy con- sump- tion (kWh/ cycle) ¹	Water con- sump- tion (I/ cycle) ¹	Max- imum temper- ature (°C) 5 mins ¹	Spin speed (rpm) ¹	Resid- ual mois- ture (%) ¹
Eco 40-60 ²	8,0	3:29	1,060	58,0	44	1400	50,00
Eco 40-60 ²	4,0	2:44	0,600	43,0	37	1400	50,00
Eco 40-60 ²	2,0	2:11	0,170	27,0	23	1400	56,00
Cot- tons 20 °C	8,0	3:14	0,320	88,0	23	1400	52,00
Cot- tons 40 °C	8,0	3:14	1,210	88,0	45	1400	52,00
Cot- tons 60 °C	8,0	3:28	1,350	88,0	53	1400	52,00
Cot- tons 40 °C + Prewash	8,0	3:44	1,250	98,0	45	1400	52,00
Easy Care 40 °C	4,0	2:28	0,780	61,0	44	1200	27,00
Mixed Load 40 °C	4,0	0:59	0,620	44,0	41	1400	53,00
֎ Wool 30 ° C	2,0	0:40	0,200	40,0	22	800	25,00

¹ Due to the influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions, the actual values may deviate from the stated values.

² Test programme in accordance with the EU Ecodesign Directive and the EU Energy Labelling Regulation with cold water (15 °C).

22 Technical data

Appliance height	84,5 cm			
Appliance width	59,8 cm			
Appliance depth	63,3 cm			
Weight	70,7 kg ¹			
Maximum load	8,0 kg			
Mains voltage	220-240 V, 50 Hz			
Minimum in- stallation protec- tion	10 A			
Nominal power	2300 W			
Power consump- tion	 Off mode: 0,10 W Left-on mode: 0,50 W 			
Water pressure	 Minimum: 100 kPa (1 bar) Maximum: 1000 kPa (10 bar) 			
Length of the wa- ter inlet hose	150 cm			
Length of the wa- ter outlet hose	150 cm			
Length of the power cable	210 cm			
¹ Depending on the appliance spe- cifications				
You can find more information about your model online at https://eprel.ec.europa.eu/ ¹ . This web address is linked to the official EU EPREL product database. Please then follow the instructions on searching for the model. The model identifier is made up of the charac- ters before the slash in the product				

number (E-Nr.) on the rating plate. Alternatively, you can also find the model identifier in the first line of the EU energy label.

¹ Only applies to countries in the European Economic Area



Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- Expert tips & tricks for your appliance
- Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome**

BOSCH HOME APPLIANCES SERVICE

Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: **www.bosch-home.com/service**

Contact data of all countries are listed in the attached service directory.

Robert Bosch Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München GERMANY www.bosch-home.com



Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom