

Register your new device on MyBosch now and get free benefits: bosch-home.com/ welcome



# Washer dryer

#### WNG254YCHK

[en] User manual and installation instructions



## **Table of contents**

1 S	afety	. 4
	General information	
	Intended use	
1.3	Restriction on user group	. 4
1.4	Safe installation	. 5
	Safe use	. 6
1.6	Safe cleaning and mainten-	_
	ance	. 9
2 P	reventing material damage	10
	nvironmental protection and	
	aving energy	
	Disposing of packaging Save energy and conserve	11
J.Z	resources	11
3.3	Energy saving mode	
	nstallation and connection	
	Unpacking the appliance	
	Contents of package	
	Requirements for the install-	12
4.0	ation location	12
4.4	Removing the transit bolts	
	Connecting the appliance	
	Aligning the appliance	
	Connecting the appliance to	
	the electricity supply	15
5 F	amiliarising yourself with	
y	our appliance	
	Appliance	
	Detergent drawer	
5.3	Control panel	18
	efore using for the first time	19
6.1	Starting an empty washing	
	cycle	19

7 Display	20
8 Buttons	23
9 Programmes	25
10 Accessories	29
<b>11 Laundry</b> 11.1 Preparing the laundry	
12 Detergents and care products	29
<ul><li><b>13 Basic operation</b></li><li>13.1 Switching on the appliance</li><li>13.2 Setting a programme</li><li>13.3 Adjusting the programme</li></ul>	30 30
settings 13.4 Loading laundry 13.5 Adding detergent and care	
<ul> <li>13.6 Starting the programme</li> <li>13.7 Soaking laundry</li> <li>13.8 Adding laundry</li> <li>13.9 Cancelling the programme</li> <li>13.10 Cancelling the drying programme</li> <li>13.11 Unloading the laundry</li> <li>13.12 Switching off the appli-</li> </ul>	31 31 31 31 31
ance	
14 Childproof lock	32
	32
14.2 Deactivating the childproof lock	32
15 Basic settings	32

16 Cleaning and servicing 3	2
16.1 Cleaning the drum	3
16.2 Cleaning the detergent	
drawer3	
16.3 Cleaning the drain pump 3	4
17 Troubleshooting 3	37
17.1 Emergency release 4	
18 Transportation, storage and	
disposal 4	7
18.1 Removing the appliance 4	7
18.2 Inserting the transit bolts 4	7
18.3 Using the appliance again 4	7
18.4 Disposing of old appliance 4	8
19 Customer Service 4	8
19.1 Product number (E-Nr.) and	_
production number (FD)4	8
20 Consumption values 4	9
21 Technical data 4	9

# 1 Safety

Observe the following safety instructions.

# 1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

# 1.2 Intended use

Only use this appliance:

- For washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- With tap water and commercially available detergents and care products suitable for washing machines.
- For drying and freshening up fabrics that are washed with water and suitable for dryers.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

## 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

## 1.4 Safe installation

Take note of the safety instructions when installing the appliance.

## ▲ WARNING – Risk of electric shock!

Improper installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ► When using a residual current circuit breaker, only use a type with the mtext{mark}.
- Never equip the appliance with an external switching device, e.g. a timer or remote control.
- Never connect the appliance to a circuit that is regularly switched on and off by the energy supplier.
- When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ► Never kink, crush or modify the power cord.

# ▲ WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ► Do not use extension cables or multiple socket strips.
- ► If the power cord is too short, contact Customer Service.
- ► Only use adapters approved by the manufacturer.

## ▲ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted. • Do not lift the appliance on your own.

## ▲ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material.

# ▲ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ► Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level.

If hoses and power cords have been laid incorrectly, this causes a tripping hazard.

Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

Do not move the appliance by holding onto protruding parts.

# ▲ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ► Do not touch the sharp edges on the appliance.
- Wear protective gloves when installing and transporting the appliance.

# 1.5 Safe use

## ▲ WARNING – Risk of electric shock!

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.

► Call customer services. → Page 48

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

## ▲ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

## ▲ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

## ▲ WARNING – Risk of explosion!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

► Keep the area around the appliance clean during operation.

## ▲ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ► If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

## ▲ WARNING – Risk of explosion!

Highly flammable objects such as lighters or matches may ignite during the drying process.

Remove all highly flammable objects from any pockets in your laundry before the drying process. en Safety

Unwashed laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when drying is in progress.

- Do not place laundry in this appliance to be dried if the laundry has not been washed first.
- Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- Do not use the appliance if industrial chemicals have been used to clean the laundry beforehand.

Laundry that has been pretreated with cleaning agents that contain solvents may cause an explosion in the appliance.

Rinse pretreated laundry thoroughly with water before washing.

## ▲ WARNING – Risk of fire!

If drying is interrupted early, the laundry is not cooled sufficiently and may ignite.

- ► Do not interrupt the drying programme early.
- If drying is interrupted early, remove the laundry immediately and spread it out.

# ▲ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

► Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ► Do not sit on or lean against the appliance door.
- ► Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

 Wait for the drum to come to a complete stop before reaching inside.

## ▲ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

► Do not touch the hot detergent solution.

## ▲ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ► If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

## 1.6 Safe cleaning and maintenance

Take note of the safety instructions when cleaning and performing maintenance work on the appliance.

## ▲ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

## ▲ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

Only use the manufacturer's original spare parts and original accessories.

## ▲ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

► Do not use cleaning agents that contain solvents.

# 2 Preventing material damage

Follow these instructions to avoid material damage and damage to the appliance.

### ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

► Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

 Observe the maximum load capacity for each programme and do not exceed it.

 $\rightarrow$  "Programmes", Page 25 Foam and foam rubber may deform or melt during the drying process.

 Do not dry laundry that contains foam or foam rubber.

The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.

- Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- Before transport, fit the transit bolts fully in order to prevent damage in transit.

Material damage may be caused if the water inlet hose is connected incorrectly.

- Tighten the screw connections on the water inlet until they are handtight.
- Ideally, connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions, valves or similar.

- Ensure that the inner diameter of the water tap is at least 17 mm.
- Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- Ensure that the water pressure in the water supply system is at least 100 kPa (1 bar) and max.
   1000 kPa (10 bar).
- If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may lead to material damage and damage to the appliance.

 Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.

 Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

### 3 Environmental protection and saving energy

### 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

### 3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

Choose programmes with low temperatures and longer wash times and use maximum load capacity.

 Energy consumption and water consumption is most efficient.

detergent based on the laundry's degree of soiling.

For light to normal soiling, a smaller amount of detergent is sufficient. Observe the dosage recommendation from the detergent manufacturer.

Reduce the washing temperature for lightly and normally soiled laundry.

 At lower temperatures, the appliance consumes less energy. For light to normal soiling, lower temperatures than indicated on the care label are also sufficient. Set the maximum spin speed if you want to dry the laundry in the appliance afterwards.

 The drier the laundry, the shorter the programme duration when drying which, in turn, reduces energy consumption. A higher spin speed reduces the residual moisture in the laundry and increases the volume of the spin noise.

The appliance has a continuous automatic load adjustment function.

 Depending on the type of fabric and load capacity, the continuous automatic load adjustment function optimally adjusts the water consumption and programme duration.

## 3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. Energy-saving mode ends when you use the appliance again.

### 4 Installation and connection

## 4.1 Unpacking the appliance

### **ATTENTION!**

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

 Remove these objects, along with all supplied accessories, from the drum before starting the appliance. 1. Remove any packaging and protective covers completely from the appliance.

 $\rightarrow$  "Disposing of packaging", Page 11

- 2. Check the appliance for visible damage.
- **3.** Open the appliance door. → "Basic operation", Page 30
- 4. Remove any accessories from the drum.
- 5. Close the appliance door.

## 4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

### ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- Do not operate the appliance with incomplete or defective accessories.
- Replace the accessories in question before operating the appliance.

→ "Accessories", Page 29

**Note:** The appliance has been tested at the factory to check it is in working order. As a result, water stains may remain in the appliance. These marks will disappear after the first wash cycle.

The delivery consists of the following:

- Washer dryer
- Accompanying documentsTransit bolts
- → "Removing the transit bolts", Page 13
- Cover caps

Water inlet hose
 → "Connecting the water inlet
 hose", Page 14

### 4.3 Requirements for the installation location

### WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

 Do not operate the appliance without a cover cap.

# MARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

 Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 29 before using the appliance for the first time.

### **ATTENTION!**


If residual water in the appliance freezes, this may cause damage to the appliance.

 Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- Tilt the appliance carefully.
- Transport the appliance in an upright position.

# Installation loca- Requirements tion



Secure the appliance with fixing brackets  $\rightarrow$  Page 29.


# Installation loca- Requirements tion

Wooden joist floor



Place the appliance on a waterresistant wooden board (minimum thickness of 30 mm) which is screwed tightly to the floor.

Kitchen unit



Only install the appliance underneath a continuous worktop that is securely connected to adjacent cabinets. Required niche width: 60 cm.

Against a wall




Do not trap the hoses between the wall and the appliance.

# 4.4 Removing the transit bolts


The appliance is secured for transportation using transit bolts on the rear of the appliance.

**Note:** Keep the transit bolt screws and the sleeves in a safe place for future transport  $\rightarrow$  *Page* 47.

1. Pull the hoses out of the holders.




2. Unscrew ① and remove ② all screws for the 4 transit bolts with a WAF 13 wrench.



**3.** Remove the power cable from the holder.




- en Installation and connection
- 4. Remove the 4 sleeves.



5. Put on the 4 cover caps.




6. Press down on the 4 cover caps.




### 4.5 Connecting the appliance

### Connecting the water inlet hose

1. Connect the water inlet hose.



2 Connect the water inlet hose to a tap (26.4 mm = 3/4").



**3.** Open the water tap carefully and check that the connection points are tight.

### Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.

#### **ATTENTION!**

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.


 Secure the water outlet hose against unintentional loosening. **Note:** Observe the draining heights. The maximum draining height is 100 cm.

Siphon	Secure the con- nection point with a (24-40 mm) hose clamp.
Sink	Fix and secure the water outlet hose with an el- bow.
Plastic pipe with rubber sleeve or gully	Fix and secure the water outlet hose with an el- bow.


### 4.6 Aligning the appliance

In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

1. Loosen the lock nuts using a WAF 17 wrench by turning it in a clock-wise direction.




2 To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

**3.** Screw the lock nuts tightly against the housing using a WAF 17 wrench.



In doing so, hold the foot tight and do not adjust its height.

# 4.7 Connecting the appliance to the electricity supply

**Note:** Your electrical domestic installation for this appliance must comply with the local legal provisions and safety regulations, and should include a residual current circuitbreaker.


 Insert the mains plug of the appliance's power cable in a socket nearby. The connection details of the appliance can be found under Technical data  $\rightarrow$  Page 49.

2. Check the mains plug is inserted properly.

# 5 Familiarising yourself with your appliance


### 5.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

Maintenance flap for the drain pump $\rightarrow$ Page 34
Door
Detergent drawer → Page 18
Control panel → Page 18
Water outlet hose $\rightarrow$ Page 14
Power cord → Page 15
Transit bolts → Page 13



### 5.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



1	Programmes → Page 25
2	Programme selector → Page 30
3	Display
4	Buttons


# 6 Before using for the first time

Prepare the appliance for use.

### 6.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

- 1. Turn the programme selector to © Drum Care .
- **2.** Close the door.
- 3. Pull out the detergent drawer.
- 4. Pour standard washing powder into compartment II.



To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

- 5. Push in the detergent drawer.
- 6. Press D**II Start** / **Reload** to start the programme.
- The display shows the remaining programme duration.
- After the programme has ended, the display shows: End.

- 7. Start the first wash cycle or set the programme selector to Off to switch off the appliance.
  → "Basic operation" Page 20
  - → "Basic operation", Page 30

# 7 Display

The display shows the current settings, options or relevant information.

 20° ∦≹	400 Ø		
30°	800 600	Ð	
90° 60° 40°	800	•	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$

#### Example: Display

display	Designation	Description
0:40 1	Programme dura- tion/programme time remaining	Approximate expected programme dura- tion or programme time remaining.
+8h 1	"Ready in" time	→ "Buttons", Page 23
6,0 kg <sup>1</sup>	Recommended load	The maximum load capacity for the selec- ted programme in kg.
Ø - 1400	Spin speed	Set spin speed in rpm. → <i>"Buttons", Page 23</i> Ø: No spin cycle, draining only
₩ - 90	Temperature	Set temperature in °C. → <i>"Buttons", Page 23</i> <b>*</b> (cold)
_	Start/Pause	<ul> <li>Start, cancel or pause</li> <li>Lights up: The programme is running and can be cancelled or paused.</li> <li>Flashes: The programme can be star- ted or continued.</li> </ul>
	Pretreatment	Programme status
<b></b>	Wash	Programme status
<sup>1</sup> Example		

Rinse Spin End of pro- gramme Drying Anti-crease Childproof lock	Programme status Programme status Programme status Programme status Programme status Programme status
End of pro- gramme Drying Anti-crease	Programme status Programme status Programme status
gramme Drying Anti-crease	Programme status Programme status
Anti-crease	Programme status
Childproof lock	
	<ul> <li>lights up: The childproof lock is activated.</li> <li>flashes: The childproof lock is activated and the appliance has been operated.</li> <li>→ "Deactivating the childproof lock", Page 32</li> </ul>
Additional rinse	Additional rinse cycles are activated. → "Buttons", Page 23
Wash	Washing is activated.
Wash and dry	Washing with subsequent drying is activated.
Dry	Drying is activated.
SpeedPerfect	Short wash activated. → "Buttons", Page 23
Blood	The stain type is activated.
Soil and sand	The stain type is activated.
Sweat	The stain type is activated.
Grease and oil	The stain type is activated.
Reminder to clean the drum	Flashes: Drum is dirty. Run the <sup>(2)</sup> Drum Care programme for cleaning and caring for the drum and the outer tub. → "Cleaning the drum", Page 33
Pretreatment with hot air	The gentle pretreatment of dry laundry us- ing hot air for increased hygienic de- mands is activated. → "Buttons", Page 23
Door	<ul> <li>Lights up: The door is locked and cannot be opened.</li> <li>Flashes: The door is not closed properly.</li> <li>Off: The door is unlocked and can be opened.</li> </ul>
	Additional rinse Wash Wash and dry Dry SpeedPerfect Blood Soil and sand Sweat Grease and oil Reminder to clean the drum Pretreatment with hot air

display	Designation	Description
<u>گ</u>	Тар	<ul><li>No water pressure.</li><li>The water pressure is too low.</li></ul>
E:35 / -10 <sup>1</sup>	Error	Error code, error display, signal.
<sup>1</sup> Example		

# 8 Buttons

Button	Selection	Description
l Temp.	≉-90 °C	Adjust the temperature in °C.
© Spin	Ø - 1400 rpm	Adjust the spin speed or deactivate the spin cycle. If $\mathscr{G}$ is selected, the water is drained and the spin cycle is deactivated. The laundry stays wet inside the drum.
DII Start / Re- Ioad	<ul><li>Start</li><li>Cancel</li><li>Pause</li></ul>	Start, cancel or pause the pro- gramme.
() Finish in/ My Time	Up to 24 hours	Set the programme end. The programme duration is already in- cluded in the set number of hours. Once the programme has started, the programme duration is displayed.
ල Spin	Multiple selection	→ "Basic settings", Page 32
=ੴ Speed Perfect	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate a shorter pro- gramme duration. <b>Note:</b> Energy consumption increases. The washing result is not affected by this.
₩ Rinse	■ +1 ■ +2 ■ +3	Activate or deactivate up to three ad- ditional rinse cycles. Recommended for particularly sensit- ive skin or in regions with very soft water.
ŵ Hygiene Care + ⊕ Fin- ish in/My Time	<ul><li>Activate</li><li>Deactivate</li></ul>	→ "Childproof lock", Page 32
͡ŵ Hygiene Care	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate gentle pretreat- ment of dry laundry with hot air up to 65 °C for increased hygiene de- mands. After the fabrics have been pretreated with hot air, they are washed at low temperatures. <b>Note:</b> The drum lighting remains act- ive for up to approx. 10 minutes after the programme starts.

Button	Selection	Description
ƁAnti Stain	Multiple selection	Select the type of stain. The temperature, drum movement and soaking time are all adjusted to suit the type of stain.
ਔ Wash+Dry	• ₩ • ☆ + ₩ • ☆	<ul> <li>When m is selected, only washing is activated.</li> <li>When 读十m is selected, washing with subsequent drying is activated.</li> <li>When 读 is selected, only drying is activated.</li> </ul>
		Note: For the adjustable combinations of washing, drying or washing and drying, observe the information for the selected programme. → "Programmes", Page 25

# 9 Programmes

**Note:** The laundry's care labels provide you with additional information on programme selection.

Programme	Description	Max. Ioad (kg) Wash	Max. load (kg) Dry- ing
Cottons 🏠	<ul> <li>Wash hard-wearing items made from cotton, linen or blended fabrics.</li> <li>Also suitable as a short programme for normally soiled laundry when you activate =♡</li> <li>Speed Perfect.</li> <li>Programme setting:</li> <li>Max. 90 °C</li> <li>Max. 1400 rpm</li> </ul>	10,0 5,0 <sup>1</sup>	6,0
Cottons Eco @	<ul> <li>Wash hard-wearing items made from cotton, linen or blended fabrics.</li> <li>Energy-saving programme.</li> <li>Note: To save energy, the actual washing temperature may deviate from the set washing temperature. The washing performance meets legal requirements.</li> <li>Programme setting:</li> <li>Max. 90 °C</li> <li>Max. 1400 rpm</li> </ul>	10,0	6,0
Mix 🏦	Wash items made from cotton, linen, or syn- thetic or blended fabrics. Suitable for lightly soiled laundry. Programme setting: Max. 60 °C Max. 1400 rpm	4,0	2,5
Delicates/ Silk 🕼	Wash delicate, washable items made from silk, viscose and synthetic fabrics. Use a detergent that is suitable for delicates or silk. <b>Note:</b> Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag.	2,0	_2

<sup>3</sup> Washing not possible

Programme	Description	Max. Ioad (kg) Wash	Max. load (kg) Dry- ing
	Programme setting: Max. 40 °C Max. 800 rpm		
S Wool 🖉	<ul> <li>Hand- or machine-washable items that are made from wool or contain wool.</li> <li>To prevent the laundry from shrinking, the drum moves the items very gently with long pauses.</li> <li>Use a detergent that is suitable for wool.</li> <li>Programme setting:</li> <li>Max. 40 °C</li> <li>Max. 800 rpm</li> </ul>	2,0	1,0
🖼 Rinse	Rinse and then spin the laundry, and drain the water. Programme setting: Max. 1400 rpm	_	_
Spin/Drain ⓒ / ¥	Spin and drain the water. If you only want to drain the water, activate $\mathscr{D}$ . The laundry is not spun. Programme setting: Max. 1400 rpm	_	-
AllergyPlus ₪	<ul> <li>Wash hard-wearing items made from cotton, linen or blended fabrics.</li> <li>Suitable for allergy sufferers and for strict hygiene requirements.</li> <li>Note: Once the set temperature has been reached, it remains constant throughout the entire washing process.</li> <li>Programme setting:</li> <li>Max. 60 °C</li> <li>Max. 1400 rpm</li> </ul>	6.5	5,0
Shirts	Wash non-iron shirts and blouses made from cotton, linen, or synthetic or blended fabrics. <b>Note:</b> Use the Delicates/Silk the programme to wash shirts and blouses made from silk or delicate fabrics. Programme setting: Max. 60 °C	2,0	2,0
<sup>1</sup> <b>=♡ Speed P</b> <sup>2</sup> Drying not po <sup>3</sup> Washing not			

Programme	Description	Max. Ioad (kg) Wash	Max. load (kg) Dry- ing
	<ul> <li>Max. 800 rpm</li> </ul>		
☞ Drum Care	<ul> <li>Cleaning and caring for the drum.</li> <li>After cleaning, the residual water in the drum is removed by supplying hot air.</li> <li>Use this programme in the following cases:</li> <li>Before using the appliance for the first time</li> <li>If you regularly wash at temperatures of 40 °C or lower</li> <li>After a prolonged period of non-use</li> </ul>	_3	_2
	Use washing powder or a detergent that con- tains bleach. Halve the amount of detergent to avoid foam- ing. Do not use fabric softener. Do not use liquid detergent or detergent that is intended for woollens or delicates.		
	<b>Note:</b> The drum cleaning indicator will flash to remind you if you have not used a programme at 60 °C or higher for a long time.		
I Auto Dry	Dry items made from cotton or linen. Intensive programme with temperatures for hard-wearing fabrics.	_3	6,0
ነነን Dry Hy- giene	Kill bacteria in jackets made of cotton or down jackets. Note: The laundry is not dried or washed.	_3	3,0
My Time ©	<ul> <li>Wash items made from cotton, linen, or synthetic or blended fabrics.</li> <li>Short programme for items of lightly to normally soiled laundry.</li> <li>Note: If you only want to dry the laundry and not wash it, press</li></ul>	2,0	6,0

<sup>3</sup> Washing not possible

Programme	Description	Max. load (kg) Wash	Max. load (kg) Dry- ing
<sup>™</sup> Wash&Dry 60'	Wash and dry items made from cotton, linen, or synthetic or blended fabrics. Short programme for small items of lightly soiled laundry. Programme setting: Max. 40 °C Max. 1000 rpm	2,0	1,0
<sup>1</sup> = ⑦ Speed P <sup>2</sup> Drying not po <sup>3</sup> Washing not			

### **10 Accessories**

Use original accessories. These have been made especially for your appliance.

	Use	Order number
Water inlet hose exten- sion	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Fixing brackets	Improves the stability of the appliance.	WMZ2200

# 11 Laundry

**Note:** You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

### 11.1 Preparing the laundry

### **ATTENTION!**

Objects remaining in the laundry may damage the laundry and the drum.

- Remove all items from any pockets in your laundry before using the appliance.
- To protect your appliance and the laundry, prepare the laundry beforehand.
  - Empty any pockets
  - Brush sand out of all collars and pockets
  - Close bed covers and cushion covers
  - Close all zips, Velcro fasteners, hooks and eyes
  - Tie cloth belts, apron strings, etc. together or use a laundry bag.
  - Tie together longer drawstrings, and tie cords with solid endpieces in hoods or trousers

- Remove curtain hooks and lead strips or use a mesh laundry bag
- Use a mesh laundry bag for small items of laundry, such as children's socks
- Some stubborn or dried-in stains can be removed by washing several times
- Wash large and small items of laundry together
- Do not rub fresh stains but dab them with soapy water
- Separate items of laundry and shake them out, or observe the programme description
- Spin the laundry before drying

# 12 Detergents and care products

#### Notes

- You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.
- Observe the information on safety
   → Page 4 and preventing material
   damage → Page 10.

The manufacturer's instructions for use and dosage can be found on the packaging.

#### Notes

- Only use liquid detergents that are self-flowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances (e.g. bleach)
- Use dyes sparingly as salt may damage stainless steel
- Do not use bleaching agents in the appliance

# 13 Basic operation

**Note:** You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

### 13.1 Switching on the appliance

**Requirement:** The appliance has been correctly installed and connected.

 $\rightarrow$  "Installation and connection", Page 11

Turn the programme selector to a programme.

**Note:** The lighting for the drum goes out automatically.

### 13.2 Setting a programme

 Turn the programme selector and set the required programme.
 → "Programmes", Page 25 2. If necessary, adjust the programme settings.

### 13.3 Adjusting the programme settings

**Requirement:** A programme has been set.

- → "Setting a programme", Page 30
- Adjust the programme settings.
   → "Buttons", Page 23

**Note:** The programme settings are not saved permanently for the programme.

### 13.4 Loading laundry

**Note:** To prevent creasing, take note of the maximum load for the → "Programmes", Page 25.

**Requirement:** The laundry is prepared.

- → "Laundry", Page 29
- Open the door. Make sure that the drum is empty.
- **2.** Place the laundry in the drum.
- 3. Close the door.

Ensure that there is no laundry trapped in the door.

# 13.5 Adding detergent and care product

**Note:** Observe the information about detergents and care products  $\rightarrow$  *Page 29*.

- 1. Pull out the detergent drawer.
- Pour in detergent.
   → "Detergent drawer", Page 18
- 3. If required, add the care product.
- 4. Push in the detergent drawer.

### 13.6 Starting the programme

**Note:** If you want to change the time until the programme ends, set the "Ready in" time first.

#### 1. Press DI Start / Reload.

- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- The display shows either the programme duration or the "Ready in" time.
- After the programme has ended, the display shows: End.
- If Ø is selected, the laundry is not spun and the water is drained after rinsing.

#### Notes

- If the laundry is not removed, the Anti-Crease programme starts after 15 minutes. The programme takes around 30 minutes. The display shows 0 : 00, ERP, to and End alternately and ☺ appears. Press any button to stop the Anti-Crease programme and to remove the laundry.
- If "Hot" appears, the appliance cools the laundry. When "Hot" goes out, the laundry has cooled down.

### 13.7 Soaking laundry

**Note:** No additional detergent is required. The washing solution is then used for washing.

- 1. Start the programme.
- To pause the programme, after approx. 10 minutes, press DN Start / Reload.
- 3. To resume the programme, after the desired soaking time, press D₪ Start / Reload.

### 13.8 Adding laundry

#### 1. Press DI Start / Reload.

During the washing cycle, the appliance pauses.

During the drying cycle, the appliance checks whether it is possible to add laundry.

**Note:** If <sup>(C)</sup> appears, it is not possible to add laundry. When <sup>(C)</sup> goes out, it is possible to add laundry.

- 2. Open the appliance door.
- 3. Add or remove laundry.
- 4. Close the appliance door.
- 5. Press DI Start / Reload.

### 13.9 Cancelling the programme

- 1. Press DI Start / Reload.
- 2. Open the appliance door.
  - The appliance door remains locked for safety reasons if the temperature and water levels are high.
    - If the temperature is high, start the m Rinse programme.
    - If the water level is high, start the Spin I programme or select a suitable programme for draining.

→ "Programmes", Page 25

**3.** Remove the laundry  $\rightarrow$  *Page 32*.

# 13.10 Cancelling the drying programme

- Turn the programme selector to set any other programme.
- The door lock opens automatically after a cooling period of a few minutes.

## 13.11 Unloading the laundry

- 1. Open the appliance door.
- 2. Remove the laundry.

### 13.12 Switching off the appliance

- 1. Turn the programme selector to **Off** .
- 2. Turn off the tap.
- **3.** Wipe the rubber gasket dry and remove any foreign objects.



4. Leave the appliance door and detergent drawer open so that residual water can evaporate.

# 14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

# 14.1 Activating the childproof lock

- Press and hold the two 🐨 Hygiene Care + (9) Finish in/My Time buttons for approx. 3 seconds.
- The display shows Cm.
- The controls are locked.
- The childproof lock remains active even after the appliance has been switched off and in the event of a power failure.

### 14.2 Deactivating the childproof lock

**Requirement:** To deactivate the childproof lock, the appliance must be switched on.

- Press and hold the two J Hygiene Care + D Finish in/My Time buttons for approx. 3 seconds.
- ✓ C goes out in the display.

# 15 Basic settings

You can configure the basic settings for your appliance to meet your needs.

**Note:** You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

## 16 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

**Note:** You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

### 16.1 Cleaning the drum


### CAUTION Risk of injury!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.


- Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- ► Run the ☺ Drum Care programme without laundry and using all-purpose washing powder.

# 16.2 Cleaning the detergent drawer


- 1. Pull out the detergent drawer.
- 2. Press down on the insert and remove the detergent drawer.




3. Pull out the insert upwards.



4. Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and click it into place.



- en Cleaning and servicing
- 6. Clean the opening for the detergent drawer.




7. Push in the detergent drawer.

### 16.3 Cleaning the drain pump


Clean the drain pump in the event of faults, e.g. blockages or rattling noises.

### Emptying the drain pump


- 1. Turn off the water tap.
- 2. Switch off the appliance.
- **3.** Disconnect the appliance's mains plug from the power supply.
- 4. Open and remove the service flap.



**5.** Slide a sufficiently large container under the opening.




6. Take the drain hose out of the holder.




- 7. A CAUTION Risk of scalding! When you wash at high temperatures, the detergent solution gets hot.
- Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



8. Firmly press on the sealing cap.




9. Insert the drain hose into the holder.




#### Cleaning the drain pump

**Requirement:** The drain pump is empty.  $\rightarrow$  *Page 34* 


1. Since water may remain in the drain pump, unscrew the pump cap carefully.




2. Clean the interior, the thread on the pump cap and the pump housing.



3. Insert the pump cap.




- en Cleaning and servicing
- 4. Screw the pump cap as far as it will go.



The handle on the pump cap must be in a vertical position.

5. Insert and close the service flap.



#### 17 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

#### 

#### **Risk of electric shock!**

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting		
Creasing.	The load is too large.		
	<ul><li>The laundry lies in the drum for too long after drying.</li><li>1. Remove the laundry from the drum as soon as the drying programme has finished.</li><li>2. Spread the items of laundry for cooling.</li></ul>		
	<ul><li>Unsuitable programme for the type of fabric.</li><li>Set the suitable programme for the type of fabric.</li></ul>		
	Easy-Care fabrics are dried for too long.		
Spin noise during the drying phase.	Thermal spinning is active.		
The drying time is too long.	<ul> <li>The ambient temperature is greater than 30 °C.</li> <li>Ensure that the ambient temperature is lower than 30 °C.</li> </ul>		
	<ul> <li>Insufficient air circulation at the appliance's installation location.</li> <li>Ventilate the appliance's installation location.</li> </ul>		
	<ul> <li>Fluff has accumulated in the drum.</li> <li>▶ Run the <sup>(A)</sup> Drum Care <sup>(A)</sup> programme without any laundry or detergent.</li> </ul>		
Odours have formed in the appliance.	<ul> <li>Humidity and detergent residue may promote the formation of bacteria.</li> <li>→ "Cleaning the drum", Page 33</li> <li>If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate.</li> </ul>		

Fault	Osuss and traublack sating		
Fault	Cause and troubleshooting		
The display goes out and D <b>II Start</b> / <b>Reload</b> flashes.	<ul><li>Energy-saving mode is active</li><li>Press any button.</li><li>The symbol lights up again.</li></ul>		
"E:36 / -10"	<ul><li>Drain pipe or water outlet hose is blocked.</li><li>Clean the drain pipe and the water outlet hose.</li></ul>		
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>		
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 34		
	<ul> <li>The water outlet hose is connected too high.</li> <li>Install the water outlet hose at a maximum height of 1 metre.</li> </ul>		
	<ul> <li>Detergent dosage is too high.</li> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down).</li> <li>Reduce the amount of detergent for the next washing cycle with the same load.</li> </ul>		
	<ul> <li>Unapproved extension installed on the water drain hose.</li> <li>▶ Remove any unapproved extensions from the water hose.</li> <li>→ "Connecting the appliance", Page 14</li> </ul>		
	<ul> <li>The pump cap is not fully screwed in.</li> <li>Ensure that the pump cap is screwed in all the way into the appliance. The handle on the pump cap must be in a vertical position.</li> <li>→ "Cleaning the drain pump", Page 35</li> </ul>		
"H:32"	<ul> <li>The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.</li> <li>Redistribute the laundry in the drum.</li> </ul>		
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
ج	The water pressure is low. No remedial action possible.		
	<ul><li>The filters in the water inflow are blocked.</li><li>Clean the filters in the water inflow.</li></ul>		

Fault	Cause and troubleshooting
上 译	The tap is turned off. Turn on the tap.
	<ul><li>The water inlet hose is kinked or jammed.</li><li>Ensure that the water inlet hose is not kinked or jammed.</li></ul>
	<ul> <li>Water level measurement system is defective.</li> <li>Call the after-sales service.</li> <li>→ "Customer Service", Page 48</li> </ul>
© lights up.	<ul> <li>The temperature is too high.</li> <li>▶ Wait until the temperature has dropped.</li> <li>▶ → "Cancelling the programme", Page 31</li> </ul>
	<ul> <li>Water level is too high.</li> <li>Select a suitable programme for draining.</li> <li>→ "Programmes", Page 25</li> </ul>
© flashes.	<ul> <li>Door is not closed.</li> <li>1. Close the door.</li> <li>2. Press DII Start / Reload to start the programme.</li> </ul>
	<ul> <li>Laundry is caught in the door.</li> <li>1. Open the door again.</li> <li>2. Remove any trapped laundry.</li> <li>3. Close the door.</li> <li>4. Press DI Start / Reload to start the programme.</li> </ul>
Ċ	Drum cleaning is required. ► → "Cleaning the drum", Page 33
"H:95" lights up altern- ately with End.	The water pressure is low. ► See → "ఊ", Page 39
All other error codes.	Malfunction <ul> <li>Call the after-sales service.</li> <li>→ "Customer Service", Page 48</li> </ul>
The appliance is not working.	<ul><li>The mains plug of the power cord is not plugged in.</li><li>Connect the appliance to the power supply.</li></ul>
	<ul><li>The circuit breaker in the fuse box has tripped.</li><li>Check the circuit breaker in the fuse box.</li></ul>
	<ul><li>There has been a power cut.</li><li>Check whether the lighting in your kitchen or other appliances are working.</li></ul>
The programme does not start.	You have not pressed <b>DII Start</b> / <b>Reload</b> . ▶ Press <b>DII Start</b> / <b>Reload</b> .

Fault	Cause and troubleshooting		
The programme does not start.	<ul> <li>Door is not closed.</li> <li>1. Close the door.</li> <li>2. Press D<b>II</b> Start / Reload to start the programme.</li> </ul>		
	Childproof lock is activated. ► → "Deactivating the childproof lock", Page 32		
	<ul> <li>● Finish in/My Time is activated.</li> <li>▶ Check whether ● Finish in/My Time is activated.</li> <li>→ "Buttons", Page 23</li> </ul>		
	<ul> <li>Laundry is caught in the door.</li> <li>1. Open the door again.</li> <li>2. Remove any trapped laundry.</li> <li>3. Close the door.</li> <li>4. Press DI Start / Reload to start the programme.</li> </ul>		
The door cannot be opened.	<ul> <li>The temperature is too high.</li> <li>▶ Wait until the temperature has dropped.</li> <li>▶ → "Cancelling the programme", Page 31</li> </ul>		
	<ul> <li>Water level is too high.</li> <li>▶ Select a suitable programme for draining.</li> <li>→ "Programmes", Page 25</li> </ul>		
	<ul> <li>Power failure.</li> <li>Open the door using the emergency release.</li> <li>→ "Emergency release", Page 47</li> </ul>		
The water is not drain- ing.	<ul><li>Drain pipe or water outlet hose is blocked.</li><li>Clean the drain pipe and the water outlet hose.</li></ul>		
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>		
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 34		
	<ul> <li>The water outlet hose is connected too high.</li> <li>Install the water outlet hose at a maximum height of 1 metre.</li> </ul>		
	<ul> <li>Detergent dosage is too high.</li> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down).</li> <li>Reduce the amount of detergent for the next washing cycle with the same load.</li> </ul>		

Fault	Cause and troubleshooting
The water is not drain- ing.	<ul> <li>Unapproved extension installed on the water drain hose.</li> <li>▶ Remove any unapproved extensions from the water hose.</li> <li>→ "Connecting the appliance", Page 14</li> </ul>
	<ul> <li>The pump cap is not fully screwed in.</li> <li>Ensure that the pump cap is screwed in all the way into the appliance. The handle on the pump cap must be in a vertical position.</li> <li>→ "Cleaning the drain pump", Page 35</li> </ul>
Water is not flowing in. Detergent is not being dispensed.	You have not pressed <b>DII</b> Start / Reload. ► Press <b>DII</b> Start / Reload.
	<ul><li>The filters in the water inflow are blocked.</li><li>Clean the filters in the water inflow.</li></ul>
	The tap is turned off. ► Turn on the tap.
	<ul><li>The water inlet hose is kinked or jammed.</li><li>Ensure that the water inlet hose is not kinked or jammed.</li></ul>
The spin cycle runs several times.	<ul><li>The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry.</li><li>Not a fault – no action required.</li></ul>
	<b>Note:</b> When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
No water is visible in the drum.	<ul> <li>Water is below the visible area.</li> <li>Not a fault – no action required.</li> <li>Do not add any extra water to the appliance while it is operating.</li> </ul>
Residual water is present in the compartment &.	Insert in compartment & is blocked. ► → "Cleaning the detergent drawer", Page 33
Vibrations and move- ment of the appliance whilst spinning.	Appliance is not correctly aligned. ► → "Aligning the appliance", Page 15
	<ul> <li>The appliance feet are not fixed.</li> <li>Secure the appliance feet.</li> <li>→ "Aligning the appliance", Page 15</li> </ul>
	Transit bolts have not been removed. ► → "Removing the transit bolts", Page 13.

Fault	Cause and troubleshooting		
Drum rotates, water does not flow in.	Load detection is active. ► Not a fault – no action required.		
	Note: The load detection can take up to two minutes.		
Heavy foam build-up	<ul> <li>Detergent dosage is too high.</li> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down).</li> <li>Reduce the amount of detergent for the next washing cycle with the same load.</li> </ul>		
High spin speed not reached.	<ul><li>A low spin speed is selected.</li><li>The next time you run a wash cycle, set a higher spin speed.</li></ul>		
	<ul><li>Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.</li><li>Redistribute the laundry in the drum.</li></ul>		
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	<ul> <li>Start the Spin I programme.</li> </ul>		
The spin programme does not start.	<ul><li>Drain pipe or water outlet hose is blocked.</li><li>Clean the drain pipe and the water outlet hose.</li></ul>		
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>		
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distrib- uted.		
	<ul> <li>Redistribute the laundry in the drum.</li> </ul>		
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	► Start the Spin <sup>®</sup> programme.		
Loud noises during the spin cycle.	Appliance is not correctly aligned. ► → "Aligning the appliance", Page 15		
	<ul> <li>The appliance feet are not fixed.</li> <li>► Secure the appliance feet.</li> <li>→ "Aligning the appliance", Page 15</li> </ul>		
	Transit bolts have not been removed.		

Fault	Cause and troubleshooting		
Loud noises during the spin cycle.	• $\rightarrow$ "Removing the transit bolts", Page 13.		
Banging noises, rat- tling in the drain pump.	Foreign bodies have got into the drain pump. ► → "Cleaning the drain pump", Page 34		
Slurping, rhythmical suction noise.	<ul><li>The drain pump is active, the detergent solution is pumped out.</li><li>Not a fault – normal operating noise.</li></ul>		
The spin result is not satisfactory. The laun- dry is too wet/too damp.	<ul> <li>A low spin speed is selected.</li> <li>The next time you run a wash cycle, set a higher spin speed.</li> <li>Start the Spin ③ programme.</li> </ul>		
	<ul><li>Drain pipe or water outlet hose is blocked.</li><li>Clean the drain pipe and the water outlet hose.</li></ul>		
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>		
	<ul> <li>The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.</li> <li>Redistribute the laundry in the drum.</li> </ul>		
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	<ul> <li>Start the Spin I programme.</li> </ul>		
	<ul><li>Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.</li><li>Redistribute the laundry in the drum.</li></ul>		
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	<ul> <li>Start the Spin I programme.</li> </ul>		
Detergent residue on the damp washing.	<ul><li>Detergents may contain water-insoluble substances that deposit on the laundry.</li><li>Start the I Rinse programme.</li></ul>		
Detergent residue on the dry laundry.	<ul><li>Detergents may contain water-insoluble substances that deposit on the laundry.</li><li>Brush out the laundry after washing and drying.</li></ul>		
the damp washing.	<ul> <li>Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.</li> <li>Redistribute the laundry in the drum.</li> <li>Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.</li> <li>Start the Spin O programme.</li> <li>Detergents may contain water-insoluble substances that deposit on the laundry.</li> <li>Start the Winse programme.</li> <li>Detergents may contain water-insoluble substances that deposit on the laundry.</li> </ul>		

Fault	Cause and troubleshooting
Water is leaking out at the water inlet hose.	<ul> <li>Water inlet hose is not correctly/securely connected.</li> <li>1. Connect the water supply hose correctly.</li> <li>→ "Connecting the water inlet hose", Page 14</li> <li>2. Tighten the screw connection.</li> </ul>
Water is leaking out at the water outlet hose.	<ul><li>The water outlet hose is damaged.</li><li>Replace the damaged water outlet hose.</li></ul>
	<ul> <li>Water outlet hose is not connected correctly.</li> <li>Connect the water outlet hose correctly.</li> <li>→ "Water outlet connection types", Page 14</li> </ul>
Fluff on the laundry.	<ul> <li>Fluff has accumulated in the drum.</li> <li>Run the @ Drum Care * programme without any laundry or detergent.</li> </ul>
Water inlet noise dur- ing the drying phase.	<ul><li>Drying phase requires water.</li><li>1. Not a fault.</li><li>2. Make sure that the water tap also remains open during the drying phase.</li></ul>
Drying programme does not start.	<ul> <li>Door is not closed.</li> <li>1. Close the door.</li> <li>2. Press D<b>II</b> Start / Reload to start the programme.</li> </ul>
	<ul> <li>No drying programme is selected.</li> <li>Select a suitable drying programme.</li> <li>→ "Programmes", Page 25</li> </ul>
The laundry is too	Unsuitable programme for the type of fabric.
damp.	<ul><li>There has been a power cut.</li><li>Check whether the lighting in your kitchen or other appliances are working.</li></ul>
	The load is too large.
	<ul><li>After the end of the programme, warm laundry feels damper than it actually is.</li><li>1. Remove the laundry from the drum as soon as the drying programme has finished.</li><li>2. Spread the items of laundry for cooling.</li></ul>
	Unsuitable dryness level set.
	Drying target not adjusted.
	Load too small.
	Moisture sensor dirty.
	<ul> <li>Water tap is closed during the drying phase.</li> <li>Make sure that the water tap also remains open during the drying phase.</li> </ul>

Fault	Cause and troubleshooting		
The laundry is too damp.	<ul> <li>The ambient temperature is greater than 30 °C.</li> <li>Ensure that the ambient temperature is lower than 30 °C.</li> </ul>		
	<ul> <li>Insufficient air circulation at the appliance's installation location.</li> <li>Ventilate the appliance's installation location.</li> </ul>		
	The water pressure is low. No remedial action possible.		
	<ul> <li>Laundry is not spun sufficiently.</li> <li>Always select the highest possible spin speed for the washing programme in question.</li> </ul>		
	<ul> <li>Thick and multi-layered fabrics require a longer drying time.</li> <li>▶ Set a timed programme for the subsequent drying.</li> <li>→ "Programmes", Page 25</li> </ul>		
Fan noise during the washing phase.	<ul><li>Process fan is active.</li><li>Not a fault – normal operating noise.</li></ul>		
The programme dura- tion changes during the wash cycle.	<ul> <li>The programme operation is optimised electronically.</li> <li>This may change the programme duration.</li> <li>Not a fault – no action required.</li> </ul>		
	<ul> <li>The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry.</li> <li>Not a fault – no action required.</li> </ul>		
	<b>Note:</b> When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	Foam detection system switches on a rinse cycle if foam build-up is too high. ► Not a fault – no action required.		
Drum jerks after the programme starts.	This is caused by an internal motor test. ► Not a fault – no action required.		
Rushing, hissing noise.	<ul><li>Water is flushed under pressure into the detergent drawer.</li><li>▶ Not a fault – normal operating noise.</li></ul>		
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	<ul> <li>Too much detergent/fabric softener in the detergent drawer.</li> <li>When dosing liquid detergent and fabric softener, observe the marking in the detergent drawer and do not dose above this.</li> </ul>		

Fault	Cause and troubleshooting
<b>DII</b> Start / Reload cannot be operated.	<ul><li>Drying phase active.</li><li>Not a fault – no action required.</li></ul>

Transportation, storage and disposal en


#### 17.1 Emergency release

#### Releasing the door

**Requirement:** The drain pump is empty.  $\rightarrow$  *Page 34* 

- 1. **ATTENTION!** Escaping water may cause material damage.
- Do not open the door if you can see water through the glass.

Pull the emergency release downwards with a tool and release.



- ✓ The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

#### 18 Transportation, storage and disposal

You can find out here how to prepare your appliance for transportation and storage. You will also find out how to dispose of old appliances.

### 18.1 Removing the appliance

**Note:** You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.


- 1. Turn off the tap.
- 2. Empty the water inlet hose.

- 3. Switch off the appliance.
- 4. Unplug the appliance's mains plug.
- Drain the water.
   → "Cleaning the drain pump", Page 34
- 6. Detach the hoses.

## 18.2 Inserting the transit bolts

Secure the appliance for transportation using transit bolts in order to prevent damage.

**1.** Use a screwdriver to remove the 4 cover caps.



Keep the cover caps.

2 Install the 4 transit bolts. Refer to the description

→ "Removing the transit bolts", Page 13 for this and proceed in reverse order.

# 18.3 Using the appliance again

For further information, see
 → "Installation and connection",
 Page 11 and
 → "Before using for the first time",
 Page 19.

#### 18.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

## MARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.

This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

#### **19 Customer Service**

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

#### 19.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate.

Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

#### 20 Consumption values

The indicated consumption values are approximate. Values determined in accordance with the applicable version of IEC60456.

Programme	Load (kg)	Pro- gramme duration (h:min) <sup>1</sup>	Energy consump- tion (kWh/ cycle) <sup>1</sup>	Water con- sumption (I/cycle) <sup>1</sup>
Cottons î 20 °C	10,0	3:00	0,420	82,0
Cottons 🏠 40 °C	10,0	3:00	1,300	82,0
Cottons Eco @ 60 °C <sup>2</sup>	10,0	5:45	1,07	55,0
Cottons 🕯 60 °C	10,0	3:00	1,600	82,0
Mix î 🗛 40 °C	4,0	1:00	0,610	47,0
Delicates/Silk 5 30 °C	2,0	0:45	0,180	36,0
& Wool ֎ 30 °C	2,0	0:45	0,280	36,0

<sup>1</sup> The values may deviate from the indicated values depending on water pressure, water hardness, water inlet temperature, room temperature, type of laundry, amount and soiling of laundry, detergent used, fluctuations in the mains voltage and selected settings.

<sup>2</sup> Programme setting with maximum speed for testing in accordance with the applicable version of IEC60456 with cold water (15 °C).

#### 21 Technical data

Appliance height	84,8 cm	
Appliance width	59,8 cm	
Appliance depth	59,0 cm	
Weight	80,9 kg <sup>1</sup>	
Maximum load	10,0 kg	
Mains voltage	220-240 V, 50 Hz	
Minimum in- stallation protec- tion	10A	
Nominal power	1900 W	
<sup>1</sup> Depending on the appliance spe- cifications		

Water pressure	<ul> <li>Minimum: 100 kPa (1 bar)</li> <li>Maximum: 1000 kPa (10 bar)</li> </ul>
Length of the wa- ter inlet hose	150 cm
Length of the wa- ter outlet hose	150 cm
Length of the power cord	210 cm
<sup>1</sup> Depending on the appliance spe- cifications	



# Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- Expert tips & tricks for your appliance
- Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome** 

#### BOSCH HOME APPLIANCES SERVICE

## Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: **www.bosch-home.com/service** 

Contact data of all countries are listed in the attached service directory.

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com

A Bosch Company

