



# Fridge-freezer

KGN56..

[en] Information for Use



# You can find additional information and explanations online. Scan the QR code on the title page.



### **Table of contents**

1 Safety	7 Basic operation	n 15
1.1 General information	7.1 Switching on	the appliance 15
1.2 Intended use	7.2 Operating tips	3 16
1.3 Restriction on user group	7.3 Switching off	the appliance 16
1.4 Safe transport	7.4 Setting the ter	mperature 16
1.5 Safe installation	8 Additional fund	tions 16
1.6 Safe use		ı 17
1.7 Damaged appliance		g17
2 Preventing material damage		17
3 Environmental protection and	8.4 Energy-saving	mode 17
saving energy	8.5 Freshness mo	ode 18
3.1 Disposing of packaging	9 Alarm	18
3.2 Saving energy		18
4 Installation and connection		alarm18
4.1 Scope of delivery	10 Home Connec	t18
4.2 Criteria for the installation loc-		ome Connect 19
ation	10.2 Switching or	
4.3 Installing the appliance 1		home network
4.4 Preparing the appliance for	(Wi-Fi)	19
the first time 1	10.3 Switching of	
4.5 Connecting the appliance to		home network
the electricity supply 1	• ,	19
5 Familiarising yourself with	10.4 Installing upo	
your appliance1		ect software 19
5.1 Appliance 1	10.5 Resetting Ho	19
5.2 Control panel 1		ion 20
6 Features 1	•	
6.1 Shelf 1	_	ompartment 20
6.2 Snack container 1		ng food in the re-
6.3 Storage container 1	11.2 Chill zones i	mpartment 20
6.4 Fruit and vegetable container		it 20
with humidity control 1	·	
6.5 Butter and cheese compart-		artment 21
ment 1	12.1 Fully utilising	ine ireezer it volume21
6.6 Door tray 1	12.2 Tips for stori	
6.7 Ice cube maker 1 6.8 Accessories 1		partment 21
0.0 ACCESSUITES I		, L 1

12.3 Tips for freezing fresh food 21 12.4 Shelf life of frozen food at	<b>15 Troubleshooting</b> 15.1 Power failure	
-18 °C	15.2 Conducting an appliance self-test	31
frozen food22	16 Storage and disposal	
13 Defrosting	16.1 Taking the appliance out of operation	32
compartment22	16.2 Disposing of old appliance	
13.2 Defrosting in the freezer compartment	<b>17 Customer Service</b> 17.1 Product number (E-Nr.), pro-	33
<b>14 Cleaning and servicing 22</b> 14.1 Preparing the appliance for	duction number (FD) and consecutive numbering (Z-	
cleaning22	Nr.)	33
14.2 Cleaning the appliance	18 Technical data	
ponents 25	19 Declaration of Conformity	



Observe the following safety instructions.

#### 1.1 General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

#### 1.2 Intended use

Only use this appliance:

- for chilling and freezing food and for making ice cubes.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 2000 m above sea level.

### 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are

Safety en

supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

### 1.4 Safe transport

#### 

The heavy weight of the appliance may result in injury when lifted.

► Do not lift the appliance on your own.

#### 1.5 Safe installation

#### ⚠ WARNING – Risk of electric shock!

Incorrect installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.
- When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

▶ Never let the power cord come into contact with heat sources.

### **⚠ WARNING – Risk of explosion!**

If the appliance's ventilation openings are closed off, a leak in the refrigeration circuit may result in a flammable mixture of gas and air.

► Keep ventilation openings in the appliance casing or in the integrated casing clear of obstruction.

#### 

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.
- If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

Portable multiple socket strips or portable power supply units may overheat and cause a fire.

► Do not place portable multiple socket strips or power supply units on the back of the appliance.

#### 1.6 Safe use

#### ⚠ WARNING – Risk of electric shock!

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners to clean the appliance.

#### 

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

- Keep small parts away from children.
- Do not let children play with small parts.

### 

If the cooling circuit is damaged, flammable refrigerant may escape and explode.

► To accelerate the defrosting process, do not use any other mechanical devices or means other than those recommended by the manufacturer.

#### en Safety

▶ If food is stuck to the freezer compartment, loosen it with a blunt object such as the handle of a wooden spoon.

Products which contain flammable propellants and explosive substances may explode, e.g. spray cans.

▶ Do not store products which contain flammable propellants (e.g. spray cans) or explosive substances in the appliance.

#### 

Electrical devices within the appliance may cause a fire, e.g. heaters or electric ice makers.

▶ Do not operate electrical devices within the appliance.

### **⚠ WARNING** – Risk of injury!

Containers that contain carbonated drinks may burst.

► Do not store containers that contain carbonated drinks in the freezer compartment.

Injury to the eyes caused by escaping flammable refrigerant and hazardous gases.

▶ Do not damage the tubes of the refrigerant circuit or the insulation.

The appliance may tip.

► Do not stand or support yourself on the base, runners or doors.

#### 

Individual parts on the back of the appliance become hot during operation.

► Never touch these hot parts.

#### 

Contact with frozen food and cold surfaces may cause burns by refrigeration.

- ► Never put frozen food straight from the freezer compartment into your mouth.
- ► Avoid prolonged contact of the skin with frozen food, ice and surfaces in the freezer compartment.

#### 

To prevent food from being contaminated, you must observe the following instructions.

- ▶ If the door is open for an extended period of time, this may lead to a considerable temperature increase in the compartments of the appliance.
- ► Regularly clean the surfaces that may come into contact with food and accessible drain systems.
- ► Store raw meat and fish in suitable containers in the refrigerator so that they do not touch or drip on other food.
- ▶ If the fridge/freezer is empty for an extended period of time, switch off the appliance, defrost it, clean it and leave the door open to prevent the formation of mould.

Metal or metal-style parts in the appliance may contain aluminium. If acidic food comes into contact with aluminium in the appliance, aluminium foil ions may pass into the food.

▶ Do not consume soiled food.

### 1.7 Damaged appliance

#### 

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer service. → Page 33 Improper repairs are dangerous.
- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

### **⚠ WARNING** – Risk of fire!



If the tubes are damaged, flammable refrigerant and harmful gases may escape and ignite.

- Keep naked flames and ignition sources away from the appliance.
- Ventilate the room.
- ► Switch off the appliance. → Page 16
- ► Unplug the mains plug from the mains or switch off the circuit breaker in the fuse box.
- Call customer service. → Page 33

# 2 Preventing material damage

#### **ATTENTION**

If not rolling freely, the appliance's castors may damage the floor when the appliance is moved.

- Transport the appliance using a sack truck.
- ► Use floor protection when moving the appliance, and do not move it in a zigzag fashion.

Using the appliance, base, runners or doors as a seat or climbing surface may damage the appliance.

- ► Do not stand or lean on the appliance, base, runners or doors. Contamination with oil or fat may cause plastic parts and door seals to become porous.
- Keep plastic parts and door seals free of oil and grease.

Metal or metal-style parts in the appliance may contain aluminium. When aluminium comes into contact with acidic foods, it corrodes and discolours.

 Only store packaged food in the appliance. If you clean fittings and accessories in the dishwasher, this may cause them to become deformed or discolour

Never clean fittings and accessory in the dishwasher.

# 3 Environmental protection and saving energy

#### 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

#### 3.2 Saving energy

If you follow these instructions, your appliance will use less power.

#### Selecting the installation location

- Keep the appliance out of direct sunlight.
- Install the appliance as far away as possible from heating elements, cookers and other heat sources:

- Maintain a 30 mm clearance to electric or gas cookers.
- Maintain a 300 mm clearance to oil or solid-fuel cookers.
- Make sure there is a small gap between the side wall and the appliance.
- Never cover or block the external ventilation openings.

#### Saving energy during use

**Note:** The arrangement of the fittings does not affect the energy consumption of the appliance.

- Open the appliance only briefly and then close it carefully.
- Never cover or block the interior ventilation openings or the exterior ventilation openings.
- Transport purchased food in a cool bag and place in the appliance quickly.
- Allow warm food and drinks to cool down before storing them.
- Thaw frozen food in the refrigerator compartment to utilise the low temperature of the food.
- Always leave some space between the food and to the back panel.

### 4 Installation and connection

#### 4.1 Scope of delivery

After unpacking all parts, check for any transport damage and for completeness of delivery.

If you have any complaints, contact your dealer or our after-sales service *→ Page 33.* 

- The delivery consists of the following:
- Free-standing appliance
- Equipment and accessories<sup>1</sup>
- Installation instructions
- User manual
- Customer service directory
- Warranty enclosure<sup>2</sup>
- Energy label
- Information on energy consumption and noises
- Information about Home Connect

#### 4.2 Criteria for the installation location

### ⚠ WARNING Risk of explosion!

If the appliance is in a space that is too small, a leak in the refrigeration circuit may result in a flammable mixture of gas and air.

► Only install the appliance in a space with a volume of at least 1 m<sup>3</sup> per 8 g refrigerant. The volume of refrigerant is indicated on the rating plate.

→ "Appliance", Fig. 1 / 5 Page 12

The weight of the appliance ex works may be up to 110 kg depending on the model.

The subfloor must be sufficiently stable to bear the weight of the appliance.

The surface must be level.

This refrigerator is intended for use at ambient temperatures of 10 °C to 43 °C.

The appliance is fully functional within the permitted room temperature.

If the appliance is operated at colder room temperatures, the appliance will

Depending on the appliance specifications

Not in all countries

not be damaged up to a room temperature of 5 °C.

## Over-and-under and side-by-side installation

If you want to install 2 refrigerating appliances one over the other or side by side, you must maintain a clearance of at least 150 mm between the appliances. Selected appliances can be installed without a minimum clearance. Ask your dealer or kitchen planner about this.

#### 4.3 Installing the appliance

 Install the appliance in accordance with the enclosed installation instructions.

# 4.4 Preparing the appliance for the first time

1. Remove the informative material.

- 2. Remove the protective foil and transit bolts, e.g. remove the adhesive strips and carton.
- 3. Clean the appliance for the first time. → Page 23


# 4.5 Connecting the appliance to the electricity supply

- Insert the mains plug of the appliance's power cable in a socket nearby.
  - The connection data of the appliance can be found on the rating plate.
  - → "Appliance", Fig. 1/5
    Page 12
- **2.** Check the mains plug is inserted properly.
- ▼ The appliance is now ready for use.


### 5 Familiarising yourself with your appliance

#### 5.1 Appliance

You can find an overview of the parts of your appliance here.



Deviations between your appliance and the diagrams may differ with regard to their features and size.





- 2 Snack container → Page 131
- 3 Inner ventilation openings
- Temperature controller (storage container) → Page 16
- 5 Rating plate → Page 33
- 6 Storage container → Page 13
- Fruit and vegetable container
  with humidity control
  → Page 13

- Frozen food container


  → Page 24
- 9 Ice cube maker → Page 14
- 10 Screw foot
- Butter and cheese compartment

  → Page 14<sup>1</sup>
- 12 Control panel → Page 12
- Door tray for large bottles

  → Page 14

#### 5.2 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- 2
- Displays the set temperature for the refrigerator compartment in °C.
- Displays the set temperature for the freezer compartment in °C.
- alarm switches the warning signal off.
- switches the connection to the WLAN home network (Wi-Fi) on or off.
- The light bar provides visual feedback.
- eco switches energy-saving mode on or off.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

- holiday switches holiday mode on or off.
- fresh switches freshness mode on or off.
- ① switches the appliance on or 9 off.

#### 6 Features

The features of your appliance depend on the model.

#### 6.1 Shelf


To vary the shelf as required, you can remove the shelf and re-insert it elsewhere.

→ "Removing the shelf", Page 23

#### 6.2 Snack container

Store packaged food or small snacks in the snack container.

You can remove the snack container. To do this, pull out and remove the snack container. You can move the holder for the snack container.




- ரி lights up if user-defined set-
- tings have been set via the 10 Home Connect app. You can find more information in the Home Connect app.
- super (Freezer compartment) 111 switches Super freezing on or
- super (Refrigerator compart-12 ment) switches Super cooling on or off.

#### 6.3 Storage container

The temperatures in the storage container are lower than in the refrigerator compartment. Temperatures below 0 °C may occur occasionally. In order to reach temperatures close to 0 °C in the storage container, set the refrigerator compartment temperature to 2 °C. → Page 16 Use the lower temperatures in the storage container to store highly perishable food, e.g. fish, meat and sausages.

#### 6.4 Fruit and vegetable container with humidity control

Store fresh fruit and vegetables loose in the fruit and vegetable container. Cover any chopped fruit and vegetables, or store in air-tight packaging. You can adjust the humidity in the fruit and vegetable container using the humidity controller and a special seal. This allows fresh fruit and vegetables to be stored for up to twice as long as with conventional storage.



The air humidity in the fruit and vegetable container can be set according to the type and amount of food to be stored by pressing the humidity controller:

- Push in and engage for low humidity & when primarily storing fruit or mixed items, or if the appliance is very full.
- Release for high humidity & & when primarily storing vegetables or when the appliance is not very full.

Condensation may form in the fruit and vegetable container depending on the food and quantity stored. Remove the condensation with a dry cloth and adjust the air humidity to a lower setting using the humidity controller.

To ensure that the quality and aroma are retained, store fruit and vegetables that are sensitive to cold outside of the appliance at temperatures of approx. 8 °C to 12 °C, e.g. pineapple, bananas, citrus fruits, cucumbers, courgettes, peppers, tomatoes and potatoes.

# 6.5 Butter and cheese compartment

Store butter and hard cheese in the butter and cheese compartment.

#### 6.6 Door tray

To adjust the door tray as required, you can remove the door tray and reinsert elsewhere.

→ "Removing door tray", Page 24


#### 6.7 Ice cube maker

Use the ice cube maker to make ice cubes out of drinking water.

#### Making ice cubes

Use only drinking water to make ice cubes.


Remove the ice cube tray ①, fill ¾
full with drinking water ② and reinsert ③.




**Note:** If it is filled with too much drinking water, this may impair the function of the ice cube maker. The ice cubes cannot be removed individually from the ice cube tray. Too much drinking water was added and is running into the ice cube container, causing any ice cubes to freeze together.

2. When the ice cubes are frozen, rotate the knob on the ice cube tray

several times in a clockwise direction and release it.



- The ice cubes will loosen and fall into the ice cube container.
- 3. Pull out the ice storage container and remove the ice cubes.



#### 6.8 Accessories

Use original accessories. These have been made especially for your appliance.


The accessories for your appliance depend on the model.

#### Egg tray

Store eggs safely on the egg tray.


#### **Bottle holder**

The bottle holder prevents bottles from falling over when the appliance door is opened and closed.



#### Variable bottle shelf

Store bottles securely on the variable bottle shelf.



### 7 Basic operation

### 7.1 Switching on the appliance

1. Electrically connect the appliance. → Page 10

**Note:** If the appliance has been previously switched off using the control panel, press and hold ① for three seconds.

- ✓ The appliance begins to cool.
- ✓ A warning signal sounds and the temperature display flashes because the freezer compartment is still too warm.

- **2.** Switch off the warning tone using **alarm**.
- "alarm" goes out as soon as the set temperature has been reached.
- 3. Set the required temperature. → Page 16

#### 7.2 Operating tips

- Once you have switched on the appliance, the set temperature is only reached after several hours.
   Do not put any food in the appliance until the set temperature has been reached.
- The front panels of the housing are temporarily heated slightly. This prevents condensation in the area of the door seal.
- When closing the door, make sure that the door is not blocked by stored items.
- When you close the door, a vacuum may be created. The door is then difficult to open again. Wait a moment until the vacuum is offset.
- The temperature in the appliance varies due to the following conditions:
  - How often the appliance is opened
  - Load capacity
  - Temperature of newly stored food
  - Ambient temperature
  - Direct sunlight

#### 7.3 Switching off the appliance

▶ Press and hold ① for 3 seconds.

#### 7.4 Setting the temperature

# Setting the refrigerator compartment temperature


► Press the required temperature. To reach the set temperature, slide the temperature controller for the storage container to a position that is one third from the bottom.

→ Page 16

The recommended temperature in the refrigerator compartment is 4 °C.

# Setting the storage container temperature

- ► Select one of the options:
  - ► To reduce the temperature, move the temperature controller up towards "extra cold".
  - To increase the temperature, move the temperature controller down towards "cold".



# Setting the freezer compartment temperature

► Press the required temperature. The recommended temperature in the freezer compartment is -18 °C.

#### 8 Additional functions

Find out which additional functions can be used for your appliance.

#### 8.1 Super cooling

With Super cooling, the refrigerator compartment cools as cold as possible.

Switch on Super cooling before placing large quantities of food in the refrigerator compartment.

Note: When Super cooling is switched on, increased noise may occur.

#### Switching on Super cooling

- ► Press **super** (Refrigerator compartment).
- ✓ "super" (Refrigerator compartment) lights up.

Note: After approx. 6 hours, the appliance switches to normal operation.

#### Switching off Super cooling

► Press **super** (Refrigerator compartment).

### 8.2 Super freezing

With Super freezing, the freezer compartment cools as cold as possible. Switch on Super freezing four to six hours before placing food weighing 2 kg or more into the freezer compartment.

**Note:** When Super freezing is switched on, increased noise may occur.

#### Switching on Super freezing

- Press super (Freezer compartment).
- ✓ "super" (Freezer compartment) lights up.

**Note:** After approx. 54 hours, the appliance switches to normal operation.

#### Switching off Super freezing

▶ Press **super** (Freezer compartment).

#### 8.3 Holiday mode

If you are going to be away for a long time, you can switch on energy-saving holiday mode on the appliance.

#### ⚠ CAUTION

#### Risk of harm to health!

The refrigerator compartment heats up while the holiday mode is switched on. The increased temperature may cause bacteria to increase and spoil the food.

When the holiday mode is switched on, do not store any food in the refrigerator compartment.

The appliance automatically sets the temperatures.

partment	14 °C
Freezer compart-	Temperature re-
ment	mains unchanged

#### Switching on holiday mode

- Press holidav.
- "holiday" lights up.

#### Switching off holiday mode

Press holiday.

#### 8.4 Energy-saving mode

You can set the appliance to save energy with the energy-saving mode. The appliance automatically sets the temperatures.

Refrigerator com- 8 °C partment Freezer compart- -16 °C

#### Switching on energy-saving mode

Press eco.

ment

✓ "eco" lights up.

#### Switching off energy-saving mode

Press eco.

#### 8.5 Freshness mode

In order to keep the food fresh for longer, you can switch on the freshness mode on the appliance.

The appliance automatically sets the temperatures.

Refrigerator com-	2 °C
partment	
Freezer compart-	
ment	mains unchanged

#### Switching freshness mode on

- ► Press fresh.
- ✓ "fresh" lights up.

#### Switching off freshness mode

Press fresh.

#### 9 Alarm

#### 9.1 Door alarm

If the appliance door is open for a while, the door alarm switches on. A warning tone sounds, "alarm" flashes, the light bar flashes and the temperature display for the affected compartment flashes.

#### Switching off the door alarm

- Close the appliance door or press alarm.
- ▼ The warning tone is switched off.

#### 9.2 Temperature alarm

If the freezer compartment becomes too warm, the temperature alarm is switched on.

A warning tone sounds and the set temperature (freezer compartment), "alarm" and the light bar flash.

#### **△** CAUTION

#### Risk of harm to health!

During the thawing process, bacteria may multiply and spoil the frozen food.

- Do not refreeze food after it has been defrosted or started to defrost.
- Refreeze food only after cooking.
- These items should no longer be stored for the maximum storage period.

The temperature alarm can be switched on in the following cases:

- The appliance is switched on.
   Do not store any food until the appliance has reached the set temperature.
- Large quantities of fresh food are being placed inside.
   Switch on Super freezing before placing large quantities of food in the appliance.
- The freezer compartment door is open for too long.
   Check whether the frozen food has defrosted or thawed.

# Switching off the temperature alarm

- Press alarm.
- ✓ The warning tone is switched off.

### 10 Home Connect

This appliance is network-capable. Connect your appliance to a mobile device to control its functions via the Home Connect app.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of the Home Connect services in your coun-

try. You can find information about this at: www.home-connect.com. To be able to use Home Connect. vou must first set up the connection to the WLAN home network (Wi-Fi<sup>1</sup>) and to the Home Connect app. After switching on the appliance, wait at least 2 minutes until internal device initialisation is complete. Only then should you set up Home Connect. The Home Connect app guides you through the entire login process. Follow the instructions, noting the information in the Home Connect app.

#### Notes

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app. → "Safety", Page 3
- Operating the appliance on the appliance itself always takes priority. During this time it is not possible to operate the appliance using the Home Connect app.

### 10.1 Setting up Home Connect

Requirement: The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.

1. Scan the following QR code.



You can install the Home Connect app and connect your appliance via the QR code.

2. Follow the instructions in the Home Connect app.

### 10.2 Switching on the connection to the WLAN home network (Wi-Fi)

▶ Press 🛜.

### 10.3 Switching off the connection to the WLAN home network (Wi-Fi)

▶ Press 🗟.

#### 10.4 Installing updates for the **Home Connect software**

Note: If an update of the Home Connect software is available, a message appears in the Home Connect app.

- ► To install the update for the Home Connect software, follow the instructions in the Home Connect app.
- ▼ The control panel is partially locked during the installation.

#### 10.5 Resetting Home Connect settinas

If your appliance experiences connection problems with the WLAN

<sup>&</sup>lt;sup>1</sup> Wi-Fi is a registered trademark of the Wi-Fi Alliance.

home network (Wi-Fi) or your appliance wants to log into a different WLAN home network (Wi-Fi), you can reset the Home Connect settings.

- ► Press and hold 🥱 for six seconds until 🐬 goes out.
- ▼ The Home Connect settings have been reset.

#### 10.6 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the installed Wi-Fi communication module).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous resetting to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

**Note:** Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

### 11 Refrigerator compartment

You can keep meat, sausage, fish, dairy products, eggs, prepared meals and pastries in the refrigerator compartment.

The temperature can be set from 2 °C to 8 °C.

The refrigerator compartment can also be used to store highly perishable foods in the short to medium term. The lower the selected temperature, the longer the food remains fresh.

# 11.1 Tips for storing food in the refrigerator compartment

- Only store food when fresh and undamaged.
- Store food covered or in air-tight packaging.
- To avoid impeding the circulation of air and to prevent food from freezing, do not place food in front of the inner ventilation openings or in direct contact with the back wall.
- Allow hot food and drinks to cool down first before placing in the appliance.
- Observe the best-before date or use-by date specified by the manufacturer.

# 11.2 Chill zones in the refrigerator compartment

The air circulation in the refrigerator compartment creates different chill zones.

#### Coldest zone

The coldest zone is in the storage container.

Tip: Store highly perishable food such as fish, sausages and meat in the coldest zone.

#### Warmest zone

The warmest zone is at the very top of the door.

**Tip:** Store food that does not spoil easily in the warmest zone, e.g. hard cheese and butter. Cheese can then continue to release its aroma and the butter will still be easy to spread.

### 12 Freezer compartment

You can store frozen food, freeze food and make ice cubes in the freezer compartment.

The temperature can be set from -16 °C to -24 °C.

Long-term storage of food should be at -18 °C or lower.

The freezer compartment can be used to store perishable food longterm. The low temperatures slow down or stop the spoilage.

### 12.1 Fully utilising the freezer compartment volume

Learn how to store the maximum amount of frozen food in the freezer compartment.

- 1. Remove all fittings from the freezer compartment. → Page 23
- 2. Store food directly on the shelves and on the floor of the freezer compartment.

### 12.2 Tips for storing food in the freezer compartment

- Store food in air-tight packaging.
- Do not bring food which is to be frozen into contact with frozen food.

- Place the food over the whole area of the frozen food containers.
- To ensure that the air can circulate freely in the appliance, push the frozen food containers in as far as they will go.

#### 12.3 Tips for freezing fresh food

- Freeze fresh and undamaged food only.
- Freeze food in portions.
- Cooked food is more suitable than food that can be eaten raw.
- Vegetables: Wash, chop up and blanch before freezing.
- Fruit: Wash, pit and perhaps peel, possibly add sugar or ascorbic acid solution.
- Food that is suitable for freezing includes baked items, fish and seafood, meat, game, poultry, eggs without shells, cheese, butter and guark, ready meals and leftovers.
- Food that is unsuitable for freezing includes lettuce, radishes, eggs in shells, grapes, raw apples and pears, yoghurt, sour cream, crème fraîche and mayonnaise.

#### Packing frozen food

If you select suitable packaging material and the correct type of packaging, you can determine the product quality and prevent freezer burn.

- 1. Place the food in the packaging.
- 2. Squeeze out the air.
- 3. Pack food airtight to prevent it from losing flavour and drying out.
- 4. Label the packaging with the contents and the date of freezing.

# 12.4 Shelf life of frozen food at -18 °C

Food	Storage time
Fish, sausages, pre- pared meals and baked goods	up to 6 months
Poultry, meat	up to 8 months
Vegetables, fruit	up to 12 months

The imprinted freezer calendar indicates the maximum storage duration in months at a constant temperature of –18 °C.

# 12.5 Defrosting methods for frozen food

# ⚠ CAUTION Risk of harm to health!

During the thawing process, bacteria may multiply and spoil the frozen food.

- Do not refreeze food after it has been defrosted or started to defrost.
- ► Refreeze food only after cooking.
- These items should no longer be stored for the maximum storage period.
- Defrost animal-based food, such as fish, meat, cheese, quark, in the refrigerator compartment.
- Defrost bread at room temperature.
- Prepare food for immediate consumption in the microwave, in the oven, or on the hob.

### 13 Defrosting

#### 13.1 Defrosting in the refrigerator compartment

The refrigerator compartment in your appliance defrosts automatically.

# 13.2 Defrosting in the freezer compartment

The fully automatic NoFrost system ensures that the freezer compartment remains frost-free. Defrosting is not required.

### 14 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully. Customer Service must clean inaccessible points. Cleaning by customer service can give rise to costs.

# 14.1 Preparing the appliance for cleaning

- 1. Switch off the appliance.
  - → Page 16
- 2. Disconnect the appliance from the power supply.
  - Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- 3. Take out all of the food and store it in a cool place.
  - Place ice packs (if available) onto the food.
- **4.** Remove all fittings and accessories from the appliance.
  - → Page 23
- **5.** Remove the shelf above the fruit and vegetable container.
  - → Page 25

#### 14.2 Cleaning the appliance

#### **⚠ WARNING**

#### Risk of electric shock!

An ingress of moisture can cause an electric shock.

► Do not use steam- or high-pressure cleaners to clean the appliance.

Liquid in the lighting, controls or inner ventilation openings can be danaerous.

► The rinsing water must not drip into the lighting, controls or inner ventilation openings.

#### **ATTENTION**

Unsuitable cleaning products may damage the surfaces of the appliance.

- ► Do not use hard scouring pads or cleaning sponges.
- ► Do not use harsh or abrasive detergents.
- ► Do not use cleaning products with a high alcohol content.

If you clean fittings and accessories in the dishwasher, this may cause them to become deformed or discol-


- Never clean fittings and accessory in the dishwasher.
- 1. Prepare the appliance for cleaning. → Page 22
- 2. Clean the appliance, the fittings, the accessories and the door seals with a dish cloth, lukewarm water and a little pH-neutral washing-up liauid.
- 3. Dry thoroughly with a soft, dry cloth.
- 4. Insert the fittings and install the removable appliance parts.
- **5.** Electrically connect the appliance. → Page 10
- 6. Putting the food into the appliance.

#### 14.3 Removing the fittings

If you want to clean the fittings thoroughly, remove these from your appliance.


#### Removing the shelf

▶ Pull out and remove the shelf.




#### Removing the snack container with holder

- Remove the snack container.
- 2. Remove the shelf with the holder.
- 3. Slide the holder sideways off the shelf.




#### Removing door tray

► Lift the door tray and remove it.




#### Removing the storage container

- **1.** Pull out the storage container as far as it will go.
- **2.** Lift the storage container at the front ① and remove it ②.




## Removing the fruit and vegetable container

- 1. Pull out the fruit and vegetable container as far as it will go.
- Lift the fruit and vegetable container at the front ① and remove it ②.



# Removing the frozen food container


- 1. Take out the frozen food container as far as it will go.
- **2.** Lift the frozen food container at the front ① and remove it ②.



# Removing the front of the container


You can remove the front of the fruit and vegetable container to facilitate cleaning.

▶ Press in the snap-in hooks on the side of the container ① and remove the front from the container in a turning motion ②.




#### Removing the ice cube maker

 Remove and empty the ice cube tray ① and the ice storage container ②.




2. Press the push-button ① to release the ice cube maker from the holder and remove the ice cube maker ②.



3. Lift the rear end of the holder and lower it behind the freezer com-

partment shelf ①. Remove the holder towards the front ②.



# 14.4 Removing appliance components

If you want to clean your appliance thoroughly, you can remove certain components from your appliance.


## Shelf above the fruit and vegetable container

You can remove the cover of the fruit and vegetable container in order to clean it thoroughly.

# Removing the shelf above the fruit and vegetable container


- 1. Remove the fruit and vegetable container. → Page 24
- 2. Remove the storage container.

  → Page 24
- Tilt the shelf above the fruit and vegetable container to the side ① and remove it ②.




en Cleaning and servicing

**4.** Lift the fruit and vegetable container cover ① and remove it ②.




# Fitting the shelf above the fruit and vegetable container


**1.** Clip the fruit and vegetable container cover in place.




2. Tilt the shelf above the fruit and vegetable container to one side to insert it ① and then lower ②.




**3.** Move the humidity controller to the front.





Make sure that the fruit and vegetable container cover sits in the opening under the humidity controller.

**4.** Insert the storage containers and the fruit and vegetable containers.



### 15 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

#### **⚠** WARNING

#### Risk of electric shock!

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ► If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting
The appliance is not cooling, the displays and lighting are lit.	<ol> <li>Showroom mode is switched on.</li> <li>Switch off the appliance. → Page 16</li> <li>Wait 2 minutes.</li> <li>Switch the appliance back on. → Page 15</li> <li>Wait 1 minute and then press and hold super (Refrigerator compartment) until 4 audible signals have sounded.</li> <li>After a short time, check whether your appliance is cooling.</li> </ol>
The LED lighting does not work.	Different causes are possible.  ► Call customer service.  The customer service number can be found in the enclosed customer service directory.
The refrigeration unit is switching on more	The appliance has been opened frequently.  Do not open appliance door unnecessarily.
frequently and for longer.	<ul> <li>External ventilation openings are covered up.</li> <li>Remove any obstructions from in front of the external ventilation openings.</li> </ul>
	Not a fault. Modern refrigeration machines switch on more frequently and have different power levels to cool more efficiently.  Remove any obstructions from in front of the ex-

ternal ventilation openings.

#### en Troubleshooting

Fault	Cause and troubleshooting
The refrigeration unit is switching on more frequently and for longer.	<ul> <li>Cause and troubleshooting</li> <li>Install the appliance as far away as possible from heating elements, cookers and other heat sources. Avoid prolonged exposure of the appliance to direct sunlight.</li> <li>Only open the appliance door as briefly as necessary.</li> <li>Allow hot food and drinks to cool down first before storing in the appliance.</li> </ul>
A layer of frost forms on the back wall of the refrigerator compartment.	Not a fault. Modern refrigeration machines ensure a more even temperature in the refrigerator compartment. The back wall of the refrigerator compartment is defrosted automatically at regular intervals.
	<ul> <li>Only open the appliance door as briefly as necessary.</li> <li>Pack the food airtight or cover it.</li> <li>Allow hot food and drinks to cool down first before storing in the appliance.</li> <li>Always leave some space between the food and the interior walls.</li> </ul>
Side panels of the appliance are warm.	Not a fault. The side panels contain pipes which heat up during the cooling process. Units touching the appliance will not be damaged by the heat. No action required.
Home Connect is not working properly.	Different causes are possible.  • Go to www.home-connect.com.
A warning tone sounds and the temperature display (refrigerator compartment), "alarm" and the light bar flash. The door alarm is switched on.	The refrigerator compartment door is open.  Close the refrigerator compartment door.

Fault	Cause and troubleshooting
A warning tone sounds and the temperature display (freezer compartment), "alarm" and the light bar flash. The door alarm is switched on.	The freezer compartment door is open.  Close the freezer compartment door.
A warning tone sounds and the set temperature (freezer compartment), "alarm" and the light bar flash. The temperature	Different causes are possible.  ► Press alarm.  ✓ The alarm is switched off.  External ventilation openings are covered up.  ► Remove any obstructions from in front of the external ventilation openings.
alarm is switched on.	Larger quantities of fresh food have been put in.  ▶ Do not exceed the max. freezing capacity.
The set temperature is not reached. Fully automatic defrosting no longer works.	The freezer compartment door was open for a long time. The evaporator (refrigeration unit) in the noFrost system is heavily iced up. <b>Requirement:</b> Store the frozen food well insulated in a cool place.


_			-
<b>⊢</b> :	ลเ	П	t

#### Cause and troubleshooting

The set temperature is not reached. Fully automatic defrosting no longer works.

- **1.** Switch off the appliance.  $\rightarrow$  *Page 16*
- 2. Disconnect the appliance from the mains.

  Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- 3. Move the appliance away from the wall.
- 4. Leave the appliance door open.
- After approx. 20 minutes, the condensation starts to run into the evaporation pan at the rear of the appliance.



- 5. To prevent the evaporation pan from overflowing, mop up the condensation water with a sponge. The evaporator is defrosted if no more condensation water runs into the evaporation pan.
- **6.** Clean the interior of the appliance.  $\rightarrow$  *Page 23*
- 7. Switch the appliance back on. → Page 15

The temperature differs greatly from the setting.

Different causes are possible.

- 1. Switch off the appliance. → Page 16
- 2. Switch the appliance back on after five minutes. 
  → Page 15
  - ► If the temperature is too warm, check the temperature again after a couple of hours.
  - ► If the temperature is too cold, check the temperature again on the following day.

Condensation accumulates on the surface of the appliance and on the shelves inside.

The water contained in warm and humid air condenses on the colder surfaces of the appliance.

- Wipe away the condensation water with a soft, dry cloth.
- 2. Open the appliance as briefly as possible.
- **3.** Ensure that the appliance is always closed properly.

The appliance hums, bubbles, buzzes, gargles, clicks or crackles.

Not a fault. A motor is running, e.g. refrigerating unit, fan. Refrigerant flows through the pipes. The motor, switches or solenoid valves are switching on or off. Automatic defrosting is running. No action required.

#### Fault

The appliance makes noises.



#### Cause and troubleshooting

The appliance is not level.

 Align the appliance using a spirit level and the screw feet.

The appliance is not free-standing.

► Observe the minimum clearances for the appliance.

Fittings wobble or stick.

Check the removable fittings and, if required, replace these.

Bottles or containers are touching.

 Move the bottles or containers away from each other.

Super freezing is switched on. No action required.

#### 15.1 Power failure

During a power failure, the temperature in the appliance rises; this reduces the storage time and the quality of the frozen food.

#### **Notes**

- Open the appliance as little as possible during a power failure and do not place any other food in the appliance.
- Check the quality of the food immediately after a power failure.
  - Dispose of any frozen food that has defrosted and is hotter than 5 °C.
  - Cook or fry slightly thawed frozen food, and then either consume it or freeze it again.

# 15.2 Conducting an appliance self-test

Your appliance has an appliance selftest which displays faults that can be eliminated by your customer service.

- **1.** Switch off the appliance.
  - → Page 16

- Disconnect the appliance from the power supply. Unplug the appliance from the mains or switch off the circuit
- 3. Electrically reconnect the appliance after 5 minutes. → Page 10

breaker in the fuse box.

- 4. One minute after connecting to the power supply, press and hold super (Refrigerator compartment) for 3 to 5 seconds until a second audible signal sounds.
- ✓ If, at the end of the appliance selftest, 2 audible signals sound and the temperature display indicates the set temperature, the temperature sensors on your appliance are OK. The appliance switches to normal operation.
- ✓ If, at the end of the appliance selftest, 5 audible signals sound and the temperature display LEDs light up with a different brightness, inform customer service. The LEDs provide customer service with information about this fault.

### 16 Storage and disposal

#### 16.1 Taking the appliance out of operation

- 1. Switch off the appliance. → Page 16
- 2. Disconnect the appliance from the power supply. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- 3. Remove all of the food.
- **4.** Clean the appliance.  $\rightarrow$  *Page 23*
- 5. To guarantee the ventilation inside the appliance, leave the appliance open.

#### 16.2 Disposing of old appliance

Valuable raw materials can be reused by recycling.

### **⚠ WARNING**

#### Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Leave shelves and containers inside the appliance to prevent children from climbina in.
- ► Keep children away from the redundant appliance.

#### ⚠ WARNING Risk of fire!

If the tubes are damaged, flammable refrigerant and harmful gases may escape and ignite.

- ► Do not damage the tubes of the refrigerant circuit or the insulation.
- 1. Unplug the appliance from the mains.

- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



Dispose of packaging in an environmentally-responsible manner. This appliance is certified in accordance with the quidelines on E-waste (Management) Rules 2022 which govern waste electrical and electronic equipment.

The guideline provide a framework for the return and recycling of used appliances.

**Note:** This product doesn't contain any of hazardous substances as specified in the e-waste Management and Handling Rules 2022. Dos

- Please visit our website https://www.boschhome.in/metapages/ewaste-management to find out more details. regarding e-waste dis-
- Keep the product in isolated area, after it becomes non-functional/un-repairable so as to prevent its accidental breakage.

posal.

 Consult the authorized service center as to whether the Electronic Equipment can be repaired or not, before discarding.

- Consult the retailer about appliance take back schemes.

#### Don'ts

- The product should not be opened by the user himself/herself. but only by authorized service personnel.
- The product is not meant for re-sale to any unauthorized agencies/scrap dealers/ kabariwalah.
- Don't dispose of the discarded Electronic Equipment in household bins or Municipal hins
- Don't dump the discarded Flectronic Equipment in the open or in any land fill site, as this will result in contamination of the soil and the ground water.
- Do not keep any replaced spare part(s) from the product in exposed area.

### 17 Customer Service

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

If you contact Customer Service, you will require the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) of vour appliance.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website. Helpline no.: 1800-266-1880

(Monday to Saturday - 8 am to (mg 8 Fmail ID: service.in@bosch-

home.com Chat with us (WhatsApp):



### 17.1 Product number (E-Nr.), production number (FD) and consecutive numbering (Z-Nr.)

You can find the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) on the appliance's rating plate.

→ "Appliance", Fig. 1 / 5 Page 12 Make a note of your appliance's details and the Customer Service telephone number to find them again auickly.

#### 18 Technical data

Refrigerant, cubic capacity and further technical specifications can be found on the rating plate.

→ "Appliance", Fig. 1 / 5 Page 12

#### 18.1 Information regarding Free and Open Source Software

This product includes software components that are licensed by the

#### en Declaration of Conformity

copyright holders as free or open source software.

The applicable licence information is stored on your home appliance. You can also access the applicable licence information via your Home Connect app: "Profile -> Legal information -> Licence Information". ¹ You can download the licence information on the brand product website. (Please search on the product website for your appliance model and additional documents). Alternatively, you can request the relevant information from oss-request@bshq.com or BSH Hausger-

äte GmbH, Carl-Wery-Str. 34, 81739 Munich, Germany.

The source code will be made available to you on request.

Please send your request to oss-request@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str.34, 81739 Munich, Germany.

Subject: "OSSREQUEST"

The cost of performing your request will be charged to you. This offer is valid for three years from the date of purchase or at least as long as we offer support and spare parts for the relevant appliance.

### 19 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the essential requirements and other relevant provisions of Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at *www.bosch-home.com* among the additional documents on the product page for your appliance.

CE

2.4 GHz band (2400–2483.5 MHz): Max. 100 mW 5-GHz band (5150–5350 MHz + 5470–5725 MHz): max. 130 mW

	BE	BG	CZ	DK	DE	EE	ΙΕ	EL	ES
	FR	HR	IT	CY	LI	LV	LT	LU	HU
	MT	NL	AT	PL	PT	RO	SI	SK	FI
	SE	NO	CH	TR	IS	UK (NI)		•	
5 GH	5 GHz WI AN (Wi-Fi): For indoor use only								

5 GHz WLAN (Wi-Fi): For indoor use only.

AL	ВА	MD	ME	MK	RS	UK	UA	
5 GHz WLAN (Wi-Fi): For indoor use only.								

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications





# Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- · Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome** 



# Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you:

#### www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

#### **BSH Hausgeräte GmbH**

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com

A Bosch Company



9001731119 (050630)