





WGG2449RAU

[en] User manual and installation instructions



You can find additional information and explanations online. Scan the QR code on the title page.

Table of contents

1 Safety	. 3
1.1 General information	
1.2 Intended use	. 3
1.3 Restriction on user group	. 3
1.4 Safe installation	. 4
1.5 Safe use	. 6
1.6 Safe cleaning and mainten-	
ance	. 8
2 Preventing material damage	. 8
3 Environmental protection and	
saving energy	10
3.1 Disposing of packaging	10
3.2 Save energy and conserve re-	
sources	10
3.3 Energy saving mode	10
4 Installation and connection	10
4.1 Unpacking the appliance	10
4.2 Contents of package	10
4.3 Requirements for the installa-	
tion location	11
4.4 Removing the transit bolts	11
4.5 Connecting the appliance	12
4.6 Aligning the appliance	13
5 Before using for the first time	14
5.1 Starting an empty washing	
cycle	14
6 Familiarising yourself with	
your appliance	15
6.1 Appliance	15
6.2 Detergent drawer	16
6.3 Control panel	17
7 Display	17
8 Buttons	19
9 Programmes	21
10 Accessories	24



11 Laundry	25
11.1 Preparing the laundry	25
11.2 Care symbols on the care la-	
bels	25
12 Detergents and care	
products	25
13 Basic operation	26
13.1 Switching on the appliance	26
13.2 Setting a programme	26
13.3 Opening the door	26
13.4 Loading laundry	26
13.5 Inserting the measuring aid	26
13.6 Using the measuring aid	27
13.7 Adding detergent and care	
product	27
13.8 Starting the programme	27
13.9 Soaking laundry	
13.10 Adding laundry	
13.11 Cancelling the program-	
me	28
13.12 Resuming the programme	
when the programme status	
is Rinse Hold	28
13.13 Unloading the laundry	28
13.14 Switching off the appli-	
ance	28
14 Childproof lock	29
14.1 Activating the childproof	
lock	29
14.2 Deactivating the childproof	
lock	29
15 Basic settings	29
15.1 Overview of the basic set-	
tings	29
15.2 Changing the basic set-	-
tings	29
16 Cleaning and servicing	30

16.1 Cleaning the drum 16.2 Cleaning the detergent	30
drawer 16.3 Cleaning the drain pump 16.4 Cleaning the rubber gasket	31
	_
17 Troubleshooting 17.1 Emergency release 17.2 Restart the appliance	39

18.1 Removing the appliance 39

A 1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- with tap water and commercially available detergents and care products suitable for washing machines.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or

inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

⚠ WARNING – Risk of electric shock!

Incorrect installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ► When using a residual current circuit breaker, only use a type with the area mark.
- Never equip the appliance with an external switching device, e.g. a timer or remote control.
- When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.
- When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ► Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ► Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.
- If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

The heavy weight of the appliance may result in injury when lifted.

► Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- Do not install a washer-dryer stack on a platform; the appliances may tip over.

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material.

▲ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ► Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level.

If hoses and power cords have been laid incorrectly, this causes a tripping hazard.

Lay hoses and power cords in such a way that there is no risk of tripping. If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

► Do not move the appliance by holding onto protruding parts.

▲ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ► Do not touch the sharp edges on the appliance.
- Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

⚠ WARNING – Risk of electric shock!

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer service. → Page 40

An ingress of moisture can cause an electric shock.

- Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
 When spinning larger, waterproof items of laundry, imbalances may arise and lead to injuries.
- Do not wash and spin larger items of laundry, such as blankets or mattress covers, in the appliance.

⚠ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

⚠ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ► If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

\triangle WARNING – Risk of explosion!

Laundry that has been pretreated with flammable cleaning agents that contain solvents may cause an explosion in the appliance.

Rinse pretreated laundry thoroughly with water before washing.

▲ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ► Do not sit on or lean against the appliance door.
- ► Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

 Wait for the drum to come to a complete stop before reaching inside.

▲ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

► Do not touch the hot detergent solution.

▲ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance.

Contact with eyes or skin may cause irritation.

Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.

- ► If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

▲ WARNING – Risk of electric shock!

Improper repairs are dangerous.

- Never make any technical modifications to the appliance or its features.
- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

- Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

► Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION

The functionality of the appliance may be impaired if you use the

wrong quantity of fabric softener, detergent, care product or cleaning agent.

► Follow the dosage recommendations from the manufacturer. Exceeding the maximum load capacity impairs the function of the appliance.

 Observe the maximum load capacity for each programme and do not exceed it.

 \rightarrow "Programmes", Page 21 The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.

- Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- Before transport, fit the transit bolts fully in order to prevent damage in transit.

Material damage may be caused if the water inlet hose is connected incorrectly.

- Tighten the screw connections on the water inlet until they are handtight.
- Connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions or valves.
- Make sure that the valve housing for the water inlet hose does not come into contact with its surroundings and is not subjected to any external forces.
- Ensure that the inner diameter of the water tap is at least 17 mm.
- Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

 Ensure that the water pressure in the water supply system is at least 100 kPa (1 bar) and max. 1000 kPa (10 bar).

- If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may lead to material damage and damage to the appliance.

 Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

- Choose programs with low temperatures and longer wash times and use maximum load capacity.
 → Page 21
- Add detergent based on the laundry's degree of soiling. Detergent dosage
- Reduce the washing temperature for lightly and normally soiled laundry.
- Set the maximum spin speed if you want to dry the laundry in the tumble dryer afterwards.
- Wash the laundry without prewash.

3.3 Energy saving mode

If you do not use the appliance for a brief period, it automatically switches to energy-saving mode.

Energy-saving mode ends when you use the appliance again.

4 Installation and connection

4.1 Unpacking the appliance ATTENTION

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- 1. Remove any packaging and protective covers completely from the appliance.

 \rightarrow "Disposing of packaging", Page 10

- 2. Check the appliance for visible damage.
- **3.** Open the door. \rightarrow *Page 26*
- 4. Remove any accessories from the drum.
- 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- Do not operate the appliance with incomplete or defective accessories.
- Replace the accessories in question before operating the appliance.

→ "Accessories", Page 24

Note: The appliance has undergone a function test at the factory. This may cause water stains in the appliance, which the first wash cycle removes.

The delivery consists of the following:

- Washing machine
- Accompanying documents
- Transit bolts

 → "Removing the transit bolts", Page 11
- Cover caps
- Water inlet hose
 → "Connecting the water inlet
 hose", Page 12
- Elbow for securing the water outlet hose

4.3 Requirements for the installation location

⚠ WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

 Do not operate the appliance without a cover cap.

⚠ WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 25 before using the appliance for the first time.

ATTENTION

If residual water in the appliance freezes, this may cause damage to the appliance.

 Do not install or operate this appliance anywhere that is liable to experience frost or outdoors. If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- Tilt the appliance carefully.
- Transport the appliance in an upright position.

Installation loca- Requirements tion

Base



Secure the appliance with fixing brackets \rightarrow Page 25.

Wooden joist

floor



Place the appliance on a waterresistant wooden board (minimum thickness of 30 mm) which is screwed tightly to the floor.



Only install the appliance underneath a continuous worktop that is securely connected to adjacent cabinets. Required niche width: 60 cm.

Against a wall



Do not trap the power cord or the hoses between the wall and the appliance.

4.4 Removing the transit bolts

The appliance is secured for transportation using transit bolts on the rear of the appliance. **Note:** Keep the transit bolt screws and the sleeves in a safe place for future transport.

 \rightarrow "Inserting the transit bolts", Page 40

1. Pull the hose out of the holders.



2. Unscrew ① and remove ② all of the screws for the 4 transit bolts using a WAF 13 wrench.



3. Remove the power cable from the holder.



4. Remove the 4 sleeves.



5. Insert the 4 cover caps 1 and push them downwards 2.



Note: To install the transit bolts to transport the appliance, perform these steps again in the reverse order.

4.5 Connecting the appliance

Connecting the water inlet hose ATTENTION

Material damage may be caused if the water inlet hose is connected incorrectly.

 Tighten the screw connections on the water inlet until they are handtight. 1. Connect the water inlet hose.



2. Connect the water inlet hose to a tap (26.4 mm = 3/4").



3. Open the water tap carefully and check that the connection points are tight.

Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.

ATTENTION

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

 Secure the water outlet hose against unintentional loosening.
 In the event of a blocked or covered.

outlet, accumulated wastewater can flow back into the appliance.

 Before operating the appliance, ensure that the wastewater drains away quickly and eliminate any blockages. **Note:** Observe the draining heights. The maximum draining height is 100 cm.



Sink



Fix and secure the water outlet hose with an elbow. → "Accessories", Page 25

Plastic pipe with rubber sleeve or gully



Fix and secure the water outlet hose with an elbow. → "Accessories"

→ "Accessories", Page 25

Connecting the appliance to the electricity supply

Note: Your electrical domestic installation for this appliance must comply with the local legal provisions and safety regulations, and should include a residual current circuitbreaker.

 Insert the mains plug of the appliance's power cable in a socket nearby.

The connection details of the appliance can be found under Technical data $\rightarrow Page 43$.

2. Check the mains plug is inserted properly.

4.6 Aligning the appliance

In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

1. Use a WAF 17 wrench to loosen the lock nuts in a clockwise direction.



2. To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

3. Use a WAF 17 wrench to tighten the lock nuts against the housing until they are hand-tight.



In doing so, hold the foot tight and do not adjust its height.

5 Before using for the first time

Prepare the appliance for use.

5.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

- **2.** Close the door.
- 3. Pull out the detergent drawer.
- **4.** Pour approx. 1 litre of tap water into compartment II.



5. Add washing powder containing oxygen bleach to compartment II.



To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

- 6. Push in the detergent drawer.
- **7.** Start the programme. \rightarrow *Page 27*
- Start the first wash cycle or set the programme selector to Off to switch off the appliance.
 - → "Basic operation", Page 26

6 Familiarising yourself with your appliance

6.1 Appliance

You can find an overview of the parts of your appliance here.



On certain models, specific details such as the colour and shape may differ from those pictured.

en Familiarising yourself with your appliance

- Maintenance flap for the drain pump \rightarrow *Page 31*
- 2 Door \rightarrow Page 26
- 3 Detergent drawer \rightarrow Page 16

6.2 Detergent drawer

Note: Observe the manufacturer's instructions on the use and dosage of the detergent and care product and the information in the programme descriptions.



4	Control panel → Page 17
5	Water outlet hose \rightarrow Page 13
6	Power cord → <i>Page 13</i>
7	Transit bolts → <i>Page 11</i>
1	Measuring aid for liquid deter- gent → <i>Page 26</i>
2	Compartment II: Detergent for the main wash
3	Compartment %: Fabric softener
4	Compartment I: Detergent for prewash

6.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



7 Display

The display shows the current settings, options or relevant information.

en Display

Depending on the programme status, the display shows some information in the B:BB area, e.g. E $\neg d.$

ب ۲ ۵.	90° 60° 40° 30° 20° ₩	1400 1200 800 600 400 Ø		L Æ		0	DM Start/ Reload
۲ AntiStain	₽ Temp. °C	ි Spin Speed	ව Easy Iron	↓ Prewash	Rinse Plus	Finished in	- ≕ ᠿ Speed Perfect

Example: Display

Display	Description
0:40 1	Expected programme duration or programme time re- maining in hours and minutes.
"10" / — (() Fin- ished in) ¹	Program end time → "Buttons", Page 20
9.0 ¹	Recommendation for the maximum load capacity for the selected program in kg.
<u></u> - 1400	Set spin speed in rpm. <i>→Page 20</i> Ø: No final spin, only draining
₩ - 90	Set temperature in °C. <i>→Page 20</i> � (cold)
— (DII Start/Re- load)	 Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be started or continued.
L	Programme status: Prewashing
\	Programme status: Washing
	Programme status: Rinsing
6	Programme status: Spinning

Display	Description
End	Programme status: Programme end
سر)	 Lights up: The childproof lock is activated. Flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 29
🗕 (🛆 Easy Iron)	The crease-reduction function is activated. \rightarrow Page 21
🗕 (😃 Prewash)	Prewash is activated. \rightarrow Page 20
- (Rinse Plus)	Washing with additional water and a rinse cycle is activated. \rightarrow Page 20
	Rinse Hold is activated.
— (=Ü SpeedPer- fect)	Shortened programme duration is activated. → "Buttons", Page 20
2	The "Blood" stain type is activated.
ů	The "Grass" stain type is activated.
9	The "Red wine" stain type is activated.
<u>•</u>	The "Cooking fat/cooking oil" stain type is activated.
Ċ	Flashes: Drum cleaning is required. Run the \textcircled{O} Drum Clean programme for cleaning and caring for the drum and the outer tub. \rightarrow "Cleaning the drum", Page 30
:	Flashes: The voltage control system has paused the pro- gramme due to impermissible voltage drops. \rightarrow ": <i>flashes and the programme is paused.</i> ", <i>Page 36</i>
	Note: The programme continues when the voltage is per- missible again.
©	 Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened.
<u>ب</u>	No water pressure.The water pressure from the tap is too low.
E:351	Error code, error display, signal. \rightarrow Page 34

8 Buttons

The selection of programme settings depends on the programme that is set.

¹ Example

en Buttons

Button	Selection	More information
DII Start/Reload	StartCancelPause	Start, cancel or pause the programme.
= [™] SpeedPerfect	ActivateDeactivate	Activate or deactivate a shorter pro- gramme duration.
		Note: Energy consumption increases. The washing result is not affected by this.
谙 Anti Stain	Multiple selection	Select the type of stain. The temperature, drum movement and soaking time are all adjusted to suit the type of stain.
© Finished in	Up to 24 hours	Set the programme end time. The programme duration is already in- cluded in the set number of hours. Once the programme has started, the programme duration is displayed.
ℓTemp. °C	* - 90	Adjust the temperature. Set temperature in °C.
© Spin Speed	└ - 1400	Adjust the spin speed or activate (Rinse Hold). Set spin speed in rpm. If is selected, the water is not drained at the end of the washing cycle and the spin cycle is deactivated. The laundry remains in the water used for rinsing.
∽ 3 sec.	ActivateDeactivate	→ "Childproof lock", Page 29
[⊥] Prewash	ActivateDeactivate	Activate or deactivate prewash, e.g. for washing heavily soiled laundry. Note: Add the detergent for the pre- wash in compartment I and the deter- gent for the main wash in compartment II of the detergent drawer. → "Detergent drawer", Page 16
🖮 Rinse Plus	ActivateDeactivate	Activate or deactivate a washing pro- gramme with more water and an addi- tional rinse cycle. Recommended for particularly sensitive skin or in regions with very soft water.

Button	Selection	More information
a Easy Iron	ActivateDeactivate	Activate or deactivate the reduced creasing programme. In order to reduce creasing in the laun- dry, the spin cycle and the spin speed are adapted.
		Note: The laundry has a higher residual moisture after washing. To reduce creasing, hang up the laundry immediately after washing.

9 Programmes

Notes

 The laundry's care labels provide you with additional information about programme selection.

→ "Care symbols on the care labels", Page 25

• The programme's temperature setting guarantees that the recommended temperature on the care label is not exceeded. The temperature that is reached in the appliance may differ from the set temperature. This means that the best possible washing performance is achieved with optimal energy efficiency.

Programme	Description	Max. load (kg)
☆ Cottons	 Wash hard-wearing items made from cotton or linen. Also suitable as a short program when you activate =[™] SpeedPerfect. Programme setting: Max. 90 °C Max. 1400 rpm 	9.0 5.0 ¹
Cottons Eco	Wash hard-wearing items made from cotton or linen. Energy-saving program for normally soiled laundry. Note: To save energy, the actual washing temperat- ure may deviate from the set washing temperature. The washing performance meets legal require- ments.	9.0

¹ = C SpeedPerfect activated

Programme	Description	Max. load (kg)
	Programme setting: Max. 90 °C Max. 1400 rpm	
☆ Easy Care	Wash items made from synthetic fabrics. Programme setting: Max. 60 °C Max. 1200 rpm	4.0
≫î≩⊼ Quick Mixed	 Wash items made from cotton, linen or synthetic fabrics. Suitable for lightly soiled laundry. Programme setting: Max. 60 °C Max. 1400 rpm 	4.0
t‰ Delicates/Silk	Wash delicate, washable items made from silk, vis- cose and synthetic fabrics. Use a detergent that is suitable for delicates or silk. Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag.	2.0
	 Tip: Gently cleaning the laundry reduces abrasion of textile fibres and microplastic fibres. Programme setting: Max. 40 °C Max. 800 rpm 	
S & Wool	 Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool. Programme setting: Max. 40 °C Max. 800 rpm 	2.0
₩ Rinse	Rinse and then spin the laundry, and drain the wa- ter. Programme setting: Max. 1400 rpm	-
© Spin/≆ Drain	Spin the laundry and drain the water. If you only want to drain the water, activate Ø. The laundry is not spun. Programme setting: Max. 1400 rpm	_
B AllergyPlus	Wash hard-wearing items made from cotton or linen.	6.5

Programme	Description	Max. load (kg)
	Suitable for allergy sufferers and for strict hygiene requirements.	
	Note: Once the set temperature has been reached, it remains constant throughout the entire washing process.	
	Programme setting: Max. 60 °C Max. 1400 rpm	
	Wash non-iron shirts and blouses made from cot- ton, linen or synthetic fabrics.	2.0
	Tip: In order to avoid creasing in your laundry, you can activate Easy Iron. The laundry is only given a short spin and can be removed while still dripping wet. Hang out shirts and blouses while they are still dripping wet so that they drip dry.	
	Note: Use the ^{the} Delicates/Silk programme to wash shirts and blouses made from silk or delicate fabrics.	
	Programme setting: Max. 60 °C Max. 800 rpm	
	Wash sports and leisure items made from synthetic fabrics. Use a detergent that is suitable for sports items. Do not use fabric softener.	2.0
	Tip: Use the ☆ Easy Care programme to wash heavily soiled laundry.	
	Programme setting: Max. 40 °C Max. 800 rpm	
№ Jeans	Wash dark-coloured and colour-intense items made from cotton or easy-care fabric, e.g. jeans. Turn laundry inside-out before washing. Use liquid detergent. Programme setting: Max. 40 °C Max. 1200 rpm	4.0

Programme	Description	Max. load (kg)	
& Drum Clean	 [®] Drum Clean Clean and care for the drum. → Page 30 Use this programme in the following cases: Before using the appliance for the first time If you regularly wash at temperatures of 40 °C or lower After a prolonged period of non-use Use washing powder containing oxygen bleach. Add the washing powder containing oxygen bleach to compartment II for the main wash. → Page 16 Halve the amount of detergent to avoid foaming. Do not use fabric softener. Do not use liquid detergent or detergent that is intended for woollens or delicates. Note: The drum cleaning indicator flashes to re- 		
	mind you if you have not used a programme at 60 °C or higher for a long time.		
ੴ/Ũ Super 15'/ 30'	 Wash items made from cotton or synthetic fabrics. Short programme for small items of lightly soiled laundry. The programme duration is approx. 30 minutes. If you wish to reduce the programme duration to 15 minutes, activate =^① SpeedPerfect. The maximum load is reduced to 2.0 kg. Programme setting: Max. 40 °C Max. 1200 rpm 	4.0 2.0 ²	

10 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order num- ber
Water inlet hose ex- tension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Water outlet hose extension	Extend the water outlet hose (2.20 m).	11057910

¹ Washing not possible ² = 🖰 SpeedPerfect activated

	Use	Order num- ber
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Elbow	Secure the water outlet hose in place.	00655300
Liquid detergent in- sert	Measure liquid detergent.	00605740

11 Laundry

11.1 Preparing the laundry ATTENTION

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, hook and loop fasteners, hooks and eyes
- Tie cloth belts, cloth straps and cords together
- Remove curtain fittings and lead strips
- Wash small or particularly delicate items in a mesh washing bag
- Wash large and small items of laundry together
- Wash laundry with fresh stains immediately
- Pretreat laundry with dried stains and wash several times
- Load the laundry unfolded into the drum
- Before loading the drum, any laundry that has been pre-treated with chlorine bleach should be rinsed several times

11.2 Care symbols on the care labels

Washing care symbols

Symbol	Recommended pro- gramme			
957 607 407 307	Cottons (normal)			
<u>607 407 307</u>	Easy Care (gentle)			
	Delicates/Silk for washing by hand (particularly gentle)			
TWY	Woollens (hand wash)			
\boxtimes	(not suitable for machine- washing)			

12 Detergents and care products

You can protect your appliance and your laundry by selecting and using the correct detergents and care products.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- When using liquid detergents, only use liquid detergents that are selfflowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener

- Do not use products that have expired or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances
- Do not use chlorine bleach
- Do not use dyes regularly as fixing salt can damage stainless steel
- Do not use color-bleaching agents in the appliance

13 Basic operation

13.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected. \rightarrow *Page 10*

Turn the programme selector to a programme.

13.2 Setting a programme

- Turn the programme selector and set the required programme.
 → "Programmes", Page 21
- 2. If required, adjust the programme settings.

→ "Buttons", Page 19

The programme settings are not saved permanently for the programme.

13.3 Opening the door

1. Grip under the door handle and pull on the door.



2. Open the door.



13.4 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes. → "Programmes", Page 21

Requirements

- The laundry is prepared and sorted.
 - → "Laundry", Page 25
- The drum is empty.
- **1.** Open the door. \rightarrow *Page 26*
- 2. Place the laundry in the drum.
- **3.** Close the door. Ensure that there is no laundry trapped in the door.

13.5 Inserting the measuring aid

1. Pull out the detergent drawer.

2. Press down on the insert and remove the detergent drawer.



3. Insert the measuring aid.



13.6 Using the measuring aid

To more easily measure the liquid detergent, you can use a measuring aid in the detergent drawer.

Note: Do not use a measuring aid for viscous detergents, for washing powder, or when the prewash or programme end time is activated.

Requirements

- The detergent drawer → Page 16 has been pulled out.
- The measuring aid is inserted.
 → Page 26

1. Slide the measuring aid forwards.



2. Fold the measuring aid down and click it into place.



13.7 Adding detergent and care product

Note: Observe the information about detergents and care products \rightarrow *Page 25*.

- 1. Pull out the detergent drawer.
- **2.** If required, use the dosing aid. \rightarrow *Page 27*
- 3. Pour in the detergent.
 - → "Detergent drawer", Page 16
- 4. If required, add the care product.
- 5. Push in the detergent drawer.

13.8 Starting the programme

Requirements

- A programme is set. \rightarrow *Page 26*
- The door is closed.
- Press DI Start/Reload.
- The drum rotates and load detection takes place. This can take up

to 2 minutes, after which water enters the drum.

- The display shows the programme duration or the programme end time.
- After the programme has ended, the display shows: "End".

13.9 Soaking laundry

Note: No additional detergent is required for soaking. The appliance uses the filled detergent for soaking and washing.

Requirements

- The laundry is placed in the appliance. → Page 26
- A programme has started.
 → Page 27
- Press DW Start/Reload approx. 10 minutes after the programme start.

The programme pauses and the laundry can soak.

2. Press DW Start/Reload after the required soaking time.

13.10 Adding laundry

After the programme starts, you can remove or add laundry depending on the programme status.

1. Press DI Start/Reload.

The appliance pauses. **Note:** If you want to add laundry,

follow the instructions on the display.

→ "Display", Page 19

- **2.** Open the door. \rightarrow *Page 26*
- 3. Add or remove laundry.
- 4. Close the door.
- **5.** Start the programme. \rightarrow *Page 27*

13.11 Cancelling the programme

1. Press DI Start/Reload.

- 2. Open the door. → Page 26 The appliance door remains locked for safety reasons if the temperature and water levels are high.
 - If the temperature is high, start the *B* Rinse programme.
 - If the water level is high, start the Spin programme or select a suitable programme for draining.

→ "Programmes", Page 21

3. Remove the laundry. \rightarrow *Page 28*

13.12 Resuming the programme when the programme status is Rinse Hold

Requirements

- Rinse Stop is activated.
 → "Buttons", Page 20
- The last rinse cycle of the set programme has ended and the laundry is in the rinsing water.
- Set the ^⑤ Spin programme or a programme for draining the water. → Page 21
- 2. Press DI Start/Reload.

13.13 Unloading the laundry

- **1.** Open the door. \rightarrow *Page 26*
- 2. Remove the laundry from the drum.

13.14 Switching off the appliance

- 1. Turn the programme selector to Off .
- 2. Turn off the tap.
- **3.** Cleaning the rubber gasket. \rightarrow *Page 33*

Note: Leave the appliance door and the detergent drawer open to dry.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof lock

- Press on both cm 3 sec. buttons for approx. 3 seconds.
- ✓ The display shows c∞.
- The control elements are locked.
- The childproof lock remains active even after the appliance has been switched off and in the event of a power cut.

14.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

- Press on both c= 3 sec. buttons for approx. three seconds.
 So that the programme currently running is not cancelled, the programme selector must be set to the initial programme.
- \bigcirc goes out on the display.

15 Basic settings

You can configure the basic settings for your appliance to meet your needs.

15.1 Overview of the basic settings



Programme selector with programme positions

1	No basic setting.
2	Set the volume of the signal at the end of the programme: 0 (off) to 4 (very loud)
3	Set the volume of the signal tone emitted when the buttons are pressed: 0 (off) to 4 (very loud)
4	Activate (On) or deactivate (OFF) the reminder to clean the drum.
5	Display the number of finished programmes.

15.2 Changing the basic settings

- Set the programme selector to position 1. → Page 29
- 2. Press (**Spin Speed** and, at the same time, turn the programme selector to position 2.
- The display shows the current value.
- Use the programme selector to select the required basic setting.
 → Page 29

- en Cleaning and servicing
- **5.** To save the changes, switch off the appliance.

16 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

16.1 Cleaning the drum

Clean the drum if you have carried out 20 washing cycles at a temperature of 40 °C or lower, if \textcircled flashes, or if you have not used the appliance for a prolonged period, but at least once a year.

⚠ CAUTION Risk of injury!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.

- Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.

Tip: You can get our tested and approved machine care and machine cleaner products online at *https://www.bosch-home.com/store* or from customer service.

 Run the I Drum Clean programme without laundry but with washing powder that contains oxygen bleach or a cleaning agent for caring for the inside of the appliance.

16.2 Cleaning the detergent drawer

Note: Scan the QR code to see an animation of the process.



- 1. Pull out the detergent drawer.
- 2. Press down on the insert and remove the detergent drawer.



3. Pull out the insert upwards.



4. Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and click it into place.



6. Clean the opening for the detergent drawer.



7. Push in the detergent drawer.

16.3 Cleaning the drain pump

Clean the drain pump regularly, at least once a year, as well as in the event of faults, e.g. blockages or rattling noises. **Note:** Scan the QR code to see an animation of the process. Observe the following safety instructions before you start the animation.



Emptying the drain pump

- 1. Turn off the tap.
- **2.** Switch off the appliance. \rightarrow *Page 28*
- **3.** Disconnect the appliance's mains plug from the power supply.
- 4. Open and remove the maintenance flap.



5. Slide a suitable receptacle under the opening for draining the detergent solution.



- en Cleaning and servicing
- 6. Take the drain hose out of the holder.



- CAUTION Risk of scalding! When you wash at high temperatures, the detergent solution gets hot.
 - Do not touch the hot detergent solution.

To allow the detergent solution to flow out into the container, remove the sealing cap.



8. Once emptied, press firmly on the locking cap.



9. Insert the drain hose into the holder.



Cleaning the drain pump

Requirement: The drain pump is empty. \rightarrow *Page 31*

- 1. Since water may remain in the drain pump, unscrew the pump cap carefully.
 - The filter insert in the pump housing may become stuck due to coarse particles of dirt. Loosen the dirt and remove the filter insert.



The pump cap is comprised of two parts which can be taken apart for cleaning.

2. Clean the interior, the thread on the pump cap and the pump housing.



- **3.** Ensure that the impeller in the drain pump can rotate.
- 4. Insert the pump cap.
 - Ensure that the parts of the pump cap are correctly assembled.





5. Screw the pump cap as far as it will go.



The handle on the pump cap must be in a vertical position.

6. Insert and close the maintenance flap.



Before the next wash

To prevent unused detergent from flowing straight into the outlet in the next wash, run a suitable programme for draining after you have emptied the drain pump.

- 1. Open the water tap.
- 2. Insert the mains plug.
- **3.** Switch on the appliance.
- 4. Pour 1 litre of water into compartment II.
- **5.** Select a suitable programme for draining.
 - → "Programmes", Page 21

16.4 Cleaning the rubber gasket

Clean the rubber gasket regularly.

en Troubleshooting

- **1.** Open the door. \rightarrow *Page 26*
- 2. Remove any foreign objects and fluff from the rubber gasket.



3. Clean the outside and the inside of the rubber gasket with a damp cloth and wipe dry.

17 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

Risk of electric shock!

Improper repairs are dangerous.

- Never make any technical modifications to the appliance or its features.
- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting			
The display goes out and D II Start/Reload flashes.	Energy-saving mode is active ► Press D II Start/Reload .			
E:36 -10 / E:30 -80 / E:18 The detergent solution is not being pumped	 The water outlet hose is connected too high, is kinked or trapped, or has been extended impermissibly. ► Check the installation of the water outlet hose. → Page 12 			
out.	Drain pipe or water outlet hose is blocked.Clean the drain pipe and the water outlet hose.			
	 The drain pump is blocked or the pump cover is not installed correctly. ► Check that the pump cover is installed correctly. → Page 31 			

Fault	Cause and troubleshooting			
E:36 -10 / E:30 -80 /	• Clean the drain pump. \rightarrow Page 31			
E:18 The detergent solution is not being pumped out.	 Detergent dosage is too high. Reduce the amount of detergent for the next washing cycle with the same load. 			
out.	 → is activated. Start the ③ Spin programme or a suitable draining programme. → Page 21 			
E:36 -25 -26	Drain pump is blocked. ► Clean the drain pump. → <i>Page 31</i>			
E:60 -2B / E:32 / H:32	The appliance has interrupted the spin cycle because the laundry is unevenly distributed.Redistribute the laundry in the drum.			
E:30 -10 / 严	The tap is turned off. • Turn on the tap.			
	 The water inlet hose is kinked or jammed. Check the installation of the water inlet hose. → Page 12 			
	 The filters in the water inflow are blocked. Clean the filters in the water inflow. Scan the QR code to see an animation of the process. 			
	The water pressure is low.Check whether the tap has sufficient water pressure.			
	 The water level measuring system is defective. With this error message, the appliance starts a draining process. 1. Wait approx. 5 minutes until the draining process ends. 2. Restart the appliance. If required, start the draining process again. 3. If the fault persists, call customer service. → Page 40 			
E:30 -20	 Critical malfunction. Turn off the water tap. With this error message, the appliance starts a draining process. 			

Fault	Cause and troubleshooting
E:30 -20	 Wait approx. 5 minutes until the draining process ends. Restart the appliance. If required, start the draining process again. If the fault persists, call customer service. → Page 40
	 Detergent dosage is too high. Reduce the amount of detergent for the next washing cycle with the same load.
	Additional water has been added.Do not add any extra water to the appliance while it is operating.
All other error codes.	 Malfunction 1. Restart the appliance. 2. If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. 3. If the fault persists, call customer service. → Page 40 Please specify the exact error message when calling. If possible, document the fault with photos and videos.
: flashes and the pro- gramme is paused.	The appliance has detected fluctuations in the power supply. No action required. If the power supply is stable, the programme continues to run as normal.
Heavy foam build-up.	 Detergent dosage is too high. Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into compartment II (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load.
© flashes.	The door is not completely closed.1. Ensure that there is no laundry trapped in the door.2. Close the door.
Ċ	Drum cleaning is required. ► Clean the drum. → Page 30
The programme does not start.	Childproof lock is activated. ► Deactivate the childproof lock. → Page 29

Fault	Cause and troubleshooting		
The programme does not start.	 ● Finished in is activated. ▶ Check whether ⁽) Finished in is activated. → Page 20 		
The programme is paused or has been interrupted, but the	 The temperature is too high. Start the <i>m</i> Rinse programme or wait until the temperature has dropped. 		
door will not open.	 Water level is too high. Start the ^⑤ Spin programme or a suitable draining programme. → Page 21 		
The door cannot be opened due to a power cut.	 The door is locked. Open the door using the emergency release. → Page 39 		
Drum jerks after the programme starts.	Not a fault. An internal motor test is started. No action required.		
Drum rotates, water does not flow in.	Not a fault. Load detection is active for up to 2 minutes. No action required.		
No water is visible in the drum.	Not a fault. Water is below the visible area. No action required.		
The spin cycle runs several times.	Not a fault. The appliance eliminates an imbalance by repeatedly redistributing the laundry. No action required.		
The appliance is vi- brating, 'wandering'	 Appliance is not correctly aligned. ▶ Align the appliance. → Page 13 		
and making loud noises during the spin	The appliance feet are not fixed. ► Secure the appliance's feet. → Page 13		
cycle.	Transit bolts have not been removed. ► Remove the transit bolts. → <i>Page 11</i>		
High spin speed not reached.	 ∠ Easy Iron is activated. Select a programme that is suitable for the type of fabric. → Page 21 		
	The appliance is using a reduced spin speed to elimin- ate an imbalance. No action required.		
The programme dura- tion changes during the wash cycle.	Not a fault. The programme sequence is optimised electronically, another rinse cycle is switched on due to heavy foam build-up, or an imbalance is eliminated. No action required.		
Whooshing, hissing or sucking noises.Not a fault. Water is pumped in or detergent solut pumped out. No action required.			

en Troubleshooting

Fault	Cause and troubleshooting
Banging noises, rat- tling in the drain pump.	 A foreign object is in the drain pump. ▶ Clean the drain pump. → Page 31
There are detergent residues on the laun- dry.	 Detergents may contain water-insoluble substances that deposit on the laundry. Start the <i>Rinse</i> programme or brush out the laundry after drying.
The laundry is too wet after the spinning cycle.	 A low spin speed is selected. Start the S Spin programme. The next time you run a wash cycle, set a higher spin speed.
	 The appliance is using a reduced spin speed to eliminate an imbalance. 1. Redistribute the laundry in the drum. 2. Start the ③ Spin programme.
	 <i>⊇</i> Easy Iron is activated. ▶ Set a suitable programme. → Page 21
Creasing.	The selected programme is unsuitable for the type of fabric. ► Set a suitable programme. → Page 21
	 A high spin speed is selected. ► The next time you run a wash cycle, set a lower spin speed.
	 The load is unsuitable. Observe the programme's maximum load capacity. → Page 21 Prepare the laundry. → Page 25
Water is leaking out at the water inlet hose.	 The water inlet hose is not correctly connected or is damaged. Check the installation of the water inlet hose. → Page 10 Replace the water inlet hose if it is damaged.
Water is leaking out at the water outlet hose.	 The water outlet hose is not connected correctly or is damaged. Check the installation of the water outlet hose. → Page 10 Replace the water outlet hose if it is damaged.
Water is leaking from below the door.	Dirt on the door or seal causes leaks.▶ Clean the door and the seal.

Fault	Cause and troubleshooting		
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	 There is too much detergent or fabric softener in the detergent drawer. When dosing, observe the marking in the detergent drawer. → Page 27 		
Residual water is present in the compartment &.	 Insert in compartment [®] is blocked. ► Clean the detergent drawer. → Page 30 		
Fabric softener re- mains in the detergent drawer.	 The use of fabric softener is not supported for the selected programme. Check whether the use of fabric softener is supported for the selected programme. → Page 21 		
Odours have formed in the appliance.	 Humidity and detergent residue may promote the formation of bacteria. Clean the drum. → Page 30 If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate. 		

17.1 Emergency release

Releasing the door

Requirement: The drain pump is empty. \rightarrow *Page 31*

- **1. ATTENTION** Escaping water may cause material damage.
 - Do not open the door if you can see water through the glass.

Pull the emergency unlock downwards with a tool and release.



- ✓ The door lock is released.
- 2. Insert the maintenance flap and lock it into place.

3. Close the service flap.

17.2 Restart the appliance.

- 1. Restart the appliance.
- If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- If the fault persists, call customer service. → Page 40 Please specify the exact error message when calling. If possible, document the fault with photos and videos.

18 Transportation, storage and disposal

18.1 Removing the appliance

- 1. Turn off the tap.
- 2. Empty the water inlet hose.

- **3.** Switch off the appliance. \rightarrow *Page 28*
- 4. Unplug the appliance's mains plug.
- 5. Drain the water.
 → "Cleaning the drain pump", Page 31
- 6. Detach the hoses.

18.2 Inserting the transit bolts

Secure the appliance before transportation using transit bolts in order to prevent transport damage.

1. Use a screwdriver to remove the 4 cover caps.



Keep the cover caps.

 Insert the 4 transit bolts.
 → "Removing the transit bolts", Page 11

18.3 Using the appliance again

 For further information, see Installation and connection → Page 10 and Starting an empty washing cycle → Page 14.

18.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

19 Customer Service

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website.

19.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate.

Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

20 Consumption values

The indicated consumption values are approximate.

The values may deviate from the indicated values depending on water pressure, water hardness, water inlet temperature, room temperature, type of laundry, amount and soiling of laundry, detergent used, fluctuations in the mains voltage and selected settings.

Programme	Temperat- ure (°C)	Load (kg)	Energy consump- tion (kWh) ¹	Water con- sumption (I) ¹	Pro- gramme duration (h:min) ¹
î Cottons	20	9.0	0.360	82.0	4:00
î Cottons	40	9.0	0.650	82.0	2:55
Cottons	60	9.0	1.100	82.0	3:05
î≵ Cottons + ⊥ Prewash	40	9.0	0.700	100.0	3:15
Cottons Eco	60	9.0	0.590	78.0	5:33
් Easy Care	40	4.0	0.800	61.0	2:37

¹ Values determined according to the valid version of IEC60456

² Programme setting with maximum speed for testing according to AS/NZS2040.1 and labelling according to AS/NZS2040.2 and AS/NZS 6400 with cold water supply (20 °C).

The program is recommended for normally soiled laundry.

Programme	Temperat- ure (°C)	Load (kg)	Energy consump- tion (kWh) ¹	Water con- sumption (I) ¹	Pro- gramme duration (h:min) ¹
≫î͡≵⊼ Quick Mixed	40	4.0	0.640	44.0	1:05
belicates/ Silk	30	2.0	0.230	35.0	0:40
🏽 🖉 Wool	30	2.0	0.300	48.0	0:41

20.1 Information for test institute



Layer 1: tablecoth

- 2 Layer 2: shirts, T-shirts, pillow cases
- Layer 3: shorts (all), wash cloths (all), handkerchiefs (all)
- 4 Layer 4: shirts, T-shirts, pillow cases
- 5 Layer 5: tablecloth
- 6 Drum
- 7 External circle: sheets, bath towels

Pre-treatment of new appliance

Run two empty runs of **Cottons** 90 °C with 1400 rpm: The 1st run with 50 g detergent and 8 g anti

sudsing agent, the 2nd run without detergent and sudsing agent.

According to standard

AS NZS 2040.1-2005 AS NZS 2040.2-2005 AS NZ 6400-2016

Washing programme

Cottons Eco 60 °C, 9.0 kg, 1400 rpm

Testing instructions

The dosage of detergent: 12.5 g/kg The dosage of anti sudsing agent: 2 g/kg

Add the dry powder detergent into main wash dispenser before start. After detergent is flushed in add the PBIS solution and anti-sudsing agent as soon as possible.

Age of test loads

The average age of test load around 10-20 times is recommended to replicate normal use.

Loading procedure

First, load the laundry items into the drum by filling the external circle. Fill possible gaps with wash clothes, handkerchiefs and laundry items without soil swatches. Afterwards, load the laundry items into the drum in layers as shown in the table and pictures below.

¹ Values determined according to the valid version of IEC60456

Make sure that swatches are flat and below the laundry item when loading items into the drum.

21 Technical data

Appliance height	84.8 cm
Appliance width	59.8 cm
Appliance depth	59.0 cm
Appliance depth with door closed	63.6 cm
Appliance depth with door open	107.3 cm
Weight	73.6 kg
Maximum load	9.0 kg

Mains voltage	220-240 V, 50-60 Hz
← Minimum in- stallation protec- tion	10 A
Nominal power	2300 W
Water pressure	 Minimum: 100 kPa (1 bar) Maximum: 1000 kPa (10 bar)
Length of the wa- ter inlet hose	150 cm
Length of the wa- ter outlet hose	150 cm
Length of the power cord	160 cm



Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- Expert tips & tricks for your appliance
- Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones:

www.bosch-home.com/welcome



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: **www.bosch-home.com/service**

Contact data of all countries are listed in the attached service directory.

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com

A Bosch Company

