

Register your new device on MyBosch now and get free benefits: bosch-home.com/ welcome



## Washing machine

#### WGG254A0TH

[en] User manual and installation instructions

## Further information and explanations are available online:



## **Table of contents**

1 Safety	. 4
1.1 General information	. 4
1.2 Intended use	. 4
1.3 Restriction on user group	. 4
1.4 Safe installation	. 5
1.5 Safe use	
1.6 Safe cleaning and mainten-	• •
ance	. 9
2 Preventing material damage	10
3 Environmental protection and	
saving energy	11
3.1 Disposing of packaging	11
3.2 Save energy and conserve	
resources	11
3.3 Energy saving mode	11
4 Installation and connection	12
4.1 Unpacking the appliance	12
4.2 Contents of package	12
4.3 Requirements for the install-	
ation location	12
4.4 Removing the transit bolts	13
4.5 Connecting the appliance	14
4.6 Aligning the appliance	16
	-
5 Familiarising yourself with	17
your appliance	17
	17
5.2 Detergent drawer	18
5.3 Control panel	10
6 Before using for the first time	19
6.1 Starting an empty washing	
cycle	19
7 Display	20

8 Buttons	23
9 Programmes	25
10 Accessories	29
<b>11 Laundry</b> 11.1 Preparing the laundry	<b>29</b> 29
12 Detergents and care products	29
<ul> <li><b>13 Basic operation</b></li> <li>13.1 Switching on the appliance</li> <li>13.2 Setting a programme</li> <li>13.3 Adjusting the programme settings</li> <li>13.4 Loading laundry</li> <li>13.5 Adding detergent and care product</li> <li>13.6 Starting the programme</li> <li>13.7 Soaking laundry</li> <li>13.8 Adding laundry</li> <li>13.9 Cancelling the programme</li> <li>13.10 Unloading the laundry</li> <li>13.11 Switching off the appliance</li></ul>	<b>30</b> 30 30 30 30 30 31 31 31 31 31
<b>14 Childproof lock</b> 14.1 Activating the childproof	32
lock	32
14.2 Deactivating the childproof lock	32
<ul><li><b>15 Intelligent dosing system</b></li><li>15.1 Starting the programme with intelligent dosing sys-</li></ul>	32
tem	32

<ul><li>15.2 Filling the dispensers</li><li>15.3 Basic dosage</li></ul>	33 34
16 Basic settings	35
16.1 Overview of the basic set- tings	35
16.2 Changing the basic set- tings	36
17 Cleaning and servicing	36
17.1 Cleaning the drum	36
17.2 Cleaning the detergent drawer	37
17.3 Cleaning the drain pump	38
<b>18 Troubleshooting</b> 18.1 Emergency release	<b>42</b> 53
19 Transportation, storage and	50
disposal	53
191 Removing the appliance	53
<ul><li>19.1 Removing the appliance</li><li>19.2 Inserting the transit bolts</li></ul>	53 53
<ul><li>19.2 Inserting the transit bolts</li><li>19.3 Using the appliance again</li><li>19.4 Disposing of old appliance</li><li>20 Customer Service</li></ul>	53 53
<ul><li>19.2 Inserting the transit bolts</li><li>19.3 Using the appliance again</li><li>19.4 Disposing of old appliance</li></ul>	53 53 54
<ul> <li>19.2 Inserting the transit bolts</li> <li>19.3 Using the appliance again</li> <li>19.4 Disposing of old appliance</li> <li>20 Customer Service</li> <li>20.1 Product number (E-Nr.) and</li> </ul>	53 53 54 <b>54</b>

## 1 Safety

Observe the following safety instructions.

## 1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

## 1.2 Intended use

Only use this appliance:

- For washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- With tap water and commercially available detergents and care products suitable for washing machines.
- in private households and in enclosed spaces in a domestic environment.
- up to an altitude of max. 4000 m above sea level.

## 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

## 1.4 Safe installation

### ▲ WARNING – Risk of electric shock!

Incorrect installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ► When using a residual current circuit breaker, only use a type with the mtext{mark}.
- Never equip the appliance with an external switching device, e.g. a timer or remote control.
- When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ► Never kink, crush or modify the power cord.

## ▲ WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ► Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.
- If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

### ▲ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

► Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- Do not install a washer-dryer stack on a platform; the appliances may tip over.

## ▲ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material.

## ▲ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ► Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level.

If hoses and power cords have been laid incorrectly, this causes a tripping hazard.

Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

► Do not move the appliance by holding onto protruding parts.

## ▲ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

► Do not touch the sharp edges on the appliance.

Wear protective gloves when installing and transporting the appliance.

## 1.5 Safe use

### ▲ WARNING – Risk of electric shock!

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer services. → Page 54

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

### ▲ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

## ▲ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

### ▲ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ► If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

## ▲ WARNING – Risk of explosion!

Laundry that has been pretreated with cleaning agents that contain solvents may cause an explosion in the appliance.

Rinse pretreated laundry thoroughly with water before washing.

## ▲ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

► Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- Do not sit on or lean against the appliance door.
- ► Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

 Wait for the drum to come to a complete stop before reaching inside.

## ▲ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

► Do not touch the hot detergent solution.

## ▲ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ► If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

## 1.6 Safe cleaning and maintenance

### ▲ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

## ▲ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

Only use the manufacturer's original spare parts and original accessories.

## ▲ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

► Do not use cleaning agents that contain solvents.

## 2 Preventing material damage

#### ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

► Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

 Observe the maximum load capacity for each programme and do not exceed it.

→ "Programmes", Page 25 The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.

- Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- Before transport, fit the transit bolts fully in order to prevent damage in transit.

Material damage may be caused if the water inlet hose is connected incorrectly.

- Tighten the screw connections on the water inlet until they are handtight.
- Connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions or valves.
- Ensure that the inner diameter of the water tap is at least 17 mm.
- Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- Ensure that the water pressure in the water supply system is at least 100 kPa (1 bar) and max.
   1000 kPa (10 bar).
- If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may lead to material damage and damage to the appliance.

 Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

#### 3 Environmental protection and saving energy

#### 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

#### 3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

Choose programmes with low temperatures and longer wash times and use maximum load capacity.

 Energy consumption and water consumption is most efficient.

Add detergent based on the laundry's degree of soiling.

For light to normal soiling, a smaller amount of detergent is sufficient. Observe the dosage recommendation from the detergent manufacturer.

Reduce the washing temperature for lightly and normally soiled laundry.

 At lower temperatures, the appliance consumes less energy. For light to normal soiling, lower temperatures than indicated on the care label are also sufficient. Set the maximum spin speed if you want to dry the laundry in the tumble dryer afterwards.

 The drier the laundry, the shorter the programme duration when drying which, in turn, reduces energy consumption. A higher spin speed reduces the residual moisture in the laundry and increases the volume of the spin noise.

Wash the laundry without prewash.

 Washing with prewash increases the programme duration and increases energy and water consumption.

The appliance has a continuous automatic load adjustment function.

 Depending on the type of fabric and load capacity, the continuous automatic load adjustment function optimally adjusts the water consumption and programme duration.

The appliance comes with an Aqua-Sensor.

 During the rinse cycle, the Aqua-Sensor checks the degree of turbidity of the rinsing water, and adjusts the duration and number of rinse cycles accordingly.

#### 3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. Energy-saving mode ends when you use the appliance again.

#### 4 Installation and connection

#### 4.1 Unpacking the appliance

#### ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- 1. Remove any packaging and protective covers completely from the appliance.

→ "Disposing of packaging", Page 11

- 2. Check the appliance for visible damage.
- 3. Open the door.
- 4. Remove any accessories from the drum.
- 5. Close the door.

### 4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

#### **ATTENTION!**

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

 Do not operate the appliance with incomplete or defective accessories.  Replace the accessories in question before operating the appliance.

→ "Accessories", Page 29

**Note:** The appliance has been tested at the factory to check it is in working order. As a result, water stains may remain in the appliance. These marks will disappear after the first wash cycle.

The delivery consists of the following:

- Washing machine
- Accompanying documents
- Transit bolts

   → "Removing the transit bolts", Page 13
- Cover caps
- Water inlet hose
   → "Connecting the water inlet
   hose", Page 14
- Elbow for securing the water outlet hose

#### 4.3 Requirements for the installation location

## WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

 Do not operate the appliance without a cover cap.

## A WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 29 before using the appliance for the first time.

#### **ATTENTION!**


If residual water in the appliance freezes, this may cause damage to the appliance.

Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- Tilt the appliance carefully.
- Transport the appliance in an upright position.

#### Installation loca- Requirements tion



resistant wooden board (minimum 30 mm) which is screwed tightly to the floor.


Kitchen unit



Only install the appliance underneath a continuous worktop that is securely connected to adiacent cabinets. Required niche width: 60 cm.

#### Installation loca- Requirements tion

Against a wall



Do not trap the power cord or the hoses between the wall and the appliance.


#### 4.4 Removing the transit bolts

The appliance is secured for transportation using transit bolts on the rear of the appliance.


**Note:** Keep the transit bolt screws and the sleeves in a safe place for future transport.

 $\rightarrow$  "Inserting the transit bolts". Page 53

1. Pull the hoses out of the holders.




- en Installation and connection
- 2. Unscrew ① and remove ② all of the screws for the 4 transit bolts using a WAF 13 wrench.



**3.** Remove the power cable from the holder.




4. Remove the 4 sleeves.



5. Put on the 4 cover caps.



6. Push the 4 cover caps downwards.




**Note:** To install the transit bolts to transport the appliance, perform these steps again in the reverse order.


#### 4.5 Connecting the appliance

#### Connecting the water inlet hose

1. Connect the water inlet hose.



2. Connect the water inlet hose to a tap (26.4 mm = 3/4").



**3.** Open the water tap carefully and check that the connection points are tight.

#### Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.

#### **ATTENTION!**

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

 Secure the water outlet hose against unintentional loosening.

**Note:** Observe the draining heights. The maximum draining height is 100 cm.

Siphon	Secure the con- nection point with a (24-40 mm) hose clamp.
Sink	Fix and secure the water outlet hose with an el- bow $\rightarrow$ Page 29.

Plastic pipe with rubber sleeve or gully



Fix and secure the water outlet hose with an elbow



## Connecting the appliance to the electricity supply

**Note:** Your electrical domestic installation for this appliance must comply with the local legal provisions and safety regulations, and should include a residual current circuitbreaker.

 Insert the mains plug of the appliance's power cable in a socket nearby.


The connection details of the appliance can be found under Technical data  $\rightarrow$  Page 55.

2. Check the mains plug is inserted properly.


### 4.6 Aligning the appliance

In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

1. Use a WAF 17 wrench to loosen the lock nuts in a clockwise direction.




2. To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

**3.** Use a WAF 17 wrench to tighten the lock nuts against the housing until they are hand-tight.




In doing so, hold the foot tight and do not adjust its height.

## 5 Familiarising yourself with your appliance

#### 5.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

1	Maintenance flap for the drain pump $\rightarrow$ Page 38
2	Door
3	Detergent drawer → Page 17
4	Control panel → Page 18
5	Water outlet hose $\rightarrow$ Page 15
6	Power cord → Page 15
7	Transit bolts → Page 13

#### 5.2 Detergent drawer

**Note:** Observe the manufacturer's instructions on the use and dosage of the detergent and care product and the information in the programme descriptions.


→ "Programmes", Page 25



1	Manual dosing compartment
2	<ul> <li>Bispenser for fabric</li> <li>softener</li> </ul>
3	O : Dispenser for liquid deter- gent

#### 5.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



1	Programmes → Page 25
2	Programme selector → Page 30
3	Display → Page 20
4	Buttons → Page 23


## 6 Before using for the first time

Prepare the appliance for use.


#### 6.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

- Turn the programme selector to ล้างถังชัก <sup>(C)</sup>.
- 2. Close the door.
- 3. Pull out the detergent drawer.
- **4.** Pour approx. 1 litre of water into the manual dosing compartment.



5. Add washing powder that contains a bleaching agent to the manual dosing compartment.



To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

- 6. Push in the detergent drawer.
- 7. Press D**III Start/Reload/Pause** to start the programme.
- The display shows the remaining programme duration.
- After the programme has ended, the display shows: End.
- 8. Start the first wash cycle or set the programme selector to Dn to switch off the appliance.
  - → "Basic operation", Page 30

## 7 Display

The display shows the current settings, options or relevant information.

	90°	1400		¢ (	ج ج	<u> </u>	
	60°	1000		⇒ ŕ		0	
	40°	800					
	30°	600		+3 D		t ml	DⅢ Start/
0	20°	400		+2 🕽		l kg	Reload/ Pause
8	*	Ø		+1		+	
<u></u>	A	6		÷	2		-≡Ŭ
i-DOS	อุณหภูมิ Temp. °C	ปั่นหมาด Spin	เพิ่มรอบซัก Prewash	Extra Rinse	ลดรอยยับ Easy Iron C	เวลาสินสุด Ready In ๛	Speed Perfect

Example: Display

Display	Description	
0:40 1	Expected programme duration or programme time re- maining in hours and minutes.	
+8h 1	Program end time → "Buttons", Page 23	
10.0 <sup>1</sup>	Recommendation for the maximum load capacity for the selected program in kg.	
Ø - 1400	Set spin speed in rpm. → <i>"Buttons", Page 23</i> Ø : No spin cycle, draining only	
≵ - 90	Set temperature in °C. → <i>"Buttons", Page 23</i> 巻 (cold)	
— (Start/Reload/ Pause)	<ul> <li>Start, cancel or pause</li> <li>Lights up: The programme is running and can be cancelled or paused.</li> <li>Flashes: The programme can be started or continued.</li> </ul>	
	Prewash Programme status	
<b>⇔</b>	Wash Programme status	
	Rinse Programme status	
<sup>1</sup> Example		

Display	Description
0	Spin Programme status
End	Program end Programme status
<del>س</del> ک	<ul> <li>Lights up: The childproof lock is activated.</li> <li>Flashes: The childproof lock is activated and the appliance has been operated.</li> <li>→ "Deactivating the childproof lock", Page 32</li> </ul>
— (ลดรอยยับ Easy Iron)	The crease-reduction function is activated. → "Buttons", Page 24
+1 +2 +3	Additional rinse cycles are activated. → "Buttons", Page 24
— (เพิ่มรอบซัก Pre- wash)	Prewash is activated. → "Buttons", Page 24
(Speed Per- fect)	Shortened programme length is activated. → "Buttons", Page 23
Ŷ	Flashes: Drum is dirty. Run the ล้างถังซัก & programme for cleaning and caring for the drum and the outer tub. → "Cleaning the drum", Page 36
0	<ul> <li>Lights up: The intelligent dosing system for liquid detergent is activated.</li> <li>Flashes: The fill level of the dispenser is below the minimum level.</li> <li>→ "Intelligent dosing system", Page 32</li> </ul>
	0 (liquid detergent)
8	<ul> <li>Lights up: The intelligent dosing system for fabric softener is activated.</li> <li>Flashes: The fill level of the dispenser is below the minimum level.</li> <li>→ "Intelligent dosing system", Page 32</li> </ul>
	8 (fabric softener)
50 ml <sup>1</sup>	Basic dosage for detergent or fabric softener. → "Basic dosage", Page 34
©	<ul> <li>Lights up: The door is locked and cannot be opened.</li> <li>Flashes: The door is not closed properly.</li> <li>Off: The door is unlocked and can be opened.</li> </ul>
で	<ul><li>No water pressure.</li><li>The water pressure from the tap is too low.</li></ul>
۲ <u>م</u>	The detergent drawer has not been pushed in fully.
<sup>1</sup> Example	

Display	Description
E:35 / -10 <sup>1</sup>	Error code, error display, signal. → "Troubleshooting", Page 42
<sup>1</sup> Example	

### 8 Buttons

The selection of programme settings depends on the programme that is set.

Button	Selection	More information
DII Start/Reload/ Pause	<ul><li>Start</li><li>Cancel</li><li>Pause</li></ul>	Start, cancel or pause the pro- gramme.
=O Speed Perfect	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate a shorter pro- gramme duration.
		<b>Note:</b> Energy consumption increases. The washing result is not affected by this.
Ĝ i-DOS	<ul><li>Activate</li><li>Deactivate</li><li>Basic dosage</li></ul>	Briefly press the button to activate or deactivate the intelligent dosing sys- tem for fabric softener $\circledast$ or liquid de- tergent $\diamond$ . Press the button for approx. three seconds to set the basic dosage. $\rightarrow$ "Intelligent dosing system", Page 32
🕲 เวลาสิ้น สุด Ready In	Up to 24 hours	Set the programme end time. The programme duration is already in- cluded in the set number of hours. Once the programme has started, the programme duration is displayed.
ึ่ อุณหภูมิ Temp. °C	≉ - 90	Adjust the temperature. Set temperature in °C.
์ ® ปั่นหมาด Spin	Ø - 1400	Adjust the spin speed or deactivate the spin cycle. Set spin speed in rpm. If $\mathscr{O}$ is selected, the water is drained and the spin cycle is deactivated. The laundry stays wet inside the drum.
่	<ul><li>Activate</li><li>Deactivate</li></ul>	→ "Childproof lock", Page 32

Button	Selection	More information
🖖 เพิ่มรอบซัก Pre- wash	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate prewash, e.g. for washing heavily soiled laundry.
		<b>Note:</b> If the intelligent dosing system is activated, the detergent will be dis- pensed automatically for the prewash and the main wash. If the intelligent dosing system is de- activated, place the detergent for the prewash directly in the drum.
⊯ Extra Rinse	■ +1 ■ +2 ■ +3	Activate or deactivate up to three ad- ditional rinse cycles. Recommended for particularly sensit- ive skin or in regions with very soft water.
🛆 ลดรอยยับ Easy Iron	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate the reduced creasing programme. In order to reduce creasing in the laundry, the spin cycle and the spin speed are adapted. <b>Note:</b> The laundry has a higher resid- ual moisture after washing. To reduce creasing, hang up the laundry immedi- ately after washing.

## 9 Programmes

**Note:** The laundry's care labels provide you with additional information on programme selection.

Programme	Description	
ผ้าฝ้าย 🕼 Cottons	<ul> <li>Wash hard-wearing items made from cotton, linen or blended fabrics.</li> <li>Also suitable as a short programme for normally soiled laundry when you activate =♡ Speed Perfect.</li> <li>Programme setting:</li> <li>Max. 90 °C</li> <li>Max. 1400 rpm</li> </ul>	
ซักประหยัด @ Cottons Eco	<ul> <li>Wash hard-wearing items made of cotton, linen or blended fabrics.</li> <li>Energy-saving programme.</li> <li>Note: To save energy, the actual washing temperature may deviate from the set washing temperature. The washing performance meets legal requirements.</li> <li>Programme setting:</li> <li>Max. 90 °C</li> <li>Max. 1400 rpm</li> </ul>	10.0
ผ้าสังเคราะห์ 企 Synthetics	Wash items made from synthetic or blended fab- rics. Programme setting: • Max. 60 °C • Max. 1000 rpm	4.0
ผ้าหลายชนิด ชิ่ิิ่ิ่ Mix Load	<ul> <li>Wash items made from cotton, linen, or synthetic or blended fabrics.</li> <li>Suitable for lightly soiled laundry.</li> <li>Programme setting:</li> <li>Max. 60 °C</li> <li>Max. 1400 rpm</li> </ul>	4.0
ผ้าบอบบาง/ผ้า ไหม ‰ Delicates/ Silk	Wash delicate, washable items made from silk, vis- cose and synthetic fabrics. Use a detergent that is suitable for delicates or silk. <b>Note:</b> Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag.	2.0
<sup>1</sup> = O Speed Pe <sup>2</sup> Washing not p	rfect activated	

Programme	Description	
	Programme setting: Max. 40 °C Max. 800 rpm	
ซักถนอมผ้าขน สัตว์ § ֎ Wool	<ul> <li>Hand- or machine-washable items that are made from wool or contain wool.</li> <li>To prevent the laundry from shrinking, the drum moves the items very gently with long pauses.</li> <li>Use a detergent that is suitable for wool.</li> <li>Programme setting:</li> <li>Max. 40 °C</li> <li>Max. 800 rpm</li> </ul>	
🤓 ล้างน้ำ Rinse	Rinse and then spin the laundry, and drain the wa- ter. Programme setting: Max. 1400 rpm	_
ิ ช ี ปั่นหมาด/ ระบายน้ำ Spin/Drain	Spin and drain the water. If you only want to drain the water, activate $\mathscr{D}$ . The laundry is not spun. Programme setting: Max. 1400 rpm	-
ษ ป้องกันภูมิแพ้ AllergyPlus	<ul> <li>Wash hard-wearing items made from cotton, linen or blended fabrics.</li> <li>Suitable for allergy sufferers and for strict hygiene requirements.</li> <li>Note: Once the set temperature has been reached, it remains constant throughout the entire washing process.</li> <li>Programme setting:</li> <li>Max. 60 °C</li> <li>Max. 1400 rpm</li> </ul>	6.5
ซี ชุดกีฬา Sportswear	Wash sports and leisure items made from synthetic fibres, microfibre or fleece. Use a detergent that is suitable for sports items. Do not use fabric softener. <b>Tip:</b> Use the ผาสังเคราะห์ ช่ programme to wash heavily soiled laundry. Programme setting: Max. 40 °C Max. 800 rpm	2.0
<ul> <li><sup>1</sup> = ⑦ Speed Perfect activated</li> <li><sup>2</sup> Washing not possible</li> </ul>		

Programme	Description	Max. load (kg)
∖A/ ซักอัตโนมัติ 40°C Automatic 40°	<ul> <li>Wash hard-wearing items made from cotton, or synthetic or blended fabrics.</li> <li>The degree of soiling and the type of fabric are automatically detected. The washing process is adapted.</li> <li>Note: The temperature and spin speed cannot be adjusted in this programme and are set automatically.</li> <li>The maximum temperature is 40 °C.</li> <li>The maximum spin speed is 1400 rpm.</li> </ul>	6.0
⊞ ผ้านวม Quilt/Blanket	<ul> <li>Wash pillows or quilts stuffed with synthetic fibres or down fillings.</li> <li>Wash large items separately.</li> <li>Use a detergent that is suitable for down or delicates.</li> <li>Use sparingly.</li> <li>Do not use fabric softener.</li> <li>Note: To prevent excessive foaming, remove air from laundry items by rolling them up before you wash them.</li> <li>Programme setting:</li> <li>Max. 60 °C</li> <li>Max. 1000 rpm</li> </ul>	2.5
ล้างถังซัก ଔ Drum Clean	<ul> <li>Clean and care for the drum.</li> <li>Use this programme in the following cases:</li> <li>Before using the appliance for the first time</li> <li>If you regularly wash at temperatures of 40 °C or lower</li> <li>After a prolonged period of non-use</li> <li>Use washing powder that contains bleach. Place the washing powder containing bleach in the manual dosing compartment.</li> <li>→ "Detergent drawer", Page 17</li> <li>Halve the amount of detergent to avoid foaming.</li> <li>Do not use fabric softener.</li> <li>Do not use liquid detergent or detergent that is intended for woollens or delicates.</li> <li>Note: The drum cleaning indicator flashes to remind you if you have not used a programme at 60 °C or higher for a long time.</li> </ul>	_2

<sup>1</sup> = I Speed Perfect activated
 <sup>2</sup> Washing not possible

Programme	Description	Max. load (kg)
(ซี เขิด่วน 15นาที/30นาที Quick 15/30 min	<ul> <li>Wash items made from cotton, or synthetic or blended fabrics.</li> <li>Short programme for small items of lightly soiled laundry.</li> <li>The programme duration is approx. 30 minutes.</li> <li>If you wish to reduce the programme duration to 15 minutes, activate =♡ Speed Perfect. The maximum load is reduced to 2.0 kg.</li> <li>Programme setting:</li> <li>Max. 40 °C</li> <li>Max. 1000 rpm</li> </ul>	4.0 2.0 <sup>1</sup>
<ul> <li><sup>1</sup> = O Speed Perfect activated</li> <li><sup>2</sup> Washing not possible</li> </ul>		

#### **10 Accessories**

Use original accessories. These have been made especially for your appliance.

	Use	Order num- ber
Water inlet hose ex- tension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Elbow	Secure the water outlet hose in place.	00655300
Washing machine cleaners	Cleaning products for maintaining the appliance interior.	00311929

### 11 Laundry

#### 11.1 Preparing the laundry

#### **ATTENTION!**

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

#### Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, Velcro fasteners, hooks and eyes
- Tie cloth belts, cloth straps and cords together
- Remove curtain fittings and lead strips
- Wash small or particularly delicate items in a mesh washing bag
- Wash large and small items of laundry together
- Wash laundry with fresh stains immediately

- Pretreat laundry with dried stains and wash several times
- Load the laundry unfolded into the drum

## 12 Detergents and care products

The manufacturer's instructions for use and dosage can be found on the packaging.

#### Notes

- When using liquid detergents, only use liquid detergents that are selfflowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed
- do not use products containing solvents, caustic agents or volatile substances
- Use dyes sparingly as salt may damage stainless steel
- Do not use color-bleaching agents in the appliance
- Do not pour vinegar into the dispensers → Page 33 of the intelligent dosing system

### 13 Basic operation

#### 13.1 Switching on the appliance

**Requirement:** The appliance has been correctly installed and connected.

 $\rightarrow$  "Installation and connection", Page 12

- Turn the programme selector to a programme.
- An audible function test is carried out.

#### 13.2 Setting a programme

- Turn the programme selector and set the required programme.
   → "Programmes", Page 25
- 2. If required, adjust the programme settings.

 $\rightarrow$  "Adjusting the programme settings", Page 30

#### 13.3 Adjusting the programme settings

**Requirement:** A programme has been set.

→ "Setting a programme", Page 30

Adjust the programme settings.
 → "Buttons", Page 23

#### Notes

- The programme settings are not saved permanently for the programme.
- The setting is saved if you activate or deactivate the intelligent dosing system.

#### 13.4 Loading laundry

**Note:** To prevent creasing, note the maximum load for the programmes. → "Programmes", Page 25

#### Requirements

- The laundry is prepared and sorted.
  - → "Laundry", Page 29
- The drum is empty.
- 1. Open the door.
- 2. Place the laundry in the drum.
- 3. Close the door.

Ensure that there is no laundry trapped in the door.

## 13.5 Adding detergent and care product

For programmes in which intelligent dosing is not possible or desirable, you can add detergent manually.

**Tip:** In addition to intelligent dosing, you can also add additional care product for laundry, e.g. stain remover, starch or bleach, to the manual dosing compartment. Do not add any additional detergent to the manual dosing compartment to avoid overdosage and/or foaming.

**Note:** Observe the information about detergents and care products  $\rightarrow$  *Page 29*.

- 1. Pull out the detergent drawer.
- 2. Pour in detergent. → "Detergent drawer", Page 17
- 3. If required, add the care product.
- 4. Push in the detergent drawer.

#### 13.6 Starting the programme

**Requirement:** A programme is set. → "Setting a programme", Page 30

► Press DI Start/Reload/Pause.

- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- The display shows the programme duration or the programme end time.
- After the programme has ended, the display shows: End.

### 13.7 Soaking laundry

**Note:** No additional detergent is required. The washing solution is then used for washing.

- 1. Start the programme.
- 2. To pause the programme, after approx. 10 minutes, press D**II Start**/ **Reload/Pause**.
- 3. To resume the programme, after the desired soaking time, press ▷ Start/Reload/Pause.

## 13.8 Adding laundry

After the programme starts, you can remove or add laundry depending on the programme status.

1. Press DI Start/Reload/Pause.

The appliance pauses.

**Note:** If you want to add laundry, follow the instructions on the display.

→ "Display", Page 21

- 2. Open the door.
- 3. Add or remove laundry.
- 4. Close the door.
- 5. Press DI Start/Reload/Pause.

#### 13.9 Cancelling the programme

- 1. Press DI Start/Reload/Pause.
- 2. Open the door.

The appliance door remains locked for safety reasons if the temperature and water levels are high.

- If the temperature is high, start the ซ ด้างน้ำ programme.
- If the water level is high, start the อิปันหมาด programme or select a suitable programme for draining.

→ "Programmes", Page 25

 Remove the laundry.
 → "Unloading the laundry", Page 31

#### 13.10 Unloading the laundry

- 1. Open the door.
- 2. Remove the laundry from the drum.

#### 13.11 Switching off the appliance

- 1. Turn the programme selector to บิด .
- 2. Turn off the tap.
- **3.** Wipe the rubber gasket dry and remove any foreign objects.



4. Leave the appliance door and detergent drawer open so that residual water can evaporate.

## 14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

## 14.1 Activating the childproof lock

- The display shows  $\, \, {f C} \, {f w}$  .
- The control elements are locked.
- The childproof lock remains active even after the appliance has been switched off and in the event of a power cut.

#### 14.2 Deactivating the childproof lock

**Requirement:** To deactivate the childproof lock, the appliance must be switched on.

- Press and hold the two อิ ลดรอย

   ยับ Easy Iron & () เวลาสิ้นสุด Ready

   In buttons for approx. 3 seconds.
- ✓ C goes out in the display.

#### 15 Intelligent dosing system

The optimum quantities of liquid detergent and fabric softener are dispensed automatically depending on the programme and settings.

# 15.1 Starting the programme with intelligent dosing system

If you do not want to dose liquid detergent and fabric softener manually, use the intelligent dosing system. This function is available depending on the selected programme and is activated automatically.

#### Note

If you are using the intelligent dosing system, do not add additional detergent or fabric softener into the compartment for manual dosing.

→ "Adding detergent and care product", Page 30

If you want to dose manually for a set programme, observe the following information:

 Deactivate the intelligent dosing system before starting the programme. The selected settings are retained even after the appliance has been switched off.
 → "Buttons", Page 23

 Pour detergent or fabric softener into the compartment for manual dosing.

→ "Adding detergent and care product", Page 30

- Activate the intelligent dosing system once the programme has ended.
  - → "Buttons", Page 23

#### Requirements

- The laundry is prepared.
   → "Preparing the laundry", Page 29
- The laundry is sorted.
- The laundry is placed in the appliance.
  - → "Loading laundry", Page 30
- The programme is set.
   → "Setting a programme", Page 30
- The intelligent dosing system is activated.
  - → "Display", Page 21
- Fill the dispensers.

   → "Filling the dispensers", Page 33

To replace the contents of the dispenser with another product, clean the detergent drawer.

 $\rightarrow$  "Cleaning the detergent drawer", Page 37

- 2. If required, adjust the contents of the dispenser.
- If required, adjust the basic dosage → Page 34.
- 4. If required, adjust the programme settings.

 $\rightarrow$  "Adjusting the programme settings", Page 30

- 5. Start the programme. → "Starting the programme", Page 30
- 6. Remove the laundry. → "Unloading the laundry", Page 31

#### 15.2 Filling the dispensers

If you want to use the intelligent dosing system or if the appliance displays a notification during operation of the appliance, fill the dispensers.


**Note:** Fill the dispensers only with suitable detergent and care products  $\rightarrow$  *Page* 29.

If you want to add more liquid detergent or fabric softener in the dispenser, use the same product. If you want to replace the liquid detergent or fabric softener in the dispenser with another product, clean the detergent drawer beforehand. → "Cleaning the detergent drawer", Page 37

**Requirement:** The display shows a notification to fill the dispenser. → "Display", Page 21


1. Pull out the detergent drawer.

2. Open the dispenser cover.



 Pour liquid detergent ◊ and fabric softener ⊗ into the relevant dispensers.

→ "Detergent drawer", Page 17



Do not exceed the marking for the maximum fill level when filling.

**4.** Close the dispenser cover.

**Note:** To prevent the liquid detergent or fabric softener from drying out, close the dispenser cover immediately after filling.

5. If required, pour washing aid into the compartment for manual dosing.

→ "Adding detergent and care product", Page 30

- 6. Push in the detergent drawer.
- 7. Adjust the basic dosage  $\rightarrow$  Page 34.

#### 15.3 Basic dosage

The basic dosage depends on the manufacturer's instructions for the detergent, the water hardness and the degree of soiling of the laundry. Always set a basic dosage that corresponds to the dosage for a standard load of 4.5 kg.


#### Adjusting the basic dosage

- Press and hold i-DOS for approx. 3 seconds.
- ✓ The display shows the basic dosage set for <sup></sup>𝔅.
- 2. To adjust the basic dosage for ℅, press ♣ i-DOS.
- 3. To adjust the setting, press (b) Ready In.
- 4. To end the setting process, wait briefly.

## 16 Basic settings

You can configure the basic settings for your appliance to meet your needs.


#### 16.1 Overview of the basic settings



Basic setting	Programme position	Value	Description
End signal	2	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	Set the volume of the signal at the end of the programme.
Button signal	3	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	The volume of the audible signal emitted when the buttons are pressed.
Drum cleaning reminder	4	On OFF	Activate or deactivate the re- minder to clean the drum.

#### 16.2 Changing the basic settings

**1.** Set the programme selector to position 1.



- Press () ปั่นหมาด Spin and, at the same time, turn the programme selector to position 2.
- The display shows the current value.
- Set the programme selector to the required position.
   → "Overview of the basic settings", Page 35
- 4. To change the value, press (b) Ready In.
- **5.** To save the changes, switch off the appliance.

## 17 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

### 17.1 Cleaning the drum

#### CAUTION Risk of injury!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.

- Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- Run the ล้างถังชัก <sup>(b)</sup> programme without laundry and with a cleaning agent for caring for the inside of the appliance

 $\rightarrow$  "Accessories", Page 29 or with washing powder that contains bleach.

# 17.2 Cleaning the detergent drawer


If you want to replace the liquid detergent or fabric softener in the dispenser with another product or if the detergent drawer is dirty, clean the detergent dispenser.

### **ATTENTION!**


The pump unit contains electrical components. Electrical components may be damaged if they come into contact with liquids.

- Do not clean the pump unit in the dishwasher and do not immerse it in water.
- Protect the electrical connection on the rear against water, detergent and fabric softener residue.
- Switch off the appliance.


   → "Switching off the appliance", Page 31
- 2. Pull out the detergent drawer.
- **3.** Press down on the insert and remove the detergent drawer.




4. Remove the pump unit.




5. Unclip the detergent drawer cover and remove it.




6. Empty the detergent drawer.




- en Cleaning and servicing
- 7. Clean the pump unit with a damp cloth.




8. Clean the detergent drawer and the cover with a soft, damp cloth or hand shower.



9. Dry the detergent drawer, cover and pump unit and reinsert them.





**10.** Clean the housing of the detergent drawer in the appliance.



11. Push in the detergent drawer.


### 17.3 Cleaning the drain pump

Clean the drain pump regularly, at least once a year, as well as in the event of faults, e.g. blockages or rattling noises.


### Emptying the drain pump

- 1. Turn off the tap.
- 2 Switch off the appliance.
   → "Switching off the appliance", Page 31
- **3.** Disconnect the appliance's mains plug from the power supply.


4. Open and remove the maintenance flap.



**5.** Slide a sufficiently large container under the opening.




6. Take the drain hose out of the holder.




- 7. A CAUTION Risk of scalding! When you wash at high temperatures, the detergent solution gets hot.
- Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



8. Firmly press on the sealing cap.




9. Insert the drain hose into the holder.




### Cleaning the drain pump

**Requirement:** The drain pump is empty.  $\rightarrow$  *Page 38* 

1. Since water may remain in the drain pump, unscrew the pump cap carefully.




2. Clean the interior, the thread on the pump cap and the pump housing.




**3.** Ensure that the impeller in the drain pump can rotate.

4. Insert the pump cap.




5. Screw the pump cap as far as it will go.



The handle on the pump cap must be in a vertical position.

6. Insert and close the maintenance flap.



#### Before the next wash

To prevent unused detergent from flowing straight into the outlet in the next wash, run a suitable programme for draining after you have emptied the drain pump.

**1.** Open the water tap.

- 2. Insert the mains plug.
- **3.** Switch on the appliance.
- 4. Pour 1 litre of water into the manual dosing compartment.
- **5.** Select a suitable programme for draining.
  - → "Programmes", Page 25

## **18 Troubleshooting**

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

### 

#### **Risk of electric shock!**

Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting					
The display goes out and DI Start/Reload/ Pause flashes.	Energy-saving mode is active / ► Press any button. <ul> <li>The display lights up again.</li> </ul>					
"E:36 / -10"	<ul><li>Drain pipe or water outlet hose is blocked.</li><li>Clean the drain pipe and the water outlet hose.</li></ul>					
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>					
	<ul> <li>The water outlet hose is connected too high.</li> <li>Install the water outlet hose at a maximum height of 1 metre.</li> </ul>					
	<ul> <li>Unapproved extension installed on the water drain hose.</li> <li>▶ Remove any unapproved extensions from the water hose.</li> <li>→ "Connecting the appliance", Page 14</li> </ul>					
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 38					
	<ul> <li>The pump cap is not fully screwed in.</li> <li>Ensure that the pump cap is screwed in all the way into the appliance. The handle on the pump cap must be in a vertical position.</li> <li>→ "Cleaning the drain pump", Page 40</li> </ul>					
	Detergent dosage is too high.					

Detergent dosage is too high.

Fault	Cause and troubleshooting					
"E:36 / -10"	<ul> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mix- ture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down).</li> </ul>					
	<ul> <li>If intelligent dosing is activated, reduce the basic dosage → Page 34.</li> </ul>					
	<ul> <li>If you dose manually, reduce the amount of deter- gent for the next washing cycle with the same load.</li> </ul>					
"E:10 / -00 / -10 / -20"	<ul> <li>The pump for the intelligent dosing system is blocked.</li> <li>1. Switch off the appliance.</li> <li>2. Clean the pump unit. <ul> <li>→ "Cleaning the detergent drawer", Page 37</li> </ul> </li> <li>3. Switch the appliance on.</li> <li>4. If the display appears again after you clean the pump unit, call customer service. <ul> <li>→ "Customer Service", Page 54</li> </ul> </li> </ul>					
	Note: You can deactivate and manually dose the intel- ligent dosing system until the fault is rectified. → "Buttons", Page 23					
"H:32"	<ul> <li>The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.</li> <li>Redistribute the laundry in the drum.</li> </ul>					
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.					
"E:30 / -10" and/or 严	The water pressure is low. No remedial action possible.					
	<ul><li>The filters in the water inflow are blocked.</li><li>Clean the filters in the water inflow.</li></ul>					
	The tap is turned off. ► Turn on the tap.					
	<ul> <li>The water inlet hose is kinked or jammed.</li> <li>Ensure that the water inlet hose is not kinked or jammed.</li> </ul>					
	Water level measurement system is defective.					
	<b>Note:</b> With the error message, the appliance starts a draining process.					
	<ol> <li>First wait approx. 5 minutes until the drain process ends.</li> </ol>					

Fault	Cause and troubleshooting				
"E:30 / -10" and/or 严	<ol> <li>To reset the error message, switch the appliance off.</li> <li>Switch the appliance back on.</li> <li>If the error message is displayed again, call customer service.</li> <li>→ "Customer Service", Page 54</li> </ol>				
	<ul> <li>The detergent drawer has not been pushed in fully.</li> <li>Push in the detergent drawer until the symbol goes out.</li> </ul>				
	<ul> <li>The pump unit is not inserted.</li> <li>1. Insert the pump unit into the detergent drawer. → "Cleaning the detergent drawer", Page 37</li> <li>2. Push in the detergent drawer until the symbol goes out.</li> </ul>				
© lights up.	<ul> <li>The temperature is too high.</li> <li>Wait until the temperature has dropped.</li> <li>→ "Cancelling the programme", Page 31</li> </ul>				
	<ul> <li>Water level is too high.</li> <li>Select a suitable programme for draining.</li> <li>→ "Programmes", Page 25</li> </ul>				
© flashes.	<ul><li>Door is not closed.</li><li>Close the door.</li></ul>				
	<ul><li>Laundry is caught in the door.</li><li>Remove any trapped laundry.</li></ul>				
Ċ	Drum cleaning is required. ► → "Cleaning the drum", Page 36				
"E:30/-20"	<ul> <li>Detergent dosage is too high.</li> <li>If you dose manually, reduce the amount of detergent for the next washing cycle with the same load.</li> </ul>				
	<ul><li>Additional water is added.</li><li>Do not add any extra water to the appliance while it is operating.</li></ul>				
	<ul> <li>Solenoid valve defective.</li> <li>Call the after-sales service.</li> <li>→ "Customer Service", Page 54</li> </ul>				

Fault	Cause and troubleshooting				
All other error codes.	<ul> <li>Malfunction</li> <li>1. Switch the appliance off and then on again.</li> <li>2 If the message appears again, disconnect the appliance from the power supply for at least 30 seconds by pulling out the plug or by switching off the relevant circuit breaker in the fuse box.</li> <li>✓ If the fault was a one-off, the message disappears.</li> <li>3. If the message appears again, call the after-sales service. Please specify the exact error message when calling.</li> <li>→ "Customer Service", Page 54</li> </ul>				
The appliance is not working.	<ul><li>The mains plug of the power cord is not plugged in.</li><li>Connect the appliance to the power supply.</li></ul>				
	<ul><li>The circuit breaker in the fuse box has tripped.</li><li>Check the circuit breaker in the fuse box.</li></ul>				
	<ul> <li>There has been a power cut.</li> <li>Check whether the lighting in your room or other appliances are working.</li> </ul>				
The programme does not start.	You have not pressed <b>DII Start/Reload/Pause</b> . ► Press <b>DII Start/Reload/Pause</b> .				
	Door is not closed. ► Close the door.				
	<ul> <li>Childproof lock is activated.</li> <li>▶ Deactivate childproof lock.</li> <li>→ "Deactivating the childproof lock", Page 32</li> </ul>				
	<ul> <li>         เวลาสิ้นสุด Ready In is activated.     </li> <li>         Check whether</li></ul>				
	Laundry is caught in the door. Remove any trapped laundry.				
	<ul><li>The detergent drawer has not been pushed in fully.</li><li>Push in the detergent drawer until the symbol goes out.</li></ul>				
	<ul> <li>The pump for the intelligent dosing system is blocked.</li> <li>1. Switch off the appliance.</li> <li>2. Clean the pump unit. <ul> <li>→ "Cleaning the detergent drawer", Page 37</li> </ul> </li> <li>3. Switch the appliance on.</li> </ul>				

Fault	Cause and troubleshooting				
The programme does not start.	<ul> <li>If the display appears again after you clean the pump unit, call customer service.</li> <li>→ "Customer Service", Page 54</li> </ul>				
	Note: You can deactivate and manually dose the intel- ligent dosing system until the fault is rectified. → "Buttons", Page 23				
The door cannot be opened.	<ul> <li>The temperature is too high.</li> <li>Wait until the temperature has dropped.</li> <li>Cancel the programme.</li> <li>→ "Cancelling the programme", Page 31</li> </ul>				
	<ul> <li>Water level is too high.</li> <li>Select a suitable programme for draining.</li> <li>→ "Programmes", Page 25</li> </ul>				
	<ul> <li>Power failure.</li> <li>Open the door using the emergency release.</li> <li>→ "Emergency release", Page 53</li> </ul>				
The water is not drain- ing.	<ul><li>Drain pipe or water outlet hose is blocked.</li><li>Clean the drain pipe and the water outlet hose.</li></ul>				
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>				
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 38				
	<ul><li>The water outlet hose is connected too high.</li><li>Install the water outlet hose at a maximum height of 1 metre.</li></ul>				
	<ul> <li>Detergent dosage is too high.</li> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down).</li> </ul>				
	<ul> <li>If intelligent dosing is activated, reduce the basic dosage → Page 34.</li> </ul>				
	<ul> <li>If you dose manually, reduce the amount of deter- gent for the next washing cycle with the same load.</li> </ul>				
	Unapproved extension installed on the water drain hose.				
	<ul> <li>Remove any unapproved extensions from the water hose.</li> <li>         "Connecting the appliance" Page 14     </li> </ul>				
	→ "Connecting the appliance", Page 14				

Fault	Cause and troubleshooting				
The water is not drain- ing.	<ul> <li>The pump cap is not fully screwed in.</li> <li>Ensure that the pump cap is screwed in all the way into the appliance. The handle on the pump cap must be in a vertical position.</li> <li>→ "Cleaning the drain pump", Page 40</li> </ul>				
Water is not flowing in. Detergent is not	You have not pressed <b>▷ Start/Reload/Pause</b> . ► Press <b>▷ Start/Reload/Pause</b> .				
being dispensed.	The filters in the water inflow are blocked. ► Clean the filters in the water inflow.				
	The tap is turned off. ► Turn on the tap.				
	<ul> <li>The water inlet hose is kinked or jammed.</li> <li>Ensure that the water inlet hose is not kinked or jammed.</li> </ul>				
The spin cycle runs several times.	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. Not a fault – no action required.				
	<b>Note:</b> When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.				
The programme dura- tion changes during the wash cycle.	<ul><li>The programme operation is optimised electronically.</li><li>This may change the programme duration.</li><li>Not a fault – no action required.</li></ul>				
	<ul> <li>The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry.</li> <li>Not a fault – no action required.</li> </ul>				
	<b>Note:</b> When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.				
	<ul><li>Foam detection system switches on a rinse cycle if foam build-up is too high.</li><li>Not a fault – no action required.</li></ul>				
No water is visible in the drum.	<ul> <li>Water is below the visible area.</li> <li>Not a fault – no action required.</li> <li>Do not add any extra water to the appliance while it is operating.</li> </ul>				
Drum jerks after the programme starts.	<ul><li>This is caused by an internal motor test.</li><li>Not a fault – no action required.</li></ul>				

Fault	Cause and troubleshooting				
Vibrations and move- ment of the appliance	Appliance is not correctly aligned. ► → "Aligning the appliance", Page 16				
whilst spinning.	<ul> <li>The appliance feet are not fixed.</li> <li>Secure the appliance feet.</li> <li>→ "Aligning the appliance", Page 16</li> </ul>				
	Transit bolts have not been removed. ► → "Removing the transit bolts", Page 13.				
Drum rotates, water does not flow in.	Load detection is active. ► Not a fault – no action required.				
	Note: The load detection can take up to two minutes.				
Heavy foam build-up	<ul> <li>Detergent dosage is too high.</li> <li>Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the compartment for manual dosing (not for outdoor clothing, sportswear or items stuffed with down).</li> <li>If intelligent dosing is activated, reduce the basic dosage → Page 34.</li> <li>If you dose manually, reduce the amount of detergent for the next washing cycle with the same load.</li> </ul>				
i-DOS cannot be actuated.	<ul> <li>Intelligent dosing is not intended for this programme.</li> <li>Not a fault – no action required.</li> <li>→ "Starting the programme with intelligent dosing system", Page 32</li> </ul>				
	Programme progress does not allow intelligent dos- ing. No remedial action possible.				
High spin speed not reached.	<ul><li>A low spin speed is selected.</li><li>The next time you run a wash cycle, set a higher spin speed.</li></ul>				
	<ul> <li>ลิตรอยยับ Easy Iron is activated.</li> <li>Select the programmes that are suitable for the type of fabric.</li> </ul>				
	<ul><li>Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.</li><li>Redistribute the laundry in the drum.</li></ul>				
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.				
	<ul> <li>Start the O ปั่นหมาด programme.</li> </ul>				

Fault	Cause and troubleshooting			
The spin programme does not start.	<ul><li>Drain pipe or water outlet hose is blocked.</li><li>Clean the drain pipe and the water outlet hose.</li></ul>			
	<ul> <li>Drain pipe or water drain hose is caught or jammed.</li> <li>Ensure that the drain pipe and water drain hose are not kinked or trapped.</li> </ul>			
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distrib- uted.			
	<ul> <li>Redistribute the laundry in the drum.</li> </ul>			
	<b>Note:</b> Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
	<ul> <li>Start the          <ul> <li>ชั่นหมาด programme.</li> </ul> </li> </ul>			
Rushing, hissing noise.	Water is flushed under pressure into the detergent drawer.			
	<ul> <li>Not a fault – normal operating noise.</li> </ul>			
Longer, whirring noise before the start of the	Intelligent dosing system dispenses detergent or care products.			
wash cycle or fabric softening.	<ul> <li>Not a fault – normal operating noise.</li> </ul>			
Brief whirring noise after switching on the appliance.	<ul><li>Intelligent dosing system carries out a function test.</li><li>Not a fault – normal operating noise.</li></ul>			
Loud noises during the spin cycle.	Appliance is not correctly aligned. ► → "Aligning the appliance", Page 16			
	<ul> <li>The appliance feet are not fixed.</li> <li>► Secure the appliance feet.</li> <li>→ "Aligning the appliance", Page 16</li> </ul>			
	Transit bolts have not been removed. ► → "Removing the transit bolts", Page 13.			
Banging noises, rat- tling in the drain pump.	Foreign bodies have got into the drain pump. ► → "Cleaning the drain pump", Page 38			
Slurping, rhythmical suction noise.	<ul><li>The drain pump is active, the detergent solution is pumped out.</li><li>Not a fault – normal operating noise.</li></ul>			
Creasing.	<ul><li>The spin speed is too high.</li><li>The next time you run a wash cycle, set a lower spin speed.</li></ul>			
	The load is too large.			

Fault	Cause and troubleshooting					
Creasing.	<ul> <li>The next time you run a wash cycle, reduce the</li> </ul>					
oreasing.	amount of laundry being loaded.					
	Unsuitable programme for the type of fabric.					
	<ul> <li>Select the programmes that are suitable for the type of fabric.</li> </ul>					
The spin result is not	A low spin speed is selected.					
satisfactory. The laun- dry is too wet/too	<ul> <li>The next time you run a wash cycle, set a higher</li> </ul>					
damp.	spin speed. ► Start the ⊙ ปันหมาด programme.					
	<ul> <li>อิลตรอยยับ Easy Iron is activated.</li> </ul>					
	<ul> <li>Select the programmes that are suitable for the</li> </ul>					
	type of fabric.					
	Drain pipe or water outlet hose is blocked.					
	Clean the drain pipe and the water outlet hose.					
	<ul><li>Drain pipe or water drain hose is caught or jammed.</li><li>Ensure that the drain pipe and water drain hose are</li></ul>					
	not kinked or trapped.					
	The unbalanced load detection system has interrupted					
	the spin cycle because the laundry is unevenly dis					
	<ul><li>uted.</li><li>Redistribute the laundry in the drum.</li></ul>					
	<b>Note:</b> Where possible, mix large and small items in					
	the drum. Different sized items of laundry distribute					
	themselves better during the spin cycle.					
	<ul> <li>Start the          <ul> <li>ปันหมาด programme.</li> </ul> </li> </ul>					
	Unbalance load detection system is using a reduced					
	<ul><li>spin speed to eliminate an unbalance.</li><li>Redistribute the laundry in the drum.</li></ul>					
	<b>Note:</b> Where possible, mix large and small items in					
	the drum. Different sized items of laundry distribute					
	themselves better during the spin cycle.					
	<ul> <li>Start the O ปั่นหมาด programme.</li> </ul>					
Detergent residue on	Detergents may contain water-insoluble substances					
the damp washing.	that deposit on the laundry. ► Start the 🖙 ด้างน้ำ programme.					
	Unsuitable detergent added to the dispenser of the in-					
	telligent dosing system.					
	1. Check whether the detergent used is suitable.					
	→ "Detergents and care products", Page 29					

Fault	Cause and troubleshooting				
Detergent residue on the damp washing.	<ol> <li>2 Drain the dispenser.         <ul> <li>→ "Cleaning the detergent drawer", Page 37</li> <li>3. Clean the dispenser.</li> </ul> </li> <li>4. Refill the dispenser.         <ul> <li>→ "Filling the dispensers", Page 33</li> </ul> </li> </ol>				
	<ul> <li>Basic dosage is not correctly adjusted.</li> <li>If intelligent dosing is activated, reduce the basic dosage → Page 34.</li> </ul>				
Detergent residue on the dry laundry.	<ul><li>Detergents may contain water-insoluble substances that deposit on the laundry.</li><li>Brush out the laundry after washing and drying.</li></ul>				
	<ul> <li>Unsuitable detergent added to the dispenser of the intelligent dosing system.</li> <li>1. Check whether the detergent used is suitable. → "Detergents and care products", Page 29</li> <li>2. Drain the dispenser. → "Cleaning the detergent drawer", Page 37</li> <li>3. Clean the dispenser.</li> <li>4. Refill the dispenser. → "Filling the dispensers", Page 33</li> </ul>				
	<ul> <li>Basic dosage is not correctly adjusted.</li> <li>If intelligent dosing is activated, reduce the basic dosage → Page 34.</li> </ul>				
Insufficient cleaning.	<ul> <li>Basic dosage not adjusted.</li> <li>If intelligent dosing is activated, adjust the basic dosage → Page 34.</li> </ul>				
	<ul> <li>Detergent or care products have congealed in dispensers of the intelligent dosing system.</li> <li>1. Check whether the detergent used is suitable. <ul> <li>→ "Detergents and care products", Page 29</li> </ul> </li> <li>2. Drain the dispenser. <ul> <li>→ "Cleaning the detergent drawer", Page 37</li> </ul> </li> <li>3. Clean the dispenser.</li> <li>4. Refill the dispenser. <ul> <li>→ "Filling the dispensers", Page 33</li> </ul> </li> </ul>				
	<ul> <li>Unsuitable detergent added to the dispenser of the intelligent dosing system.</li> <li>1. Check whether the detergent used is suitable. → "Detergents and care products", Page 29</li> <li>2. Drain the dispenser. → "Cleaning the detergent drawer", Page 37</li> </ul>				

Fault	Cause and troubleshooting			
Insufficient cleaning.	<ol> <li>Clean the dispenser.</li> <li>Refill the dispenser.         <ul> <li>→ "Filling the dispensers", Page 33</li> </ul> </li> </ol>			
Water is leaking out at the water inlet hose.	<ul> <li>Water inlet hose is not correctly/securely connected.</li> <li>1. Connect the water supply hose correctly.</li> <li>→ "Connecting the water inlet hose", Page 14</li> <li>2. Tighten the screw connection.</li> </ul>			
Water is leaking out at the water outlet hose.	<ul><li>The water outlet hose is damaged.</li><li>Replace the damaged water outlet hose.</li></ul>			
	<ul> <li>Water outlet hose is not connected correctly.</li> <li>Connect the water outlet hose correctly.</li> <li>→ "Water outlet connection types", Page 15</li> </ul>			
Odours have formed in the appliance.	<ul> <li>Humidity and detergent residue may promote the formation of bacteria.</li> <li>→ "Cleaning the drum", Page 36</li> <li>If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate.</li> </ul>			
Water is leaking from below the door.	<ul><li>Dirt on the door or seal causes leaks.</li><li>Clean the door and the seal.</li></ul>			


### 18.1 Emergency release

#### **Releasing the door**

**Requirement:** The drain pump is empty.  $\rightarrow$  *Page 38* 

- 1. **ATTENTION!** Escaping water may cause material damage.
- Do not open the door if you can see water through the glass.

Pull the emergency release downwards with a tool and release.



- ✓ The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

### 19 Transportation, storage and disposal


### 19.1 Removing the appliance

- 1. Turn off the tap.
- 2. Empty the water inlet hose.
- Switch off the appliance.
   → "Switching off the appliance", Page 31
- 4. Unplug the appliance's mains plug.
- Drain the water.
   → "Cleaning the drain pump", Page 38
- 6. Detach the hoses.
- 7. Empty the dispensers.

# 19.2 Inserting the transit bolts

Secure the appliance before transportation using transit bolts in order to prevent transport damage.

**1.** Use a screwdriver to remove the 4 cover caps.



Keep the cover caps.

 2 Insert the 4 transit bolts.
 → "Removing the transit bolts", Page 13

# 19.3 Using the appliance again

For further information, see
 → "Installation and connection",
 Page 12 and
 → "Starting an empty washing
 cycle", Page 19.

### 19.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

# MARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- Dispose of the appliance in an environmentally friendly manner.
   Information about current disposal methods are available from your specialist dealer or local authority.

X

This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

# 20 Customer Service

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

### 20.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

## 21 Consumption values

The indicated consumption values are approximate.

The values may deviate from the indicated values depending on water pressure, water hardness, water inlet temperature, room temperature, type of laundry, amount and soiling of laundry, detergent used, fluctuations in the mains voltage and selected settings.

Programme	Temperat- ure (°C)	Load (kg)	Energy consump- tion (kWh) <sup>1</sup>	Water con- sumption (I) <sup>1</sup>	Pro- gramme duration (h:min) <sup>1</sup>
ผ้าฝ้าย î	20	10.0	0.400	90.0	3:45
ผ้าฝ้าย î	40	10.0	1.150	90.0	3:30
ผ้าฝ้าย î	60	10.0	1.550	90.0	3:15
ผ้าฝ้าย î	90	10.0	2.750	106.0	3:00
ผ้าสังเคราะห์ 🕁	40	4.0	0.850	65.0	2:30
ผ้าหลายชนิด 🕻 🕅	40	4.0	0.660	45.0	1:15
ผ้าบอบบาง/ผ้า ไหม ⊑็∞	30	2.0	0.250	37.0	0:45
์ ซักถนอมผ้าขน สัตว์ ®	30	2.0	0.350	41.0	0:45

<sup>1</sup> values determined according to the valid version of IEC60456

## 22 Technical data

Appliance height	84.8 cm
Appliance width	59.8 cm
Appliance depth	59.0 cm
Appliance depth with door closed	63.6 cm
Appliance depth with door open	107.3 cm
Weight	81.3 kg
Maximum load	10.0 kg
Mains voltage	220-240 V, 50 Hz

Hinimum in- stallation protec- tion	10 A
Nominal power	1900-2300 W
Water pressure	<ul> <li>Minimum: 100 kPa (1 bar)</li> <li>Maximum: 1000 kPa (10 bar)</li> </ul>
Length of the wa- ter inlet hose	150 cm
Length of the wa- ter outlet hose	150 cm
Length of the power cord	210 cm



# Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- Expert tips & tricks for your appliance
- Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome** 

#### BOSCH HOME APPLIANCES SERVICE

# Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: **www.bosch-home.com/service** 

Contact data of all countries are listed in the attached service directory.

#### BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com

A Bosch Company

