



Washing machine

WGA256BGHK

[en]

User manual and installation instructions

Further information and explanations are available online:



Table of contents

1 Safety	
1.1 General information	
1.2 Intended use	
1.3 Restriction on user group	
1.5 Safe use	
1.6 Safe cleaning and mainten-	. /
ance	. 9
2 Preventing material damage	10
3 Environmental protection and	
saving energy	11
3.1 Disposing of packaging	11
3.2 Save energy and conserve resources	11
3.3 Energy saving mode	11
4 Installation and connection 4.1 Unpacking the appliance	12 12
4.2 Contents of package	12
4.3 Requirements for the install-	12
ation location	12
4.4 Removing the transit bolts	13
4.5 Removing the transport	4 1
struts	14 15
4.7 Aligning the appliance	16
	. 0
5 Familiarising yourself with your appliance	18
5.1 Appliance	18
5.2 Detergent drawer	18
5.3 Control panel	19
6 Before using for the first time	20
6.1 Starting an empty washing	20
cycle	20

7 Display	21
B Buttons	23
Programmes	25
10 Accessories	28
I1 Laundry 11.1 Preparing the laundry	28 28
12 Detergents and care products	28
13.1 Switching on the appliance 13.2 Setting a programme	29 29 29 29 30 30 31 31 31 31
ance	32

			en
14 Childproof lock	32	21 Consumption values	54
14.1 Activating the childproof lock	32	22 Technical data	54
14.2 Deactivating the childproof lock	32		
15 Home Connect	32		
15.1 Setting up the Home Connect app			
15.3 Activating Wi-Fi on the appliance	33		
15.4 Deactivating Wi-Fi on the appliance	33		
network settings	34 34		
16 Basic settings	35		
17 Cleaning and servicing			
17.1 Cleaning the drum 17.2 Cleaning the detergent			
drawer			
ing in the rubber gasket	40		
18 Troubleshooting 18.1 Emergency release			
19 Transportation, storage and disposal	51 51		
20 Customer Service	52		

20.1 Product number (E-Nr.) and production number (FD)...... 52
20.2 AQUA-STOP guarantee..... 52



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- with tap water and commercially available detergents and care products suitable for washing machines.
- in private households and in enclosed spaces in a domestic environment.
- up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Incorrect installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ▶ The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ► When using a residual current circuit breaker, only use a type with the am mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ▶ When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edaes.
- ▶ Never kink, crush or modify the power cord.

⚠ WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ▶ Only use adapters and power cords approved by the manufacturer.
- ▶ If the power cord is too short and a longer one is not available. please contact an electrician to have the domestic installation adapted.

⚠ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- ► Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

△ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material.

⚠ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

▶ Do not touch the sharp edges on the appliance.

Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer services. → Page 52

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

△ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

△ WARNING – Risk of explosion!

Laundry that has been pretreated with cleaning agents that contain solvents may cause an explosion in the appliance.

► Rinse pretreated laundry thoroughly with water before washing.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

Wait for the drum to come to a complete stop before reaching inside.

△ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

▶ Do not touch the hot detergent solution.

△ CAUTION – Risk of injury!

This appliance runs programmes that use active oxygen. Active oxygen can cause eyes to water and irritate the mucosa.

- ▶ Do not open the appliance door using the emergency release if a programme is running with active oxygen.
- ▶ Wait for the appliance door to be released.

△ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- ► Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

△ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appli-

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 25 The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.
- Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- Before transport, fit the transit bolts fully in order to prevent damage in

Material damage may be caused if the water inlet hose is connected incorrectly.

- Tighten the screw connections on the water inlet until they are handtight.
- Connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions or valves.
- Make sure that the valve housing for the water inlet hose does not come into contact with its surroundings and is not subjected to any external forces.
- Ensure that the inner diameter of the water tap is at least 17 mm.

Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- ► Ensure that the water pressure in the water supply system is at least 100 kPa (1 bar) and max. 1000 kPa (10 bar).
- ▶ If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- ► Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may lead to material damage and damage to the appliance.

 Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- ▶ Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.

 Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

Choose programmes with low temperatures and longer wash times and use maximum load capacity.

Energy consumption and water consumption is most efficient.

Use the economy programme settings.

✓ If you adjust the programme settings for a programme, the display shows the expected consumption.

Add detergent based on the laundry's degree of soiling.

 For light to normal soiling, a smaller amount of detergent is sufficient. Observe the dosage recommendation from the detergent manufacturer.

Reduce the washing temperature for lightly and normally soiled laundry.

✓ At lower temperatures, the appliance consumes less energy. For light to normal soiling, lower temperatures than indicated on the care label are also sufficient.

Set the maximum spin speed if you want to dry the laundry in the tumble dryer afterwards.

 ✓ The drier the laundry, the shorter the programme duration when drying which, in turn, reduces energy consumption. A higher spin speed reduces the residual moisture in the laundry and increases the volume of the spin noise.

Wash the laundry without prewash.

 Washing with prewash increases the programme duration and increases energy and water consumption.

The appliance has a continuous automatic load adjustment function.

✓ Depending on the type of fabric and load capacity, the continuous automatic load adjustment function optimally adjusts the water consumption and programme duration.

3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. Energy-saving mode ends when you use the appliance again. If you do not continue operating the appliance, it switches off.

Note: If Wi-Fi is activated, the appliance will not switch itself off automatically.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- 1. Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 11
- 2. Check the appliance for visible damage.
- 3. Open the door.
- 4. Remove any accessories from the drum.
- 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories. the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

▶ Do not operate the appliance with incomplete or defective accessories.

- ► Replace the accessories in question before operating the appliance.
 - → "Accessories", Page 28

Note: The appliance has been tested at the factory to check it is in working order. As a result, water stains may remain in the appliance. These marks will disappear after the first wash cycle.

The delivery consists of the following:

- Washing machine
- Accompanying documents
- Transit bolts
 - → "Removing the transit bolts", Page 13
- Cover caps
- Elbow for securing the water outlet hose

4.3 Requirements for the installation location

. WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

▶ Do not operate the appliance without a cover cap.

⚠ WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 28 before using the appliance for the first time.

ATTENTION!

If residual water in the appliance freezes, this may cause damage to the appliance.

▶ Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- ► Tilt the appliance carefully.
- Transport the appliance in an upright position.

Installation loca- Requirements tion

Base



Secure the appliance with fixing brackets


→ Page 28.

Wooden joist floor




Place the appliance on a waterresistant wooden board (minimum thickness of 30 mm) which is screwed tightly to the floor.

Kitchen unit



Only install the appliance underneath a continuous worktop that is securely connected to adjacent cabinets. Required niche width: 60 cm.

Against a wall



Do not trap the power cord or the hoses between the wall and the appliance.


4.4 Removing the transit bolts

The appliance is secured for transportation using transit bolts on the rear of the appliance.


Note: Keep the transit bolt screws and the sleeves in a safe place for future transport.

→ "Inserting the transit bolts", Page 51

1. Pull the hoses out of the holders.



2. Unscrew 1) and remove 2 all of the screws for the 4 transit bolts using a WAF 13 wrench.




en Installation and connection

holder.




4. Remove the 4 sleeves.



5. Put on the 4 cover caps.




3. Remove the power cable from the 6. Push the 4 cover caps downwards.




Note: To install the transit bolts to transport the appliance, perform these steps again in the reverse order.

4.5 Removing the transport struts


1. Unscrew and remove the screws in the vertical transport struts using a T20 screwdriver.




2. Remove the transport struts.



3. Undo and remove the screws in the horizontal transport strut using a T20 screwdriver



4. Remove the transport strut.




4.6 Connecting the appliance Connecting the water inlet hose

WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

- ► Do not immerse the electrical AquaStop valve in water.
- 1. Connect the water inlet hose to a tap (26.4 mm = 3/4").



2. Open the water tap carefully and check that the connection points are tight.

Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.

ATTENTION!

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

Secure the water outlet hose against unintentional loosening.


Note: Observe the draining heights. The maximum draining height is 100 cm.

Siphon




Secure the connection point with a (24–40 mm) hose clamp.

Sink



Fix and secure the water outlet hose with an elbow.

Plastic pipe with rubber sleeve or gully



Fix and secure the water outlet hose with an elbow.

Connecting the appliance to the electricity supply

Note: Your electrical domestic installation for this appliance must comply with the local legal provisions and safety regulations, and should include a residual current circuit-breaker.

 Insert the mains plug of the appliance's power cable in a socket nearby.


The connection details of the appliance can be found under Technical data \rightarrow *Page 54*.

2. Check the mains plug is inserted properly.


4.7 Aligning the appliance

In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

 Use a WAF 17 wrench to loosen the lock nuts in a clockwise direction




To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

3. Use a WAF 17 wrench to tighten the lock nuts against the housing until they are hand-tight.




In doing so, hold the foot tight and do not adjust its height.

5 Familiarising yourself with your appliance

5.1 Appliance

You can find an overview of the parts of your appliance here.



On certain models, specific details such as the colour and shape may differ from those pictured.


- Maintenance flap for the drain pump → Page 37 Door
- Detergent drawer → Page 18
- Control panel → Page 19
- 5 Water outlet hose → Page 15
- Transport struts → Page 14
- Power cord → Page 16

- Transit bolts → Page 13
- Water inlet hose → Page 15

5.2 Detergent drawer

Note: Observe the manufacturer's instructions on the use and dosage of the detergent and care product and the information in the programme descriptions.


→ "Programmes", Page 25



- Measuring aid for liquid deter-→ "Inserting the measuring aid for liquid detergent", Page 29
- Dispenser II: detergent for the main wash
- Compartment &: Fabric softener
- Compartment I: Detergent for prewash

5.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- Programmes → Page 25
- Programme selector → Page 29
- Buttons → Page 23
- Display → Page 21


6 Before using for the first time

Prepare the appliance for use.

6.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

- 1. Press ①.
 - The switch-on process takes a few seconds.
- 2. Set the **Drum Clean** programme.
- 3. Close the door.
- 4. Pull out the detergent drawer.
- Add washing powder that contains a bleaching agent to compartment II.




To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

- 6. Push in the detergent drawer.
- **7.** Press **Start/Reload D I** to start the programme.
- The display shows the remaining programme duration.

- ✓ After the programme has ended, the display shows: -0-.
- 8. Start the first wash cycle or press ① to switch off the appliance.
 - → "Basic operation", Page 29

7 Display

The display shows the current settings, options or relevant information.



Example: Display

Display	Description
0:40 1	Expected programme duration or programme time remaining in hours and minutes.
10h ¹	Program end time → "Buttons", Page 23
10.0 1	Recommendation for the maximum load capacity for the selected program in kg.
□ - 1600	Set spin speed in rpm. → "Buttons", Page 23 0: No final spin, only draining □: Rinse Hold, no draining
* - 90	Set temperature in °C. → "Buttons", Page 23 If (cold)
	Prewash Programme status
**	Active oxygen treatment Programme status
	Wash Programme status
¹ Example	

en Display

Display	Description
	Rinse Programme status
<u>©</u>	Spin Programme status
-P-	Pause Programme status
-0-	Program end Programme status
Cm	 Lights up: The childproof lock is activated. Flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 32
10	Energy consumption for the selected programme. — : Low energy consumption — : High energy consumption
O	Water consumption for the selected programme. - Low water consumption - Low water consumption
Ŕ	 Lights up: The appliance is connected to your home network via Wi-Fi. Flashes: The appliance is trying to connect to your home network via Wi-Fi.
	→ "Home Connect ", Page 32
ტ"	The appliance is connected to the smart energy system (energy manager).
<u> </u>	Active oxygen treatment is activated.
⊕ and ©	A programme with active oxygen treatment has been interrupted and the door is locked until the active oxygen has been removed. Note: It may take up to 25 minutes for the active oxygen to be removed
******	The appliance has detected too much foam.
(D)	The door is unlocked and can be opened.
是	No water pressure.The water pressure from the tap is too low.
E:35 / -10 ¹	Error code, error display, signal. → "Troubleshooting", Page 41
¹ Example	

8 Buttons

The selection of programme settings depends on the programme that is set.

Button	Selection	More information
Start/Reload ▷M	StartCancelPause	Start, cancel or pause the programme.
SpeedPerfect =♡	ActivateDeactivate	Activate or deactivate a shorter programme duration. Note: Energy consumption increases. The washing result is not affected by this.
Intensive Plus ®	ActivateDeactivate	Activate or deactivate an extended washing programme. The programme duration is extended by up to 30 minutes. Suitable for heavily soiled laundry.
③ Active Oxygen	ActivateDeactivate	Activate or deactivate active oxygen treatment. Active oxygen is a special type of oxygen which effectively reduces odours. Active oxygen does not remove stains or sweat odours.
- Finish in (9 +	Up to 24 hours	Set the programme end time. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
Temp. &	₩ - 90	Adjust the temperature. Set temperature in °C.
Spin ©	₩ - 1600	Adjust the spin speed or activate (Rinse Hold). Set spin speed in rpm. If is selected, the water is not drained at the end of the washing cycle and the spin cycle is deactivated. The laundry remains in the rinsing water.
① (mains switch)	Switch onSwitch off	Switch the appliance on or off.

en Buttons

Button	Selection	More information
Remote Start □*	ActivateDeactivateOpen the Home Connect menu	→ "Remote start", Page 34
Child Lock C 3 sec.	ActivateDeactivate	→ "Childproof lock", Page 32
Spin ©	Multiple selection	→ "Basic settings", Page 35
Pre-wash <pre>₺</pre>	ActivateDeactivate	Activate or deactivate prewash, e.g. for washing heavily soiled laundry.
Extra Rinse 🖶	ActivateDeactivate	Activate or deactivate an additional rinse cycle. Recommended for particularly sensitive skin or in regions with very soft water.

9 Programmes

Note: The laundry's care labels provide you with additional information on programme selection.

Programme	Description	Max. load (kg)
Cottons 12	Wash hard-wearing items made of cotton, linen or blended fabrics. Also suitable as a short programme for normally soiled laundry when you activate SpeedPerfect =♥. Programme setting: • Max. 90 °C • Max. 1600 rpm	10.0 5.0 ¹
Cottons Eco €	Wash hard-wearing items made of cotton, linen or blended fabrics. Energy-saving programme. Note: To save energy, the actual washing temperature may deviate from the set washing temperature. The washing performance meets legal requirements. Programme setting: Max. 90 °C Max. 1600 rpm	10.0
Synthetics ம்	Wash items made from synthetic or blended fabrics. Programme setting: ■ Max. 60 °C ■ Max. 1200 rpm	4.0
Mix »%	Wash items made from cotton, linen, or synthetic or blended fabrics. Suitable for lightly soiled laundry. Programme setting: Max. 60 °C Max. 1600 rpm	4.0
Delicates/	cose and synthetic fabrics. Use a detergent that is suitable for delicates or silk. Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag.	2.0
SpeedPerfectWashing not p		

en Programmes

Programme	Description	Max. load (kg)
	Programme setting: Max. 40 °C Max. 800 rpm	
	Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool. Programme setting: Max. 40 °C Max. 800 rpm	2.0
Rinse	Rinse and then spin the laundry, and drain the water. Programme setting: Max. 1600 rpm	-
©₩ Spin/Drain	Spin and drain the water. If you only want to drain the water, activate 0. The laundry is not spun. Programme setting: Max. 1600 rpm	_
♣ AllergyPlus	Wash hard-wearing items made from cotton, linen or blended fabrics. Suitable for allergy sufferers and for strict hygiene requirements. Note: Once the set temperature has been reached, it remains constant throughout the entire washing process. Programme setting: Max. 60 °C Max. 1600 rpm	6.5
	Wash non-iron shirts and blouses made from cotton, linen, or synthetic or blended fabrics. Note: Use the Delicates/Silk programme to wash shirts and blouses made from silk or delicate fabrics. Programme setting: Max. 60 °C Max. 800 rpm	2.0
មិ Sportswear	Wash sports and leisure items made from synthetic fibres, microfibre or fleece. Use a detergent that is suitable for sports items.	2.0
SpeedPerfectWashing not p		

Description	Max. load (kg)
Do not use fabric softener. Tip: Use the Synthetics & programme to wash heavily soiled laundry. Programme setting: ■ Max. 40 °C ■ Max. 800 rpm	
Clean and care for the drum. Cleaning programme with active oxygen. Use this programme in the following cases: ■ Before using the appliance for the first time ■ If you regularly wash at temperatures of 40 °C or lower ■ After a prolonged period of non-use Use washing powder that contains bleach. Add the washing powder containing bleach to compartment II for the main wash. → "Detergent drawer", Page 18	_2
Halve the amount of detergent to avoid foaming. Do not use fabric softener. Do not use liquid detergent or detergent that is intended for woollens or delicates.	
Wash items made from cotton, or synthetic or blended fabrics. Short programme for small items of lightly soiled laundry. The programme duration is approx. 30 minutes. If you wish to reduce the programme duration to 15 minutes, activate SpeedPerfect = The maximum load is reduced to 2.0 kg. Programme setting: Max. 40 °C Max. 1200 rpm	4.0 2.0 ¹
For all washable items and for items that are suitable for professional cleaning only. Programme for freshening up dry laundry or removing odours, e.g. cigarette or kitchen odours. Dry the drum with a cloth before loading the laundry. Tip: The programme does not remove stains or sweat odours.	1.0
	Do not use fabric softener. Tip: Use the Synthetics & programme to wash heavily soiled laundry. Programme setting: ■ Max. 40 °C ■ Max. 800 rpm Clean and care for the drum. Cleaning programme with active oxygen. Use this programme in the following cases: ■ Before using the appliance for the first time ■ If you regularly wash at temperatures of 40 °C or lower ■ After a prolonged period of non-use Use washing powder that contains bleach. Add the washing powder containing bleach to compartment ll for the main wash. → "Detergent drawer", Page 18 Halve the amount of detergent to avoid foaming. Do not use fabric softener. Do not use liquid detergent or detergent that is intended for woollens or delicates. Wash items made from cotton, or synthetic or blended fabrics. Short programme duration is approx. 30 minutes. If you wish to reduce the programme duration to 15 minutes, activate SpeedPerfect = □. The maximum load is reduced to 2.0 kg. Programme setting: ■ Max. 40 °C ■ Max. 1200 rpm For all washable items and for items that are suitable for professional cleaning only. Programme for freshening up dry laundry or removing odours, e.g. cigarette or kitchen odours. Dry the drum with a cloth before loading the laundry. Tip: The programme does not remove stains or

10 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order num- ber
Water inlet hose extension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Liquid detergent in- sert	Measure liquid detergent.	00605740
Washing machine cleaners	Cleaning products for maintaining the appliance interior.	00311929

11 Laundry

To remove odours, you can also simply freshen up fabrics using active oxygen.

11.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, Velcro fasteners, hooks and eyes
- Tie cloth belts, cloth straps and cords together
- Remove curtain fittings and lead strips
- Wash small or particularly delicate items in a mesh washing bag

- Wash large and small items of laundry together
- Wash laundry with fresh stains immediately
- Pretreat laundry with dried stains and wash several times
- Load the laundry unfolded into the drum

12 Detergents and care products

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- When using liquid detergents, only use liquid detergents that are selfflowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances
- Use dyes sparingly as salt may damage stainless steel

Do not use color-bleaching agents in the appliance

13 Basic operation

13.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected.

- → "Installation and connection", Page 12
- Press ①. The switch-on process takes a few seconds.

Note: The lighting for the drum goes out automatically.

13.2 Setting a programme

- 1. Turn the programme selector and set the required programme. → "Programmes", Page 25
- 2. If required, adjust the programme settings.
 - → "Adjusting the programme settings", Page 29

13.3 Adjusting the programme settings

Requirement: A programme has been set.

- → "Setting a programme". Page 29
- Adjust the programme settings. → "Buttons". Page 23

Note: The programme settings are not saved permanently for the programme.

13.4 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes. → "Programmes", Page 25


Requirements

- The laundry is prepared and sor-
 - → "Laundry", Page 28
- The drum is empty.
- 1. Open the door.
- 2. Place the laundry in the drum.
- 3. Close the door. Ensure that there is no laundry trapped in the door.


13.5 Inserting the measuring aid for liquid detergent

If you order the measuring aid as an accessory, you must use the measuring aid.

- 1. Pull out the detergent drawer.
- 2. Press down on the insert and remove the detergent drawer.



3. Insert the measuring aid.




4. Insert the detergent drawer.


13.6 Use the measuring aid for liquid detergent

To add liquid detergent, you can use a measuring aid in the detergent drawer.

- 1. Pull out the detergent drawer.
- 2. Slide the measuring aid forwards.



3. Fold the measuring aid down and click it into place.



4. Push in the detergent drawer.

13.7 Adding detergent and care product

Notes

- Do not use the measuring aid for liquid detergent for gel detergents, washing powder, or if Prewash or "Ready in" time are activated.
- Observe the information about detergents and care products
 → Page 28.
- **1.** Pull out the detergent drawer.
- 2. Pour in detergent.
 - → "Detergent drawer", Page 18
- 3. If required, add the care product.
- 4. Push in the detergent drawer.

13.8 Starting the programme

Requirement: A programme is set. → "Setting a programme", Page 29

- ▶ Press Start/Reload DM.
- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- The display shows the programme duration or the programme end time

- ✓ If you start a programme with active oxygen, the mist generated may be visible in the illuminated drum
- After the programme has ended, the display shows: **-0-**.

13.9 Soaking laundry

Note: No additional detergent is reguired. The washing solution is then used for washing.

- 1. Start the programme.
- 2. To pause the programme, after approx. 10 minutes, press Start/Reload DM
- 3. To resume the programme, after the desired soaking time, press Start/Reload DM.

13.10 Adding laundry

After the programme starts, you can remove or add laundry depending on the programme status.

Note: If you a start a programme with active oxygen, you cannot add any laundry after the programme has started.

 Press Start/Reload DM. The appliance pauses.

Note: If you want to add laundry, follow the instructions on the displav.

- → "Display", Page 22
- 2. Open the door.
- 3. Add or remove laundry.
- Close the door.
- Press Start/Reload DM.

13.11 Cancelling the programme

Note: If you cancel a programme with active oxygen, the door will remain locked for up to 25 minutes un-

til there is no longer any active oxygen in the drum. On and Of flash while the active oxygen is being removed. The door is then unlocked.

- 1. Press Start/Reload DM.
- 2. Open the door.

The appliance door remains locked for safety reasons if the temperature and water levels are hiah.

- If the temperature is high, start the Rinse programme.
- If the water level is high, start the © Spin programme or select a suitable programme for drain-
 - → "Programmes", Page 25
- 3. Remove the laundry.
 - → "Unloading the laundry", Page 31

13.12 Resuming the programme when the programme status is Rinse Hold

Requirements

- Rinse Stop is activated. → "Buttons", Page 23
- The last rinse cycle of the set programme has ended and the laundry is in the rinsing water.
- 1. Set the **Spin** programme or a programme for draining the water. → "Programmes", Page 25
- Press Start/Reload DM.

13.13 Unloading the laundry

- 1. Open the door.
- 2. Remove the laundry from the drum.

13.14 Switching off the appliance

- 1. Press ①.
- 2. Wipe the rubber gasket dry and remove any foreign objects.



3. Leave the appliance door and detergent drawer open so that residual water can evaporate.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof lock

- ► Press and hold the two Child Lock C= 3 sec. buttons for approx. 3 seconds.
- ▼ The display shows Cm.
- ▼ The control elements are locked.
- The childproof lock remains active even after the appliance has been switched off and in the event of a power cut.

14.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

- ► Press and hold the two Child Lock C= 3 sec. buttons for approx. 3 seconds.
 - So that the programme currently running is not cancelled, the programme selector must be set to the initial programme.
- ✓ come goes out in the display.

15 Home Connect

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: www.home-connect.com.

The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

Tips

- Please consult the documents supplied by Home Connect.
- Please also follow the instructions in the Home Connect app.

Notes

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app. → "Safety", Page 4
- Operating the appliance on the appliance itself always takes priority.
 During this time it is not possible to operate the appliance using the Home Connect app.

15.1 Setting up the **Home Connect app**

1. Install the Home Connect app on your mobile device.



2. Start the Home Connect app and set up access for Home Connect. The Home Connect app guides you through the entire login process.

15.2 Setting up Home Connect

Requirements

- The Home Connect app has been installed on your mobile device.
- Wi-Fi has been activated on the router.
- The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.
- 1. Use the Home Connect app to scan the QR code.



2. Follow the instructions in the Home Connect app.

15.3 Activating Wi-Fi on the appliance

Note: When Wi-Fi is activated, the energy consumption increases in comparison to the values specified in the consumption value table.

- **1.** Press and hold **Remote Start** \Box for approx. 3 seconds.
- **2.** Set the programme to position 4.
- ✓ The display shows Con.
- 3. Press Start/Reload DII repeatedly until the display shows **On**.
- ✓ Wi-Fi is activated.

Note: If Wi-Fi is activated, the appliance will not switch itself off automatically.

15.4 Deactivating Wi-Fi on the appliance

- 1. Press and hold **Remote Start** T for at least three seconds.
- **2.** Set the programme to position 4.
- ✓ The display shows Con.
- 3. Press Start/Reload D nepeatedly until the display shows **OFF**.
- Wi-Fi is deactivated.

Note: The connection is automatically re-established when the Wi-Fi is switched back on.

15.5 Resetting the appliance network settings

- 1. Press and hold **Remote Start** \cap for at least 3 seconds.
- 2. Set the programme to position 5.
- ✓ The display shows rES.

Apple App Store und the Apple App Store logo are trademarks of Apple Inc. Google Play and the Google Play logo are trademarks of Google LLC.

- 3. Press Start/Reload DII.
- The display shows YES.
- 4. Press Start/Reload DI.
- The network settings are reset.
- If End is shown on the display, the network settings are reset.

15.6 Remote start

Enable the appliance for remote start via the Home Connect app.

Note

Remote start is deactivated for safety reasons in the following circumstances:

- The appliance door is opened.
- Start/Reload DII is pressed.
- Remote Start 🖺 is pressed.
- The appliance is switched off.
- Following a power cut.

Activating remote start

Requirements

- The appliance is connected to your home WiFi network.
- The appliance is connected to the Home Connect app.
- A programme is selected.
- The appliance door is closed.
- ► Press Remote Start 🗇.
- → Remote Start

 illights up and the appliance is enabled for remote start via the Home Connect app.

Deactivating remote start

- ► Press Remote Start 🗇.
- ✓ Remote Start

 goes out.

15.7 Remote diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance.

Tip: For further information and details about the availability of Remote Diagnostics in your country, please visit the service/support section of your local website: www.home-connect.com.

15.8 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the Wi-Fi communication module installed).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous reset to factory settings.


This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

Note: Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

16 Basic settings

You can configure the basic settings for your appliance to meet your needs.


16.1 Overview of basic settings



Basic setting	Programme position	Value	Description
End signal	2	0 (off) 1 (quiet) 2 (medium) 3 (loud) 4 (very loud)	Set the volume of the signal at the end of the pro- gramme.
Button signal	3	0 (off) 1 (quiet) 2 (medium) 3 (loud) 4 (very loud)	The volume of the audible signal emitted when the buttons are pressed.
Drum cleaning reminder	4	On OFF	Activate or deactivate the reminder to clean the drum.

16.2 Changing the basic settings

1. Set the programme selector to position 1.



- 2. Press **Spin** © and, at the same time, turn the programme selector to position 2.
- The display shows the current value.
- **3.** Set the programme selector to the required position.
 - → "Overview of basic settings", Page 35
- 4. To change the value, press / +.
- **5.** To save the changes, switch off the appliance.

17 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

17.1 Cleaning the drum

⚠ CAUTION Risk of injury!


Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.

- Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- ► Run the **Drum Clean** programme without laundry and with a cleaning agent for caring for the inside of the appliance
 - → "Accessories", Page 28 or with washing powder that contains bleach.


17.2 Cleaning the detergent drawer

1. Pull out the detergent drawer.


2. Press down on the insert and remove the detergent drawer.




3. Pull out the insert upwards.



4. Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and click it into place.



6. Clean the opening for the detergent drawer.



7. Push in the detergent drawer.

17.3 Cleaning the drain pump


Clean the drain pump regularly, at least once a year, as well as in the event of faults, e.g. blockages or rattlina noises.

Emptying the drain pump


- 1. Turn off the tap.
- 2. Switch off the appliance. → "Switching off the appliance", Page 32
- 3. Disconnect the appliance's mains plug from the power supply.

en Cleaning and servicing


4. Open and remove the maintenance flap.



5. Slide a sufficiently large container under the opening.




6. Take the drain hose out of the holder.




- ► Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



8. Firmly press on the sealing cap.




9. Insert the drain hose into the holder.




Cleaning the drain pump

Requirement: The drain pump is empty. → Page 37

- 1. Since water may remain in the drain pump, unscrew the pump cap carefully.
 - The filter insert in the pump housing may become stuck due to coarse particles of dirt. Loosen the dirt and remove the filter insert




2. Clean the interior, the thread on the pump cap and the pump housing.




The pump cap is comprised of two parts which can be taken apart for cleaning.


3. Ensure that both impellers can turn.



- 4. Insert the pump cap.
 - Ensure that the parts of the pump cap are correctly assembled.




5. Screw the pump cap as far as it will go.



The handle on the pump cap must be in a vertical position.

- en Cleaning and servicing
- **6.** Insert and close the maintenance flap.




17.4 Cleaning the intake opening in the rubber gasket

Regularly check the intake opening in the rubber gasket for any blockages and clean the intake opening.

1. Open the appliance door.

2. Remove any blockages from the intake opening.



Note: Do not use any sharp or pointed objects.

18 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.



. WARNING

Risk of electric shock!

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ► If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting			
The display goes out and Start/Reload DIII flashes.	Energy-saving mode is active ► Press Start/Reload DW. - The symbol lights up again			
	→ The symbol lights up again.			
"E:30 / -80"	Drain pipe or water outlet hose is blocked.▶ Clean the drain pipe and the water outlet hose.			
	 Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped. 			
	The water outlet hose is connected too high. ► Install the water outlet hose at a maximum height of 1 metre.			
	Unapproved extension installed on the water drain hose. ► Remove any unapproved extensions from the water hose. → "Connecting the appliance", Page 15			
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 37			
	Pump cover is not correctly assembled. Correctly assemble the pump cover.			
	 The pump cap is not fully screwed in. Ensure that the pump cap is screwed in all the way into the appliance. The handle on the pump cap must be in a vertical position. 			
	Detergent dosage is too high.			

Fault	Cause and troubleshooting		
"E:30 / -80"	 Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into compartment II (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load. 		
F.00 / 05 / 00			
"E:36 / -25 / -26"	Drain pump is blocked. ► → "Cleaning the drain pump", Page 37.		
"E:38 / -25 / -26"	 Drain pump is blocked. → "Cleaning the drum", Page 36 if the fault is displayed again, → "Cleaning the drain pump", Page 37 		
	Inlet opening of the rubber gasket is blocked. ► → "Cleaning the intake opening in the rubber gasket", Page 40		
"E:60 / -2B"	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. • Redistribute the laundry in the drum.		
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
"E:30 / -10" and/or 凸	The water pressure is low. No remedial action possible.		
	The filter in the water inflow is blocked. Clean the water inflow filter.		
	The tap is turned off. ► Turn on the tap.		
	The water inlet hose is kinked or jammed. ► Ensure that the water inlet hose is not kinked or jammed.		
	Water level measurement system is defective.		
	Note: With the error message, the appliance starts a draining process.		
	 First wait approx. 5 minutes until the drain process ends. To reset the error message, switch the appliance off. 		

3. Switch the appliance back on.

Fault	Cause and troubleshooting	
"E:30 / -10" and/or 凸	 4. If the error message is displayed again, call customer service. → "Customer Service", Page 52 	
"E:35 / -10"	There is water in the base trough. ► Turn off the water tap. ► Call the after-sales service. → "Customer Service", Page 52	
	The appliance is leaking. ► Turn off the water tap. ► Call the after-sales service. → "Customer Service", Page 52	
****	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into compartment II (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load. 	
Dights up.	The temperature is too high. ► Wait until the temperature has dropped. ► → "Cancelling the programme", Page 31	
	Water level is too high. ► Select a suitable programme for draining. → "Programmes", Page 25	
(1) flashes.	Door is not closed. Close the door.	
	Laundry is caught in the door. ▶ Remove any trapped laundry.	
"E:30/-20"	 Detergent dosage is too high. Reduce the amount of detergent for the next washing cycle with the same load. 	
	Additional water is added.Do not add any extra water to the appliance while it is operating.	
	Solenoid valve defective. ► Call the after-sales service. → "Customer Service", Page 52	

Fault	Cause and troubleshooting		
All other error codes.	 Malfunction Switch the appliance off and then on again. If the message appears again, disconnect the appliance from the power supply for at least 30 seconds by pulling out the plug or by switching off the relevant circuit breaker in the fuse box. ✓ If the fault was a one-off, the message disappears. If the message appears again, call the after-sales service. Please specify the exact error message when calling. → "Customer Service", Page 52 		
The appliance is not working.	The mains plug of the power cord is not plugged in. Connect the appliance to the power supply. The circuit breaker in the fuse box has tripped. Check the circuit breaker in the fuse box.		
	There has been a power cut. ► Check whether the lighting in your room or other appliances are working.		
The programme does not start.	You have not pressed Start/Reload D I II. ► Press Start/Reload D I II.		
	Door is not closed. ► Close the door.		
	Childproof lock is activated. ► Deactivate childproof lock. → "Deactivating the childproof lock", Page 32		
	- Finish in ⊕ + is activated. ► Check whether - Finish in ⊕ + is activated. → "Buttons", Page 23		
	Laundry is caught in the door. ▶ Remove any trapped laundry.		
The door cannot be opened.	 is activated. Continue the programme by selecting ⑤ Spin or ♥ Drain and pressing Start/Reload ▷ ill. in Resuming the programme when the programme status is Rinse Hold", Page 31 		
	The temperature is too high. ► Wait until the temperature has dropped. ► Cancel the programme. → "Cancelling the programme", Page 31		
	Water level is too high.		

	Troubleshooting en		
Fault	Cause and troubleshooting		
The door cannot be opened.	 Select a suitable programme for draining. → "Programmes", Page 25 		
	Power failure. ► Open the door using the emergency release. → "Emergency release", Page 51		
The water is not draining.	Drain pipe or water outlet hose is blocked. Clean the drain pipe and the water outlet hose.		
	 Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped. 		
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 37		
	 □ is activated. Continue the programme by selecting ⑤ Spin or ⑤ Drain and pressing Start/Reload ▷ II. □ "Resuming the programme when the programme status is Rinse Hold", Page 31 		
	The water outlet hose is connected too high. ► Install the water outlet hose at a maximum height of 1 metre.		
	Pump cover is not correctly assembled. Correctly assemble the pump cover.		
	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into compartment II (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load. 		
	Unapproved extension installed on the water drain hose. ► Remove any unapproved extensions from the water hose. → "Connecting the appliance", Page 15 The pump cap is not fully screwed in.		
	Ensure that the pump cap is screwed in all the way into the appliance. The handle on the pump cap must be in a vertical position.		
Water is not flowing in. Detergent is not being dispensed.	You have not pressed Start/Reload D I II. ► Press Start/Reload D I II.		

Fault	Cause and troubleshooting	
Water is not flowing in. Detergent is not being dispensed.	The filter in the water inflow is blocked. Clean the water inflow filter.	
	The tap is turned off. ► Turn on the tap.	
	The water inlet hose is kinked or jammed.Ensure that the water inlet hose is not kinked or jammed.	
The spin cycle runs several times.	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. ▶ Not a fault – no action required.	
	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.	
The programme duration changes during the wash cycle.	The programme operation is optimised electronically. This may change the programme duration. ▶ Not a fault – no action required.	
	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. Not a fault – no action required.	
	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.	
	Foam detection system switches on a rinse cycle if foam build-up is too high. Not a fault – no action required.	
No water is visible in the drum.	 Water is below the visible area. Not a fault – no action required. Do not add any extra water to the appliance while it is operating. 	
Drum jerks after the programme starts.	This is caused by an internal motor test. ► Not a fault – no action required.	
Residual water is present in the compartment &.	Insert in compartment ⊗ is blocked. ► → "Cleaning the detergent drawer", Page 36	
Vibrations and movement of the appliance whilst spinning.	Appliance is not correctly aligned. ► → "Aligning the appliance", Page 16	
willist spillillig.	The appliance feet are not fixed.	

Fault	Cause and troubleshooting		
Vibrations and movement of the appliance	 Secure the appliance feet. → "Aligning the appliance", Page 16 		
whilst spinning.	Transit bolts have not been removed. ► → "Removing the transit bolts", Page 13.		
Drum rotates, water does not flow in.	Load detection is active. ► Not a fault – no action required.		
	Note: The load detection can take up to two minutes.		
Heavy foam build-up	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into compartment II (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load. 		
High spin speed not reached.	A low spin speed is selected.► The next time you run a wash cycle, set a higher spin speed.		
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance. Redistribute the laundry in the drum.		
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	► Start the ⑤ Spin programme.		
The spin programme does not start.	Drain pipe or water outlet hose is blocked. • Clean the drain pipe and the water outlet hose.		
	Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped.		
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.		
	Redistribute the laundry in the drum.		
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	► Start the ⑤ Spin programme.		

en Troubleshooting

Fault	Cause and troubleshooting		
Rushing, hissing noise.	Water is flushed under pressure into the detergent drawer. ► Not a fault – normal operating noise.		
Loud noises during the spin cycle.	Appliance is not correctly aligned. ► → "Aligning the appliance", Page 16		
	The appliance feet are not fixed. ► Secure the appliance feet. → "Aligning the appliance", Page 16		
	Transit bolts have not been removed. ► → "Removing the transit bolts", Page 13.		
Persistent, quiet whirring fan noise.	Active oxygen treatment is active. Not a fault – normal operating noise.		
Banging noises, rattling in the drain pump.	Foreign bodies have got into the drain pump. ▶ → "Cleaning the drain pump", Page 37		
Slurping, rhythmical suction noise.	The drain pump is active, the detergent solution is pumped out. Not a fault – normal operating noise.		
Creasing.	The spin speed is too high.▶ The next time you run a wash cycle, set a lower spin speed.		
	The load is too large. ➤ The next time you run a wash cycle, reduce the amount of laundry being loaded.		
	Unsuitable programme for the type of fabric.▶ Select the programmes that are suitable for the type of fabric.		
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	Too much detergent/fabric softener in the detergent drawer. When dosing liquid detergent and fabric softener, observe the marking in the detergent drawer and do not dose above this.		
The spin result is not satisfactory. The laundry is too wet/too damp.	 A low spin speed is selected. ► The next time you run a wash cycle, set a higher spin speed. ► Start the ⑤ Spin programme. 		
	Drain pipe or water outlet hose is blocked. Clean the drain pipe and the water outlet hose.		
	Drain pipe or water drain hose is caught or jammed.		

Fault	Cause and troubleshooting		
The spin result is not satisfactory. The laundry is too wet/too damp.	Ensure that the drain pipe and water drain hose are not kinked or trapped.		
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. • Redistribute the laundry in the drum.		
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	► Start the ⑤ Spin programme.		
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance. Redistribute the laundry in the drum.		
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	► Start the ⑤ Spin programme.		
Detergent residue on the damp washing.	Detergents may contain water-insoluble substances that deposit on the laundry. Start the Rinse w programme.		
Detergent residue on the dry laundry.	Detergents may contain water-insoluble substances that deposit on the laundry. • Brush out the laundry after washing and drying.		
Home Connect is not working properly.	Different causes are possible. • Go to www.home-connect.com.		
No connection to the home network.	Wi-Fi is switched off. ► Activating Wi-Fi on the appliance. → "Activating Wi-Fi on the appliance", Page 33.		
	 Wi-Fi is activated but a connection to your home network cannot be established. 1. Ensure that the home network is available. 2. Reconnect the appliance to the home network.		
Water is leaking out at the water inlet hose.	Water inlet hose is not correctly/securely connected. 1. Connect the water supply hose correctly. → "Connecting the water inlet hose", Page 15 2. Tighten the screw connection.		
Water is leaking out at the water outlet hose.	The water outlet hose is damaged. • Replace the damaged water outlet hose.		

en Troubleshooting


Fault	Cause and troubleshooting		
Water is leaking out at the water outlet hose.	Water outlet hose is not connected correctly. ► Connect the water outlet hose correctly. → "Water outlet connection types", Page 15		
Odours have formed in the appliance.	 Humidity and detergent residue may promote the formation of bacteria. → "Cleaning the drum", Page 36 If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate. 		
Fabric softener remains in the detergent drawer.	The use of fabric softener is not supported for the selected programme. ▶ Before washing, check whether the use of fabric softener is supported for the selected programme. → "Programmes", Page 25		
Water is leaking from below the door.	Dirt on the door or seal causes leaks. Clean the door and the seal.		

18.1 Emergency release

Releasing the door

Requirement: The drain pump is empty. → Page 37

- 1. **ATTENTION!** Escaping water may cause material damage.
- Do not open the door if you can see water through the glass. Pull the emergency release downwards with a tool and release.



- The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

19 Transportation, storage and disposal


19.1 Removing the appliance

- 1. Turn off the tap.
- 2. Empty the water inlet hose.
- 3. Switch off the appliance. → "Switching off the appliance", Page 32
- 4. Unplug the appliance's mains plug.
- 5. Drain the water. → "Cleaning the drain pump", Page 37
- 6. Detach the hoses.

19.2 Inserting the transit bolts

Secure the appliance before transportation using transit bolts in order to prevent transport damage.

1. Use a screwdriver to remove the 4 cover caps.



Keep the cover caps.

2. Insert the 4 transit bolts. → "Removing the transit bolts", Page 13

19.3 Using the appliance again

► For further information, see → "Installation and connection". Page 12 and → "Starting an empty washing

cycle", Page 20.

19.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- Unplug the appliance from the mains.
- 2. Cut through the power cord.
- Dispose of the appliance in an environmentally friendly manner.
 Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

20 Customer Service

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

20.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate.
Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

20.2 AQUA-STOP guarantee

In addition to warranty claims against the seller under the purchase agreement and in addition to our manufacturer's warranty, we offer compensation under the following conditions.

 If our Aqua-Stop system is defective and causes water damage, we will make good the damage for private users. To ensure protection

- from water damage, the appliance must be connected to the power supply.
- The liability quarantee is valid for the service life of the appliance.
- A claim can only be made under the guarantee if the appliance has been correctly installed and connected with Aqua-Stop according to our instructions; this also includes correctly fitting the Agua-Stop extension (genuine accessory). Our guarantee does not cover defective supply lines or fittings up to the Aqua-Stop connection on the tap.
- If your appliance is fitted with Aqua-Stop, you can in principle leave your appliance unattended during operation and the tap turned on afterwards. The tap only needs to be turned off if you are away from home for a long period, e.g. on holiday for several weeks.

21 Consumption values

The indicated consumption values are approximate.

The values may deviate from the indicated values depending on water pressure, water hardness, water inlet temperature, room temperature, type of laundry, amount and soiling of laundry, detergent used, fluctuations in the mains voltage and selected settings.

Programme	Temperat- ure (°C)	Load (kg)	Energy consump- tion (kWh) ¹	Water consumption (I)1	Pro- gramme duration (h:min) ¹
Cottons 🏗	20	10.0	0.500	95.0	3:00
Cottons 🏗	40	10.0	1.300	95.0	3:45
Cottons 🏗	60	10.0	2.100	95.0	3:45
Cottons 🛣	90	10.0	2.500	110.0	3:00
Cottons Eco @2	60	10.0	0.860	54.0	4:38
Synthetics ம்	40	4.0	0.750	57.0	2:30
Mix ≫®®	40	4.0	0.650	44.0	1:00
Delicates/ Silk	30	2.0	0.220	36.0	0:45
	30	2.0	0.210	40.0	0:45
	-	1.0	0.020	0.0	0:45

values determined according to the valid version of IEC60456

Programme setting with maximum speed for testing in accordance with the applicable version of IEC60456 with cold water (15 °C).

22 Technica	al data
Appliance height	84.8 cm
Appliance width	59.8 cm
Appliance depth	59.0 cm
Appliance depth with door closed	63.2 cm
Appliance depth with door open	106.3 cm
Weight	83.4 kg
Maximum load	10.0 kg

Mains voltage	220-240 V, 50-60 Hz
■ Minimum installation protection	10 A
Nominal power	2300 W
Water pressure	 Minimum: 100 kPa (1 bar) Maximum: 1000 kPa (10 bar)
Length of the water inlet hose	150 cm

Technical c	lata en
-------------	----------------

Length of the wa- 150 cm ter outlet hose	Length of the power cord	210 cm



Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- · Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome**



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com

A Bosch Company

