



Washing machine

WGB25600AU

[en]

User manual and installation instructions

Further information and explanations are available online:



Table of contents

1 Safety	
1.6 Safe cleaning and main ance	9
2 Preventing material dam	age 10
3 Environmental protectio	
saving energy3.1 Disposing of packaging	
3.2 Save energy and conse	erve
resources3.3 Energy saving mode	
4 Installation and connect	
4.1 Unpacking the appliance	e 11
4.2 Contents of package	
4.3 Requirements for the in ation location	siaii- 12
4.4 Removing the transit bo	olts 13
4.5 Connecting the appliant	
4.6 Aligning the appliance	
5 Before using for the first5.1 Starting an empty wash	
5.1 Starting an empty wash cycle	
6 Familiarising yourself wi	ith
your appliance	17
6.1 Appliance	
6.3 Control panel	
6.4 Operating logic	
7 Display	20

8 Buttons	22
9 Programmes	25
10 Accessories	29
11 Laundry	29 29 30
12 Detergents and care products	30
13.1 Switching on the appliance 13.2 Setting a programme	30 30 30 31 31 31 32 32 32 33 33 33 33 33

14 Childproof lock	34	20 Customer Service	49
 15 Home Connect 15.1 Setting up the Home Connect app 15.2 Setting up Home Connect 15.3 Activating Wi-Fi on the appliance 15.4 Deactivating Wi-Fi on the appliance 15.5 Installing the software update 15.6 Resetting the appliance network settings 15.7 Remote start 15.8 Remote diagnostics 15.9 Data protection 	34 34 35 35 35 35 35 35 35	21 Consumption values	50 51 51
16 Basic settings	36		
17 Cleaning and servicing	37 38 41 42 48		
 18.2 Restart the appliance. 19 Transportation, storage and disposal. 19.1 Removing the appliance. 19.2 Inserting the transit bolts. 19.3 Using the appliance again. 19.4 Disposing of old appliance. 	48 48 48 49		



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- with tap water and commercially available detergents and care products suitable for washing machines.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Incorrect installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.
- ► When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ► Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ► Only use adapters and power cords approved by the manufacturer.
- ▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

⚠ WARNING – Risk of injury!

The heavy weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- ► Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material.

⚠ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

▶ Do not touch the sharp edges on the appliance.

Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer services. → Page 49

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

When spinning larger, waterproof items of laundry, imbalances may arise and lead to injuries.

▶ Do not wash and spin larger items of laundry, such as blankets or mattress covers, in the appliance.

△ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

⚠ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

△ WARNING – Risk of explosion!

Laundry that has been pretreated with flammable cleaning agents that contain solvents may cause an explosion in the appliance.

► Rinse pretreated laundry thoroughly with water before washing.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

Wait for the drum to come to a complete stop before reaching inside.

△ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

▶ Do not touch the hot detergent solution.

△ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

Improper repairs are dangerous.

- Never make any technical modifications to the appliance or its features.
- Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

- ▶ Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 25
 The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.
- Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- Before transport, fit the transit bolts fully in order to prevent damage in transit.

Material damage may be caused if the water inlet hose is connected incorrectly.

- Tighten the screw connections on the water inlet until they are handtight.
- Connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions or valves.
- Make sure that the valve housing for the water inlet hose does not come into contact with its surroundings and is not subjected to any external forces.
- Ensure that the inner diameter of the water tap is at least 17 mm.

Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- ► Ensure that the water pressure in the water supply system is at least 100 kPa (1 bar) and max. 1000 kPa (10 bar).
- If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may lead to material damage and damage to the appliance.

 Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive detergents.
- ▶ Do not use cleaning products with a high alcohol content.
- ► Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.

 Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

- Choose programs with low temperatures and longer wash times and use maximum load capacity.
 → Page 25
- Add detergent based on the laundry's degree of soiling.
- Reduce the washing temperature for lightly and normally soiled laundry.
- Set the maximum spin speed if you want to dry the laundry in the tumble dryer afterwards.
- Wash the laundry without prewash.

3.3 Energy saving mode

If you do not use the appliance for a brief period, it automatically switches to energy-saving mode. All displays go out and II \triangleright flashes.

Energy-saving mode ends when you use the appliance again.

If you do not use the appliance for an extended period, it automatically switches to standby mode.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 11
- 2. Check the appliance for visible damage.
- 3. Open the door. → Page 31
- Remove any accessories from the drum.
- 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- Do not operate the appliance with incomplete or defective accessories.
- Replace the accessories in question before operating the appliance.
 - → "Accessories", Page 29

Note: The appliance has undergone a function test at the factory. This may cause water stains in the appliance, which the first wash cycle removes.

The delivery consists of the following:

- Washing machine
- Accompanying documents
- Transit bolts
 - → "Removing the transit bolts", Page 13
- Cover caps
- Water inlet hose
 - → "Connecting the water inlet hose", Page 14
- Elbow for securing the water outlet hose

4.3 Requirements for the installation location

⚠ WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

► Do not operate the appliance without a cover cap.

⚠ WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 29 before using the appliance for the first time.

ATTENTION!

If residual water in the appliance freezes, this may cause damage to the appliance.

 Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- ► Tilt the appliance carefully.
- Transport the appliance in an upright position.

Installation loca- Requirements tion

Base

Secure the appliance with fixing brackets

→ Page 29.

Wooden joist



Place the appliance on a water-resistant wooden board (minimum thickness of 30 mm) which is screwed tightly to the floor.


Installation loca- Requirements tion

Kitchen unit



Only install the appliance underneath a continuous worktop that is securely connected to adiacent cabinets. Required niche width: 60 cm.

Against a wall



Do not trap the power cord or the hoses between the wall and the appliance.


4.4 Removing the transit bolts

The appliance is secured for transportation using transit bolts on the rear of the appliance.


Note: Keep the transit bolt screws and the sleeves in a safe place for future transport.

→ "Inserting the transit bolts", Page 48


1. Pull the hose out of the holders.




2. Unscrew ① and remove ② all of the screws for the 4 transit bolts using a WAF 13 wrench.



3. Remove the power cable from the holder.




4. Remove the 4 sleeves.



5. Put on the 4 cover caps.



6. Push the 4 cover caps downwards.




Note: To install the transit bolts to transport the appliance, perform these steps again in the reverse order.

4.5 Connecting the appliance Connecting the water inlet hose


ATTENTION!

Material damage may be caused if the water inlet hose is connected incorrectly.

Tighten the screw connections on the water inlet until they are handtight. 1. Connect the water inlet hose.



2. Connect the water inlet hose to a tap (26.4 mm = 3/4").



3. Open the water tap carefully and check that the connection points are tight.

Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.

ATTENTION!

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

 Secure the water outlet hose against unintentional loosening. In the event of a blocked or covered outlet, accumulated wastewater can flow back into the appliance.

 Before operating the appliance, ensure that the wastewater drains away quickly and eliminate any blockages.

Note: Observe the draining heights. The maximum draining height is 100 cm.

Siphon




Secure the connection point with a (24–40 mm) hose clamp.

Sink



Fix and secure the water outlet hose with an elbow.

Plastic pipe with rubber sleeve or qully



Fix and secure the water outlet hose with an elbow.

Connecting the appliance to the electricity supply

Note: Your electrical domestic installation for this appliance must comply with the local legal provisions and safety regulations, and should include a residual current circuit-breaker.


 Insert the mains plug of the appliance's power cable in a socket nearby.

- The connection details of the appliance can be found under Technical data \rightarrow *Page 51*.
- 2. Check the mains plug is inserted properly.


4.6 Aligning the appliance

In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

 Use a WAF 17 wrench to loosen the lock nuts in a clockwise direction.




2. To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

3. Use a WAF 17 wrench to tighten the lock nuts against the housing until they are hand-tight.



In doing so, hold the foot tight and do not adjust its height.

5 Before using for the first time

Prepare the appliance for use.


5.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.


- 1. Press \emptyset .

 The switch-on process takes a few seconds.
- Select the Cottons 90°C programme or the drum cleaning programme in the Home Connect app.
- 3. Close the door.
- 4. Pull out the detergent drawer.

5. Pour approx. 1 litre of tap water into compartment II.



Add washing powder containing oxygen bleach to compartment II.




To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

- 7. Push in the detergent drawer.
- **8.** Press **II >** to start the programme.
- → The display shows the remaining programme duration.
- After the programme has ended, the display shows: End.
- Start the first wash cycle or press ⁽¹⁾ to put the appliance in standby mode
 - → "Basic operation", Page 30

6 Familiarising yourself with your appliance

6.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

1	Maintenance flap for the drain pump → Page 38
2	Door → Page 31
3	Detergent drawer → Page 17
4	Control panel → Page 18
5	Water outlet hose → Page 14
6	Power cord → Page 15
7	Transit bolts → Page 13

6.2 Detergent drawer


Note: Observe the manufacturer's instructions on the use and dosage of the detergent and care product and the information in the programme descriptions.



- Dosing aid for liquid detergent → Page 32
- Compartment II: Detergent for the main wash
- 3 Compartment &: Fabric softener
- Compartment I: Detergent for prewash

6.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- 1 Programmes → Page 25
- Programme selector

 → Page 30
- Buttons → Page 22 and display → Page 20

6.4 Operating logic

Some areas of the display are buttons and respond to touch. You can activate, deactivate or change set-

tings by pressing the buttons. The activated settings are highlighted brightly on the display.

ATTENTION!


Pressing on the display with force may cause damage.

- Do not apply heavy pressure on the display.
- Do not press on the display using pointed or sharp objects.


Displaying or hiding additional buttons

Some buttons are hidden for a reduced display. If you display these additional buttons on the display, you can activate or deactivate the corresponding settings.

1. To display the additional buttons, briefly press **More**.



 The display shows all additional buttons.



2. To hide the additional buttons, briefly press **More** again.

Changing a setting value

If you activate certain settings, the display shows selection buttons and you can change the setting value.

Press the selection buttons → Page 22.

The display shows the setting value.


7 Display

The display shows the current settings, options or relevant information.

Depending on the programme status, the display shows some information in the 88:88 area, e.g. End.

Note: Additional functions may be available as a result of software updates. → *Page 35*

If a software update is available, you can find further information in the Home Connect app.



Example: Display

Display	Description
0:40 1	Expected programme duration or programme time remaining in hours and minutes.
10 h ¹	Program end time → "Buttons", Page 22
10.0 ¹	Recommendation for the maximum load capacity for the selected program in kg.
□ - 1600	Set spin speed in rpm. → Page 23 0: No final spin, only draining : Rinse Hold, no draining
₩ - 90	Set temperature in °C. → Page 22 (cold)
End	Programme status: Programme end
\$	Programme status: Steaming
¹ Example	

Display	Description
Blood	The "Blood" stain type is activated.
Grass	The "Grass" stain type is activated.
Red Wine	The "Red wine" stain type is activated.
Sweat	The "Sweat" stain type is activated.
Butter/Oil	The "Cooking fat/cooking oil" stain type is activated.
Tomatoes	The "Tomato" stain type is activated.
⊗	Flashes: Drum cleaning is required. Run the Cottons 90°C programme for cleaning and caring for the drum and the outer tub. → "Cleaning the drum", Page 37
	 Lights up: The appliance is connected to your home network via Wi-Fi. Flashes: The appliance is trying to connect to your home network via Wi-Fi.
	→ "Home Connect ", Page 34
*&**	The appliance has detected too much foam. → "" or heavy foam build-up.", Page 44
©	 Lights up: The door is locked. To add laundry, the door can be unlocked. → "Adding laundry", Page 33 To open the door, you can cancel the programme. → "Cancelling the programme", Page 33 Flashes: The door is not closed.
문 ×	No water pressure.The water pressure from the tap is too low.
E:35¹	Error code, error display, signal. → Page 42
¹ Example	· · · · · ·

8 Buttons

Note: Additional functions may be available as a result of software updates. → *Page 35*

If a software update is available, you can find further information in the Home Connect app.

Some buttons are hidden for a reduced display. You can display these additional buttons on the display.

→ "Displaying or hiding additional buttons", Page 19

The selection of programme settings depends on the programme that is set.

Button	Selection	More information
	StartCancelPause	Start, cancel or pause the programme. If II is displayed, you can pause the programme. If \triangleright is displayed, you can start the programme.
\Diamond	Multiple selection	To change a setting, press the ∧ or ✓ selection button until the display shows the required setting.
SpeedPerfect	ActivateDeactivate	Activate or deactivate a shorter programme duration. Note: Energy consumption increases. The washing result is not affected by this.
Intensive Plus	ActivateDeactivate	Activate or deactivate an extended washing programme. The programme duration is extended by up to 30 minutes. Suitable for heavily soiled laundry.
AntiStain	Multiple selection	Select the type of stain. The temperature, drum movement and soaking time are all adjusted to suit the type of stain.
Finished in	Up to 24 hours	Set the programme end time. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed. Note: Press ∧ or ✓ until the display shows the required setting.
^~	₩ - 90	Adjust the temperature. Set temperature in °C.

Button	Selection	More information
^ /	□ - 1600	Adjust the spin speed or activate (Rinse Hold). Set spin speed in rpm. If is selected, the water is not drained at the end of the washing cycle and the spin cycle is deactivated. The laundry remains in the water used for rinsing.
の (mains switch)	Switch onStandby modeRestart the appliance	Switch on the appliance or put it in standby mode. If the control panel does not respond, press and hold ⊕ for approximately 5 seconds to restart the appliance. → "The display and buttons do not respond.", Page 44
☐ Remote Start	ActivateDeactivateOpening the Home Connect settings	Activate or deactivate remote start. → Page 35
c∞ 3 sec.	ActivateDeactivate	→ "Childproof lock", Page 34
Basic Settings	Multiple selection	→ "Basic settings", Page 36
More	 Displaying or hiding addi- tional buttons 	 If you briefly press the button, you can display or hide additional buttons. → "Displaying or hiding additional buttons", Page 19
Mini Load	ActivateDeactivate	Wash small loads of delicate or hard-wearing fabrics. The programme duration is shortened, and the water and energy consumption adjusted to the load. Note: If you activate the setting, the programme's maximum load capacity is reduced to 0.5 kg.
Prewash	ActivateDeactivate	Activate or deactivate prewash, e.g. for washing heavily soiled laundry. Note: Add the detergent for the prewash in compartment I and the detergent for the main wash in compartment II of the detergent drawer. → "Detergent drawer", Page 17

en

Button	Selection	More information
Water/Rinse+	ActivateDeactivate	Activate or deactivate a washing programme with more water and an additional rinse cycle. Recommended for particularly sensitive skin or in regions with very soft water.
Night Wash	ActivateDeactivate	Activate or deactivate quiet operation, e.g. for operation at night. The operating signals and the information signals are deactivated and the appliance is adjusted for quiet operation, e.g. by reduced drum movement.
Favourite	■ Store ■ Adjust	Press the button for approx. 3 seconds to save your customised programme settings. → "Saving the programme settings", Page 31 If you briefly press the button, you set your saved programme with individual programme settings.

9 Programmes

Notes

- The laundry's care labels provide you with additional information about programme selection.
 - → "Care symbols on the care labels", Page 30
- The programme's temperature setting guarantees that the recommended temperature on the care label is not exceeded. The temperature that is reached in the appliance may differ from the set temperature. This means that the best possible washing performance is achieved with optimal energy efficiency.
- Additional functions may be available as a result of software updates.
 → Page 35
 If a software update is available, you can find further information in the Home Connect app.

Programme	Description	Max. load
		(kg)
Cottons	Wash hard-wearing items made from cotton or linen. Also suitable as a short program when you activate SpeedPerfect. Programme setting: Max. 90 °C Max. 1600 rpm	10.0 5.0
Cottons Eco	Wash hard-wearing items made from cotton or linen. Energy-saving program for normally soiled laundry. Note: To save energy, the actual washing temperature may deviate from the set washing temperature. The washing performance meets legal requirements. Programme setting: Max. 90 °C Max. 1600 rpm	10.0
Easy Care	Wash items made from synthetic fabrics. Programme setting: ■ Max. 60 °C ■ Max. 1400 rpm	4.0

² Washing not possible

Programme	Description	Max. load
		(kg)
Quick Mixed	Wash items made from cotton, linen or synthetic fabrics. Suitable for lightly soiled laundry. Programme setting: Max. 60 °C Max. 1600 rpm	4.0
Delicates/Silk	Wash delicate, washable items made from silk, viscose and synthetic fabrics. Use a detergent that is suitable for delicates or silk. Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag. Tip: Gently cleaning the laundry reduces abrasion of textile fibres and microplastic fibres. Programme setting: Max. 40 °C Max. 800 rpm	2.0
≥ Wool	Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool. Programme setting: Max. 40 °C Max. 800 rpm	2.0
Rinse	Rinse and then spin the laundry, and drain the water. Programme setting: Max. 1600 rpm	-
Spin/Drain	Spin the laundry and drain the water. If you only want to drain the water, activate 0. The laundry is not spun. Programme setting: Max. 1600 rpm	_
∄ App Programs	Select additional programmes directly via the Home Connect app. A description of the programmes can be found in the Home Connect app. Note: Your appliance must be connected to your home network and registered in your Home Connect app. → Page 34	_
SpeedPerfectWashing not p		

Programme	Description	Max. load
		(kg)
Hygiene Plus	Wash hard-wearing items made from cotton or linen. Suitable for allergy sufferers and for strict hygiene requirements. Note: Once the set temperature has been reached, it remains constant throughout the entire washing process. Programme setting: Max. 60 °C	6.5
	■ Max. 1600 rpm	
Sportswear	Wash sports and leisure items made from synthetic fabrics. Use a detergent that is suitable for sports items. Do not use fabric softener. Tip: Use the Easy Care programme to wash heavily soiled laundry. Programme setting: Max. 40 °C Max. 800 rpm	2.0
Iron Assist ∜	Suitable for shirts, T-shirts and similar fabrics made from cotton or linen. Programme for warming and steaming dry items using steam in order to hang them up once the programme has ended or to make them easier to iron. The programme's maximum load is five shirts or five t-shirts. Activate SpeedPerfect if you only want to steam one item of laundry. Notes Immediately after the programme ends, hang up the warm, steamed items or iron them. The laundry is not washed or cleaned. Do not use any detergent or cleaning products. The steam is hot and may cause damage to certain fabrics or fabric types. The programme is therefore not suitable for outdoor clothing or items made from silk or wool, such as jumpers.	_2

SpeedPerfect activatedWashing not possible

Programme	Description	Max. load
		(kg)
Jeans/Dark Wash	Wash dark-coloured and colour-intense items made from cotton or easy-care fabric, e.g. jeans. Turn laundry inside-out before washing. Use liquid detergent. Programme setting: Max. 40 °C Max. 1200 rpm	4.0
Super 15'/30'	Wash items made from cotton or synthetic fabrics. Short programme for small items of lightly soiled laundry. The programme duration is approx. 30 minutes. If you wish to reduce the programme duration to 15 minutes, activate SpeedPerfect. The maximum load is reduced to 2.0 kg. Programme setting: Max. 40 °C Max. 1200 rpm	4.0 2.0 ¹

SpeedPerfect activatedWashing not possible

10 Accessories

Use original accessories. These have been made especially for your appliance.

Tip: Some accessories are available in other colours. Contact customer service. → *Page 49*

	Use	Order num- ber
Water inlet hose extension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Water outlet hose extension	Extend the water outlet hose (2.20 m).	11057910
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Liquid detergent insert	Measure liquid detergent.	00605740
Platform	Install the appliance at a raised height so that it can be easily loaded and unloaded.	WMZP- W20W
Washing machine cleaners	Cleaning products for maintaining the appliance interior.	00311928

11 Laundry

11.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels

- Close all zips, hook and loop fasteners, hooks and eyes
- Tie cloth belts, cloth straps and cords together
- Remove curtain fittings and lead strips
- Wash small or particularly delicate items in a mesh washing bag
- Wash large and small items of laundry together
- Wash laundry with fresh stains immediately
- Pretreat laundry with dried stains and wash several times
- Load the laundry unfolded into the drum
- Before loading the drum, any laundry that has been pre-treated with chlorine bleach should be rinsed several times

11.2 Care symbols on the care labels

Washing care symbols

Symbol	Recommended programme
95 60 40 30	Cottons (normal)
60 40 30	Easy Care (gentle)
	Delicates/Silk for washing by hand (particularly gentle)
KIN	Woollens (hand wash)
×	(not suitable for machine- washing)

12 Detergents and care products

You can protect your appliance and your laundry by selecting and using the correct detergents and care products.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- When using liquid detergents, only use liquid detergents that are selfflowing
- Do not mix different liquid deteraents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances
- Do not use chlorine bleach
- Do not use dyes regularly as fixing salt can damage stainless steel
- Do not use color-bleaching agents in the appliance

13 Basic operation

13.1 Switching on the appliance

Note: If you switch the appliance on the first time after you have connected it to the electrical system, the switch-on process takes up to one minute.

Requirement: The appliance has been correctly installed and connected. → Page 11

► Press U.

The switch-on process takes a few


seconds.

Note: The lighting for the drum goes out automatically.

13.2 Setting a programme

1. Press the required programme.

→ "Programmes", Page 25



- The display shows the programme settings.
- 2. Adjust the programme settings. → "Buttons", Page 22

Observe the information about operating logic → Page 18. The programme settings are not saved permanently for the programme.

Setting additional programmes

Requirement: Home Connect is set up. → *Page 34*

- 1. Set the **App Programs** programme.
- ✓ □ Remote Start flashes.
- 2. Press [Remote Start.
- The Home Connect app displays the programmes that can be selected.
- 3. Set a programme in the Home Connect app.
- **4.** If required, adjust the programme settings.
 - → "Buttons", Page 22
- 5. Start the programme. → Page 32

13.3 Saving the programme settings

You can save your individual programme settings as favourites.

Requirement: A programme is set. → *Page 30*


Press and hold Favourite for approx. 3 seconds.

Press **Favourite** to call up the saved programme.


Note: To overwrite the saved programme, repeat the steps above.

13.4 Opening the door

1. Grip under the door handle and pull on the door.



2. Open the door.



13.5 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes. → "Programmes", Page 25


Requirements

- The laundry is prepared and sorted
 - → "Laundry", Page 29
- The drum is empty.
- **1.** Open the door. \rightarrow *Page 31*
- 2. Place the laundry in the drum.
- 3. Close the door.


Ensure that there is no laundry trapped in the door.

13.6 Inserting the measuring aid

- 1. Pull out the detergent drawer.
- **2.** Press down on the insert and remove the detergent drawer.



3. Insert the measuring aid.



13.7 Using the measuring aid


To more easily measure the liquid detergent, you can use a measuring aid in the detergent drawer.

Note: Do not use a measuring aid for viscous detergents, for washing powder, or when the prewash or programme end time is activated.


Requirements

- The detergent drawer → Page 17 has been pulled out.
- The measuring aid is inserted. → Page 32

1. Slide the measuring aid forwards.



2. Fold the measuring aid down and click it into place.



13.8 Adding detergent and care product

Note: Observe the information about detergents and care products → *Page 30*.

- **1.** Pull out the detergent drawer.
- 2. If required, use the dosing aid.
 - → Page 32
- 3. Pour in the detergent.
 - → "Detergent drawer", Page 17
- **4.** If required, add the care product.
- 5. Push in the detergent drawer.

13.9 Starting the programme

Requirement: A programme is set.

- → Page 30
- ▶ Press II D.

- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- The display shows the programme duration or the programme end time.
- After the programme has ended, the display shows: End.

13.10 Soaking laundry

Note: No additional detergent is required for soaking. The appliance uses the filled detergent for soaking and washing.

Requirements

- The laundry is placed in the appliance. → Page 31
- A programme has started.→ Page 32
- Press II ▷ approx. 10 minutes after the programme start.

The programme pauses and the laundry can soak.

Press II ▷ after the required soaking time.

13.11 Adding laundry

After the programme starts, you can remove or add laundry depending on the programme status.

1. Press II D.

The appliance pauses.

Note: If you want to add laundry, follow the instructions on the display.

- → "Display", Page 21
- 2. Open the door. → Page 31
- 3. Add or remove laundry.
- 4. Close the door.
- 5. Press II D.

13.12 Cancelling the programme

- 1. Press II D.
- 2. Open the door. → Page 31 The appliance door remains locked for safety reasons if the temperature and water levels are high.
 - If the temperature is high, start the **Rinse** programme.
 - If the water level is high, start the **Spin** programme or select a suitable programme for draining.
 → "Programmes". Page 25
- 3. Remove the laundry. → Page 33

13.13 Resuming the programme when the programme status is Rinse

Requirements

- Rinse Stop is activated.→ "Buttons", Page 23
- The last rinse cycle of the set programme has ended and the laundry is in the rinsing water.
- Set the **Spin** programme or a programme for draining the water.
 → Page 25
- 2. Press II D.

13.14 Unloading the laundry

- 1. Open the door. → Page 31
- **2.** Remove the laundry from the drum.

13.15 Put the appliance into standby mode

- 1. Press \odot .
- 2. Turn off the tap.
- Cleaning the rubber gasket.
 → Page 41

Note: Leave the appliance door and the detergent drawer open to dry.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof lock

- ▶ Press and hold c 3 sec. for approx. 3 seconds.
- ▼ The control elements are locked.
- The childproof lock also remains activated when the appliance is in standby mode and in the event of a power cut.

14.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

▶ Press and hold c 3 sec. for approx. 3 seconds.

15 Home Connect

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: www.home-connect.com.

The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

Tip: Please also follow the instructions in the Home Connect app.

Notes

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app. → "Safety", Page 4
- Operating the appliance on the appliance itself always takes priority.
 During this time it is not possible to operate the appliance using the Home Connect app.

15.1 Setting up the Home Connect app

- **1.** Install the Home Connect app on your mobile device.
- 2 Start the Home Connect app and set up access for Home Connect. The Home Connect app guides you through the entire login process.

15.2 Setting up Home Connect

Requirements

- The Home Connect app has been installed on your mobile device.
- The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.
- 1. Press and hold () Remote Start for approx. 3 seconds.
- 2. Follow the instructions in the Home Connect app.

15.3 Activating Wi-Fi on the appliance

- 1. Press and hold (i) Remote Start for approx. 3 seconds.
- 2. Press (i) Remote Start repeatedly until the display shows "oFF".
- 3. Press **II ▶** to activate the Wi-Fi.
- ✓ The display shows "on".

Notes

- If the Wi-Fi is activated, the display alternately shows "on" and the signal strength of the Wi-Fi connection.
- To exit the Home Connect settings, press and hold
 \(\text{Pemote Start} \) for approx. 3 seconds.

15.4 Deactivating Wi-Fi on the appliance

- 1. Press and hold () Remote Start for approx. 3 seconds.
- 2. Press (i) Remote Start repeatedly until the display shows "on".
- 3. Press II ▶ to deactivate the Wi-Fi.
- ✓ The display shows "oFF".

Note: To exit the Home Connect settings, press and hold \Box **Remote Start** for approx. 3 seconds.

15.5 Installing the software update

Note: If a software update is available, a message appears in the Home Connect app.

- To install the software update, follow the instructions in the Home Connect app.
- The control panel is partially locked during the installation.

✓ In the event of a malfunction, installation may take up to 40 minutes. Do not reset the network settings or the appliance to the factory settings.

15.6 Resetting the appliance network settings

- 1. Press and hold (i) Remote Start for approx. 3 seconds.
- 2. Press (i) Remote Start repeatedly until the display shows "rES".
- Press and hold II ▷ for approx.
 3 seconds.
- ▼ The network settings are reset.

15.7 Remote start

Enable the appliance for remote start via the Home Connect app.

Note

Remote start will be deactivated in the following circumstances:

- The appliance door is opened.
- □ Remote Start is pressed.
- Following a power cut.

Activating remote start

Requirement: The appliance door is closed.

- ▶ Press ① Remote Start.
- → D Remote Start lights up and the appliance is enabled for remote start via the Home Connect app.

Deactivating remote start

- Press [] Remote Start.
- ✓ □ Remote Start goes out.

15.8 Remote diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance.

Tip: For further information and details about the availability of Remote Diagnostics in your country, please visit the service/support section of your local website: www.home-connect.com.

15.9 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the Wi-Fi communication module installed).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous reset to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

Note: Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

16 Basic settings


You can configure the basic settings for your appliance to meet your needs.

Note: You can also adjust the basic settings in the Home Connect app.

16.1 Overview of the basic settings

Note: Additional functions may be available as a result of software updates. → *Page 35*

If a software update is available, you can find further information in the Home Connect app.



Programme selector with programme positions

- Set the volume of the signal at the end of the programme: 0 (off) to 4 (very loud)
- Set the volume of the signal tone emitted when the buttons are pressed:
 0 (off) to 4 (very loud)
- 3 Set the display brightness: 1 (low) to 4 (very high)
- Activate (on) or deactivate (oFF) the reminder to clean the drum.
- Display the number of finished programmes (PC).

7

Restore the appliance to the factory settings (rES).

16.2 Changing the basic settings

Requirement: The display shows all additional buttons. → *Page 19*

- To call up the basic settings, press Basic Settings.
- Use the programme selector to select the required basic setting.
 → Page 36
- 3. Adjust the basic setting:
 - To change the value, press ∧ or ∨.
 - To reset the appliance to the factory settings, press and hold II > for approx. 3 seconds.
- **4.** To exit the basic settings, press **Basic Settings**.

17 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

17.1 Cleaning the drum

Clean the drum if you have carried out 20 washing cycles at a temperature of 40 °C or lower, if ® flashes, or

if you have not used the appliance for a prolonged period, but at least once a year.

A CAUTION Risk of injury!


Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.

- Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- Select the Cottons 90°C programme or the drum cleaning programme in the Home Connect app.


Run the programme without laundry but with washing powder that contains oxygen bleach or a cleaning agent for caring for the inside of the appliance.

17.2 Cleaning the detergent drawer


- 1. Pull out the detergent drawer.
- 2. Press down on the insert and remove the detergent drawer.




3. Pull out the insert upwards.



4. Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and click it into place.



6. Clean the opening for the detergent drawer.



7. Push in the detergent drawer.




17.3 Cleaning the drain pump

Clean the drain pump regularly, at least once a year, as well as in the event of faults, e.g. blockages or rattling noises.


Emptying the drain pump

- 1. Turn off the tap.
- 2. Put the appliance into standby mode. → Page 33
- **3.** Disconnect the appliance's mains plug from the power supply.


4. Open and remove the maintenance flap.



5. Slide a suitable receptacle under the opening for draining the detergent solution.




6. Take the drain hose out of the holder.




- ► Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



8. Once emptied, press firmly on the locking cap.




9. Insert the drain hose into the holder.



Cleaning the drain pump


Requirement: The drain pump is empty. → *Page 38*

- Since water may remain in the drain pump, unscrew the pump cap carefully.
 - The filter insert in the pump housing may become stuck due to coarse particles of dirt.
 Loosen the dirt and remove the filter insert.




The pump cap is comprised of two parts which can be taken apart for cleaning.


Clean the interior, the thread on the pump cap and the pump housing.




3. Ensure that both impellers can turn.



- 4. Insert the pump cap.
 - Ensure that the parts of the pump cap are correctly assembled.




5. Screw the pump cap as far as it will go.



The handle on the pump cap must be in a vertical position.

6. Insert and close the maintenance flap.





17.4 Cleaning the rubber gasket


Clean the rubber gasket regularly.

1. Open the door. → Page 31

2. Remove any foreign objects and fluff from the rubber gasket.



3. Remove any blockages from the intake opening.



4. Clean the outside and the inside of the rubber gasket with a damp cloth and wipe dry.

18 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

⚠ WARNING

Risk of electric shock!

Improper repairs are dangerous.

- ▶ Never make any technical modifications to the appliance or its features.
- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting				
The display goes out and II > flashes.	Energy-saving mode is active ▶ Press II ▷.				
E:36 -10 / E:30 -80 The detergent solution is not being pumped out.	The water outlet hose is connected too high, is kinked or trapped, or has been extended impermissibly. ► Check the installation of the water outlet hose. → Page 14				
	Drain pipe or water outlet hose is blocked. • Clean the drain pipe and the water outlet hose.				
	 The drain pump is blocked or the pump cover is not installed correctly. Check that the pump cover is installed correctly. Page 38 Clean the drain pump. → Page 38 				
	Detergent dosage is too high. ► Reduce the amount of detergent for the next washing cycle with the same load.				
	 is activated. Start the Spin programme or a suitable draining programme. → Page 25 				
E:36 -25 -26	Drain pump is blocked. ► Clean the drain pump. → Page 38				
E:38 -25 -26	 Drain pump is blocked. 1. Clean the drum. → Page 37 2. If the fault persists, clean the drain pump. → Page 38 				

Foult	Cause and troublesheating					
Fault	Cause and troubleshooting					
E:38 -25 -26	Inlet opening of the rubber gasket is blocked. • Clean the inlet opening in the rubber gasket.					
H:32	The appliance has interrupted the spin cycle because the laundry is unevenly distributed. • Redistribute the laundry in the drum.					
E:30 -10 / ₽	The tap is turned off. ► Turn on the tap.					
	The water inlet hose is kinked or jammed. ► Check the installation of the water inlet hose. → Page 14					
	The filters in the water inflow are blocked. ▶ Clean the filters in the water inflow.					
	The water pressure is low. ► Check whether the tap has sufficient water pressure.					
	The water level measuring system is defective. With this error message, the appliance starts a draining process. 1. Wait approx. 5 minutes until the draining process ends. 2. Restart the appliance. If required, start the draining process again. 3. If the fault persists, call customer service.					
E:30 -20	 → Page 49 Critical malfunction. ► Turn off the water tap. With this error message, the appliance starts a draining process. 1. Wait approx. 5 minutes until the draining process ends. 2. Restart the appliance. If required, start the draining process again. 3. If the fault persists, call customer service. → Page 49 					
	Detergent dosage is too high.Reduce the amount of detergent for the next washing cycle with the same load.					
	Additional water has been added.Do not add any extra water to the appliance while it is operating.					

Cause and troubleshooting
 Malfunction 1. To restart the appliance, press and hold ∅ for approximately 5 seconds. 2. If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. 3. If the fault persists, call customer service. → Page 49 Please specify the exact error message when calling. If possible, document the fault with photos and videos.
 Detergent dosage is too high. Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into compartment II (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load.
Drum cleaning is required. ► Clean the drum. → Page 37
 Software fault. 1. To restart the appliance, press and hold of for approximately 5 seconds. 2. If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
Different causes are possible. 1. Reset the appliance network settings. → Page 35 2. Set up Home Connect again. → Page 34 Go to www.home-connect.com.
Childproof lock is activated. ► Deactivate the childproof lock. → Page 34
Finished in is activated. ► Check whether Finished in is activated. → Page 22
The temperature is too high. ► Start the Rinse programme or wait until the temperature has dropped. Water level is too high.

Fault	Cause and troubleshooting				
The programme is paused or has been interrupted, but the door will not open.	Start the Spin programme or a suitable draining programme. → Page 25				
The door cannot be opened due to a power cut.	The door is locked. ► Open the door using the emergency release. → Page 48				
Drum jerks after the programme starts.	Not a fault. An internal motor test is started. No action required.				
Drum rotates, water does not flow in.	Not a fault. Load detection is active for up to 2 minutes. No action required.				
No water is visible in the drum.	Not a fault. Water is below the visible area. No action required.				
The spin cycle runs several times.	Not a fault. The appliance eliminates an imbalance by repeatedly redistributing the laundry. No action required.				
The appliance is vibrating, 'wandering'	Appliance is not correctly aligned. ► Align the appliance. → Page 15				
and making loud noises during the spin cycle.	The appliance feet are not fixed. ► Secure the appliance's feet. → Page 15				
	Transit bolts have not been removed. ▶ Remove the transit bolts. → Page 13				
High spin speed not reached.	The appliance is using a reduced spin speed to eliminate an imbalance. No action required.				
The programme duration changes during the wash cycle.	Not a fault. The programme sequence is optimised electronically, another rinse cycle is switched on due to heavy foam build-up, or an imbalance is eliminated. No action required.				
Whooshing, hissing or sucking noises.	Not a fault. Water is pumped in or detergent solution is pumped out. No action required.				
Banging noises, rattling in the drain pump.	A foreign object is in the drain pump. ► Clean the drain pump. → Page 38				
There are detergent residues on the laundry.	 Detergents may contain water-insoluble substances that deposit on the laundry. Start the Rinse programme or brush out the laundry after drying. 				

Fault	Cause and troubleshooting
Damp stains have formed on the fabrics after the Iron Assist \$\ointilde{\text{programme}}\$ programme has ended.	Water droplets from the drum or from the door have moistened the fabrics. The drops come from either condensed steam or the residual moisture from the previous wash programme. In the fabrics or hang them up to dry.
The laundry is too wet after the spinning cycle.	 A low spin speed is selected. ► Start the Spin programme. ► The next time you run a wash cycle, set a higher spin speed.
	The appliance is using a reduced spin speed to eliminate an imbalance. 1. Redistribute the laundry in the drum. 2. Start the Spin programme.
Creasing.	The selected programme is unsuitable for the type of fabric. ▶ Set a suitable programme. → Page 25
	A high spin speed is selected.► The next time you run a wash cycle, set a lower spin speed.
	The load is unsuitable. ► Observe the programme's maximum load capacity. → Page 25 ► Prepare the laundry. → Page 29
Water is leaking out at the water inlet hose.	The water inlet hose is not correctly connected or is damaged. ► Check the installation of the water inlet hose. → Page 11 Replace the water inlet hose if it is damaged.
Water is leaking out at the water outlet hose.	The water outlet hose is not connected correctly or is damaged. ► Check the installation of the water outlet hose. → Page 11 Replace the water outlet hose if it is damaged.
Water is leaking from below the door.	Dirt on the door or seal causes leaks. Clean the door and the seal.
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	 There is too much detergent or fabric softener in the detergent drawer. When dosing, observe the marking in the detergent drawer. → Page 32

Fault	Cause and troubleshooting				
Residual water is present in the compartment &.	Insert in compartment ⊗ is blocked. ► Clean the detergent drawer. → Page 37				
Fabric softener remains in the detergent drawer.	The use of fabric softener is not supported for the selected programme. ► Check whether the use of fabric softener is supported for the selected programme. → Page 25				
Odours have formed in the appliance.	 Humidity and detergent residue may promote the formation of bacteria. Clean the drum. → Page 37 If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate. 				


18.1 Emergency release

Releasing the door

Requirement: The drain pump is empty. → *Page 38*

- **1. ATTENTION!** Escaping water may cause material damage.
- ► Do not open the door if you can see water through the glass.

Pull the emergency release downwards with a tool and release.



- ✓ The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

18.2 Restart the appliance.

- To restart the appliance, press and hold Φ for approximately 5 seconds.
- 2. If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- 3. If the fault persists, call customer service. → Page 49

Please specify the exact error message when calling. If possible, document the fault with photos and videos.

19 Transportation, storage and disposal


19.1 Removing the appliance

- 1. Turn off the tap.
- 2. Empty the water inlet hose.
- 3. Put the appliance into standby mode. → Page 33
- 4. Unplug the appliance's mains plug.
- 5. Drain the water.
 - → "Cleaning the drain pump", Page 38
- 6. Detach the hoses.

19.2 Inserting the transit bolts

Secure the appliance before transportation using transit bolts in order to prevent transport damage.

1. Use a screwdriver to remove the 4 cover caps.



Keep the cover caps.

2 Insert the 4 transit bolts. → "Removing the transit bolts", Page 13

19.3 Using the appliance again

► For further information, see

→ "Installation and connection",
Page 11 and

→ "Starting an empty washing
cycle", Page 16.

19.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

★ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- Unplug the appliance from the mains.
- 2. Cut through the power cord.
- Dispose of the appliance in an environmentally friendly manner.
 Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and elec-

tronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

20 Customer Service

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

20.1 Product number (E-Nr.), production number (FD) and consecutive numbering (Z-Nr.)

You can find the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

21 Consumption values

The indicated consumption values are approximate.


The values may deviate from the indicated values depending on water pressure, water hardness, water inlet temperature, room temperature, type of laundry, amount and soiling of laundry, detergent used, fluctuations in the mains voltage and selected settings.

Programme	Temperat- ure (°C)	Load (kg)	Energy consump- tion (kWh) ¹	Water consumption (I) ¹	Pro- gramme duration (h:min) ¹
Cottons	20	10.0	0.500	90.0	3:25
Cottons	40	10.0	1.000	90.0	3:25
Cottons	60	10.0	1.900	90.0	3:40
Cottons + Pre- wash	40	10.0	1.200	100.0	3:40
Cottons Eco ²	60	10.0	0.685	72.0	5:56
Easy Care	40	4.0	0.780	45.0	2:29
Quick Mixed	40	4.0	0.670	42.0	1:00
Delicates/Silk	30	2.0	0.200	34.0	0:37
№ Wool	30	2.0	0.210	40.0	0:41

¹ Values determined according to the valid version of IEC60456

The program is recommended for normally soiled laundry.

21.1 Information for test institute



1	Layer 1: tablecoth
2	Layer 2: shirts, T-shirts, pillow cases
3	Layer 3: shorts (all), wash cloths (all), handkerchiefs (all)
4	Layer 4: shirts, T-shirts, pillow cases
5	Layer 5: tablecloth
6	Drum
7	External circle: sheets, bath towels

Programme setting with maximum speed for testing according to AS/ NZS2040.1 and labelling according to AS/NZS2040.2 and AS/NZS 6400 with cold water supply (20 °C).

Pre-treatment of new appliance

Run two empty runs of **Cottons** 90 °C with 1600 rpm: The 1st run with 50 g detergent and 8 g anti sudsing agent, the 2nd run without detergent and sudsing agent.

According to standard

AS NZS 2040.1-2005 AS NZS 2040.2-2005 AS NZ 6400-2016

Washing programme Cottons Eco 60 °C, 10.0 kg, 1600 rpm

Testing instructions

The dosage of detergent: 11.5 g/kg The dosage of anti sudsing agent: 2 g/kg

Add the dry powder detergent into main wash dispenser before start. After detergent is flushed in add the PBIS solution and anti-sudsing agent as soon as possible.

Age of test loads

The average age of test load around 10-20 times is recommended to replicate normal use.

Loading procedure

First, load the laundry items into the drum by filling the external circle. Fill possible gaps with wash clothes, handkerchiefs and laundry items without soil swatches. Afterwards, load the laundry items into the drum in layers as shown in the table and pictures below.

Make sure that swatches are flat and below the laundry item when loading items into the drum.

22 Technical data

Appliance height 84.5 cm

Appliance width	59.8 cm
Appliance depth	59.0 cm
Appliance depth with door closed	64.8 cm
Appliance depth with door open	109.0 cm
Weight	82.8 kg
Maximum load	10.0 kg
Mains voltage	220-240 V, 50 Hz
■ Minimum installation protection	10 A
Nominal power	2300 W
Water pressure	 Minimum: 100 kPa (1 bar) Maximum: 1000 kPa (10 bar)
Length of the water inlet hose	150 cm
Length of the water outlet hose	150 cm
Length of the power cord	160 cm

22.1 Information regarding Free and Open Source Software

This product includes software components that are licensed by the copyright holders as free or open source software.

The applicable licence information is stored on your home appliance. You can also access the applicable li-

cence information via your Home Connect app: "Profile -> Legal information -> Licence Information".¹ You can download the licence information on the brand product website. (Please search on the product website for your appliance model and additional documents). Alternatively, you can request the relevant information from ossrequest@bshg.com or BSH Hausger-

request@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str. 34, 81739 Munich, Germany.

The source code will be made available to you on request.

Please send your request to oss-request@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str.34, 81739 Munich, Germany.

Subject: "OSSREQUEST"

The cost of performing your request will be charged to you. This offer is valid for three years from the date of purchase or at least as long as we offer support and spare parts for the relevant appliance.

2.4 GHz band (2400-2483.5 MHz): Max. 100 mW 5-GHz band (5150-5350 MHz + 5470-5725 MHz): max. 150 mW

23 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the essential requirements and other relevant provisions of Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at www.bosch-home.com among the additional documents on the product page for your appliance.



¹ Depending on the appliance specifications

	BE	BG	CZ	DK	DE	EE	ΙE	EL	ES
	FR	HR	IT	CY	LI	LV	LT	LU	HU
	MT	NL	AT	PL	PT	RO	SI	SK	FI
	SE	NO	CH	TR	IS	UK (NI)		'	
5 GHz WLAN (Wi-Fi): For indoor use only.									
AL	BA	٨	1D	ME	MK	RS	UK		UA
5 GHz WLAN (Wi-Fi): For indoor use only.									







Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome**



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: **www.bosch-home.com/service**

Contact data of all countries are listed in the attached service directory.

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com

A Bosch Company

