



Washing machine

WIW28302GB

[en] User manual and installation instructions





You can find additional information and explanations online. Scan the QR code on the title page.



Table of contents

1 Safety 3	11 Laundry	27
1.1 General information 3	11.1 Preparing the laundry	27
1.2 Intended use 3	11.2 Care symbols on the care la-	
1.3 Restriction on user group 3	bels	27
1.4 Safe installation 4	12 Detergents and care	
1.5 Safe use 6	products	27
1.6 Safe cleaning and mainten-	13 Basic operation	
ance 8	13.1 Switching on the appliance	
2 Preventing material damage 8	13.2 Setting a programme	
3 Environmental protection and	13.3 Opening the door	
saving energy10	13.4 Loading laundry	
3.1 Disposing of packaging 10	13.5 Inserting the measuring aid	
3.2 Save energy and conserve re-	13.6 Using the measuring aid	
sources 10	13.7 Adding detergent and care	
3.3 Energy saving mode 10	product	29
4 Installation and connection 10	13.8 Starting the programme	29
4.1 Unpacking the appliance 10	13.9 Soaking laundry	30
4.2 Contents of package 10	13.10 Adding laundry	30
4.3 Requirements for the installa-	13.11 Cancelling the program-	
tion location11	me	30
4.4 Removing the transit bolts 12	13.12 Resuming the programme	
4.5 Tools for assembly 13	when the programme status	20
4.6 Installing the appliance 13	is Rinse Hold	
4.7 Connecting the appliance 18	13.13 Unloading the laundry	30
5 Before using for the first time 19	ance	30
5.1 Starting an empty washing		
cycle19	14 Childproof lock	31
6 Familiarising yourself with	14.1 Activating the childproof lock	21
your appliance20	14.2 Deactivating the childproof	JI
6.1 Appliance 20	lock	31
6.2 Detergent drawer 20		
6.3 Control panel21	15 Basic settings	31
7 Display 21	tings	31
8 Buttons 23	15.2 Changing the basic set-	0 1
	tings	31
9 Programmes24	16 Cleaning and servicing	
10 Accessories 26	. C Cleaning and Scriving	J_

18 Transportation, storage and disposal41	20 Consumption values 21 Technical data	
17 Troubleshooting 35 17.1 Emergency release 41 17.2 Restart the appliance 41	19.1 Product number (E-Nr.) and production number (FD)	42
16.1 Cleaning the drum	18.1 Removing the appliance 18.2 Inserting the transit bolts 18.3 Using the appliance again 18.4 Disposing of old appliance 19 Customer Service	41 41 42
10.1 Classing the drum	10.1 Demoving the appliance	۸.



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- with tap water and commercially available detergents and care products suitable for washing machines.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or

Safety en

inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Incorrect installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ► When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.
- ► When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ► Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.
- If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

The heavy weight of the appliance may result in injury when lifted.

- ► Do not lift the appliance on your own.
- If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.
- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- ➤ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material.

The appliance may vibrate or move when in use.

- ► Place the appliance on a clean, even, solid surface.
- ▶ Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- ► Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

Touching sharp edges on the appliance may lead to cuts.

- ▶ Do not touch the sharp edges on the appliance.
- ► Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer service. → Page 42

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ► Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

When spinning larger, waterproof items of laundry, imbalances may arise and lead to injuries.

► Do not wash and spin larger items of laundry, such as blankets or mattress covers, in the appliance.

Children may breathe in or swallow small parts, causing them to suffocate.

- Keep small parts away from children.
- ▶ Do not let children play with small parts.

Detergents and care products may result in poisoning if consumed.

- ► If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of explosion!

Laundry that has been pretreated with flammable cleaning agents that contain solvents may cause an explosion in the appliance.

► Rinse pretreated laundry thoroughly with water before washing.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

► Wait for the drum to come to a complete stop before reaching inside.

△ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

▶ Do not touch the hot detergent solution.

If the detergent drawer is opened, detergent and care products may spray out from the appliance.

Contact with eyes or skin may cause irritation.

► Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

Improper repairs are dangerous.

- Never make any technical modifications to the appliance or its features.
- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

- ▶ Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- ► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION

The functionality of the appliance may be impaired if you use the

wrong quantity of fabric softener, detergent, care product or cleaning agent.

► Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 24 The appliance is secured for transportation using transit bolts.

Transit bolts which have not been removed may result in material damage and damage to the appliance.

- ► Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- ► Before transport, fit the transit bolts fully in order to prevent damage in transit.

Material damage may be caused if the water inlet hose is connected incorrectly.

- ► Tighten the screw connections on the water inlet until they are handtight.
- Connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions or valves.
- Make sure that the valve housing for the water inlet hose does not come into contact with its surroundings and is not subjected to any external forces.
- Ensure that the inner diameter of the water tap is at least 17 mm.
- ► Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

► Ensure that the water pressure in the water supply system is at least

- 100 kPa (1 bar) and max. 1000 kPa (10 bar).
- ► If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- ► Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- ► Never kink, crush, modify or cut through water hoses.
- ► Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may lead to material damage and damage to the appliance.

► Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- ► Do not use harsh or abrasive deteraents.
- ► Do not use cleaning products with a high alcohol content.
- ► Do not use hard scouring pads or cleaning sponges.
- ► Clean the appliance with nothing but water and a soft, damp cloth.
- ► Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

- Choose programs with low temperatures and longer wash times and use maximum load capacity. → Page 24
- Add detergent based on the laundry's degree of soiling. Detergent dosage
- Reduce the washing temperature for lightly and normally soiled laundry.
- Set the maximum spin speed if you want to dry the laundry in the tumble dryer afterwards.
- Wash the laundry without prewash.

3.3 Energy saving mode

If you do not use the appliance for a brief period, it automatically switches to energy-saving mode. All displays go out and Start/Reload flashes. Energy-saving mode ends when you use the appliance again.

4 Installation and connection

4.1 Unpacking the appliance **ATTENTION**

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- ► Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- 1. Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 10
- 2. Check the appliance for visible damage.
- **3.** Open the door. \rightarrow *Page 28*
- 4. Remove any accessories from the drum
- 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- ► Do not operate the appliance with incomplete or defective accessor-
- Replace the accessories in guestion before operating the appliance
 - → "Accessories", Page 26

Note: The appliance has undergone a function test at the factory. This may cause water stains in the appliance, which the first wash cycle removes.

The delivery consists of the following:

- Washing machine
- Accompanying documents
- Transit bolts
- Cover cap¹
- Parts required for installation → "Installing the appliance", Page 13

4.3 Requirements for the installation location

Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

► Do not operate the appliance without a cover cap.

⚠ WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

► Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 26 before using the appliance for the first time

ATTENTION

If residual water in the appliance freezes, this may cause damage to the appliance.

▶ Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- ► Tilt the appliance carefully.
- ► Transport the appliance in an upright position.

Installation loca- Requirements tion

Base



Secure the appliance with fixing brackets *→ Page 26.*

Wooden joist floor



Place the appliance on a waterresistant wooden board (minimum thickness of 30 mm) which is screwed tightly to the floor.

Kitchen unit



Only install the appliance underneath a continuous worktop that is securely connected to adiacent cabinets. Reauired niche width: 60 cm.


¹ The number of cover caps varies depending on the model.

Installation loca- Requirements tion

Note: The use of sliding plates makes it easier to slide the appliance into the recess. Moisten the sliding plates with a mixture of water and washing-up liquid before pushing the appliance in. Do not use grease or oil to do this.

→ "Accessories", Page 27

Against a wall




Do not trap the power cord or the hoses between the wall and the appliance.

4.4 Removing the transit bolts


The appliance is secured for transportation using transit bolts on the rear of the appliance.

Note: Keep the transit bolt screws and the sleeves in a safe place for future transport.


1. Remove the hose ① and the power cord ② from the holders.



2. Unscrew ① and remove ② all of the screws for the 4 transit bolts using a WAF 13 wrench.




3. Remove the 4 sleeves.




4. Insert the cover cap and push it downwards.

Notes

- Note the number of cover caps included in the scope of delivery
- If four cover caps are included in the scope of delivery, insert the cover caps in the four openings for the transit bolts.



• If one cover cap is included in the scope of delivery, insert the cover cap in the bottom left opening for the transit bolt.



Note: To install the transit bolts to transport the appliance, perform these steps again in the reverse order.


4.5 Tools for assembly

You require the following tools for the assembly:


- Spirit level
- WAF 13 wrench
- WAF 17 wrench
- Forstner 35 mm drill bit
- 2 mm twist drill
- Screwdriver

4.6 Installing the appliance Preparing the appliance


1. To make it easier to slide in the appliance, turn in the appliance's rear feet until the appliance is on the runners.



2. Measure the built-in niche.




- 3. Lay the power cord as well as the water inlet and water outlet hose.
- **4.** Slide the appliance in and, at the same time, pull through the power cord, water inlet and water outlet hose.




- 5. Connect the water inlet hose.
 - → Page 18
- 6. Connect the water outlet hose.
 - → Page 18

7. Unscrew the rear appliance feet.




8. Align the appliance using a spirit level.



9. Tighten the lock nuts on the front appliance feet hand-tight against

the housing using a WAF 17 wrench.




In doing so, hold the foot tight and do not adjust its height.


Installing the cabinet door

Note: Metal elements may impair the function of the control panel. Do not use any cabinet doors with metal elements in the area of the control panel.

1. Hold the cabinet door at the required height on the appliance and mark the upper edge of the appliance on the inside of the door.




Mark on the top edge of the appliance at the left-hand stop




Mark on the top edge of the appliance at the right-hand stop

2. Using the mark for the top edge of the appliance on the inside of the door as a basis, mark the drill holes as follows.




Mark for the holes at the left-hand stop




Mark for the holes at the right-hand


3. At the previously marked points, use a Forstner 35 mm drill to drill the holes for the hinges. At the previously marked points, use a 2 mm twist drill to drill holes for the screws.




- en Installation and connection
- **4.** Insert the hinges into the holes and screw them in.




- **5.** Screw on the counter plates for the magnetic catches.
- **6.** Insert the hinges into the appliance ① ②.




- **7.** Slide in the covering rail ③ and screw it in ④.
- **8.** Put the magnetic catches on the appliance.



Aligning the cabinet door Vertically aligning the cabinet door




Horizontally aligning the cabinet door




Installing the base panel


1. Insert the spacers for the base panel.




2. Measure dimension Z and dimension Y.




3. Screw the spacers in as per the dimensions.



4. Install the base panel.



- **5.** Connect the appliance to the power supply .
 - → "Connecting the appliance to the electricity supply", Page 19



4.7 Connecting the appliance Connecting the water inlet hose

⚠ WARNING

Risk of electric shock!


The appliance contains live parts. Touching live parts is dangerous.

► Do not immerse the electrical AquaStop valve in water.

ATTENTION

Material damage may be caused if the water inlet hose is connected incorrectly.

- Tighten the screw connections on the water inlet until they are handtight.
- 1. Connect the water inlet hose to a tap (26.4 mm = 3/4").



2. Open the water tap carefully and check that the connection points are tight.

Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.

ATTENTION

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

- ► Secure the water outlet hose against unintentional loosening. In the event of a blocked or covered outlet, accumulated wastewater can flow back into the appliance.
- Before operating the appliance, ensure that the wastewater drains away quickly and eliminate any blockages.


Note: Observe the draining heights. The maximum draining height is 100 cm.

Siphon



Secure the connection point with a (24–40 mm) hose clamp.

Sink




Fix and secure the water outlet hose with an elbow.

→ "Accessories", Page 26

Plastic pipe with rubber sleeve or gully Fix and secure the water outlet hose with an elbow.

→ "Accessories", Page 26



Connecting the appliance to the electricity supply

Note: Your electrical domestic installation for this appliance must comply with the local legal provisions and safety regulations, and should include a residual current circuitbreaker.

- 1. Insert the mains plug of the appliance's power cable in a socket nearby.
 - The connection details of the appliance can be found under Technical data → Page 44.
- 2. Check the mains plug is inserted properly.

5 Before using for the first time


Prepare the appliance for use.

5.1 Starting an empty washing cycle


Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

- 1. Turn the programme selector to Cottons 60°.
- 2. Close the door

- **3.** Pull out the detergent drawer.
- 4. Pour approx. 1 litre of tap water into compartment II.



5. Add washing powder containing oxvgen bleach to compartment II.




To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

- 6. Push in the detergent drawer.
- 7. Start the programme. \rightarrow Page 29
- 8. Start the first wash cycle or set the programme selector to Off to switch off the appliance.
 - → "Basic operation", Page 28

6 Familiarising yourself with your appliance

6.1 Appliance

You can find an overview of the parts of your appliance here.



On certain models, specific details such as the colour and shape may differ from those pictured.


- Maintenance flap for the drain pump → Page 33
- 2 Door → Page 28
- 3 Detergent drawer → Page 20
- 4 Control panel → Page 21
- 5 Water outlet hose → Page 18

- 6 Power cord → Page 19
- 7 Transit bolts
- 8 Water inlet hose → Page 18
- 9 Emergency release → Page 41
- 10 Drain hose → Page 33

6.2 Detergent drawer

Note: Observe the manufacturer's instructions on the use and dosage of the detergent and care product and


the information in the programme descriptions.



- Measuring aid for liquid detergent → Page 28
- Compartment II: Detergent for the main wash
- Compartment %: Fabric softener
- Compartment I: Detergent for prewash

6.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.




Display

The display shows the current settings, options or relevant information.

en Display

Depending on the programme status, the display shows some information in the 8:88 area, e.g. 8:98 area, e.g. 8:98 area, e.g. 8:98 area, e.g. 8:98 area, e.g. 8:98



Example: Display

Display	Description
0:40 1	Expected programme duration or programme time remaining in hours and minutes.
10h ¹	Program end time → "Buttons", Page 23
8.0 1	Recommendation for the maximum load capacity for the selected program in kg.
1400	Set spin speed in rpm. → Page 23 0: No final spin, only draining: Rinse Hold, no draining
_	Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be started or continued.
<u></u>	Programme status: Washing
(EE)	Programme status: Rinsing
<u>©</u>	Programme status: Spinning
	Programme status: Rinse hold
End	Programme status: Programme end
C	 Lights up: The childproof lock is activated. Flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 31
=U	Shortened programme duration is activated. → "Buttons", Page 23

¹ Example

Display	Description
©	 Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened.
<u>F</u>	No water pressure.The water pressure from the tap is too low.
E:351	Error code, error display, signal. → Page 35

8 Buttons

The selection of programme settings depends on the programme that is set.

Button	Selection	More information
Start/Reload	StartCancelPause	Start, cancel or pause the programme.
Speed Perfect	ActivateDeactivate	Activate or deactivate a shorter programme duration.
		Note: Energy consumption increases. The washing result is not affected by this.
Finish in	Up to 24 hours	Set the programme end time. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
Spin Speed	1400	Adjust the spin speed or activate – – (Rinse Hold). Set spin speed in rpm. If – – is selected, the water is not drained at the end of the washing cycle and the spin cycle is deactivated. The laundry remains in the water used for rinsing.
c∞ 3 sec.	ActivateDeactivate	→ "Childproof lock", Page 31
Start/Reload	Multiple selection	→ "Basic settings", Page 31

¹ Example

9 Programmes

Notes

- The laundry's care labels provide you with additional information about programme selection.
 - → "Care symbols on the care labels", Page 27
- The programme's temperature setting guarantees that the recommended temperature on the care label is not exceeded. The temperature that is reached in the appliance may differ from the set temperature. This means that the best possible washing performance is achieved with optimal energy efficiency.

Programme	Description	Max. load (kg)
Cottons	Wash hard-wearing items made from cotton or linen. Also suitable as a short programme for normally soiled laundry when you activate Speed Perfect. Programme setting: Max. 60 °C Max. 1400 rpm	8.0 5.0 ¹
Eco 40-60	Wash items made from cotton or linen. Note: Fabrics which can be washed from 40 °C wu up to 60 °C wu as per the care symbol can be washed together. The washing performance corresponds to the best possible washing performance class according to the legal requirements. For this programme, the washing temperature is automatically adjusted depending on the load size, in order to achieve the best possible energy efficiency with the best possible washing result. You cannot change the washing temperature. The maximum spin speed is 1400 rpm.	8.0
Cottons + Pre- wash	Wash hard-wearing items made from cotton or linen. Programme with prewash for heavily soiled laundry. Divide the detergent between the detergent drawer for the prewash and the main wash. → Page 20	8.0 5.0 ¹

¹ Speed Perfect activated

Max. 800 rpm

Programme	Description	Max. load (kg)
Rinse	Rinse and then spin the laundry, and drain the water. Programme setting: Max. 1400 rpm	_
Spin/Drain	Spin the laundry and drain the water. If you only want to drain the water, activate 0. The laundry is not spun. Programme setting: Max. 1400 rpm	_
AllergyPlus	Wash hard-wearing items made from cotton or linen. Suitable for allergy sufferers and for strict hygiene requirements.	6.5
	Note: Once the set temperature has been reached, it remains constant throughout the entire washing process.	
	Programme setting: ■ Max. 60 °C ■ Max. 1400 rpm	
Shirts	Wash non-iron shirts and blouses made from cotton, linen or synthetic fabrics.	2.0
	Note: Use the Delicates/Silk programme to wash shirts and blouses made from silk or delicate fabrics.	
	Programme setting: Max. 40 °C Max. 800 rpm	

10 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order num- ber
Water inlet hose extension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Water outlet hose extension	Extend the water outlet hose (2.20 m).	11057910
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Elbow	Secure the water outlet hose in place.	00655300

	Use	Order num- ber
Liquid detergent insert	Measure liquid detergent.	00605740
Slide sheets	Makes it easier to insert the appliance into the installation recess.	00661827
Taller feet	Taller feet for installing the appliance under a high worktop.	WMZ30400

11 Laundry

11.1 Preparing the laundry **ATTENTION**

Objects remaining in the laundry may damage the laundry and the drum.

► Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, hook and loop fasteners, hooks and eyes
- Tie cloth belts, cloth straps and cords together
- Remove curtain fittings and lead strips
- Wash small or particularly delicate items in a mesh washing bag
- Wash large and small items of laundry together
- Wash laundry with fresh stains immediately
- Pretreat laundry with dried stains and wash several times
- Load the laundry unfolded into the drum
- Before loading the drum, any laundry that has been pre-treated with

chlorine bleach should be rinsed several times

11.2 Care symbols on the care labels

Washing care symbols

Symbol	Recommended programme
95 660 40 30	Cottons (normal)
60 40 30	Easy Care (gentle)
<u> </u>	Delicates/Silk for washing by hand (particularly gentle)
LAN.	Woollens (hand wash)
×	(not suitable for machine- washing)

12 Detergents and care products

You can protect your appliance and your laundry by selecting and using the correct detergents and care products.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

When using liquid detergents, only use liquid detergents that are selfflowing

en Basic operation

- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances
- Do not use chlorine bleach
- Do not use dyes regularly as fixing salt can damage stainless steel
- Do not use color-bleaching agents in the appliance

13 Basic operation

13.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected. \rightarrow Page 10

► Turn the programme selector to a programme.

Note: The lighting for the drum goes out automatically.


13.2 Setting a programme

- **1.** Turn the programme selector and set the required programme.
 - → "Programmes", Page 24
- **2.** If required, adjust the programme settings.
 - → "Buttons", Page 23


The programme settings are not saved permanently for the programme.

13.3 Opening the door

1. Grip under the door handle and pull on the door.



2. Open the door.



13.4 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes.

→ "Programmes", Page 24


Requirements

- The laundry is prepared and sorted.
 - → "Laundry", Page 27
- The drum is empty.
- **1.** Open the door. \rightarrow Page 28
- 2. Place the laundry in the drum.
- Close the door.Ensure that there is no laundry trapped in the door.


13.5 Inserting the measuring aid

1. Pull out the detergent drawer.

2. Press down on the insert and remove the detergent drawer.



3. Insert the measuring aid.



13.6 Using the measuring aid


To more easily measure the liquid detergent, you can use a measuring aid in the detergent drawer.

Note: Do not use a measuring aid for viscous detergents, for washing powder, or when the prewash or programme end time is activated.

Requirements

- The detergent drawer → Page 20 has been pulled out.
- The measuring aid is inserted. → Page 28

1. Slide the measuring aid forwards.



2. Fold the measuring aid down and click it into place.



13.7 Adding detergent and care product

Note: Observe the information about detergents and care products *→ Page 27.*

- **1.** Pull out the detergent drawer.
- 2. If required, use the dosing aid. → Page 29
- 3. Pour in the detergent.
 - → "Detergent drawer", Page 20
- 4. If required, add the care product.
- 5. Push in the detergent drawer.

13.8 Starting the programme Requirements

- A programme is set. → Page 28
- The door is closed.
- Press Start/Reload.
- The drum rotates and load detection takes place. This can take up

en Basic operation

- to 2 minutes, after which water enters the drum.
- The display shows the programme duration or the programme end time.
- After the programme has ended, the display shows: End.

13.9 Soaking laundry

Note: No additional detergent is required for soaking. The appliance uses the filled detergent for soaking and washing.

Requirements

- The laundry is placed in the appliance. → Page 28
- A programme has started. → Page 29
- Press Start/Reload approx.
 minutes after the programme start.

The programme pauses and the laundry can soak.

Press Start/Reload after the required soaking time.

13.10 Adding laundry

After the programme starts, you can remove or add laundry depending on the programme status.

1. Press Start/Reload.

The appliance pauses.

Note: If you want to add laundry, follow the instructions on the display.

- → "Display", Page 23
- **2.** Open the door. \rightarrow *Page 28*
- 3. Add or remove laundry.
- 4. Close the door.
- **5.** Start the programme. \rightarrow *Page 29*

13.11 Cancelling the programme

1. Press Start/Reload.

- 2. Open the door. → Page 28

 The appliance door remains locked for safety reasons if the temperature and water levels are high.
 - If the temperature is high, start the **Rinse** programme.
 - If the water level is high, start the **Spin** programme or select a suitable programme for draining.
 → "Programmes", Page 24
- 3. Remove the laundry. → Page 30

13.12 Resuming the programme when the programme status is Rinse Hold

Requirements

- Rinse Stop is activated.

 → "Buttons", Page 23
- The last rinse cycle of the set programme has ended and the laundry is in the rinsing water.
- Set the **Spin** programme or a programme for draining the water.
 → Page 24
- 2. Press Start/Reload.

13.13 Unloading the laundry

- 1. Open the door. → Page 28
- **2.** Remove the laundry from the drum.

13.14 Switching off the appliance

- **1.** Turn the programme selector to **Off**.
- Cleaning the rubber gasket.
 → Page 35

Note: Leave the appliance door and the detergent drawer open to dry.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof

- ▶ Press on both c 3 sec. buttons for approx. 3 seconds.
- ▼ The control elements are locked.
- ▼ The childproof lock remains active even after the appliance has been switched off and in the event of a power cut.

14.2 Deactivating the childproof lock


Requirement: To deactivate the childproof lock, the appliance must be switched on.

- ▶ Press on both c 3 sec. buttons for approx. three seconds. So that the programme currently running is not cancelled, the programme selector must be set to the initial programme.
- ✓ come goes out on the display.

15 Basic settings

You can configure the basic settings for your appliance to meet your needs

15.1 Overview of the basic settings



Programme selector with programme positions

- No basic setting.
- Set the volume of the signal at the end of the programme: 0 (off) to 4 (very loud)

Set the volume of the signal

- tone emitted when the buttons are pressed: 0 (off) to 4 (very loud)
- Display the number of finished 6 programmes.

15.2 Changing the basic settinas

- 1. Set the programme selector to position 1. → Page 31
- 2. Press Start/Reload and, at the same time, turn the programme selector to position 2.
- ▼ The display shows the current value
- 3. Use the programme selector to select the required basic setting. → Page 31
- 4. To change the value, press Finish
- 5. To save the changes, switch off the appliance.

16 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

16.1 Cleaning the drum

Clean the drum if you have carried out 20 washing cycles at a temperature of 40 °C or lower, or if you have not used the appliance for a prolonged period, but at least once a year.

⚠ CAUTION Risk of injury!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.

- ► Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.

Tip: You can get our tested and approved machine care and machine cleaner products online at *https://www.bosch-home.com/store* or from customer service.


 Run the Cottons 60° programme without laundry but with washing powder that contains oxygen bleach or a cleaning agent for caring for the inside of the appliance.

16.2 Cleaning the detergent drawer


Note: Scan the QR code to see an animation of the process.




- 1. Pull out the detergent drawer.
- **2.** Press down on the insert and remove the detergent drawer.




3. Pull out the insert upwards.



4. Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and click it into place.



Clean the opening for the detergent drawer.



7. Push in the detergent drawer.

16.3 Cleaning the drain pump

Clean the drain pump regularly, at least once a year, as well as in the

event of faults, e.g. blockages or rattling noises.


Note: Scan the QR code to see an animation of the process.

Observe the following safety instructions before you start the animation.




Emptying the drain pump


- **1.** Turn off the tap.
- 2. Switch off the appliance.
- **3.** Disconnect the appliance's mains plug from the power supply.
- 4. Remove the base panel.



Slide a suitable receptacle under the opening for draining the detergent solution.




6. Take the drain hose out of the holder.




- 7. A CAUTION Risk of scalding! When you wash at high temperatures, the detergent solution gets hot.
 - ► Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the locking cap.



8. Once emptied, press firmly on the locking cap.



9. Clip the drain hose into the holder.




Cleaning the drain pump


Requirement: The drain pump is empty.

- 1. Since water may remain in the drain pump, unscrew the pump cap carefully.
 - ► The filter insert in the pump housing may become stuck due to coarse particles of dirt.


 Loosen the dirt and remove the filter insert.



2. Clean the interior, the thread on the pump cap and the pump housing.




- 3. Ensure that the impeller in the drain pump can rotate.
- 4. Insert the pump cap and screw it on as far as it will go.



The handle on the pump cap must be in a vertical position.

5. Install the base panel.



Before the next wash

To prevent unused detergent from flowing straight into the outlet in the next wash, run a suitable programme for draining after you have emptied the drain pump.

- **1.** Open the water tap.
- 2. Insert the mains plug.
- 3. Switch on the appliance.
- 4. Pour 1 litre of water into compartment II.
- **5.** Select a suitable programme for draining.
 - → "Programmes", Page 24

16.4 Cleaning the rubber gasket

Clean the rubber gasket regularly.

- **1.** Open the door. \rightarrow Page 28
- 2. Remove any foreign objects and fluff from the rubber gasket.



3. Clean the outside and the inside of the rubber gasket with a damp cloth and wipe dry.

17 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

⚠ WARNING

Risk of electric shock!

Improper repairs are dangerous.

- ▶ Never make any technical modifications to the appliance or its features.
- ► Repairs to the appliance should only be carried out by trained specialist
- ► Only use genuine spare parts when repairing the appliance.

en Troubleshooting

► If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting	
The display goes out and Start/Reload flashes.	Energy-saving mode is active▶ Press Start/Reload.	
E:36 -10 / E:30 -80 / E:18 The detergent solution is not being pumped	The water outlet hose is connected too high, is kinked or trapped, or has been extended impermissibly. ► Check the installation of the water outlet hose. → Page 18	
out.	Drain pipe or water outlet hose is blocked. ▶ Clean the drain pipe and the water outlet hose.	
	The drain pump is blocked or the pump cover is not installed correctly. ► Check that the pump cover is installed correctly. → Page 33 ► Clean the drain pump. → Page 33	
	Detergent dosage is too high.Reduce the amount of detergent for the next washing cycle with the same load.	
	 is activated. Start the Spin programme or a suitable draining programme. → Page 24 	
E:36 -25 -26	Drain pump is blocked. ► Clean the drain pump. → Page 33	
E:60 -2B / E:32 / H:32	The appliance has interrupted the spin cycle because the laundry is unevenly distributed. • Redistribute the laundry in the drum.	
E:30 -10 / ዶ	The tap is turned off. ► Turn on the tap.	
	The water inlet hose is kinked or jammed. ► Check the installation of the water inlet hose. → Page 18	

Fault	Cause and troubleshooting		
E:30 -10 / ዶ	The filter in the water inflow is blocked. Clean the filter in the water inflow. Scan the QR code to see an animation of the process.		
	The water pressure is low. ► Check whether the tap has sufficient water pressure.		
	 The water level measuring system is defective. With this error message, the appliance starts a draining process. 1. Wait approx. 5 minutes until the draining process ends. 2. Restart the appliance. If required, start the draining process again. 3. If the fault persists, call customer service. 		
E:35 -10 / E:23	The appliance is leaking. 1. Turn off the water tap. 2. Call customer service. → Page 42		
E:30 -20	 Critical malfunction. ➤ Turn off the water tap. With this error message, the appliance starts a draining process. 1. Wait approx. 5 minutes until the draining process ends. 2. Restart the appliance. If required, start the draining process again. 3. If the fault persists, call customer service. → Page 42 		
	Detergent dosage is too high.▶ Reduce the amount of detergent for the next washing cycle with the same load.		
	Additional water has been added.▶ Do not add any extra water to the appliance while it is operating.		

Fault	Cause and troubleshooting		
All other error codes.	 Malfunction 1. Restart the appliance. 2. If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. 3. If the fault persists, call customer service. → Page 42 Please specify the exact error message when calling. If possible, document the fault with photos and videos. 		
Heavy foam build-up.	 Detergent dosage is too high. Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into compartment II (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load. 		
© flashes.	The door is not completely closed. 1. Ensure that there is no laundry trapped in the door. 2. Close the door.		
The programme does not start.	Childproof lock is activated. ► Deactivate the childproof lock. → Page 31		
	Finish in is activated. ► Check whether Finish in is activated. → Page 23		
While the programme is running, no programme status is shown on the display.	Not a fault. This is not a washing programme, so a programme status display is not provided. No action required.		
The programme is paused or has been interrupted, but the	The temperature is too high. ➤ Start the Rinse programme or wait until the temperature has dropped.		
door will not open.	Water level is too high. ► Start the Spin programme or a suitable draining programme. → Page 24		
The door cannot be opened due to a power cut.	The door is locked. ► Open the door using the emergency release. → Page 41		
Drum jerks after the programme starts.	Not a fault. An internal motor test is started. No action required.		

Fault	Cause and troubleshooting		
Drum rotates, water does not flow in.	Not a fault. Load detection is active for up to 2 minutes. No action required.		
No water is visible in the drum.	Not a fault. Water is below the visible area. No action required.		
The spin cycle runs several times.	Not a fault. The appliance eliminates an imbalance by repeatedly redistributing the laundry. No action required.		
The appliance is vibrating, 'wandering'	Appliance is not correctly aligned. ► Align the appliance.		
and making loud noises during the spin cycle.	The appliance feet are not fixed. Secure the appliance's feet.		
	Transit bolts have not been removed. ▶ Remove the transit bolts.		
High spin speed not reached.	The appliance is using a reduced spin speed to eliminate an imbalance. No action required.		
The programme duration changes during the wash cycle.	Not a fault. The programme sequence is optimised electronically, another rinse cycle is switched on due to heavy foam build-up, or an imbalance is eliminated. No action required.		
Whooshing, hissing or sucking noises.	Not a fault. Water is pumped in or detergent solution in pumped out. No action required.		
Banging noises, rattling in the drain pump.	A foreign object is in the drain pump. ► Clean the drain pump. → Page 33		
There are detergent residues on the laundry.	Detergents may contain water-insoluble substances that deposit on the laundry. ➤ Start the Rinse programme or brush out the laundry after drying.		
The laundry is too wet after the spinning cycle.	 A low spin speed is selected. ► Start the Spin programme. ► The next time you run a wash cycle, set a higher spin speed. 		
	The appliance is using a reduced spin speed to eliminate an imbalance. 1. Redistribute the laundry in the drum. 2. Start the Spin programme.		

Fault	Cause and troubleshooting		
Creasing.	The selected programme is unsuitable for the type of fabric.		
	► Set a suitable programme. → Page 24		
	A high spin speed is selected.► The next time you run a wash cycle, set a lower spin speed.		
	The load is unsuitable. ► Observe the programme's maximum load capacity. → Page 24		
	Prepare the laundry. → Page 27		
Water is leaking out at the water inlet hose.	The water inlet hose is not correctly connected or is damaged. • Check the installation of the water inlet hose.		
	 → Page 10 In the event of damage, call customer service. → Page 42 		
Water is leaking out at the water outlet hose.	The water outlet hose is not connected correctly or is damaged. ► Check the installation of the water outlet hose. → Page 10 Replace the water outlet hose if it is damaged.		
Matau ia la alsia a fuera	. · ·		
Water is leaking from below the door.	Dirt on the door or seal causes leaks. ► Clean the door and the seal.		
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	 There is too much detergent or fabric softener in the detergent drawer. ▶ When dosing, observe the marking in the detergent drawer. → Page 29 		
Residual water is present in the compartment %.	Insert in compartment % is blocked. ► Clean the detergent drawer. → Page 32		
Fabric softener remains in the detergent drawer.	 The use of fabric softener is not supported for the selected programme. Check whether the use of fabric softener is supported for the selected programme. → Page 24 		
Odours have formed in the appliance.	 Humidity and detergent residue may promote the formation of bacteria. ▶ Clean the drum. → Page 32 ► If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate. 		


17.1 Emergency release

Releasing the door

Requirement: The drain pump is empty.

- 1. ATTENTION Escaping water may cause material damage.
 - ► Do not open the door if you can see water through the glass.

Pull the emergency unlock downwards with a tool and release.



- ✓ The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- **3.** Close the service flap.

17.2 Restart the appliance.

- 1. Restart the appliance.
- 2. If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- 3. If the fault persists, call customer service. → Page 42 Please specify the exact error message when calling. If possible, document the fault with photos and videos.

18 Transportation, storage and disposal


18.1 Removing the appliance

- **1.** Turn off the tap.
- 2. Empty the water inlet hose.
- 3. Switch off the appliance.
 - → Page 30
- 4. Unplug the appliance's mains plug.
- 5. Drain the water.
 - → "Cleaning the drain pump", Page 33
- 6. Detach the hoses.

18.2 Inserting the transit bolts

Secure the appliance before transportation using transit bolts in order to prevent transport damage.

1. Use a screwdriver to remove the cover cap 1.



Retain the cover cap.

2. Insert the 4 transit bolts.

18.3 Using the appliance again

► For further information, see Installation and connection \rightarrow Page 10 and Starting an empty washing cycle → Page 19.

¹ The number of cover caps varies depending on the model.

18.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING

Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- Unplug the appliance from the mains.
- 2. Cut through the power cord.
- Dispose of the appliance in an environmentally friendly manner.
 Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

19 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website.

19.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate.

Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service tele-

phone number to find them again quickly.

19.2 AQUA-STOP quarantee

In addition to warranty claims against the seller under the purchase agreement and in addition to our manufacturer's warranty, we offer compensation under the following conditions.

- If our Aqua-Stop system is defective and causes water damage, we will make good the damage for private users. To ensure protection from water damage, the appliance must be connected to the power vlagus.
- The liability guarantee is valid for the service life of the appliance.

- A claim can only be made under the quarantee if the appliance has been correctly installed and connected with Aqua-Stop according to our instructions; this also includes correctly fitting the Aqua-Stop extension (genuine accessory). Our guarantee does not cover defective supply lines or fittings up to the Aqua-Stop connection on the tap.
- If your appliance is fitted with Aqua-Stop, you can in principle leave your appliance unattended during operation and the tap turned on afterwards. The tap only needs to be turned off if you are away from home for a long period. e.g. on holiday for several weeks.

20 Consumption values

The following information is provided in accordance with the EU Ecodesian Regulation. The values given for programs other than the **Eco 40-60** are indicative only and were determined in accordance with the applicable standard EN60456.

Programme	Load (kg)	Pro- gramm e dura- tion (h:min) ¹	Energy con- sump- tion (kWh/ cycle) ¹	Water con- sump- tion (I/ cycle) 1	Max- imum temper- ature (°C) 5 mins 1	Spin speed (rpm) ¹	Residual moisture (%)1
Eco 40-60 ²	8.0	3:26	1.090	55.0	48	1400	50.00
Eco 40-60 ²	4.0	2:40	0.560	45.0	38	1390	50.00
Eco 40-60 ²	2.0	2:25	0.170	33	25	1400	54.00
Cottons 20 °C	8.0	3:20	0.320	88.0	23	1400	52.00

¹ Due to the influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions, the actual values may deviate from the stated values.

² Test programme in accordance with the EU Ecodesign Directive and the EU Energy Labelling Regulation with cold water (15 °C).

Programme	Load (kg)	Pro- gramm e dura- tion (h:min) ¹	Energy con- sump- tion (kWh/ cycle) ¹	Water con- sump- tion (I/ cycle) 1	Max- imum temper- ature (°C) 5 mins 1	Spin speed (rpm) ¹	Residual moisture (%)1
Cottons 40 °C	8.0	3:20	1.030	88.0	45	1400	52.00
Cottons 60 °C	8.0	3:20	1.350	88.0	53	1400	52.00
Cottons + Pre- wash 40 °C	8.0	4:00	1.200	92.0	45	1400	52.00
Easy-Care 40 °C	4.0	2:30	0.770	64.0	44	1200	30.00
Mixed Load 40 °C	4.0	1:05	0.610	45.0	41	1400	55.00
Wool @ 30 °C	2.0	0:45	0.220	42.0	24	800	27.00

21 Technica	al data
Appliance height	81.8 cm
Appliance width	59.6 cm
Appliance depth	54.4 cm
Appliance depth with door closed	57.4 cm
Appliance depth with door open	95.6 cm
Weight	76.3 kg
Maximum load	8.0 kg
Mains voltage	220-240 V, 50 Hz
➡ Minimum installation protection	10 A
Nominal power	2300 W

Power consumption	Off mode: 0.12WLeft-on mode: 0.50 W
Water pressure	Minimum: 100 kPa (1 bar)Maximum: 1000 kPa (10 bar)
Length of the water inlet hose	220 cm
Length of the water outlet hose	220 cm
Length of the power cord	210 cm
This product conta	ins light sources


This product contains light sources from energy efficiency class F. These light sources are available as a spare


¹ Due to the influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions, the actual values may deviate from the stated values.

part and must only be replaced by trained specialist staff. More information about your model can be found online at https://

eprel.ec.europa.eu/qr/10936271. This web address is linked to the official EU EPREL product database.

¹ Only applies to countries in the European Economic Area







Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- · Discounts for accessories & spare-parts
- · Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome**



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you:

www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com

A Bosch Company

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom



9001910046 (050522)