



# Freezer

**GUN21..** 

[en] Information for Use





You can find additional information and explanations online. Scan the QR code on the title page.



# **Table of contents**

1 Safety	8.1 Automatic Super freezing
1.5 Safe installation	9.1 Door alarm
3 Environmental protection and saving energy	10.3 Switching on the connection to the WLAN home network
4 Installation and connection 8 4.1 Scope of delivery	10.4 Intelligently networking appli- ances using Matter 1
5 Familiarising yourself with your appliance115.1 Appliance115.2 Control panel126 Features126.1 Accessories127 Basic operation13	10.8 Data protection
7.1 Switching on the appliance 13 7.2 Operating tips 13 7.3 Switching off the appliance 13 7.4 Setting the temperature 13	11.5 Shelf life of frozen food at  -18 °C

<sup>&</sup>lt;sup>1</sup> Matter is developed by Connectivity Standards Alliance™. This brand, related logos, and marks are trademarks of the Alliance, all rights reserved.

		Salety	en
(	Taking the appliance opperationDisposing of old applia		
17.1 F	ustomer Service Product number (E-Nr.) duction number (FD) a consecutive numbering	), pro- nd j (Z-	
	Vr.)		
	echnical datanformation regarding F		24
á	and Open Source Soft	ware	24
19 De	eclaration of Conformi	tv	25

19.1 Statement of Compliance for

Great Britain .......25



# 1 Safety

Observe the following safety instructions.

#### 1.1 General information

12 2-star freezer area ...... 19 13 Defrosting ...... 19 13.1 Defrosting in the freezer com-

partment ...... 19 14 Cleaning and servicing ........... 19 14.1 Preparing the appliance for

cleaning ...... 19 14.2 Cleaning the appliance .......... 19 14.3 Removing the fittings ...... 20 15 Troubleshooting ...... 20 15.1 Power failure ...... 22 16 Storage and disposal ...... 23

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

# 1.2 Intended use

This appliance is only intended to be fitted under a counter.

Only use this appliance:

- for freezing food and making ice cubes.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 2000 m above sea level.

# 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are

#### en Safety

supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Children above the age of three years old and younger than eight years old may load and unload the the fridge-freezer.

# 1.4 Safe transport

# 

The heavy weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

#### 1.5 Safe installation

#### 

Incorrect installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.
- ► When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

▶ Never let the power cord come into contact with heat sources.

# **⚠ WARNING – Risk of explosion!**

If the appliance's ventilation openings are closed off, a leak in the refrigeration circuit may result in a flammable mixture of gas and air.

► Keep ventilation openings in the appliance casing or in the integrated casing clear of obstruction.

#### 

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.
- If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

Portable multiple socket strips or portable power supply units may overheat and cause a fire.

► Do not place portable multiple socket strips or power supply units on the back of the appliance.

#### 1.6 Safe use

#### 

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners to clean the appliance.

### 

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

# **⚠ WARNING – Risk of explosion!**

If the cooling circuit is damaged, flammable refrigerant may escape and explode.

- ➤ To accelerate the defrosting process, do not use any other mechanical devices or means other than those recommended by the manufacturer.
- ▶ If food is stuck to the freezer compartment, loosen it with a blunt object such as the handle of a wooden spoon.

Products which contain flammable propellants and explosive substances may explode, e.g. spray cans.

▶ Do not store products which contain flammable propellants (e.g. spray cans) or explosive substances in the appliance.

#### 

Electrical devices within the appliance may cause a fire, e.g. heaters or electric ice makers.

▶ Do not operate electrical devices within the appliance.

# **⚠ WARNING** – Risk of injury!

Containers that contain carbonated drinks may burst.

► Do not store containers that contain carbonated drinks in the freezer compartment.

Injury to the eyes caused by escaping flammable refrigerant and hazardous gases.

▶ Do not damage the tubes of the refrigerant circuit or the insulation.

#### 

Contact with frozen food and cold surfaces may cause burns by refrigeration.

- ► Never put frozen food straight from the freezer compartment into your mouth.
- ► Avoid prolonged contact of the skin with frozen food, ice and surfaces in the freezer compartment.

#### 

To prevent food from being contaminated, you must observe the following instructions.

- ▶ If the door is open for an extended period of time, this may lead to a considerable temperature increase in the compartments of the appliance.
- ► Regularly clean the surfaces that may come into contact with food and accessible drain systems.
- ▶ If the fridge/freezer is empty for an extended period of time, switch off the appliance, defrost it, clean it and leave the door open to prevent the formation of mould.

# 1.7 Damaged appliance

#### 

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ► If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer service. → Page 23 Improper repairs are dangerous.
- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.

### **△ WARNING – Risk of fire!**



If the tubes are damaged, flammable refrigerant and harmful gases may escape and ignite.

- Keep naked flames and ignition sources away from the appliance.
- ▶ Ventilate the room.

- ► Switch off the appliance. → Page 13
- ► Unplug the mains plug from the mains or switch off the circuit breaker in the fuse box.
- ► Call customer service. → Page 23

# 2 Preventing material damage

#### **ATTENTION**

Using the base, runners or appliance doors as a seat surface or climbing surface may damage the appliance.

- ► Do not stand or support yourself on the base, runners or doors. Contamination with oil or fat may cause plastic parts and door seals to become porous.
- Keep plastic parts and door seals free of oil and grease.

If you clean fittings and accessories in the dishwasher, this may cause them to become deformed or discolour.

Never clean fittings and accessory in the dishwasher.

# 3 Environmental protection and saving energy

#### 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

## 3.2 Saving energy

If you follow these instructions, your appliance will use less power.

#### Selecting the installation location

- Keep the appliance out of direct sunlight.
- Install the appliance as far away as possible from heating elements, cookers and other heat sources:
  - Maintain a 30 mm clearance to electric or gas cookers.
  - Maintain a 300 mm clearance to oil or solid-fuel cookers.
- Never cover or block the exterior ventilation grilles.

#### Saving energy during use

**Note:** The arrangement of the fittings does not affect the energy consumption of the appliance.

- Open the appliance only briefly and then close it carefully.
- Never cover or block the interior ventilation openings or the exterior ventilation grilles.
- Transport purchased food in a cool bag and place in the appliance quickly.
- Allow warm food and drinks to cool down before storing them.
- Always leave some space between the food and to the back panel.

# 4 Installation and connection

### 4.1 Scope of delivery

After unpacking all parts, check for any transport damage and for completeness of delivery. If you have any complaints, contact your dealer or our after-sales service → Page 23.

The delivery consists of the following:

- Built-under appliance
- Equipment and accessories<sup>1</sup>
- Installation material
- Installation instructions
- User manual
- Customer service directory
- Warranty enclosure<sup>2</sup>
- Energy label
- Information on energy consumption and noises
- Information about Home Connect

#### 4.2 Criteria for the installation location

#### ⚠ WARNING Risk of explosion!

If the appliance is in a space that is too small, a leak in the refrigeration circuit may result in a flammable mixture of gas and air.

- ► Only install the appliance in a space with a volume of at least 1 m<sup>3</sup> per 8 g refrigerant. The volume of refrigerant is indicated on the rating plate.
  - → "Appliance", Fig. 1 /3 Page 12

The weight of the appliance ex works may be up to 35 kg depending on the model.

The subfloor must be sufficiently stable to bear the weight of the appliance.

This refrigerator is intended for use at ambient temperatures of 10 °C to 43 °C.

The appliance is fully functional within the permitted room temperature. If the appliance is operated at colder room temperatures, the appliance will not be damaged up to a room temperature of 5 °C.

#### Niche dimensions

Observe the niche dimensions if you install your appliance in the niche. If this is not the case, problems may occur when installing the appliance.

#### Niche depth

Install the appliance in the recommended niche depth of 560 mm. If the niche depth is smaller, the energy consumption increases slightly. The niche depth must be a minimum 550 mm.

#### Niche width

An inside niche width of at least 600 mm is required for the appliance.

#### Over-and-under and side-by-side installation

If you want to install 2 refrigerating appliances one over the other or side by side, you must maintain a clearance of at least 150 mm between the appliances. Selected appliances can be installed without a minimum clearance. Ask your dealer or kitchen planner about this.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

<sup>&</sup>lt;sup>2</sup> Not in all countries

# 4.3 Installing the appliance

#### **⚠** WARNING

#### Risk of electric shock!

Liquid in the control elements may be dangerous.

- ► Always install the enclosed niche cover in accordance with the enclosed installation instructions.
- Install the appliance in accordance with the enclosed installation instructions.

#### 4.4 Preparing the appliance for the first time

- 1. Remove the informative material.
- 2. Remove the protective foil and transit bolts, e.g. remove the adhesive strips and carton.
- 3. Clean the appliance for the first time. → Page 19

# 4.5 Connecting the appliance to the electricity supply

- 1. Insert the appliance plug of the power cord into the appliance.
- 2. Insert the mains plug of the appliance's power cable in a socket nearby.


The connection data of the appliance can be found on the rating plate.

- → "Appliance", Fig. 1/3 Page 12
- 3. Check the mains plug is inserted properly.
- ▼ The temperature display shows an animation and the control panel is locked.
- ✓ The appliance is ready to use once the animation has ended and an LED lights up for the temperature display.

# 5 Familiarising yourself with your appliance

# 5.1 Appliance

You can find an overview of the parts of your appliance here.



Deviations between your appliance and the diagrams may differ with regard to their features and size.


- Freezer compartment → Page 17
- 2-star freezer area → Page 19
- Control panel → Page 12
- Frozen food container → Page 20

3 Rating plate → Page 24

4 Exterior ventilation grille

# 5.2 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- 2
- switches the connection to the WLAN home network (Wi-Fi) on or off.
- lights up if user-defined settings have been set via the
   Home Connect app. You can find more information in the Home Connect app.
- > sets the temperature of the freezer compartment.

- > lights up when the alarm is switched on.
- ∄ lights up when Super freezing is switched on.
- Displays the set temperature for the freezer compartment in °C.
- ① switches the appliance on or off.

### 6 Features

The features of your appliance depend on the model.

#### 6.1 Accessories

Use original accessories. These have been made especially for your appliance.

The accessories for your appliance depend on the model.

### Ice cube tray

Use the ice cube tray to make ice cubes.

#### Making ice cubes

Use only drinking water to make ice cubes.

- 1. Fill the ice cube tray with drinking water up to 3/4 and place in the freezer compartment. If the ice cube tray is stuck to the freezer compartment, loosen it with a blunt object such as the handle of a wooden spoon.
- 2. To loosen the ice cubes, twist the ice cube tray slightly or hold it briefly under flowing water.

# 7 Basic operation

### 7.1 Switching on the appliance

1. Electrically connect the appliance. → Page 10

Note: If the appliance has been previously switched off using the control panel, press and hold ① for three seconds.

- ▼ The temperature display shows an animation and the control panel is locked.
- ▼ The appliance is ready to use once the animation has ended and an LED lights up for the temperature display.
- ✓ The appliance begins to cool.
- ✓ A warning signal sounds and the temperature display flashes because the freezer compartment is still too warm.
- 2. Switch off the warning tone using
- ▼ The temperature lights up as soon as the set temperature is reached.
- 3. Set the required temperature. → Page 13

# 7.2 Operating tips

 Once you have switched on the appliance, the set temperature is only reached after several hours.

- Do not put any food in the appliance until the set temperature has been reached.
- When closing the door, make sure that the door is not blocked by stored items.
- When you close the door, a vacuum may be created. The door is then difficult to open again. Wait a moment until the vacuum is offset.
- The temperature in the appliance varies due to the following conditions:
  - How often the appliance is opened
  - Load capacity
  - Temperature of newly stored
  - Ambient temperature
  - Direct sunlight

#### 7.3 Switching off the appliance

▶ Press and hold ① for 3 seconds.

# 7.4 Setting the temperature Setting the freezer compartment temperature

Press > repeatedly until the temperature display shows the required temperature setting. The recommended temperature in the freezer compartment is -18 °C.

### 8 Additional functions

Find out which additional functions can be used for your appliance. Additional functions can be set via the Home Connect app.

## 8.1 Automatic Super freezing

With automatic Super freezing, the freezer compartment cools down to a much lower temperature than in normal mode. This freezes food more quickly.

The automatic Super freezing switches on if you place fresh food in the bottom frozen food container, starting from the right-hand side. If automatic Super freezing is switched on, increased noise may occur.

After operation, the appliance switches from automatic Super freezing to normal operation.

# Activating automatic Super freezing

- Press and hold > for five seconds until an audible signal sounds.
- If 2 audible signals sound, the automatic Super freezing is activated.

# Deactivating automatic Super freezing

- Press and hold > for 5 seconds until an audible signal sounds.
- If 3 audible signals sound, the automatic Super freezing is deactivated.

# Cancelling automatic Super freezing

 Press > repeatedly until the temperature display shows the required temperature.

### 8.2 Manual Super freezing

With Super freezing, the freezer compartment cools as cold as possible. Switch on Super freezing four to six hours before placing food weighing 2 kg or more into the freezer compartment.

In order to utilise the freezer capacity, use Super freezing.

→ "Prerequisites for freezing capacity", Page 17

**Note:** When Super freezing is switched on, increased noise may occur.

# Switching on manual Super freezing

► Press > repeatedly until # lights up.

**Note:** After approx. 54 hours, the appliance switches to normal operation.

# Switching off manual Super freezing

 Press > repeatedly until the temperature display shows the required temperature.

#### 8.3 Sabbath mode

To ensure that you can also use the appliance on the Sabbath, the Sabbath mode switches off all non-essential functions.

During Sabbath mode, the following functions are switched off:

- Automatic Super freezing and manual Super freezing
- Alarm
- Interior lighting
- Signal tones
- Messages on the control panel

**Note:** The brightness of the control panel lighting is reduced during the Sabbath mode.

#### Switching on Sabbath mode

- Press and hold > for 15 seconds until a third audible signal sounds.
- A confirmation tone sounds.
- ✓ > lights up.

**Note:** After approx. 74 hours, the appliance switches to normal mode.

#### Switching off Sabbath mode

► Press and hold > for 15 seconds until an audible signal sounds.

#### 9 Alarm

#### 9.1 Door alarm

If the appliance door is open for a while, the door alarm switches on. A warning tone sounds and > lights up.

#### Switching off the door alarm

- Close the appliance door or press >.
- ✓ The warning tone is switched off.

### 9.2 Temperature alarm

If the freezer compartment becomes too warm, the temperature alarm is switched on.

#### Risk of harm to health!

During the thawing process, bacteria may multiply and spoil the frozen food.

- Do not refreeze food after it has been defrosted or started to defrost.
- Refreeze food only after cooking.
- ► These items should no longer be stored for the maximum storage period.

The temperature alarm can be switched on in the following cases:

- The appliance is switched on. Do not store any food until the appliance has reached the set temperature.
- Large quantities of fresh food are being placed inside. Switch on Super freezing before placing large quantities of food in the appliance.
- The freezer compartment door is open for too long.

Check whether the frozen food has defrosted or thawed.

#### Switching off the temperature alarm

- ► Press >.
- ✓ The warning tone is switched off.

# 10 Home Connect

This appliance is network-capable. Connect your appliance to a mobile device to control its functions via the Home Connect app.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: www.home-connect.com. To be able to use Home Connect. you must first set up the connection to the WLAN home network (Wi-Fi<sup>1</sup>) and to the Home Connect app. After switching on the appliance, wait at least 3 minutes until internal device initialisation is complete. Only then should you set up Home Connect. The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

**Tip:** Please also follow the instructions in the Home Connect app.

#### **Notes**

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app.
  - → "Safety", Page 3

<sup>&</sup>lt;sup>1</sup> Wi-Fi is a registered trademark of the Wi-Fi Alliance.

Operating the appliance on the appliance itself always takes priority.
 During this time it is not possible to operate the appliance using the Home Connect app.

# 10.1 Setting up the Home Connect app

- **1.** Install the Home Connect app on vour mobile device.
- 2. Start the Home Connect app and set up access for Home Connect. The Home Connect app guides you through the entire login process.

### 10.2 Setting up Home Connect

**Requirement:** The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.

1. Scan the following QR code.



You can install the Home Connect app and connect your appliance via the QR code.

**2.** Follow the instructions in the Home Connect app.

# 10.3 Switching on the connection to the WLAN home network (Wi-Fi)

► Press 🛜

# 10.4 Intelligently networking appliances using Matter<sup>1</sup>

The universal Matter standard makes it possible to network smart appliances from different manufacturers. You can network smart appliances using a voice assistant or other central control units, for example.

**Note:** Not all appliances support the Matter standard. Check in the Home Connect app whether your appliance supports the Matter standard.

#### Requirements

- The appliance is connected to the Wi-Fi home network and the Home Connect app.
- An app that supports the Matter standard for home appliances has been installed on your mobile device.
- ► Follow the instructions in the Home Connect app to add your appliance to your Matter network.

# 10.5 Switching off the connection to the WLAN home network (Wi-Fi)

► Press 🛜.

# 10.6 Installing updates for the Home Connect software

**Note:** If an update of the Home Connect software is available, a message appears in the Home Connect app.

- ► To install the update for the Home Connect software, follow the instructions in the Home Connect app.
- ▼ The control panel is partially locked during the installation.

<sup>&</sup>lt;sup>1</sup> Matter is developed by Connectivity Standards Alliance™. This brand, related logos, and marks are trademarks of the Alliance, all rights reserved.

# 10.7 Resetting Home Connect settings

If your appliance experiences connection problems with the WLAN home network (Wi-Fi) or your appliance wants to log into a different WLAN home network (Wi-Fi), you can reset the Home Connect settings.

- ► Press and hold 🛜 for six seconds until ? goes out.
- ▼ The Home Connect settings have been reset.

#### 10.8 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial reaistration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the installed Wi-Fi communication module).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous resetting to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

Note: Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

# 11 Freezer compartment

You can store frozen food, freeze food and make ice cubes in the freezer compartment.

The temperature can be set from -16 °C to -24 °C.

Long-term storage of food should be at -18 °C or lower.

The freezer compartment can be used to store perishable food longterm. The low temperatures slow down or stop the spoilage.

#### 11.1 Freezing capacity

The freezing capacity indicates the quantity of food that can be frozen right through to the centre within a specific period of time.

Information on freezing capacity can be found on the rating plate.

→ "Appliance", Fig. 1 /3 Page 12

## Prerequisites for freezing capacity

- 1. Approx. 24 hours before placing fresh food in the appliance, switch on Super freezing.
  - → "Switching on manual Super freezing", Page 14
- 2. Place food in the bottom frozen food container first, starting from the right-hand side.

### 11.2 Fully utilising the freezer compartment volume

Learn how to store the maximum amount of frozen food in the freezer compartment.

- **1.** Remove all fittings from the freezer compartment. → Page 20
- 2. Stack food directly on the floor of the freezer compartment.

# 11.3 Tips for storing food in the freezer compartment

- Store food in air-tight packaging.
- Do not bring food which is to be frozen into contact with frozen food.
- Place the food over the whole area of the frozen food containers.
- To ensure that the air can circulate freely in the appliance, push the frozen food containers in as far as they will go.

# 11.4 Tips for freezing fresh food

- Freeze fresh and undamaged food only.
- Freeze food in portions.
- Cooked food is more suitable than food that can be eaten raw.
- Vegetables: Wash, chop up and blanch before freezing.
- Fruit: Wash, pit and perhaps peel, possibly add sugar or ascorbic acid solution.
- Food that is suitable for freezing includes baked items, fish and seafood, meat, game, poultry, eggs without shells, cheese, butter and quark, ready meals and leftovers.
- Food that is unsuitable for freezing includes lettuce, radishes, eggs in shells, grapes, raw apples and pears, yoghurt, sour cream, crème fraîche and mayonnaise.

#### Packing frozen food

If you select suitable packaging material and the correct type of packaging, you can determine the product quality and prevent freezer burn.

- 1. Place the food in the packaging.
- 2. Squeeze out the air.

- **3.** Pack food airtight to prevent it from losing flavour and drying out.
- **4.** Label the packaging with the contents and the date of freezing.

# 11.5 Shelf life of frozen food at -18 °C

Food	Storage time
Fish, sausages, pre- pared meals and baked goods	up to 6 months
Poultry, meat	up to 8 months
Vegetables, fruit	up to 12 months

The imprinted freezer calendar indicates the maximum storage duration in months at a constant temperature of –18 °C.

# 11.6 Defrosting methods for frozen food

#### **⚠** CAUTION

#### Risk of harm to health!

During the thawing process, bacteria may multiply and spoil the frozen food.

- Do not refreeze food after it has been defrosted or started to defrost.
- Refreeze food only after cooking.
- These items should no longer be stored for the maximum storage period.
- Defrost animal-based food, such as fish, meat, cheese, quark, in the refrigerator compartment.
- Defrost bread at room temperature.
- Prepare food for immediate consumption in the microwave, in the oven, or on the hob.

# 12 2-star freezer area

You can temporarily store non-delicate food in the 2-star freezer area. The temperature in the 2-star freezer area is between -12 °C and -16 °C in normal mode and depends on the temperature in the freezer compartment.

You can store non-delicate food in the 2-star freezer area for up to 14 days, e.g. ice cubes. Long-term storage of food should be at -18 °C or lower in the freezer compartment. → Page 17

# 13 Defrosting

# 13.1 Defrosting in the freezer compartment

The fully automatic NoFrost system ensures that the freezer compartment remains frost-free. Defrosting is not required.

# 14 Cleaning and servicina

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully. Customer Service must clean inaccessible points. Cleaning by customer service can give rise to costs.

### 14.1 Preparing the appliance for cleaning

- 1. Switch off the appliance. → Page 13
- 2. Disconnect the appliance from the power supply. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

- 3. Take out all of the food and store it in a cool place.
  - Place ice packs (if available) onto the food.
- 4. Remove all fittings and accessories from the appliance. → Page 20

# 14.2 Cleaning the appliance

#### ⚠ WARNING Risk of electric shock!

An ingress of moisture can cause an electric shock.

► Do not use steam- or high-pressure cleaners to clean the appli-

Liquid in the lighting or in the controls can be dangerous.

► The rinsing water must not drip into the lighting or controls.

#### **ATTENTION**

Unsuitable cleaning products may damage the surfaces of the appliance.

- ▶ Do not use hard scouring pads or cleaning sponges.
- ▶ Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.

If you clean fittings and accessories in the dishwasher, this may cause them to become deformed or discol-

- Never clean fittings and accessory in the dishwasher.
- **1.** Prepare the appliance for cleaning. → Page 19
- 2. Clean the appliance, the fittings, the accessories and the door seals with a dish cloth, lukewarm water and a little pH-neutral washing-up liauid.
- 3. Dry thoroughly with a soft, dry cloth

#### en Troubleshooting

- **4.** Insert the fittings.
- 5. Electrically connect the appliance.

  → Page 10
- 6. Putting the food into the appliance.


## 14.3 Removing the fittings

If you want to clean the fittings thoroughly, remove these from your appliance.

# Removing the frozen food container

1. Take out the frozen food container as far as it will go.

**2.** Lift the frozen food container at the front ① and remove it ②.



# 15 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

#### **⚠** WARNING

#### Risk of electric shock!

Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.

Fault	Cause and troubleshooting
The appliance is not cooling, the displays and lighting are lit.	<ul> <li>Showroom mode is switched on.</li> <li>1. Disconnect the appliance from the mains. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.</li> <li>2. Wait 2 minutes.</li> <li>3. Reconnect the appliance. → Page 10</li> <li>4. Press and hold &gt; until 4 audible signals have sounded.</li> <li>5. After a short time, check whether your appliance is cooling.</li> </ul>
The refrigeration unit is switching on more frequently and for longer.	The appliance has been opened frequently.  ▶ Do not open appliance door unnecessarily.

#### Fault

#### Cause and troubleshooting

The refrigeration unit is switching on more frequently and for longer.

The exterior ventilation grilles are blocked.

Remove any obstructions from in front of the exterior ventilation grilles.

Not a fault. Modern refrigeration machines switch on more frequently and have different power levels to cool more efficiently.



- ► Remove any obstructions from in front of the exterior ventilation grilles.
- Install the appliance as far away as possible from heating elements, cookers and other heat sources. Avoid prolonged exposure of the appliance to direct sunlight.
- Only open the appliance door as briefly as necessary.
- ► Allow hot food and drinks to cool down first before storing in the appliance.

A layer of frost forms on the back wall of the refrigerator compartment. Not a fault. Modern refrigeration machines ensure a more even temperature in the refrigerator compartment. The back wall of the refrigerator compartment is defrosted automatically at regular intervals.



- Only open the appliance door as briefly as necessary.
- ► Pack the food airtight or cover it.
- Allow hot food and drinks to cool down first before storing in the appliance.
- ► Always leave some space between the food and the interior walls.

Home Connect is not working properly.

Different causes are possible.

► Go to www.home-connect.com.

The warning tone sounds.
The door alarm is

switched on.

The appliance door is open.

Close the appliance door.

Fault	Cause and troubleshooting			
A warning tone sounds and the temperature display flashes.	Different causes are possible.  ► Press >.  ✓ The alarm is switched off.  The exterior ventilation grilles are blocked.			
The temperature alarm is switched on.	► Remove any obstructions from in front of the exterior ventilation grilles.			
	Larger quantities of fresh food have been put in.  ► Do not exceed the max. freezing capacity.  → "Freezing capacity", Page 17			
The temperature differs greatly from the setting.	<ul> <li>Different causes are possible.</li> <li>1. Switch off the appliance. → Page 13</li> <li>2. Switch the appliance back on after five minutes. → Page 13</li> <li>If the temperature is too warm, check the temperature again after a couple of hours.</li> <li>If the temperature is too cold, check the temperature again on the following day.</li> </ul>			
The appliance hums, bubbles, buzzes, gargles, clicks or crackles.	Not a fault. A motor is running, e.g. refrigerating unit, fan. Refrigerant flows through the pipes. The motor, switches or solenoid valves are switching on or off. Automatic defrosting is running.  No action required.			
The appliance makes noises.	<ul><li>Fittings wobble or stick.</li><li>Check the removable fittings and, if required, replace these.</li></ul>			
	Containers are touching.  ► Move the containers apart.			
	Super freezing is switched on. No action required.			

#### 15.1 Power failure

During a power failure, the temperature in the appliance rises; this reduces the storage time and the quality of the frozen food.

On the website for your appliance, the technical data provides you with the storage times for frozen food in the event of a fault.

#### **Notes**

 Open the appliance as little as possible during a power failure

- and do not place any other food in the appliance.
- Check the quality of the food immediately after a power failure.
  - Dispose of any frozen food that has defrosted and is hotter than 5 °C.
  - Cook or fry slightly thawed frozen food, and then either consume it or freeze it again.

# 16 Storage and disposal

# 16.1 Taking the appliance out of operation

- 1. Switch off the appliance. → Page 13
- 2. Disconnect the appliance from the power supply. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- 3. Remove all of the food.
- **4.** Clean the appliance. → Page 19
- 5. To guarantee the ventilation inside the appliance, leave the appliance open.

#### 16.2 Disposing of old appliance

Valuable raw materials can be reused by recycling.

#### ⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ► Leave shelves and containers inside the appliance to prevent children from climbina in.
- ► Keep children away from the redundant appliance.

### ⚠ WARNING Risk of fire!

If the tubes are damaged, flammable refrigerant and harmful gases may escape and ignite.

- ► Do not damage the tubes of the refrigerant circuit or the insulation.
- 1. Unplug the appliance from the mains.
- **2.** Cut through the power cord.

3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the FU.

### 17 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty applicable to the location, the use of Customer Service is free of charge. The minimum duration of the warranty (manufacturer's warranty for private consumers) in the European Economic Area is 2 years according to the terms of warranty applicable to the location. The terms of warranty do not affect other rights or claims held by yourself under local legislation.

Detailed information about the warranty period and the warranty conditions in your country is available via

the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

If you contact Customer Service, you will require the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) of your appliance.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website.

### 17.1 Product number (E-Nr.), production number (FD) and consecutive numbering (Z-Nr.)

You can find the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) on the appliance's rating plate.

→ "Appliance", Fig. 1/3 Page 12 Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

# 18 Technical data

Refrigerant, cubic capacity and further technical specifications can be found on the rating plate.

→ "Appliance", Fig. 1/3 Page 12
You can find more information about your model online at https://
eprel.ec.europa.eu/¹. This web address is linked to the official EU
EPREL product database. Please then follow the instructions on

searching for the model. The model identifier is made up of the characters before the slash in the product number (E-Nr.) on the rating plate. Alternatively, you can also find the model identifier in the first line of the EU energy label.

# 18.1 Information regarding Free and Open Source Software

This product includes software components that are licensed by the copyright holders as free or open source software.

The applicable licence information is stored on your home appliance. You can also access the applicable licence information via your Home Connect app: "Profile -> Legal information -> Licence Information". You can download the licence information on the brand product website. (Please search on the product website for your appliance model and additional documents). Alternatively, you can request the relevant information from oss-

request@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str. 34, 81739 Munich, Germany.

The source code will be made available to you on request.

Please send your request to oss-request@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str.34, 81739 Munich, Germany.

Subject: "OSSREQUEST"

The cost of performing your request will be charged to you. This offer is valid for three years from the date of purchase or at least as long as we

<sup>&</sup>lt;sup>1</sup> Only applies to countries in the European Economic Area

<sup>&</sup>lt;sup>2</sup> Depending on the appliance specifications

offer support and spare parts for the relevant appliance.

# 19 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the essential requirements and other relevant provisions of Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at www.boschhome.com among the additional documents on the product page for your appliance.



Hereby, BSH Hausgeräte GmbH declares that the appliance with Home Connect functionality is in compliance with relevant statutory requirements. 1 A detailed Declaration of Conformity can be found online at www.boschhome.co.uk among the additional documents on the product page for your appliance. 1

# UK

2.4 GHz band (2400-2483.5 MHz): Max. 100 mW 5-GHz band (5150-5350 MHz + 5470-5725 MHz); max. 150 mW

<b>B</b> /	BE	BG	CZ	DK	DE	EE	ΙE	EL	ES	
	FR	HR	ΙΤ	CY	LI	LV	LT	LU	HU	
	MT	NL	AT	PL	PT	RO	SI	SK	FI	
	SE	NO	CH	TR	IS	UK (NI)			•	
5 GHz WLAN (Wi-Fi): For indoor use only.										
AL	ВА	N	ИD	ME	MK	RS	UK		UA	
5 GHz WI AN (Wi-Fi): For indoor use only										

### 19.1 Statement of Compliance for Great Britain

The full Statement of Compliance according to the Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023 can be found online at www.bosch-home.co.uk among the

additional documents on the product page for your appliance.

#### Product type

This statement of compliance covers the products described in this information for use whose model identifier group is seen on the title page. The full model identifier is made up of the characters before the slash in the

<sup>&</sup>lt;sup>1</sup> Only applies to Great Britain

#### en Declaration of Conformity

product number (E no.) which can be found on the rating plate. Alternatively, you can also find the model identifier in the first line of the UK Energy Label.

Name and address of manufacturer BSH Hausgeräte GmbH, Carl-Wery-Strasse 34, 81739 München, Germany

This statement of compliance is prepared by the manufacturer.

The manufacturer, BSH Hausgeräte GmbH deems that it has complied with

- provision 5.1-1 of ETSI EN 303 645 v2.1.1 and, where relevant, provision 5.1-2 of ETSI EN 303 645 v2.1.1;
- provision 5.2-1 of ETSI EN 303 645 v2.1.1:
- provision 5.3-13 of ETSI EN 303 645 v2.1.1.

#### Support period

BSH Hausgeräte GmbH will provide security updates that are necessary to maintain the main functions free of charge until at least 28/02/2034.





# Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- · Discounts for accessories & spare-parts
- · Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome** 



# Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you:

# www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

#### **BSH Hausgeräte GmbH**

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com

A Bosch Company

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom



9001916354 (050430)