



Washer dryer

WNA2E4UCIN

[en]

User manual and installation instructions

Further information and explanations are available online:



Table of contents

1 Safety 1.1 General information	. 4 . 4 . 5 . 6
2 Preventing material damage	11
3 Environmental protection and saving energy	12 12 12 12
4 Installation and connection	12 12 12 13 14 15 16
5 Before using for the first time 5.1 Starting an empty washing cycle	17 17
6 Familiarising yourself with your appliance	18 18 19
7 Display	20

8 Buttons	23
9 Programmes	25
10 Accessories	29
11 Laundry11.1 Preparing the laundry	29
12 Detergents and care products	29
13.1 Switching on the appliance 13.2 Setting a programme 13.3 Loading laundry 13.4 Adding detergent and care product 13.5 Starting the programme 13.6 Soaking laundry 13.7 Adding laundry 13.8 Cancelling the washing programme 13.9 Cancelling the drying programme	30 30 30 30 31 31 31 31 31 32
14 Childproof lock 14.1 Activating the childproof	32
lock	32
14.2 Deactivating the childproof lock	32

15 Basic settings	32
15.1 Overview of the basic settings	32
15.2 Changing the basic settings	33
16 Cleaning and servicing	33
16.1 Cleaning the drum	33
16.2 Cleaning the detergent drawer	33
16.3 Cleaning the drain pump	34
17 Troubleshooting	38
17.1 Emergency release	44
18 Transportation, storage and	
disposal	44
18.2 Inserting the transit bolts	44
10.2 moorting the transit bento	
18.3 Using the appliance again	44
18.3 Using the appliance again 18.4 Disposing of old appliance	44 45
18.4 Disposing of old appliance19 Customer Service	
18.4 Disposing of old appliance	45 46



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- with tap water and commercially available detergents and care products suitable for washing machines.
- for drying and freshening up fabrics that are washed with water and suitable for dryers.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Incorrect installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ Never connect the appliance to a circuit that is regularly switched on and off by the energy supplier.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ► When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.

en Safety

▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

⚠ WARNING – Risk of injury!

The heavy weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

△ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- ► Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ▶ Do not touch the sharp edges on the appliance.
- Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

★ WARNING – Risk of electric shock!

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.

- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer services. → Page 46

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

When spinning larger, waterproof items of laundry, imbalances may arise and lead to injuries.

▶ Do not wash and spin larger items of laundry, such as blankets or mattress covers, in the appliance.

△ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

⚠ WARNING – Risk of explosion!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

► Keep the area around the appliance clean during operation.

⚠ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

▶ If accidentally swallowed, seek medical advice.

► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of explosion!

Highly flammable objects such as lighters or matches may ignite during the drying process.

► Remove all highly flammable objects from any pockets in your laundry before the drying process.

Unwashed laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when drying is in progress.

- ▶ Do not place laundry in this appliance to be dried if the laundry has not been washed first.
- ► Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- ▶ Do not use the appliance if industrial chemicals have been used to clean the laundry beforehand.

Laundry that has been pretreated with flammable cleaning agents that contain solvents may cause an explosion in the appliance.

► Rinse pretreated laundry thoroughly with water before washing.

⚠ WARNING – Risk of fire!

If drying is interrupted early, the laundry is not cooled sufficiently and may ignite.

- ▶ Do not interrupt the drying programme early.
- ► If drying is interrupted early, remove the laundry immediately and spread it out.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

► Wait for the drum to come to a complete stop before reaching inside.

△ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

▶ Do not touch the hot detergent solution.

△ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- ► Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

Improper repairs are dangerous.

- Never make any technical modifications to the appliance or its features.
- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

- ▶ Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appli-

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 25 Foam and foam rubber may deform or melt during the drying process.
- Do not dry laundry that contains foam or foam rubber.

The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.

- Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- Before transport, fit the transit bolts fully in order to prevent damage in transit.

Material damage may be caused if the water inlet hose is connected incorrectly.

- Tighten the screw connections on the water inlet until they are handtight.
- Connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions or valves.
- Ensure that the inner diameter of the water tap is at least 17 mm.

Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- ► Ensure that the water pressure in the water supply system is at least 30 kPa (0.3 bar) and max. 1000 kPa (10 bar).
- ▶ If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may lead to material damage and damage to the appliance.

 Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appli-

- Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- ► Clean the appliance with nothing but water and a soft, damp cloth.

Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

- Choose programs with low temperatures and longer wash times and use maximum load capacity.
- Add detergent based on the laundry's degree of soiling.
- Reduce the washing temperature for lightly and normally soiled laundry.
- Set the maximum spin speed if you want to dry the laundry in the appliance afterwards.

3.3 Energy saving mode

If you do not use the appliance for a brief period, it automatically switches to energy-saving mode.

Energy-saving mode ends when you use the appliance again.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 12
- 2. Check the appliance for visible damage.
- 3. Open the door.
- Remove any accessories from the drum.
- 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

 Do not operate the appliance with incomplete or defective accessories.

- Replace the accessories in guestion before operating the appliance.
 - → "Accessories", Page 29

Note: The appliance has undergone a function test at the factory. This may cause water stains in the appliance, which the first wash cycle removes.

The delivery consists of the following:

- Washer dryer
- Accompanying documents
- Transit bolts
 - → "Removing the transit bolts". Page 14
- Cover caps
- Water inlet hose
 - → "Connecting the water inlet hose", Page 15

4.3 Requirements for the installation location

⚠ WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

► Do not operate the appliance without a cover cap.

⚠ WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 29 before using the appliance for the first time.

ATTENTION!

If residual water in the appliance freezes, this may cause damage to the appliance.

 Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- ► Tilt the appliance carefully.
- ► Transport the appliance in an upright position.

Installation loca- Requirements tion

Base

floor



Secure the appliance with fixing brackets → Page 29.

Wooden ioist




Place the appliance on a waterresistant wooden board (minimum thickness of 30 mm) which is screwed tightly to the floor.

Kitchen unit



Only install the appliance underneath a continuous worktop that is securely connected to adjacent cabinets. Required niche width: 60 cm.

Against a wall




Do not trap the power cord or the hoses between the wall and the appliance.

4.4 Removing the transit bolts


The appliance is secured for transportation using transit bolts on the rear of the appliance.

Note: Keep the transit bolt screws and the sleeves in a safe place for future transport.

- → "Inserting the transit bolts", Page 44
- 1. Pull the hoses out of the holders.




2. Unscrew ① and remove ② all of the screws for the 4 transit bolts using a WAF 13 wrench.



3. Remove the power cable from the holder.




4. Remove the 4 sleeves.



5. Put on the 4 cover caps.



6. Push the 4 cover caps downwards.




Note: To install the transit bolts to transport the appliance, perform these steps again in the reverse order.


4.5 Connecting the appliance

Connecting the water inlet hose

1. Connect the water inlet hose.



2. Connect the water inlet hose to a tap (26.4 mm = 3/4").



3. Open the water tap carefully and check that the connection points are tight.

Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.

ATTENTION!

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

- Secure the water outlet hose against unintentional loosening. In the event of a blocked or covered outlet, accumulated wastewater can flow back into the appliance.
- ▶ Before operating the appliance, ensure that the wastewater drains away quickly and eliminate any blockages.


Note: Observe the draining heights. The draining heights are: minimum: 60 cm, maximum: 100 cm

Siphon



Secure the connection point with a (24-40 mm) hose clamp.

Sink




Plastic pipe with rubber sleeve

Fix and secure the water outlet hose with an elhow.

→ "Accessories". Page 29

Fix and secure the water outlet hose with an elhow.

→ "Accessories". Page 29



Connecting the appliance to the electricity supply

Note: Your electrical domestic installation for this appliance must comply with the local legal provisions and safety regulations, and should include a residual current circuit-breaker.

 Insert the mains plug of the appliance's power cable in a socket nearby.


The connection details of the appliance can be found under Technical data \rightarrow *Page 46*.

2. Check the mains plug is inserted properly.


4.6 Aligning the appliance

In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

 Use a WAF 17 wrench to loosen the lock nuts in a clockwise direction.




2. To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

3. Use a WAF 17 wrench to tighten the lock nuts against the housing until they are hand-tight.



In doing so, hold the foot tight and do not adjust its height.


5 Before using for the first time

Prepare the appliance for use.


5.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

- 1. Turn the programme selector to \$\text{\text{\$\omega}}\$ Drum Clean
- 2. Close the door.
- 3. Pull out the detergent drawer.
- 4. Pour approx. 1 litre of tap water into compartment II.



5. Add washing powder containing oxygen bleach to compartment II.




To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

- **6.** Push in the detergent drawer.
- 7. Press DM Start/Pause to start the programme.
- ✓ The display shows the remaining. programme duration.
- After the programme has ended, the display shows: End.
- 8. Start the first wash cycle or set the programme selector to Off to switch off the appliance.
 - → "Basic operation". Page 30

6 Familiarising yourself with your appliance

6.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

1	Maintenance flap for the drain pump → Page 34
2	Door
3	Detergent drawer → Page 18
4	Control panel → Page 19
5	Water outlet hose → Page 15
6	Power cord → Page 16
7	Transit bolts → Page 14

6.2 Detergent drawer


Note: Observe the manufacturer's instructions on the use and dosage of the detergent and care product and the information in the programme descriptions.



- Dispenser II: detergent for the main wash
- Compartment &: Fabric softener
- Compartment I: Detergent for prewash

6.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- Programmes → Page 25
- Programme selector → Page 30
- Display → Page 20
- Buttons → Page 23

7 Display

The display shows the current settings, options or relevant information. Depending on the programme status, the display shows some information in the $\exists:\exists\exists$ area, e.g. $\vdash \neg \exists$.

	90°	1400		©	C= Z=	Ç ^o	
	60°	1000	\.	→	(E)	-\\doc{\doc{\doc}{\doc}}	
	40°	800	0				
- <u>;</u> Ċ-	30°	600	D	+3)_(.)_()	<u> </u>	D00
+	20°	400	Î	+2		kg kg	Start/ Pause
	*	\mathscr{D}		+1		+	
	A	©	F	***	1	(L)	=₩
Wash + Dry	Temp. °C	Spin Speed	Anti Stain	Extra Rinse	Hygiene Care C	Ready	Speed Perfect

Example: Display

Display	Description
0:40 1	Expected programme duration or programme time remaining in hours and minutes.
+8h ¹	Program end time → "Buttons", Page 23
6.0 ¹	Recommendation for the maximum load capacity for the selected program in kg.
Ø - 1400	Set spin speed in rpm. → "Buttons", Page 23 Ø: No spin cycle, draining only
* - 90	Set temperature in °C. → "Buttons", Page 23 I (cold)
—(DII Start/ Pause)	 Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be started or continued.
<u>→</u> /	Programme status: Pretreatment
<u>→</u>	Programme status: Washing
EE	Programme status: Rinsing
<u>©</u>	Programme status: Spinning
¹ Example	

Display	Description
End	Programme status: Programme end
-\document	Programme status: Drying
<u></u>	Programme status: Crease-reduction function
Cm	 Lights up: The childproof lock is activated. Flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 32
+1 +2 +3	Additional rinse cycles are activated. → "Buttons", Page 23
:\;\-;\-;\-;\-;\-;\-;\-;\-;\-;\-;\-;\-;\-	Washing with subsequent drying is activated. → "Buttons", Page 24
	Washing is activated. → "Buttons", Page 24
. ¢-	Drying is activated. → "Buttons", Page 24
Hot	The cooling process cools the laundry for a few minutes while the drum is rotating, in order to avoid damage to the laundry. Note: Do not interrupt the cooling process, and wait for the door lock to open.
	Rinse Hold is activated.
─(=U Speed Perfect)	Shortened programme duration is activated. → "Buttons", Page 23
2	The "Blood" stain type is activated.
4	The "Earth and sand" stain type is activated.
Î	The "Sweat" stain type is activated.
•	The "Cooking fat/cooking oil" stain type is activated.
€	Flashes: Drum cleaning is required. Run the ℰ Drum Clean programme for cleaning and caring for the drum and the outer tub. → "Cleaning the drum", Page 33
一(デ Hygiene Care)	The gentle pretreatment of dry laundry using hot air for increased hygienic demands is activated. → "Buttons", Page 23
©	 Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened.
¹ Example	

en Display

Display	Description
是	No water pressure.The water pressure from the tap is too low.
E:35 ¹	Error code, error display, signal. → Page 38
¹ Example	

The selection of programme settings and options to change these depend on the programme that is set as well as the programme status.

Button	Selection	Description
I Temp.°C	* - 90	Adjust the temperature. Set temperature in °C.
© Spin Speed	Ø -1400	Adjust the spin speed or deactivate the spin cycle. Set spin speed in rpm. If Ø is selected, the water is drained and the spin cycle is deactivated. The laundry stays wet inside the drum.
DW Start/ Pause	StartCancelPause	Start, cancel or pause the programme.
© Ready In	Up to 24 hours	Set the programme end time. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
© Spin Speed	Multiple selection	→ "Basic settings", Page 32
=♥ Speed Perfect	ActivateDeactivate	Activate or deactivate a shorter programme duration. Note: Energy consumption increases. The washing result is not affected by this.
Extra Rinse	■ +1 ■ +2 ■ +3	Activate or deactivate up to three additional rinse cycles. Recommended for particularly sensitive skin or in regions with very soft water.
₩ Hygiene Care and ᠑ Ready In	ActivateDeactivate	→ "Childproof lock", Page 32
₩ Hygiene Care	ActivateDeactivate	Activate or deactivate gentle pretreatment of dry laundry with hot air up to 65 °C for increased hygiene demands. After the fabrics have been pretreated with hot air, they are washed at low temperatures.

en Buttons

Button	Selection	Description
₩ Anti Stain	Multiple selection	Select the type of stain. The temperature, drum movement and soaking time are all adjusted to suit the type of stain.
⇔ Wash+Dry	■ ☆+~~ ■ ☆+~~	 When is selected, only washing is activated. When ⇒ is selected, washing with subsequent drying is activated. When is selected, only drying is activated.
		Note: For the adjustable combinations of washing, drying or washing and drying, observe the information for the selected programme. → "Programmes", Page 25

9 Programmes

Note: The laundry's care labels provide you with additional information about programme selection.

Programme	Description	Max. load (kg) Wash- ing	Max. load (kg) Dry- ing
Cottons 🔝	Wash hard-wearing items made from cotton or linen. Also suitable as a short programme for normally soiled laundry when you activate =♥ Speed Perfect. Programme setting: • Max. 90 °C • Max. 1400 rpm	10.5 5.0 ¹	6.0
⊕ Anti-Aller- gen	Wash items made from cotton, linen or synthetic fabrics. Suitable for killing dust mites. Programme setting: Max. 60 °C Max. 1400 rpm	4.0	2.5
Mix Load 🎎	Wash items made from cotton, linen or synthetic fabrics. Suitable for lightly soiled laundry. Programme setting: Max. 60 °C Max. 1400 rpm	4.0	2.5
	Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool. Programme setting: Max. 40 °C Max. 800 rpm	2.0	1.0
Rinse w	Rinse and then spin the laundry, and drain the water. Programme setting: Max. 1400 rpm	_	_
¹ = Speed P ² Drying not po	Perfect activated		

Programme	Description	Max. load (kg) Wash- ing	Max. load (kg) Dry- ing
Spin ©	Spin the laundry and drain the water. Do not use fabric softener. Programme setting: Max. 1400 rpm	_	_
된 Bedsheets/ Curtains	Wash hard-wearing bedding made from cotton or linen. Suitable for allergy sufferers and for strict hygiene requirements. Programme setting: Max. 90 °C Max. 1400 rpm	4.0	2.5
Outdoor/Wa- terpoofing দ্ব	Wash all-weather and outdoor clothing with membrane technology and water-resistant equipment. Suitable for washing and then waterproofing. Use a detergent for outdoor fabrics. Use a waterproofing agent that is suitable for machine-washing. Do not use fabric softener. Place the detergent for outdoor fabrics in compartment II in the detergent drawer and the waterproofing agent in the compartment. → "Detergent drawer", Page 18 After-treat the laundry in accordance with the manufacturer's instructions. Programme setting: Max. 40 °C Max. 800 rpm	1.0	1.0
Down &	Wash pillows, duvets or clothing stuffed with down and fillings with synthetic fibres. Wash large items separately. Use a detergent that is suitable for down or delicates. Use sparingly. Do not use fabric softener. Note: To prevent excessive foaming, remove air from laundry items by rolling them up before you wash them. erfect activated	2.0	2.0

Programme	Description	Max. load (kg) Wash- ing	Max. load (kg) Dry- ing	
	Programme setting: ■ Max. 60 °C ■ Max. 1000 rpm			
© Drum Clean	After cleaning, the residual water in the drum is removed by supplying hot air. Use this programme in the following cases: Before using the appliance for the first time If you regularly wash at temperatures of 40 °C or lower After a prolonged period of non-use	_	_2	
	Use washing powder containing oxygen bleach. Add the washing powder containing oxygen bleach to compartment II for the main wash. → Page 18 Halve the amount of detergent to avoid foaming.			
	Do not use fabric softener. Do not use liquid detergent or detergent that is intended for woollens or delicates. Note: The drum cleaning indicator flashes to			
	remind you if you have not used a programme at 60 °C or higher for a long time.			
SS Hygiene	Kill bacteria in textiles made of cotton or textiles filled with down.	_	3.0	
	Note: The laundry is not dried or cleaned. Reduce creases and airborne odours in suits and fabrics made of cotton and down. Tip: To prevent creasing, remove the laundry immediately after the programme has ended. Notes If you use the ∜ Iron Assist programme often without washing in between, this may cause odours in the appliance.	_	1.0	
¹ = Speed Perfect activated ² Drying not possible				

en Programmes

Programme	Description	Max. load (kg) Wash- ing	Max. load (kg) Dry- ing
© My Time	Wash items made from cotton, linen or synthetic fabrics. Short programme for items of lightly to normally soiled laundry. Note: If you only want to dry the laundry and not wash it, press ≅ Wash+Dry. Programme setting: ■ Max. 40 °C ■ Max. 1000 rpm	2.0	6.0
U Wasch & Dry 60 min	Wash and dry items made from cotton, linen or synthetic fabrics. Short programme for small items of lightly soiled laundry. Note: If you only want to wash the laundry and not dry it, press ⇒ Wash+Dry. Programme setting: Max. 40 °C Max. 1000 rpm	2.0	1.0

² Drying not possible

10 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order num- ber
Water inlet hose extension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Elbow	Secure the water outlet hose in place.	00655300
Washing machine cleaners	Cleaning products for maintaining the appliance interior.	00311929

11 Laundry

11.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, hook and loop fasteners, hooks and eyes
- Tie cloth belts, cloth straps and cords together
- Remove curtain fittings and lead strips
- Wash small or particularly delicate items in a mesh washing bag
- Wash large and small items of laundry together
- Wash laundry with fresh stains immediately

- Pretreat laundry with dried stains and wash several times
- Load the laundry unfolded into the drum
- Spin the laundry before drying
- Before loading the drum, any laundry that has been pre-treated with chlorine bleach should be rinsed several times

12 Detergents and care products

You can protect your appliance and your laundry by selecting and using the correct detergents and care products.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- When using liquid detergents, only use liquid detergents that are selfflowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed

en Basic operation

- Do not use products containing solvents, caustic agents or volatile substances
- Do not use chlorine bleach
- Do not use dyes regularly as fixing salt can damage stainless steel
- Do not use color-bleaching agents in the appliance

13 Basic operation

13.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected. → *Page 12*

 Turn the programme selector to a programme.

13.2 Setting a programme

- 1. Turn the programme selector and set the required programme.
 - → "Programmes", Page 25
- 2. If required, adjust the programme settings.
 - → "Buttons", Page 23

The programme settings are not saved permanently for the programme.

13.3 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes.

→ "Programmes", Page 25

Requirements

- The laundry is prepared and sorted.
 - → "Laundry", Page 29
- The drum is empty.
- 1. Open the door.
- 2. Place the laundry in the drum.

Close the door.Ensure that there is no laundry trapped in the door.

13.4 Adding detergent and care product

Note: Observe the information about detergents and care products → *Page 29*.

- 1. Pull out the detergent drawer.
- 2. Pour in the detergent.
 - → "Detergent drawer", Page 18
- 3. If required, add the care product.
- 4. Push in the detergent drawer.

13.5 Starting the programme

Requirement: A programme is set. → *Page 30*

- 1. Press DII Start/Pause.
- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- The display shows the programme duration or the programme end time.
- After the programme has ended, the display shows: End.
- If the display shows Ø, the laundry is not spun. The water is pumped out after the rinse cycle.

Notes

■ If you do not remove the laundry once the programme has ended, the crease-reduction function starts after 15 minutes and takes approx. 30 minutes. The display shows . Press any button on the display to cancel the crease-reduction programme and to remove the laundry.

■ When "Hot" is shown on the display, the appliance cools the laundry.

When "Hot" goes out, the laundry has cooled down.

13.6 Soaking laundry

Note: No additional detergent is reguired for soaking. The appliance uses the filled detergent for soaking and washing.

Requirements

- The laundry is placed in the appliance. → Page 30
- A programme has started. → Page 30
- 1. Press DI Start/Pause approx. 10 minutes after the programme

The programme pauses and the laundry can soak.

2. Press DII Start/Pause after the required soaking time.

13.7 Adding laundry

After the programme starts, you can remove or add laundry depending on the programme status.

Press DM Start/Pause.

During the washing cycle, the appliance pauses. → Page 20 During the drying cycle, the appliance checks whether it is possible to add laundry.

Note: If you want to add laundry, follow the instructions on the display.

→ "Display", Page 21

- 2. Open the door.
- 3. Add or remove laundry.
- 4. Close the door.
- 5. Press DM Start/Pause.

13.8 Cancelling the washing programme

- 1. Press DII Start/Pause.
- 2. Open the door.

The appliance door remains locked for safety reasons if the temperature and water levels are hiah.

- If the temperature is high, start the **Rinse** programme.
- If the water level is high, start the **Spin** oprogramme or select a suitable programme for draining.
 - → "Programmes", Page 25
- 3. Remove the laundry. → Page 31

13.9 Cancelling the drying programme

- ► Turn the programme selector to set any other programme.
- ▼ The door lock opens automatically after a cooling period of a few minutes.

13.10 Resuming the programme when the programme status is Rinse Hold

Requirements

- Rinse Stop is activated.
- The last rinse cycle of the set programme has ended and the laundry is in the rinsing water.
- 1. Set the **Spin** © programme or a programme for draining the water. → Page 25
- Press DII Start/Pause.

13.11 Unloading the laundry

1. Open the door.

2. Remove the laundry from the drum.

13.12 Switching off the appliance

- **1.** Turn the programme selector to **Off** .
- 2. Turn off the tap.
- **3.** Wipe the rubber gasket dry and remove any foreign objects.



 Leave the appliance door and detergent drawer open so that residual water can evaporate.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof lock

- ► Press on both Hygiene Care and Ready In buttons for approx. three seconds.
- ightharpoonup The display shows ightharpoonup.
- ▼ The control elements are locked.
- The childproof lock remains active even after the appliance has been switched off and in the event of a power cut.

14.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.


- ► Press on both Hygiene Care and Ready In buttons for approx. three seconds.

 So that the programme currently running is not cancelled, the programme selector must be set to the initial programme.
- ✓ come goes out on the display.

15 Basic settings

You can configure the basic settings for your appliance to meet your needs.

15.1 Overview of the basic settings



Programme selector with programme positions

- Set the volume of the signal at the end of the programme: 0 (off) to 4 (very loud)
- Set the volume of the signal tone emitted when the buttons are pressed:
 0 (off) to 4 (very loud)

Activate (On) or deactivate (OFF) the reminder to clean the drum.

15.2 Changing the basic settings

- 1. Set the programme selector to position 1. → Page 32
- 2. Press © Spin Speed and, at the same time, turn the programme selector to position 2.
- The display shows the current value.
- 3. Use the programme selector to select the required basic setting. → Page 32
- **4.** To change the value, press (9) Ready In.
- **5.** To save the changes, switch off the appliance.

16 Cleaning and servicina

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

16.1 Cleaning the drum

Clean the drum after 20 washing cycles at a temperature of 40 °Č and lower if & lights up, or if you have

not used the appliance for a prolonged period, but at least once a vear.


⚠ CAUTION Risk of injury!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.


- ► Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- ► Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- ► Run the Drum Clean programme without laundry but with washing powder that contains oxygen bleach or a a cleaning agent for caring for the inside of the appliance.
 - → "Accessories", Page 29

16.2 Cleaning the detergent drawer


- **1.** Pull out the detergent drawer.
- 2. Press down on the insert and remove the detergent drawer.




3. Pull out the insert upwards.



4. Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and click it into place.



6. Clean the opening for the detergent drawer.




7. Push in the detergent drawer.

16.3 Cleaning the drain pump


Clean the drain pump regularly, at least once a year, as well as in the event of faults, e.g. blockages or rattling noises.

Emptying the drain pump


- 1. Turn off the tap.
- 2. Switch off the appliance.
 - → Page 32
- **3.** Disconnect the appliance's mains plug from the power supply.
- **4.** Open and remove the maintenance flap.



5. Slide a sufficiently large container under the opening.




6. Take the drain hose out of the holder.




- 7. **A** CAUTION Risk of scalding! When you wash at high temperatures, the detergent solution gets hot.
- ► Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



8. Firmly press on the sealing cap.




9. Insert the drain hose into the holder.



Cleaning the drain pump


Requirement: The drain pump is empty. → *Page 34*

- 1. Since water may remain in the drain pump, unscrew the pump cap carefully.
 - The filter insert in the pump housing may become stuck due to coarse particles of dirt.
 Loosen the dirt and remove the filter insert.




The pump cap is comprised of two parts which can be taken apart for cleaning.

2. Clean the interior, the thread on the pump cap and the pump housing.




3. Ensure that the impeller in the drain pump can rotate.

- 4. Insert the pump cap.
 - Ensure that the parts of the pump cap are correctly assembled.




5. Screw the pump cap as far as it will go.



The handle on the pump cap must be in a vertical position.

6. Insert and close the maintenance flap.



Before the next wash

To prevent unused detergent from flowing straight into the outlet in the next wash, run a suitable programme for draining after you have emptied the drain pump.

- 1. Open the water tap.
- 2. Insert the mains plug.
- 3. Switch on the appliance.
- 4. Pour 1 litre of water into compartment II.
- 5. Select a suitable programme for draining.
 - → "Programmes", Page 25

17 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

⚠ WARNING

Risk of electric shock!

Improper repairs are dangerous.

- ▶ Never make any technical modifications to the appliance or its features.
- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting
The display goes out and DII Start/Pause flashes.	Energy-saving mode is active ► Press DII Start/Pause.
E:36 -10 / E:30 -80 / E:18 The detergent solution is not being pumped out.	The water outlet hose is connected too high, is kinked or trapped, or has been extended impermissibly. ► Check the installation of the water outlet hose. → Page 15
	Drain pipe or water outlet hose is blocked. • Clean the drain pipe and the water outlet hose.
	The drain pump is blocked or the pump cover is not installed correctly. ► Check that the pump cover is installed correctly. → Page 34
	Clean the drain pump. → Page 34
	Detergent dosage is too high. ➤ Reduce the amount of detergent for the next washing cycle with the same load.
E:60 -2B / E:32 / H:32	The appliance has interrupted the spin cycle because the laundry is unevenly distributed. Redistribute the laundry in the drum.
E:30 -10 / H:95 / 凸	The tap is turned off. ► Turn on the tap.
	The water inlet hose is kinked or jammed. ► Check the installation of the water inlet hose. → Page 15

Fault	Cause and troubleshooting
E:30 -10 / H:95 / 凸	The filters in the water inflow are blocked. Clean the filters in the water inflow.
	The water pressure is low.Check whether the tap has sufficient water pressure.
	The water level measuring system is defective. With this error message, the appliance starts a draining process. 1. Wait approx. 5 minutes until the draining process ends.
	 Restart the appliance.
	If required, start the draining process again. 3. If the fault persists, call customer service. → Page 46
E:30 -20	 Critical malfunction. Turn off the water tap. With this error message, the appliance starts a draining process. Wait approx. 5 minutes until the draining process ends. Restart the appliance. If required, start the draining process again. If the fault persists, call customer service. → Page 46
	Detergent dosage is too high. • Reduce the amount of detergent for the next washing cycle with the same load.
	Additional water has been added.Do not add any extra water to the appliance while it is operating.
All other error codes.	 Malfunction 1. Restart the appliance. 2. If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. 3. If the fault persists, call customer service.
	 → Page 46 Please specify the exact error message when calling. If possible, document the fault with photos and videos.

Fault	Cause and troubleshooting
Heavy foam build-up.	 Detergent dosage is too high. Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into compartment II (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load.
© flashes.	The door is not completely closed. 1. Ensure that there is no laundry trapped in the door. 2. Close the door.
<u></u>	Drum cleaning is required. ► Clean the drum. → Page 33
"Hot" and the drum rotates.	Not a fault. The cooling process is active. No action required.
	Note: Do not change the programme during the cooling process. The cooling process takes up to 10 minutes.
The programme does not start.	Childproof lock is activated. ► Deactivate the childproof lock. → Page 32
	 ⑤ Ready In is activated. ► Check whether ⑤ Ready In is activated. → Page 23
The programme is paused or has been interrupted, but the	The temperature is too high. ► Start the Rinse programme or wait until the temperature has dropped.
door will not open.	 Water level is too high. Start the Spin ⑤ programme or a suitable draining programme. → Page 25
The door cannot be opened due to a power cut.	The door is locked. ➤ Open the door using the emergency release. → Page 44
Drum jerks after the programme starts.	Not a fault. An internal motor test is started. No action required.
Drum rotates, water does not flow in.	Not a fault. Load detection is active for up to 2 minutes. No action required.
No water is visible in the drum.	Not a fault. Water is below the visible area. No action required.
The spin cycle runs several times.	Not a fault. The appliance eliminates an imbalance by repeatedly redistributing the laundry. No action required.

Fault	Cause and troubleshooting
The appliance is vibrating, 'wandering' and making loud noises during the spin cycle.	Appliance is not correctly aligned. ► Align the appliance. → Page 16
	The appliance feet are not fixed. ► Secure the appliance's feet. → Page 16
	Transit bolts have not been removed. ► Remove the transit bolts. → Page 14
High spin speed not reached.	The appliance is using a reduced spin speed to eliminate an imbalance. No action required.
The programme duration changes during the wash cycle.	Not a fault. The programme sequence is optimised electronically, another rinse cycle is switched on due to heavy foam build-up, or an imbalance is eliminated. No action required.
The drying time is too long.	The ambient temperature is higher than 30 °C. ► Ensure that the ambient temperature is below 30 °C.
	The air circulation at the appliance's installation location is insufficient. • Ventilate the appliance's installation location.
	Fluff has accumulated in the drum. ► Start the © Drum Clean programme without any laundry or detergent.
Water intake during the drying phase.	Not a fault. The drying phase requires water. No action required.
Spinning during the drying phase.	Not a fault. Thermal spinning is active. No action required.
Whooshing, hissing, whirring or sucking noises.	Not a fault. Water is pumped in, the process fan is active, or detergent solution is pumped out. No action required.
Banging noises, rattling in the drain pump.	A foreign object is in the drain pump. ► Clean the drain pump. → Page 34
There are detergent residues on the laundry.	Detergents may contain water-insoluble substances that deposit on the laundry. ► Start the Rinse programme or brush out the laundry after drying.
Fluff on the laundry.	Fluff has accumulated in the drum. ► Start the Drum Clean programme without any laundry or detergent.

Fault	Cause and troubleshooting
The laundry is too wet after the spinning cycle.	 A low spin speed is selected. ➤ Start the Spin ⑤ programme. ➤ The next time you run a wash cycle, set a higher spin speed.
	The appliance is using a reduced spin speed to eliminate an imbalance. 1. Redistribute the laundry in the drum. 2. Start the Spin ① programme.
The laundry is too damp.	The selected programme is unsuitable for the type of fabric. ► Set a suitable programme for subsequent drying. → Page 25
	The load is too large. ► Observe the programme's maximum load capacity. → Page 25
	After the end of the programme, warm laundry feels damper than it actually is. 1. Remove the laundry from the drum as soon as the drying programme has finished. 2. Spread the items of laundry for cooling.
	The load is too small. ► Set a suitable programme for subsequent drying. → Page 25
	The laundry has not been spun sufficiently. ➤ Always select the highest possible spin speed for the washing programme in question.
Creasing.	The selected programme is unsuitable for the type of fabric. ▶ Set a suitable programme. → Page 25
	A high spin speed is selected.► The next time you run a wash cycle, set a lower spin speed.
	The load is unsuitable. ► Observe the programme's maximum load capacity. → Page 25
	 Prepare the laundry. → Page 29 The laundry lies in the drum for too long after drying. 1. Remove the laundry from the drum as soon as the drying programme has finished. 2. Spread the items of laundry for cooling.


Fault	Cause and troubleshooting
Water is leaking out at the water inlet hose.	The water inlet hose is not correctly connected or is damaged. ► Check the installation of the water inlet hose. → Page 12
	Replace the water inlet hose if it is damaged.
Water is leaking out at the water outlet hose.	The water outlet hose is not connected correctly or is damaged. ► Check the installation of the water outlet hose. → Page 12
	Replace the water outlet hose if it is damaged.
Water is leaking from below the door.	Dirt on the door or seal causes leaks. • Clean the door and the seal.
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	There is too much detergent or fabric softener in the detergent drawer. ➤ When dosing, observe the marking in the detergent drawer. → Page 30
Residual water is present in the compartment &.	Insert in compartment % is blocked. ► Clean the detergent drawer. → Page 33
Fabric softener remains in the detergent drawer.	The use of fabric softener is not supported for the selected programme. ► Check whether the use of fabric softener is supported for the selected programme. → Page 25
Odours have formed in the appliance.	Humidity and detergent residue may promote the formation of bacteria. ► Clean the drum. → Page 33 ► If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate.

17.1 Emergency release

Releasing the door

Requirement: The drain pump is empty. → Page 34

- 1. **ATTENTION!** Escaping water may cause material damage.
- Do not open the door if you can see water through the glass. Pull the emergency release downwards with a tool and release.



- The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

18 Transportation, storage and disposal


18.1 Removing the appliance

- 1. Turn off the tap.
- 2. Empty the water inlet hose.
- 3. Switch off the appliance. → Page 32
- 4. Unplug the appliance's mains plug.
- **5.** Drain the water.
 - → "Cleaning the drain pump", Page 34
- 6. Detach the hoses.

18.2 Inserting the transit bolts

Secure the appliance before transportation using transit bolts in order to prevent transport damage.

1. Use a screwdriver to remove the 4 cover caps.



Keep the cover caps.

2. Insert the 4 transit bolts. → "Removing the transit bolts", Page 14

18.3 Using the appliance again

- ► For further information, see → "Installation and connection". Page 12 and → "Starting an empty washing
 - cycle", Page 17.

18.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



Dispose of packaging in an environmentally-responsible manner. This appliance is certified in accordance with the quidelines on E-waste (Management) Rules 2022 which govern waste electrical and electronic equipment. The guideline provide a framework for the return and recycling of used appliances.

Note: This product doesn't contain any of hazardous substances as specified in the ewaste Management and Handling Rules 2022.

Dos

- Please visit our website https:// www.bosch-home.in/ metapages/e-wastemanagement to find out more details regarding e-waste disposal.
- Keep the product in isolated area, after it becomes non-functional/un-repairable so as to prevent its accidental breakage.
- Consult the authorized service center as to whether the Electronic Equipment can be repaired or not, before discarding.
- Consult the retailer about appliance take back schemes.

Don'ts

- The product should not be opened by the user himself/herself. but only by authorized service personnel.
- The product is not meant for re-sale to any unauthorized agencies/scrap dealers/kabariwalah.
- Don't dispose of the discarded Electronic Equipment in household bins or Municipal bins.
- Don't dump the discarded Electronic Equipment in the open or in any land fill site, as this will result

in contamination of the soil and the around water.

Do not keep any replaced spare part(s) from the product in exposed area.

19 Customer Service

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

Helpline no.: 1800-266-1880 (Monday to Saturday – 8 am to (mg 8

Email ID: service.in@boschhome.com

Chat with us (WhatsApp):

+91-8451000555



19.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again auickly.

20 Technica	ıl data
Appliance height	84.8 cm
Appliance width	59.8 cm
Appliance depth	59.0 cm
Appliance depth with door closed	63.6 cm
Appliance depth with door open	107.2 cm
Weight	79.3 kg
Maximum load	10.5 kg
Mains voltage	220-240 V, 50 Hz
← Minimum installation protection	10 A
Nominal power	1900-2300 W
Water pressure	Minimum:30 kPa(0.3 bar)Maximum:

1000 kPa (10 bar)

Length of the water inlet hose	150 cm
Length of the water outlet hose	150 cm
Length of the power cord	160 cm



Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome**



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: www.bosch-home.com/service

Contact data of all countries are listed in the attached service directory.

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.in

A Bosch Company

