en

Brief Instructions: Dishwasher

Short and handy: everything your dishwasher needs...
Before using for the first time, read the Installation and Operating Instructions!



1 Add salt.

Setting the water softening system *

Find out the water **hardness** at your water utility company and **enter below**

* only **before using the dishwasher for the first time** or if **the water hardness changes**

Read off the setting

°dH	°fH	°Clarke	mmol/l	Setting	A	B	C
0–6	0–11	0–8	0–1,1	**0**	○	○	○
7–16	12–29	9–20	1,2–2,9	**1**	●	○	○
17–21	30–37	21–26	3,0–3,7	**2**	●	●	○
22–35	38–60	27–44	3,8–6,2	**3**	●	●	●

Reset

Quickly sorted

and then select a setting

– Hold down programme button **B** and switch on the main switch, then release the buttons. The display flashes and buttons **A** and **B** illuminate (water hardness setting was set to 2 at the factory).

– Each time button **B** is depressed, the setting increases by one (0-3). If buttons **A**, **B** and **C** illuminate, the maximum water hardness setting has been reached. If the water hardness setting is now increased again, the lights go out and the water hardness setting is set to 0.

– Switch off the main switch. The selected setting has been stored in the appliance.

Dissolves limescale (not required for set value **0**!)



Unscrew the lid.



Only before using the dishwasher for the first time pour approx. 1 l / 2 pt water into the salt opening.

Pour in max. 1.5 kg / 3 lb 5 oz **salt** (never detergent!)



Screw on the lid. Switch on dishwasher immediately.

2 Add rinse-aid.

Everything is sparkling clean ...

Refill whenever level indicator is light!



Press mark 1, lift up lid 2.



Pour in **rinse aid**.



Close the lid. CLICK!

3 Add detergent.

Very dirty dishes, a lot of detergent ...



If required, open the lid (press the pin).

Warning,

combination products are not suitable for all programmes, follow manufacturer's instructions.



Pour in **detergent**.



Push the lid shut, press. PLOP!

4

5 Select programme.

Quick, economical or intensive ...

Overview of programmes

This overview indicates the max. possible number of programmes. The programmes which correspond to your appliance can be found on your appliance fascia.

The programme data are values measured in the laboratory in compliance with Standard EN 50242. Deviations is practice are possible.

	Intensive 70°	Normal 65°	Eco 50°	Quick 35°	Prerinse
Duration in minutes	138	140	140	30	19
Power consumption in kWh	1,65	1,60	1,05	0,70	0,05
Water consumption in litres	16	16	12	10	4

Switch appliance ON, off we go...

Press main switch, choose programme.
Close door.

6 Switch appliance OFF, everything OK...

Signal sounds, open door. End-of-programme indicator flashes, press main switch.

Additional programmes **

Flexibility ...

Saving time (VarioSpeed)

... is obtained by increased energy consumption at a constant cleaning and drying performance.

Half load

... for a few items, saves water, energy and time

** some models

9000 196 432 (8607) 630J

Maintenance and care

For perfect rinsing results ...

Strainers ...
Check, if required, clean



Rotate filter cylinder, remove filter system ...



rinse under flowing water ...



Insert ...

Screw in filter system NOTE MARK!

Spray arms ...
Remove blockages/deposits



Pull lower arm upwards ...



Unscrew upper arm ...



Clean spray nozzles under flowing water (perhaps with toothpick) ...

Insert lower arm ...





Screw in upper arm

Cleaning the waste-water pump *

* With some models

- Ladle out water and remove filters
- Unscrew cover (Torx T20)
- Check area of fan impeller for foreign objects
- Screw in cover and insert filters



Eliminating minor faults yourself ...

... Self-help pays!

Fault	Possible Cause	Remedy
Residual water in the device	Waste-water pump blocked	Clean waste-water pump (see above).
	Programme not yet ended	Close the appliance and wait until the programme ends (end of programme display lights up) or terminate programme (see Terminating the programme).
Appliance is not running / stops Check water supply Display lights up	Supply fitting not open	Open supply fitting.
	Supply hose kinked	Lay supply hose without kinks.
	Supply fitting jammed or calcified	1. Unscrew water connection. 2. Clean filter in the water connection. 3. Flow rate must be min. 9 l/min when the water inlet is open. If the flow rate is less, replace the supply fitting.
Plastic parts / parts of dishes discoloured	Too little cleaning product	Follow manufacturer's specifications (detergent).
	Discoloration caused by food colourings (tomato sauce)	Discoloration is quite safe; fades after subsequent rinse cycles.

Fault	Possible Cause	Remedy
Dishes not clean Sand or grainy residues on dishes	Utensils are situated too close to each other or on top of each other	Spread out the utensils, avoid contact between the utensils.
	Too little cleaning product	Follow manufacturer's specifications (detergent).
	Unsuitable programme selected	Select more intensive programme.
	Spray nozzles blocked	Clean spray arms (see above).
	Filters dirty, not installed securely	Clean the strainers (see above).
	Spray arms blocked	Arrange the utensils so that the spray arms can rotate freely.
Stains and streaks	Rinse aid dosage too high / too low	Streaks: Reduce dosage. Water or limescale stains: Increase dosage.
Milky residues on dishes (can be removed)	Water softening system incorrectly set;	Set water softening system correctly.
	no special salt	Refill with special salt.
Milky film, glasses cloudy / dull (cannot be removed)	Glasses not dishwasher-proof.	Use dishwasher-proof glasses. Use glass-friendly cleaning products.
Cutlery rusty	Cutlery not rust-proof Hard knife blades are more susceptible	Use dishwasher-proof cutlery.
	Extraneous rust	Never wash rusting parts in the appliance.

Further advice can be found in the instruction manual

Interrupting the programme ...

- Open the door.
- Press the START/STOP button.
- To continue, press the START/STOP button again.
- Close the door.

Terminating the programme ...

- Open the door.
- Press the two **RESET** buttons **simultaneously** (approx. 3 seconds) (RESET).
- Close the door.



After 1 minute the programme ends. The "signal sounds and the standby indicator illuminates".

Switch off the appliance.

Arranging dishes correctly ...

Arrange dishwasher-proof dishes in accordance with the operating manual (without residual ash, wax, lubricating grease, ink, sticky labels; remove any large remnants of jam, milk products or food) and check that the spray arms can rotate freely.