

Invented for life



ErgoMixx及StyLine手提攪拌器系列

ErgoMixx & StyLine Hand Mixer Series

MFQ364V0, MFQ40302GB, MFQ4030K, MFQ4030L, MFQ4020GB, MFQ3030GB



Bosch ErgoMixx真空鎖鮮技術

Bosch ErgoMixx Fresh vacuum system

多一點鮮味、少一點浪費

Keeps your food fresh for longer and reduces food waste



真空插頭

抽取空氣，延長保鮮

Vacuum pump

Removes air to lock in freshness



真空保鮮袋

可重用BPA-free膠袋，
雙重密實鎖，並有不同大小選擇

Fresh vacuum zipper bags

Made of reusable and durable
BPA-free plastic, double zipper,
available in different sizes



ErgoMixx

手提攪拌器系列

兼容真空鎖鮮技術

ErgoMixx hand blender Series

Transforms into a vacuum
storage system



真空儲存盒

儲存時可堆疊，並有不同大小選擇

Vacuum container

Made of durable Tritan, nestable &
stackable, available in different sizes

延長食物保鮮期

Food which can be preserved for longer

| 保鮮盒 / 袋 Vacuum container / bag | 新鮮蔬果 Fresh fruits & vegetables | 肉類及魚類 Meat & Fish | 芝士及醃製肉類 Cheese* & sausage | 乾果穀物 Dry food | 剩餘 / 外帶食物 Leftovers / ToGo |
|--------------------------------------|--------------------------------------|----------------------|------------------------------|------------------|-------------------------------|
| | | | | | |
| | | | | | |

* 以傳統儲存方式對比使用真空儲存盒及真空保鮮袋儲於雪櫃，於09/2018、06/2019及12/2019實驗室測試

* stored in vacuum container and bags in refrigerator, compared to ordinary non-vacuum storage methods, study conducted by an independent laboratory 09/2018, 6/2019 and 12/2019.

ErgoMixx手提攪拌器 | MFQ364V0

ErgoMixx Hand Mixer | MFQ364V0



500毫巴強力真空插頭 500mbar Vacuum pump

兼容真空儲存盒及真空保鮮袋
Work with vacuum containers and zipper bags
從真空配件中抽取 空氣至密封狀態*
Removes air from special vacuum accessories for air-tight seal*



易拆卸按鈕

低震動靜音摩打



5段速度高速按鈕

人工力學輕觸操控，適合任何手形



不鏽鋼攪拌器



攪拌桿



攪拌量杯



真空保鮮袋



不鏽鋼麵糰鉤

易於清潔

攪拌器及麵糰鉤，可使用洗碗碟機清洗

Easy to clean

Whisks and hooks are dishwasher safe



* 可以從儲存盒中去除50%的空氣；而保鮮袋的物料有彈性，可幾乎去除所有空氣

* Removes 50% of all from container and nearly all air from bags due to flexible material

StyLine手提攪拌器系列

StyLine Hand Mixer Series



易於清潔

攪拌器及麵糰鉤
可使用洗碗碟機清洗

Easy to clean

Whisks and hooks are
dishwasher safe



易拆卸按鈕

一鍵即可拆卸攪拌器，
方便更換或清洗

5 speeds plus turbo function

Precise speed control for any recipe.



多段速度及高速按鈕

配合不同食材而需要

Easy eject button

Release tools at the touch of
a button for changing or cleaning



MFQ40302GB



MFQ4030K




MFQ4030L



MFQ4020GB



MFQ3030GB



| | | | | | | | |
|-------------------------------|--|---|---|---|---|---|--|
| 型號 Model | MFQ364V0 | MFQ40302GB | MFQ4030K | MFQ4030L | MFQ4020GB | MFQ4020GB | |
| 攪拌功率 Blending (Voltage) | 450W | 500W | 500W | 500W | 450W | 350W | |
| 特點 Feature | <ul style="list-style-type: none"> · 真空鎖鮮技術 Fresh Vacuum System · 低震動靜音摩打科技 High power silent motor · 防滯人工力學SoftTouch手柄 Soft touch handle and ergonomic shaping | <ul style="list-style-type: none"> · 嶄新的摩打科技，機身輕巧，操作寧靜 Modern motor technology Powerful, light and quiet · 人體工學的外殼設計 Ergonomically designed plastic housing · 所有與食物接觸的塑料都不含雙酚A All plastics that are in contact with food are BPA free | <ul style="list-style-type: none"> · 嶄新的摩打科技，機身輕巧，操作寧靜 Modern motor technology Powerful, light and quiet · 人體工學的外殼設計 Ergonomically designed plastic housing | <ul style="list-style-type: none"> · 嶄新的摩打科技，機身輕巧，操作寧靜 Modern motor technology Powerful, light and quiet · 人體工學的外殼設計 Ergonomically designed plastic housing | <ul style="list-style-type: none"> · 嶄新的摩打科技，機身輕巧，操作寧靜 Modern motor technology Powerful, light and quiet · 人體工學的外殼設計 Ergonomically designed plastic housing | <ul style="list-style-type: none"> · 嶄新的摩打科技，機身輕巧，操作寧靜 Modern motor technology Powerful, light and quiet · 人體工學的外殼設計 Ergonomically designed plastic housing | |
| 功能 Function | <ul style="list-style-type: none"> · 5段速度選擇 5 speed settings · 點動及快速功能 Additional pulse / turbo setting · 卸除攪拌器按鈕 Separate eject button | <ul style="list-style-type: none"> · 5段速度選擇 5 speed settings · 點動及快速功能 Additional pulse / turbo setting · 易拆卸按鈕 Easy eject button | <ul style="list-style-type: none"> · 5段速度選擇 5 speed settings · 點動及快速功能 Additional pulse / turbo setting · 易拆卸按鈕 Easy eject button | <ul style="list-style-type: none"> · 5段速度選擇 5 speed settings · 點動及快速功能 Additional pulse / turbo setting · 易拆卸按鈕 Easy eject button | <ul style="list-style-type: none"> · 5段速度選擇 5 speed settings · 點動及快速功能 Additional pulse / turbo setting · 易拆卸按鈕 Easy eject button | <ul style="list-style-type: none"> · 5段速度選擇 5 speed settings · 點動及快速功能 Additional pulse / turbo setting · 易拆卸按鈕 Easy eject button | <ul style="list-style-type: none"> · 4段速度選擇 4 speed settings · 點動及快速功能 Additional pulse / turbo setting · 易拆卸按鈕 Easy eject button |
| 清潔 Cleaning | 配件可放入洗碗碟機清洗 Easy cleaning Dishwasher safe parts | | | | | | |
| 配件 Accessories | <ul style="list-style-type: none"> · 抽真空插頭 vacuum pump · 2 支攪拌器 2 stainless steel whisks · 2 支不鏽鋼麵糰鉤 2 heavy duty stainless steel kneading hooks · 攪拌量杯 (連蓋) Mixing jug with calibration and lid · 可重用真空保鮮袋(不含BPA) Zipper bags (BPA free) · 不鏽鋼攪拌桿 Heat resistant plastic foot with stainless steel blades | <ul style="list-style-type: none"> · 2 支攪拌器 2 stainless steel fine creamer whisks · 2 支不鏽鋼麵糰鉤 2 heavy duty stainless steel kneading hooks | <ul style="list-style-type: none"> · 2 支攪拌器 2 stainless steel fine creamer whisks · 2 支不鏽鋼麵糰鉤 2 heavy duty stainless steel kneading hooks | <ul style="list-style-type: none"> · 2 支攪拌器 2 stainless steel fine creamer whisks · 2 支不鏽鋼麵糰鉤 2 heavy duty stainless steel kneading hooks | <ul style="list-style-type: none"> · 2 支攪拌器 2 stainless steel fine creamer whisks · 2 支不鏽鋼麵糰鉤 2 heavy duty stainless steel kneading hooks | <ul style="list-style-type: none"> · 2 支攪拌器 2 stainless steel fine creamer whisks · 2 支不鏽鋼麵糰鉤 2 heavy duty stainless steel kneading hooks | |

Bosch Galleria

香港中環雪廠街16號西洋會所大廈1樓 (另設入口於都爹利街)
1/F Club Lusitano, 16 Ice House Street, Central, Hong Kong
(side entrance on Duddell Street)
產品熱線 Product Hotline: 2623 7100 (香港 Hong Kong) /
0800 863 (澳門本地專線 Macau local call only)
傳真 Fax: 2565 6681
電郵 E-mail: bosch.hk.showroom@bshg.com

客戶服務中心

Customer Contact Center

香港新界荃灣青山公路388號中染大廈23樓07室
Unit 07, 23/F, CDW Building, 388 Castle Peak Road,
Tsuen Wan, New Territories, Hong Kong
客戶服務熱線 Customer Care Hotline: 2626 9655

www.bosch-home.com.hk

 www.facebook.com/boschhomeHK

 www.youtube.com/boschhomeHK

本目錄的產品圖像、型號和規格僅供參考，產品實物之顏色或與相片有輕微差異，
本目錄冊如有改動，恕不另行通知。

The product image, models number and specifications used in the catalogue
are for reference only and are subject to change without prior notice.
The colors of actual products may vary from illustrations.

經銷商可為您提供可靠的資訊。

Your dealer will be able to provide you with reliable information.


©2022博西華家用電器有限公司。所有權利保留。本目錄冊所載的全部內容和資料均屬
博西華家用電器有限公司所有，且受版權保護。任何人士如未獲得博西華家用電器有限公司
事先給予書面許可，不得複製、轉載、發放或擅用本目錄冊的任何內容或資料。

©2022 BSH Home Appliances Limited. All rights reserved. All contents
and information contained in this Catalogue are proprietary to
BSH Home Appliances Limited and are subjected to copyright protection.
Reproduction, republication, redistribution or unauthorized use of
any content or information contained in this Catalogue is expressly prohibited
without the prior written consent of BSH Home Appliances Limited.



官方網頁
Official Site



Find us on 



觀看影片
Watch Video