



BOSCH

Invented for life

Dishwashing Solutions.

Edition 2016



Contents.

Design Solutions	4 – 5
Dishwashing Features	6 – 9
Freestanding Dishwashers	10 – 11
Built-Under Dishwashers	12 – 13
Integrated Dishwashers	13
Compact Dishwashers	14
Quality Service	15



Energy Efficiency

The Energy Efficiency and Conservation Authority has introduced the Energy Star® mark on appliances to help New Zealanders choose the most energy efficient model.

ENERGY STAR qualified appliances are good for the environment: they use – and waste – less power, which means New Zealanders pay less on energy bills and contribute less to climate change. For Bosch Energy Star qualified dishwashers, go to www.eeca.govt.nz



10 Year Rust Through Warranty

Superior materials combined with our precise production and joining technologies offer protection for your dishwasher against rusting through of the inner tub.

Valid for 10 years after purchase.

When every single one of our appliances makes your life a little bit easier – that's Bosch in every detail.

We believe the perfect appliance must be designed for one thing above all else: to make your time spent in the kitchen as pleasant as possible. Every detail of every appliance has been carefully designed, produced and tested by our engineers to fully satisfy the highest standards in quality, performance and convenience. The result is cutting-edge technology, timeless design and remarkable ease of use, reducing the workload for you and consistently delivering perfect results.

Proven quality

We devote the same high level of care, passion and dedication to all areas of our work – from the first design draft right through to customer service. It's the same Bosch quality that you have been able to rely on for more than 128 years.

All Bosch ActiveWater™ dishwashers undergo 200 individual quality control checks before being released from the factory.

Bosch appliances offer premium quality, advanced technology, ease of operation and outstanding German engineered technology. These attributes have earned us many accolades, national and international, such as the red dot design award, the iF design award, Energy Star® and other endorsements year after year.

Top performance

What drives us every day is our desire to improve. We strive to make the best even better, by developing functional, durable and energy-efficient innovations that surpass all expectations.

ActiveWater™ is a revolutionary dishwashing system that uses every single drop of water to the maximum. Our ActiveWater™ dishwashers are amongst the most resource-efficient in the world, generating the cleaning power of over 4000 litres from as little as 12.3 litres per wash.

Bosch dishwashers featuring Zeolith Drying make innovative use of Zeolite, a naturally occurring mineral which has the ability to absorb moisture and convert it to energy, resulting in a better drying performance and less electricity consumption. Zeolite minerals regenerate each cycle and last the entire lifespan of the dishwasher.

Maximum convenience

Bosch is dedicated to making your life easier. Sophisticated features deliver the best results every time, and save you considerable effort and expense in the process.

Design solutions.

The perfect Bosch to fit your kitchen.


Freestanding



These dishwashers can be installed anywhere in your kitchen


- Designed to stand alone
- Removable worktop (to accommodate benchtop height)
- Elegant curved fascia

Built-Under



Built-Under dishwashers fit into a new or existing kitchen with style

- Flat control panel
- Adjustable height for flush fit
- Able to be integrated with a continuous toe kick for seamless cabinetry



Slimline, Built-Under

The Slimline 45cm Built-Under dishwasher is ideal for a kitchen where space is at a premium

- Adjustable height for flush fit
- Slim design for small kitchens or spaces
- Able to be integrated with a continuous toe kick for seamless cabinetry

Semi-Integrated




Integrate your dishwasher for a seamless look

- Can be fitted with a door panel to match your kitchen cabinetry#
- Able to be integrated with a continuous toe kick for seamless cabinetry



Fully-Integrated



A Bosch Fully Integrated dishwasher is designed to fit your new kitchen to perfection

- Can be concealed entirely behind a door panel to match the design of your kitchen cabinetry#
- Control panel neatly integrated into the top of the dishwasher door
- Able to be integrated with a continuous toe kick for seamless cabinetry

Compact

These modular dishwashers offer the freedom to perfectly coordinate your kitchen

- Can be installed individually
- Ideal for grouping together with matching Bosch appliances

Dual TFT Display.

The multi-coloured TFT display not only looks good, it also provides you with useful information throughout the wash cycle. Progress of the wash cycle, time remaining, as well as wash programs and other optional settings are clearly displayed in full colour resolution. The advanced technology even shows the predefined water and energy consumption for each wash option, allowing you to pick the most efficient solution.





ActiveWater™ Filter System

Up to 50% more filter surface area providing better water circulation and greater cleaning power.



AquaSensor™ Technology

The AquaSensor™ helps you save even more water as it measures the amount of soiling at the end of the pre-rinse cycle, reusing water when it can and saving up to 20% for the entire wash.



AquaStop Plus

For added security and safety, all Bosch models have an 'AquaStop Plus' device that cuts off the water supply directly at the tap outlet in the case of leaks. AquaStop Plus operates 24 hours a day, 7 days a week, provided the dishwasher is switched on at the mains.



AutoBrilliance™

The AutoBrilliance™ function adapts the temperature for multi-function detergent tablets, ensuring the rinse aid is fully utilised, delivering sparkling results every time.



Auto Programs

By choosing the automatic program, your dishwasher will assess how soiled the items are and adjust the program time and temperature accordingly.



Childlock

For added safety, the door can be locked manually to prevent children from inadvertently opening the door. The buttons can also be locked to prevent tampering during operation.



The revolutionary EcoSilence Drive® brushless motor is quieter and more energy-efficient than all others before it.

The brushless, frictionless construction of this advanced motor offers maximum efficiency, economy, durability and performance. Plus, with up to three levels of sound insulation and targeted spray jets, the result is a dishwasher that's even quieter.



EmotionLight

Show off your sparkling clean glassware beautifully with the cool blue EmotionLight. The LED lights never need to be changed and will last for the lifetime of your dishwasher.





InfoLight™

Selected Bosch dishwashers feature InfoLight™ – a red light that discreetly beams onto the floor during the wash cycle and disappears after the drying cycle is complete, preventing accidental interruption of the wash cycle.



TimeLight

You might not hear anything coming from your dishwasher, but it still might be on. To prevent you from interrupting the cycle, we've developed TimeLight; an illumination that projects the remaining wash cycle time onto the floor when the dishwasher is in operation.



VarioFlex™ Pro.

The innovative VarioFlex™ Pro basket system flexibly adapts to the dishes being loaded. Coloured touch points highlight moveable elements.

For maximum flexibility, every rack in both the top and bottom VarioFlex™ Pro baskets can be folded to adapt to any situation – for unsurpassed convenience, without the need to purchase expensive accessories.



VarioDrawer™ and VarioDrawer™ Pro


A third loading level for cutlery and utensils. VarioDrawer™ Pro provides loading flexibility and adjustability for larger items.



Rackmatic™ Plus

Height-adjustable upper basket provides multiple different positions for easy loading. Simply press the levers either side of the basket to adjust, even if it's full.

For the ultimate in convenience, Rackmatic™ Plus also allows the dishwasher to operate with one side of the top basket angled higher or lower than the other.



Vario and VarioFlex® Basket Systems

Be it lots or just a few items, large or small pieces, wine glasses or cups – with its special grips, foldaway racks and glass prongs, the Vario and VarioFlex systems allow the baskets to be adapted to any load. All items are assured a firm, secure place in the protective racks.

The Vario cutlery basket can be placed anywhere in the lower basket.



Delay Start

With the time delay function you can pre-select the program for the desired start time. This allows you to handle your appliance conveniently, at any time during the day, during work hours or at night. After the start of the program a display indicates the precise remaining time.



HalfLoad Plus

HalfLoad Plus provides the best possible wash performance for dishes stacked anywhere in the dishwasher, unlike other systems that only wash in either the top or bottom baskets.



DosageAssist™

The DosageAssist™ feature maximises the effectiveness of detergent tablets by dropping them into a specially designed tray that is targeted by water jets, resulting in a tablet that dissolves evenly under control.



ExtraDry

ExtraDry uses a higher temperature in the final rinse. The resulting residual heat is used in the drying process to provide an even better drying result. Especially useful for glassware and plastics.



HygienePlus™

The HygienePlus™ option offers a hotter final rinse, perfect for cooking utensils, chopping boards and baby bottles.*

* For baby bottles, traditional sanitation methods are still recommended to be used in conjunction with option.



IntensiveZone™ Wash Option

The IntensiveZone™ function transforms the entire bottom basket into a power cleaning zone, by increasing the water pressure in the bottom basket, saving you the chore of scrubbing heavily soiled pots and pans.



GlassSecure Tray model number: SMZ5300

Wine glasses should be washed by hand – or by Bosch. The GlassSecure Tray protects your glasses.




Designed for Bosch dishwashers equipped with VarioFlex™ or VarioFlex™ Pro basket systems, this unique tray securely holds four long stemmed glasses in place. The locking mechanism lifts and secures all four glasses at once. Glasses are angled and positioned to provide optimum cleaning with the highest glass protection.




Glass Wash 40°

Specially designed glass program to add an extra sparkle to your glassware at the touch of the button.



To lock glasses into the secure position



To open and remove glasses from the GlassSecure Tray



Heat Exchanger

The heat recycling reservoir located in the side panel of the machine maximises the performance by using heat that is generated in each cycle to pre-heat cold water used for the next cycle before it enters the dishwasher. The heat exchanger also works effectively as a residual heat drying system which is extremely energy efficient and a gentle form of drying. This happens by refilling the reservoir with cold water after the final rinse, creating a cooler wall that speeds up the condensation process.



Shine & Dry

A unique energy-efficient function that produces table ready, gleaming glassware by harnessing the power of Zeolith®. This special drying cycle gently brings out a streak-free shine in most delicate glassware and tableware.

Exclusive to SMU88TS03A and SMS88TI03A.



VarioSpeed™

Express Wash Option
With VarioSpeed™ you can almost halve the wash program cycle time without sacrificing washing and drying results.

Freestanding dishwashers.



Product Overview		Freestanding		
		SMS88TI03A	SMS88TI01A	SMS68M38AU
		Series 8	Series 8	Series 6
Water	Star rating (litres per wash)	5 (12)	5 (12)	5 (12)
Energy	Star rating (kWh per year)	4.5 (206)	4 (245)	4 (233)
Dimensions	(H x W x D)	845 x 600 x 600 Height with top removed: 815mm	845 x 600 x 600 Height with top removed: 815mm	845 x 600 x 600 Height with top removed: 815mm
Capacity	International Place Settings	15	15	15
Design	TFT Full Colour Display	2 Displays	2 Displays	
	EmotionLight Internal Lighting	●		
	Anti-fingerprint Stainless Steel	●	●	●
	White			
	SensorTouch Buttons	●	●	
	Polinox Base			
	Zeolith® Drying	●		
	DosageAssist™	●	●	●
Wash Programs	Auto 35-45°C (delicates)	●	●	
	Auto 45-65°C (normal daily)	●	●	●
	Auto 65-75°C (pots and pans)	●	●	
	Eco 45°C	●	●	●
	Normal 45°C			
	Intensive 65°C			
	Pots and Pans 70°C			●
	Glass Wash 40°C	●	●	●
	Super 60°C	●	●	
	Quick 45°C	●	●	●
	Pre-Rinse	●	●	●
Wash Options	VarioSpeed™	●	●	●
	IntensiveZone™	●	●	●
	HygienePlus™	●	●	●
	HalfLoad Plus	●	●	●
	Shine & Dry	●		
	ExtraDry	●	●	
ActiveWater Features	AutoBrilliance™	●	●	●
	AquaSensor™	●	●	●
	EcoSilence™ Drive	●	●	●
	Heat Exchanger	●	●	●
	ActiveWater™ Filter System	●	●	●
Flexibility	Cutlery System	VarioDrawerPro	VarioDrawerPro	VarioDrawer
	Basket System	VarioFlex™ Pro	VarioFlex™ Pro	VarioFlex™
	Rackmatic™ Plus	●	●	●
	Large Item Sprayhead	●	●	●
Convenience	dB rating	42	42	42
	Delay Start	●	●	●
Safety	AquaStop™ Plus	●	●	●
	Child Lock	●	●	●

Exclusive model.
See website for stockists.

Exclusive model.
See website for stockists.



SMS63M38AU	SMS63L18AU	SMS60D08AU	SMS50M22AU	SMS50E32AU
Series 6	Series 6	Series 4	Series 6	Series 4
5 (11)	4 (13.4)	4 (13.4)	5 (11)	4 (13.5)
4 (220)	4 (226)	4 (266)	4 (220)	3.5 (266)
845 x 600 x 600 Height with top removed: 815mm	845 x 600 x 600 Height with top removed: 815mm	845 x 600 x 600 Height with top removed: 815mm	845 x 600 x 600 Height with top removed: 815mm	845 x 600 x 600 Height with top removed: 815mm
14	14	14	14	14
●	●	●		●
			●	●
	●	●		●
●	●	●	●	●
●	●	●	●	
				●
	●	●		●
●	●	●	●	●
●				
●	●	●	●	●
●	●	●	●	●
●	●	●	●	●
●	●	●	●	●
●	●	●	●	●
●	●	●	●	●
●	●	●	●	●
●	●	●	●	●
●	●	●	●	●
VarioCutlery Basket	Cutlery Basket	Cutlery Basket	Cutlery Basket	Cutlery Basket
VarioFlex™	VarioFlex™	Vario™	Vario™	Vario™
●	●		●	
●			●	
42	45	46	44	48
●	●	●	●	●
●	●	●	●	●
●	●	●	●	●

Exclusive model.
See website for stockists.

Built-Under dishwashers.

Built-Under, Fully and Semi-Integrated dishwashers.



Product Overview		Built-Under		
		SMU88TS03A	SMU68M25AU	SMU50M05AU
		Series 8	Series 6	Series 6
Water	Star rating (litres per wash)	5 (12)	5 (12)	5 (11)
Energy	Star rating (kWh per year)	4.5 (206)	4 (233)	4 (220)
Dimensions	(H x W x D)	815-875 x 598 x 550	815-875 x 598 x 550	815-875 x 598 x 574
Capacity	International Place Settings	15	15	14
Design	TFT Full Colour Display	2 Displays		
	TimeLight Floor Projection			
	InfoLight™ Floor Projection			
	EmotionLight Internal Lighting	●		
	SensorTouch Buttons	●		
	Zeolith® Drying	●		
	DosageAssist™	●	●	●
Wash Programs	Auto 35-45°C (delicates)	●		
	Auto 45-65°C (normal daily)	●	●	●
	Auto 65-75°C (pots and pans)	●		
	Eco 45°C	●	●	●
	Normal 45°C			
	Intensive 65°C			
	Pots and Pans 70°C		●	●
	Glass Wash 40°C	●	●	
	Super 60°C	●		
	Quick 45°C	●	●	●
	Pre-Rinse	●	●	●
Wash Options	VarioSpeed™	●	●	●
	IntensiveZone™	●	●	
	HygienePlus™	●	●	
	HalfLoad Plus	●	●	●
	Shine & Dry	●		
	ExtraDry			
ActiveWater Features	AutoBrilliance™	●	●	●
	AquaSensor™	●	●	●
	EcoSilence™ Drive	●	●	●
	Heat Exchanger	●	●	●
	ActiveWater™ Filter System	●	●	●
Flexibility	Cutlery System	VarioDrawer™ Pro	VarioDrawer™	Cutlery Basket
	Basket System	VarioFlex™ Pro	VarioFlex™	VarioFlex™
	Rackmatic™ Plus	●	●	●
	Large Item Sprayhead	●	●	●
Convenience	dB rating	42	42	44
	Delay Start	●	●	●
Safety	AquaStop™ Plus	●	●	●
	Child Lock	●	●	●

Compact dishwashers.



Product Overview		Compact	
		SCE63M05AU	SKE53M05AU
		Series 6	Series 6
Water	Star rating (litres per wash)	3 (10.1)	3.5 (7.2)
Energy	Star rating (kWh per year)	3 (180)	3 (135)
Dimensions	(H x W x D)	595 x 595 x 500	454 x 595 x 500
Capacity	International Place Settings	8	6
Design	DosageAssist™	●	●
Wash Programs	Auto 35-45°C (delicates)		
	Auto 45-65°C (normal daily)	●	●
	Auto 65-75°C (pots and pans)		
	Eco 45°C		
	Normal 45°C	●	●
	Intensive 65°C	●	
	Pots and Pans 70°C	●	●
	Glass Wash 40°C		
	Super 60°C		
	Quick 45°C	●	●
	Pre-Rinse	●	●
Wash Options	VarioSpeed™	●	●
	IntensiveZone™	●	●
	HygienePlus™	●	
	HalfLoad Plus		
	Shine & Dry		
	ExtraDry		
ActiveWater Features	AutoBrilliance™	●	●
	AquaSensor™	●	●
	EcoSilence™ Drive	●	●
	Heat Exchanger	●	●
	ActiveWater™ Filter System	●	●
Flexibility	Cutlery Basket	Cutlery Basket	Cutlery Basket
	Basket System	Vario™	Vario™
	Rackmatic™ Plus		
	Large Item Sprayhead		
Convenience	dB rating	43	47
	Delay Start	●	●
Safety	AquaStop™ Plus	●	●
	Child Lock	●	●

Quality Service.

The customer service of Bosch, before and after purchase.

Important notes

Model numbers and specifications are for reference only and subject to change without prior notice.

For additional information on products, please refer to your local Bosch retailer. Bosch is continuously seeking to improve specification, design and production of its appliances and alterations may take place regularly.

All descriptions and technical diagrams are intended as a guide only. For additional technical information, full dimensional and installation details, please refer to the instruction and installation manuals supplied with the appliance.

The electrical and water connection should only be made in accordance with the regulations of the national authorities.

For model and accessory availability, please contact BSH Home Appliances Limited.

(See back cover for details)

Quality service for quality appliances

Quality of our after-sales service is just as important as the quality of our products. In the unlikely event that service is required on your appliance, our extensive network of authorised service agents throughout New Zealand will ensure you are provided with the full support to ensure your appliance is operating at optimal condition.

Warranty



All Bosch products are covered under a 2-year comprehensive parts and labour warranty.



Activating your 10 year warranty couldn't be easier

You can activate your warranty up to eight weeks after your new Bosch dishwasher has been delivered.

Activating the warranty and registering your dishwasher online is free, simple and takes just a few minutes at **www.bosch-home.co.nz**



BSH Home Appliances Ltd

Unit F2, 4 Orbit Drive
Mairangi Bay
Auckland 0632

PO Box 33-1033
Takapuna
Auckland 0740

Phone: (09) 477 0492
Fax: (09) 477 2647

Customer Service

Phone: 0800 807 723
Fax: 0800 256 535

Email: bshnz-cs@bshg.com

www.bosch-home.co.nz



Whilst every care has been taken in the preparation of this publication, BSH does not warrant the accuracy or completeness of the information in this publication and BSH reserves the right to alter specifications without notice. To the extent permitted by law, BSH excludes all liability, including negligence, for any loss incurred in reliance on the contents of this publication.

Printed in New Zealand