



Ergonomic features for high convenience and flexibility



Flex tube

90° bendable tube for easy and ergonomic cleaning under furniture and other hard-to-reach places.



Quick stand

Comfortably clean with the handheld unit while the nozzle and tube stand by themselves.



Nozzle foot release Detach the nozzle from the tube without bending over. Easily switch from floor cleaning to overhead or spot cleaning.



Easy parking clip Securely park the vacuum at the edge of a chair, table or benchtop when taking a break.



nade easy

TD

Unlimited 7

The Unlimited 7 Our most flexible vacuum cleaner.

10









*See www.bosch-home.com.au for terms of guarantee. ¹ Measured in Turbo mode on hard floors with crevices. Tested according to EN 60312-1:2017. ² Up to 40min per 3.0AH 18V battery. Measured in eco-mode without electrical nozzle. Tested according to EN IEC 62885-4:2020. Includes 2 batteries, additional batteries sold separately. ³ Per 3.0AH 18V battery. Measured in eco-mode without electrical nozzle. Tested according to EN IEC 62885-4:2020. Includes 2 batteries, additional batteries sold separately. ³ Per 3.0AH 18V battery. Measured in eco-mode without electrical nozzle. Tested according to EN IEC 62885-4:2020. Includes 1 battery, additional batteries to extend runtime sold separately.

Unlimited flexibility thanks to included accessories.*



Quick charger & 2nd battery for extendable runtime



2-in-1 furniture & upholstery nozzle

Unlimited 7 ProAnimal BCS71PETAU



ProAnimal mini power nozzle

Unlimited 7 Blue BBS711AU



Look out for model

exclusive accessories!

V

Flexible extension hose

Unlimited 7 White BCS711WAU



Keyboard nozzle



XXL upholstery nozzle with 360° rotation



Mattress nozzle



Short crevice tool

Why Bosch Unlimited 7?







40 min. 80 min.



- AllFloor DynamicPower Brush
- Motorized nozzle suitable for all floor types.
- Hinge with 180° rotation.
- Integrated LED floor lights.
- Up to 99.9% dust pick up.¹




18V Power for ALL battery

- Exchangeable 3.0Ah battery with up to 40min runtime per battery.²
- The battery is part of the Bosch Home and Garden 18-Volt cordless system (green product line).







High performance

Lightweight TurboSpin motor

10 year motor guarantee.*
Lightweight: handheld unit weighs only 1.4kg.

Intuitive 3-step power modes

- Eco: extensive runtime for longer cleaning.
- Auto: automatic power adjustment based on the floor type.
- Turbo: ultimate performance for optimal cleaning results.

 Charge when placed in the complimentary docking station.

Alternatively, connect charging

cable directly to handheld unit.



RotationClean

- Hygienic and easy cleaning.
- No filter washing needed.
- Minimal dust contact when
- emptying dust bin.



¹Measured in Turbo mode on hard floors with crevices. Tested according to EN 60312-1:2017.

Flexible charging

²Up to 40min per 3.0AH 18V battery. Measured in eco-mode without electrical nozzle. Tested according to EN IEC 62885-4:2020. Models include 1 or 2 batteries, refer to specifications. Additional batteries sold separately.

(H)

BOSCH

Clean easy #LikeABosch Can you bend it? Yes you can!