

Invented for life



Dishwasher range

Taking cleaning to the next level.



WORLD'S
No1
BRAND
dishwashers*

* For major domestic appliances.
Source: Euromonitor, volume sales, 2023

Serie | 8

Best in class.




MaxFlex Pro basket system

Stainless steel tub with three baskets; Extra Space 3rd basket, upper basket and lower basket providing space for all of your kitchen items. Cutlery basket also included.



Extra Space 3rd basket 25% more loading space for larger utensils and oddly shaped items.



Rackmatic height adjustable upper basket with **EasyClean Zone**. Anti-slip silicone protectors for wine (grey) and drink glasses (red).
6 collapsible tines.



Lower basket with higher side walls at 18cm. A new glass support with shelf design offers space for small crockery. Low friction wheels and **rack stopper** for smooth movement and no derailing.
8 collapsible tines.

Serie | 8 Specifications

Programs

- ▶ Eco 45°
- ▶ 3 Auto Programs
- ▶ Quick 45°
- ▶ Quick 60min Wash+Dry
- ▶ ExtraQuiet (40 dB)
- ▶ Pre-rinse / Favourite

Options

- ▶ EfficientDry with AutoDoor Open
- ▶ Speed on Demand
- ▶ Remote Start
- ▶ Hygiene Plus
- ▶ Machine Care



Freestanding Dishwasher SMS8EDI01A (Stainless)

Also available in

Under bench - SMU8EDS01A (Stainless)



Semi-integrated TallTub - SBI8EDS01A



TallTub
86cm

Fully integrated TallTub - SBV8EDX01A



TallTub
86cm

Serie | 6

For a little bit more.




MaxFlex basket system

Stainless steel tub with three baskets; VarioDrawer, upper basket and lower basket to suit a range of dishes and utensils. Cutlery basket also included.



VarioDrawer* for cutlery and utensils.



Rackmatic height adjustable upper basket with **EasyClean Zone**. Anti-slip silicone protectors for wine (grey) and drink glasses (red).
2 collapsible tines.



Lower basket with higher side walls at 18cm. A new glass support with shelf design offers space for small crockery. Low friction wheels and **rack stopper** for smooth movement and no derailing.
6 collapsible tines.

*excluding SMS6HAI01A



Freestanding Dishwasher

SMS6HCI01A (Stainless)
SMS6HAI01A (Stainless)
SMS6HCW01A (White)
SMS6HCB01A (Black Inox)

Also available in

Under bench - SMU6HCS01A(Stainless), SMU6HAS01A(Stainless)



Semi-integrated - SMI6HCS01A



Fully integrated - SMV6HCX01A



Please refer to www.bosch-home.com.au for model availability.

Everyday performer.



VarioFlex basket system

Polinox tub with three baskets; VarioDrawer, upper basket and lower basket to suit a range of dishes and utensils. Cutlery basket also included.



VarioDrawer* for cutlery and utensils.



Rackmatic height adjustable upper basket*.
2 collapsible tines.



Lower basket with **rack stopper** to prevent derailing.
4 collapsible tines.

Serie | 4 Specifications

Programs

- ▶ Eco 45°
- ▶ 1 Auto Program
- ▶ Pots and Pans 70°
- ▶ Quick 60min Wash+Dry
- ▶ Glass
- ▶ Pre-rinse / Favourite

Options

- ▶ ExtraDry
- ▶ Speed on Demand
- ▶ Remote Start
- ▶ Hygiene Plus
- ▶ Machine Care

#on dishwashers series 4 and up

*selected models

^Additional knife rack only on Series 4 models without VarioDrawer



Freestanding Dishwasher

SMS4HVI01A (Stainless)

SMS4HTI01A (Stainless)

SMS4HVB01A^ (Black Inox)

Also available in

Under bench - SMU4HVS01A (Stainless), SMU4HTS01A (Stainless)

Number of control buttons varies by model



Semi-integrated - SMI4HTS01A



Fully integrated - SMV4HTX01A



Serie | 2

The dishwasher you can trust.



Standard basket system

Polinox tub with two baskets; upper and lower. Also comes equipped with cutlery basket.



Upper basket with cup shelf.



Lower basket with **rack stopper** to prevent derailing.

Serie | 2 Specifications

Programs

- ▶ Eco 45°
- ▶ 1 Auto program
- ▶ Pots and Pans 70°
- ▶ Quick 60min Wash+Dry
- ▶ Pre-rinse / Favourite

Options

- ▶ ExtraDry
- ▶ Speed on Demand
- ▶ Remote Start
- ▶ Hygiene Plus
- ▶ Machine Care



Freestanding Dishwasher
SMS2ITW01A (White)

Discover our flexible basket features



VarioDrawer

A third loading level for cutlery, utensils and espresso cups. VarioDrawer provides loading flexibility where these smaller items can be separated for optimal cleaning.



Rackmatic Plus

Height-adjustable upper basket provides nine different loading positions*. The basket can be adjusted on an angle to accommodate tall plates in the bottom basket and long stem glasses in the upper basket.

**SMS8ED101A & SMU8EDS01A have 6 positions due to extra depth of the Extra Space 3rd basket.*

Wash programs

Programs vary by model.



Automatic programs

Dishwasher assesses how soiled the items are and adjusts the settings accordingly.



Quick 60mins Wash + Dry

For dishes of various soiling levels when time is of the essence.



Pre-Rinse

Uses cold water to rinse the dishes before the selected program begins.



Eco Wash 45°C

Water and energy efficient program for mixed loads.



Quick 29mins*

Express wash to clean lightly soiled dishes in a short time.

**With use of rinse aid.*



Glass Wash 40°C

Gently cleans glasses while providing optimum drying.



Pots & Pans 70°C

An intensive wash cycle designed for heavily soiled dishes.



ExtraQuiet

Washes dishes exceptionally quietly at just 40dB (Series 8) or 42dB (Series 6).

Wash options



ExtraDry

Higher temperature final rinse, for better drying results. Especially useful for drying glassware and plastics.



Speed on Demand

Speed up the selected program before or during the cycle.



HygienePlus

Increases the final rinse temperature and retains it for an extended period of time for a hygienic finish.



Machine Care

Removes grime and limescale build-up to keep your dishwasher clean and fresh. Recommended once a month or after every 30 washes.

Build types

Freestanding

845 x 600 x 600mm

Under bench

815 x 598 x 573mm

Semi-integrated

815 x 598 x 573mm

Fully integrated

815 x 598 x 550mm

Freestanding design

Flush fit height adjustable

Optional stainless steel kick panel

Matches kitchen cabinetry

Continuous kick panel

Also in TallTub 86cm

Unique InfoLight wash status indicator projection

Discover our new and improved features

Extra Space 3rd basket

Deeper third basket providing 25% more loading space for smaller items. Perfect for bowls, larger cooking utensils or oddly shaped items. Also comes equipped with a removable knife shelf.


Available in Series 8 Dishwashers.



ExtraClean Zone

Designed for dishes needing an extra soak in the upper basket. A constant spray from three rotating nozzles allows three times more water on tougher to clean items.

Available in Series 8 & 6 Dishwashers.



EfficientDry with AutoDoor Open

Series 8 dishwashers automatically open the door towards the end of the drying phase for a better dry with the added bonus of saving energy.

Available in Series 8 Dishwashers.



Favourite button

Set your favourite combination of wash program and wash option. Or, alternatively, download via the Home Connect app. When the favourite button is not selected the dishwasher will default to pre-rinse.

With Home Connect, you'll have access to smart functionality to make cleaning a breeze. Innovative features let you start, stop, and monitor the status of your dishwasher even when you're not home. With suggestive programs and tablet top up reminders, Home Connect takes the stress out of cleaning.



Mid-cycle customisation

With Home Connect, you can adjust cycles after they have begun.

Impromptu visitors? No worries. **Speed on Demand** will fast track the wash to ensure you have clean dishes in time for last minute entertaining.

Silence on demand changes settings to achieve the quietest of washes. Perfect for when you're watching a movie or entertaining.



Suggestive programs

Take the guess work out of washing the dishes. Just ask **Easy Start** in your Home Connect app.

Easy Start guides you through selecting the best possible wash program and option. Simply select the type of dishes (eg. mixed load or glassware) and your cleaning preferences such as time/energy efficiency or extra hygienic. Your recommended program will then be displayed.



Energy & water consumption indicator

We all get to choose our home appliances, but we don't always have a say when it comes to energy usage.

The Home Connect app shows you the estimated **water and energy consumption** of wash cycles. So now you can get the most out of your wash, while looking out for the environment and your utility bills at the same time.

