





de Reinigen
 en Cleaning
 fr Nettoyage
 es Limpiar
 it Pulizia
 sv Rengöring
 da Rengøring
 no Rengjøring
 el Καθαρισμός
 pl Czyszczenie
 cs Čistění
 sk Čistenie
 ro Curățarea
 ru Очистка



1 	2 	3 	4
5 	6 	7 	8
9 	10 	11 	12
13 	14 	15 	
16 			





- de Entkalken
- en Descaling
- fr Détartrage
- es Descalcificar
- it Decalcificare
- sv Avkalkning
- da Afkalkning
- no Avkalking
- el Αποσβέσωση
- pl Odkamienianie
- cs Odstranění vodního kamene
- sk Odstránenie vodného kameňa
- ro Decalcifierea
- ru Удаление накипи

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

min. 500 ml 17 fl.oz.

5 s


30 min

max

max

3x

bosch-home.com
tassimo.com
№ TCZ6004



www.tassimo.com
www.bosch-home.com
 № TCZ6004



8001137722 – 10/18

www.bosch-home.com
www.tassimo.com

