






de Reinigen  
 en Cleaning  
 fr Nettoyage  
 it Pulizia  
 es Limpiar  
 sv Rengöring  
 da Rengøring  
 no Rengjøring  
 el Καθαρισμός  
 pl Czystczenie  
 cs Čištění  
 sk Čistenie  
 ro Curățare  
 ru Очистка




1




2




3




4




5




6




7




8




9




10




11




12




13





14



15




16







- de Entkalken
- en Descaling
- fr Détartre
- it Decalcificazione
- es Descalcificar
- sv Avkalkning
- da Afkalkning
- no Avkalking
- el Αποσβέστωση
- pl Odkamienianie
- cs Odst.vod.k.
- sk Odstraňovanie vodného kameňa
- ro Decalcifiere
- ru Удаление накипи



www.tassimo.com  
www.bosch-home.com  
№ TCZ6004




1




2




3




4



5




6



7




8




9




10




11




12



13



14



15

