










de Reinigen
 en Cleaning
 fr Nettoyage
 it Pulizia
 es Limpiar
 el Καθαρισμός
 pl Czyszczenie
 cs Čištění
 sk Čistenie
 ro Curățare




www.bosch-home.com
 № 17001491






de Entkalken
 en Descaling
 fr Détartré
 it Decalcificazione
 es Descalcificar
 el Αποσβέσωση
 pl Odkamienianie
 cs Odst.vod.k.
 sk Odstraňovanie vodného kameňa
 ro Decalcifiere




www.bosch-home.com
 № 17001491



1

2



3



4

5

6








7

8

9

10









11

12

13

14



15

TASSIMO
 happy friendly



BOSCH

www.tassimo.com
www.bosch-home.com
 № TCZ6004/00311909
 № TCZ6008/00312249

www.tassimo.com
www.bosch-home.com

8001288932 - 01/24

BOSCH

