
















de	Montageanweisung
da	Monteringsvejledning
sv	Monteringsanvisning
no	Montasjeveiledning
fi	Assennus ohjeet








6




7

Scheibe entfernen
remove disc
enlever le disque
Eliminar disco



13
Dichtheit nach einem Spülgang prüfen.
Check for leaks after one wash cycle.
Vérifiez l'étanchéité après un lavage.
Verificar la estanqueidad tras un ciclo de lavado.



Ident-Nr. 48 1271

Ident-Nr. 35 0564