

Overview of programmes

Programme/type of laundry/information	Settings
Name of the programme Brief explanation of the programme and for which fabrics it is suitable.	Max. load; * Reduced load for Turbo Perfect  setting Spin speed (depending on model) Possible programme settings
Algodón/Algodão (Cotton) Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen. Algodón/Algodão (Cottons) + Prelav. (Prewash) : Divide the detergent between compartments I and II Note: The Turbo Perfect  setting is suitable as a short programme for lightly soiled laundry.	Max. 8 kg/4* kg  ... 1400 rpm Eco Perfect  , Turbo Perfect  , Fácil (Easy Iron)  , Extra 
Sintéticos (Easy-Care) Textiles made of synthetic or blended fabrics.	Max. 3.5 kg  ... 1200 rpm Eco Perfect  , Turbo Perfect  , Fácil (Easy Iron)  , Extra 
Mix A mixed load of laundry made of cotton and synthetic fabrics	Max. 3.5 kg  ... 1400 rpm Eco Perfect  , Turbo Perfect  , Fácil (Easy Iron)  , Extra 
Delicado/Seda (Delicate/Silk) For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarves) Note: Use a detergent which is suitable for machine-washing delicates or silk.	Max. 2 kg  ... 800 rpm Eco Perfect  , Turbo Perfect  , Fácil (Easy Iron)  , Extra 
Lana/Lã  (Wool) Hand- or machine-washable fabrics that are made of wool or contain wool; Particularly gentle wash programme to prevent shrinkage of laundry, with longer programme breaks (fabrics rest in the detergent solution) Notes ■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep. ■ Use a detergent that is suitable for wool.	Max. 2 kg  ... 800 rpm -
 (Rinse) /  (Spin) Programme for spinning or rinsing. Note: If you do not want to spin and instead want to rinse, select the additional programme setting Extra  .	Max. 8 kg  ... 1400 rpm Fácil (Easy Iron) 

Programme/type of laundry/information	Settings
 (Empty) The rinsing water, e.g. after setting  (Rinse stop)	Max. 8 kg  ... 1400 rpm -
Rápido (Quick) 15 min. Extra-short programme of approx. 15 minutes, suitable for small items of lightly soiled laundry.	Max. 2 kg  ... 1200 rpm -



Consumption values table

Programme duration, residual moisture, energy and water consumption for the main washing programmes (approximate information)

Programme	Load	Energy consumption*	Water*	Programme duration*
Algodón/Algodão (Cottons) frío (cold)/20 °C	8 kg	0.30 kWh	75 l	2 1/2 h
Algodón/Algodão (Cottons) 40 °C	8 kg	1.00 kWh	75 l	2 3/4 h
Algodón/Algodão (Cottons) 60 °C	8 kg	1.12 kWh	75 l	2 3/4 h
Algodón/Algodão (Cottons) 90 °C	8 kg	2.25 kWh	85 l	2 3/4 h
Sintéticos (Easy-Care) 40 °C	3.5 kg	0.64 kWh	58 l	1 3/4 h
Mix 30 °C	3.5 kg	0.54 kWh	51 l	1 h
Delicado/Seda (Delicates/Silk) frío (cold)	2 kg	0.19 kWh	35 l	3/4 h
Lana/Lã (Wool) 30 °C	2 kg	0.17 kWh	40 l	3/4 h

Programme	Approximate information on the residual moisture**		
	WA...28...	WA...24...	WA...20...
	Max. 1400 rpm	Max. 1200 rpm	Max. 1000 U/rpm
Cotton	48 %	53 %	62 %
Easy-Care	40 %	40 %	40 %
Delicate/Silk	30 %	30 %	30 %
Wool	45 %	45 %	45 %

* The values may deviate from the specified values depending on the following factors: water pressure and hardness; water inlet temperature; type, amount and soiling of laundry; detergent used; fluctuations in the power supply; and additional functions selected.

** Information on residual moisture based on programme-dependent spin speed limits and maximum loads.

Most efficient programmes for cotton fabrics

The following programmes (standard programmes, indicated by ) are suitable for cleaning normally soiled cotton fabrics and are the most efficient with respect to combined energy and water consumption.

Standard programmes for Cottons in accordance with the directive (EU) no. 1015/2010		
Programme + Button	Load	Programme duration
Algodón/Algodão (Cottons)  °C +  Eco Perfect 	8 kg	4 h
Algodón/Algodão (Cottons)  °C +  Eco Perfect 	4 kg	4 h
Algodón/Algodão (Cottons)  °C +  Eco Perfect 	4 kg	4 h
Programme setting for testing and energy labelling in accordance with Directive 2010/30/EU with cold water (15 °C). The specification of the programme temperature is based on the temperature stated on the care label in the fabrics. The actual washing temperature may deviate from the stated programme temperature for energy-saving reasons.		

Notes

- This additional sheet is a part of your operating and installation instructions. Retain all documentation for subsequent use.
- Much more important information can be found in your operating and installation instructions.

