

## Overview of programmes

Programme/Type of laundry/Information	Settings
<p><b>Name of the programme</b></p> <p>Brief explanation of the programme and for which fabrics it is suitable.</p>	<p>Max. load;</p> <p>* Reduced load for speed Perfect  setting</p> <p>Temperature</p> <p>Spin speed (depending on model)</p> <p>Possible programme settings</p>
<p><b>algodón/algodão (Cottons)</b></p> <p>Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen.</p> <p>algodón/algodão (Cottons) + <b>prelav. (Prewash)</b>: Divide detergent between compartments <b>I</b> and <b>II</b></p> <p><b>Note:</b> The speed Perfect  setting is suitable as a short programme for lightly soiled laundry.</p>	<p>Max. 8 kg / 4* kg</p> <p> - 90 °C</p> <p> ... 1400 rpm</p> <p>eco Perfect , speed Perfect , menos  (Easy Iron), extra  (Rinse Plus)</p>
<p><b>sintéticos (Easy-Care)</b></p> <p>Textiles made of synthetic or blended fabrics.</p> <p>sintéticos (Easy-Care) + <b>prelav. (Prewash)</b>: Divide the detergent between compartments <b>I</b> and <b>II</b></p>	<p>Max. 3.5 kg</p> <p> - 60 °C</p> <p> ... 1200 rpm</p> <p>eco Perfect , speed Perfect , menos  (Easy Iron), extra  (Rinse Plus)</p>
<p><b>mix (Quick/Mix)</b></p> <p>A mixed load of fabrics made of cotton and synthetic fabrics</p>	<p>Max. 3.5 kg</p> <p> - 40 °C</p> <p> ... 1400 rpm</p> <p>eco Perfect , speed Perfect , menos  (Easy Iron), extra  (Rinse Plus)</p>
<p><b>delicado/seda (Delicates/Silk)</b></p> <p>For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarves)</p> <p><b>Note:</b> Use a detergent that is suitable for machine-washing delicates or silk.</p>	<p>Max. 2 kg</p> <p> - 40 °C</p> <p> ... 800 rpm</p> <p>eco Perfect , speed Perfect , menos  (Easy Iron), extra  (Rinse Plus)</p>

Programme/Type of laundry/Information	Settings
<p> <b>lana/lã (Wool)</b></p> <p>Hand- or machine-washable fabrics that are made of wool or contain wool;</p> <p>Particularly gentle wash programme to prevent shrinkage of laundry, with longer programme breaks (fabrics rest in the detergent solution)</p> <p><b>Notes</b></p> <ul style="list-style-type: none"> <li>■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep.</li> <li>■ Use a detergent that is suitable for machine-washing wool.</li> </ul>	<p>Max. 2 kg</p> <p> - 40 °C</p> <p> ... 800 rpm</p> <p>-</p>
<p> <b>(Rinse) /  (Spin)</b></p> <p>Programme for spinning or rinsing.</p> <p><b>Note:</b> If you do not want to spin and instead want to rinse, select the additional programme setting <b>extra</b> .</p>	<p>Max. 8 kg</p> <p>-</p> <p> ... 1400 rpm</p> <p>menos  (Easy Iron)</p>
<p> <b>(Empty)</b></p> <p>the rinsing water, e.g. after setting  (without final spin)</p>	<p>Max. 8 kg</p> <p>-</p> <p> ... 1400 rpm</p> <p>-</p>
<p><b>express 15 min. (SuperQuick)</b></p> <p>Extra-short programme of approx. 15 minutes, suitable for small items of lightly soiled laundry</p>	<p>Max. 2 kg</p> <p> - 40 °C</p> <p> ... 1200 rpm</p> <p>-</p>
<p> <b>tomate</b></p> <p>Textiles made of synthetic or blended fabrics.</p> <p><b>Notes</b></p> <ul style="list-style-type: none"> <li>■ Do not allow stains to dry in, and remove any solid residue beforehand.</li> <li>■ The temperature progression, soaking time and drum movement are all adjusted depending on the type of stain.</li> <li>■ Stains are treated optimally without the use of additional special detergents.</li> </ul>	<p>Max. 3.5 kg</p> <p> - 60 °C</p> <p> ... 1200 rpm</p> <p>eco Perfect , speed Perfect ,</p> <p>menos  (Easy Iron),</p> <p>extra  (Rinse Plus)</p>
<p> <b>vino/vinho (wine)</b></p> <p>Textiles made of synthetic or blended fabrics.</p> <p><b>Notes</b></p> <ul style="list-style-type: none"> <li>■ Do not allow stains to dry in, and remove any solid residue beforehand.</li> <li>■ The temperature progression, soaking time and drum movement are all adjusted depending on the type of stain.</li> <li>■ Stains are treated optimally without the use of additional special detergents.</li> </ul>	<p>Max. 3.5 kg</p> <p> - 60 °C</p> <p> ... 1200 rpm</p> <p>eco Perfect , speed Perfect ,</p> <p>menos  (Easy Iron),</p> <p>extra  (Rinse Plus)</p>

Programme/Type of laundry/Information	Settings
<b>o aceite/azeite (oil)</b> Textiles made of synthetic or blended fabrics. <b>Notes</b> <ul style="list-style-type: none"> <li>Do not allow stains to dry in, and remove any solid residue beforehand.</li> <li>The temperature progression, soaking time and drum movement are all adjusted depending on the type of stain.</li> <li>Stains are treated optimally without the use of additional special detergents.</li> </ul>	Max. 3.5 kg * - 60 °C ∅ ... 1200 rpm eco Perfect  , speed Perfect  , menos  (Easy Iron), extra  (Rinse Plus)
<b>camisas/business (Shirts)</b> Non-iron shirts/Blouses made of cotton, linen, synthetics fibres or blended fabrics. <b>Note:</b> Wash shirts/blouses made of delicates/silk in Delicates/silk programme.	Max. 2 kg * - 60 °C ∅ ... 800 rpm eco Perfect  , speed Perfect  , menos  (Easy Iron), extra  (Rinse Plus)
<b>prendas oscuras/roupa escura (Dark Wash)</b> Dark fabrics made of cotton and dark easy-care fabrics Turn laundry inside-out before washing.	Max. 3.5 kg * - 40 °C ∅ ... 1200 rpm eco Perfect  , speed Perfect  , menos  (Easy Iron), extra  (Rinse Plus)



## Consumption values table

**Programme duration, residual moisture, energy and water consumption for the main washing programmes** (approximate information)

Programme	Load	Energy consumption*		Water*	Programme duration*
		Water inlet temperature cold	55 °C		
algodón/algodão (Cottons) 20 °C	8 kg	0.30 kWh	0.30 kWh	75 l	2 1/2 h
algodón/algodão (Cottons) 40 °C	8 kg	1.00 kWh	0.46 kWh	75 l	2 3/4 h
algodón/algodão (Cottons) 60 °C	8 kg	1.12 kWh	0.53 kWh	75 l	2 3/4 h
algodón/algodão (Cottons) 90 °C	8 kg	2.25 kWh	1.31 kWh	85 l	2 3/4 h
sintéticos (Easy-Care) 40 °C	3.5 kg	0.64 kWh	0.33 kWh	58 l	1 3/4 h
mix (Quick/Mix) 40 °C	3.5 kg	0.54 kWh	0.29 kWh	51 l	1 h
delicado/seda (Delicates/Silk) 30 °C	2 kg	0.19 kWh	0.19 kWh	35 l	3/4 h
lana/lã (Wool) 30 °C	2 kg	0.17 kWh	0.17 kWh	40 l	3/4 h

Programme	Approximate information on the residual moisture**		
	WM14... Max. 1400 rpm	WM12... Max. 1200 rpm	WM10.. Max. 1000 U/rpm
Cotton	48 %	53 %	62 %
Easy-Care	40 %	40 %	40 %
Delicate/Silk	30 %	30 %	30 %
Wool	45 %	45 %	45 %

\* The values may deviate from the specified values depending on the following factors: water pressure and hardness; water inlet temperature; type, amount and soiling of laundry; detergent used; fluctuations in the power supply; and additional functions selected.

\*\* Information on residual moisture based on programme-dependent spin speed limits and maximum loads.

### Most efficient programmes for cotton fabrics

The following programmes (standard programmes, indicated by ) are suitable for cleaning normally soiled cotton fabrics and are the most efficient with respect to combined energy and water consumption.

Standard programmes for Cottons in accordance with the directive (EU) no. 1015/2010		
Programme + Temperature + Button	Load	Programme duration
algodón/algodão (Cottons) + <input type="checkbox"/> 60°C + <input type="checkbox"/> eco Perfect	8 kg	4 h
algodón/algodão (Cottons) + <input type="checkbox"/> 60°C + <input type="checkbox"/> eco Perfect	4 kg	4 h
algodón/algodão (Cottons) + <input type="checkbox"/> 40°C + <input type="checkbox"/> eco Perfect	4 kg	4 h

Programme setting for testing and energy labelling in accordance with Directive 2010/30/EU with cold water (15 °C).  
The specification of the programme temperature is based on the temperature stated on the care label in the fabrics. The actual washing temperature may deviate from the stated programme temperature for energy-saving reasons.

### Notes

- This additional sheet is a part of your operating and installation instructions. Retain all documentation for subsequent use.
- Much more important information can be found in your operating and installation instructions.

WM10Q468ES / ...

9000934773 (9410)

