

Pregled programa

Program/vrsta rublja/napomene	Postavke
Naziv programa Kratko objašnjenje programa, odnosno za koju vrstu tkanine je primjeren.	maks. utovar; odaberiva temperatura (* = hladno) odaberivi broj okretaja centrifuge**; ---- = Stop ispiranja odaberivi dodatni Postavke programa
 Cottons (Pamuk): Otporne tkanine, pamučne ili lanene tkanine za iskuhavanje	maks. 6,5 kg/4 kg*; * - 90 °C ----, 0 - 1200** okr/min  Speed Eco  Perfect  , 
 Easy-Care (Lako za njegu): Tkanine od sintetike ili miješanih materijala	maks. 3 kg; * - 60 °C ----, 0 - 1200** okr/min  Speed Eco  Perfect  , 
 Wool (Vuna): Ručno ili strojno perivo rublje od vune ili koje sadrži vunu; izrazito blag program pranja kako bi se izbjeglo skupljanje rublja, dulje programske stanke (tkanine miruju u vodi)	maks. 2 kg; * - 40 °C ----, 0 - 800 okr/min -
Napomene - Vuna je životinjskog podrijetla, npr. angora, alpaka, lama, ovca. - Koristite deterdžent za strojno pranje primjeren za vunu.	
 SuperQuick 15'/30': Ekstra kratki program cca.30 minuta primjeren za blago zaprljanu malu odjeću	maks. 3,5 kg/2 kg*; * - 40 °C ----, 0 - 1200** okr/min  SpeedPerfect 
Napomena: kraće trajanje programa (oko 15 minuta) kod podešavanja programa  SpeedPerfect 	
 Mix (Miješano): Miješana količina rublja od pamuka i sintetike	maks. 4 kg; * - 40 °C ----, 0 - 1200** okr/min  Speed Eco  Perfect  , 
 Night wash (Noćno pranje): Iznimno tihi program za pranje noću, pogodan za pamučne, lanene, sintetičke ili mješovite tkanine	maks. 4 kg; * - 40 °C ----, 0 - 1200** okr/min  Speed Eco  Perfect  , 
Napomena: deaktiviran završni signal	
* smanjenje utovara kod podešavanja programa  SpeedPerfect  ** maks. Broj okretaja centrifuge ovisno o modelu i programu	

Program/vrsta rublja/napomene	Postavke
 Rinse (Ispiranje): Ekstra ispiranje sa centrifugiranjem	-; - ----, 0 - 1200** okr/min 
 Spin (Centrifugiranje): Ekstra centrifugiranje s mogućnošću biranja broja okretaja	-; - 0 - 1200** okr/min
 Empty (Ispumpavanje): Ispumpavanje bez vode za ispiranje	-
Napomena: Isto treba ispumpati, broj okretaja centrifuge postavite na - 0 -.	
 AllergyPlus (Higijena): Otporne tkanine od pamuka ili lana	maks. 4,5 kg; * - 60 °C
Napomena: Posebno pogodan kod povećanih higijenskih zahtjeva ili posebno osjetljive kože na temelju produženog pranja na definiranoj temperaturi, višoj razini vode i dužeg ispiranja.	
 Shirt/Blouses (Košulje/bluze): Košulje koje ne treba glačati od pamuka, lana, sintetike ili miješanoga sastava	maks. 2 kg; * - 60 °C ----, 0 - 800 okr/min  Speed Eco  Perfect   
Napomena: Košulje/bluze od svile prati u programu za fino rublje/svilu.	
 Dark wash (Tamno rublje): Tamne tkanine od pamuka i tamne tkanine lake za održavanje	maks. 2 kg; * - 40 °C ----, 0 - 1200** okr/min  Speed Eco  Perfect   
 Sportswear (Športska odjeća): Tekstil od mikro-vlakana za sport i rekreaciju	maks. 2 kg; * - 40 °C ----, 0 - 800 okr/min  Speed Eco  Perfect   
Napomene ■ Rublje se ne smije tretirati omekšivačem. ■ Prije pranja, temeljito očistite ladicu za sredstvo za pranje rublja (sve komore) od ostataka omekšivača.	
 Down (Perje): Tkanine koje možete prati u perilici punjene perjem, jastuci, prekrivači, primjereno i za punjenja sa sintetičkim vlaknima	maks. 1 kg; * - 60 °C ----, 0 - 1200** okr/min  Speed Eco  Perfect  
Napomena: Velike komade prati posebno. Koristite sredstvo za fino pranje - molimo obratite pozornost na oznaku za održavanje. Sredstvo za pranje dozirajte štedljivo.	
 Delicate/Silk (Fino/Svila): Za osjetljive, perive tkanine, npr. svila, saten, sintetika ili miješana vlakna (npr. svilene bluze, svileni šalovi)	maks. 2 kg; * - 40 °C ----, 0 - 800 okr/min  Speed Eco  Perfect   
Napomena: Koristite deterdžent za strojno pranje primjeren za osjetljivo rublje i/ili svilu.	
* smanjenje utovara kod podešavanja programa  SpeedPerfect 	
** maks. Broj okretaja centrifuge ovisno o modelu i programu	

Program/vrsta rublja/napomene	Postavke
 Drum clean (Čišćenje bubnja): Programm za čišćenje i održavanje bubnja i spremnika za sapunicu, npr. prije 1. pranja, kod učestalog pranja niskim temperaturama pranja (40 °C i niže) ili kod stvaranja neugodnih mirisa nakon duže odsutnosti.	maks. 0 kg; 90 °C 1200** okr/min -
Napomene ■ Pokrenite program bez umetanja rublja. ■ Za to koristite deterdžent u prašku. ili deterdžent koji sadrži izbjeljivač. Kako biste spriječili stvaranje pjene, koristite samo polovicu količine sredstva za pranje koju je preporučio proizvođač deterdženta. Ne upotrebljavajte sredstvo za pranje vune ili finog rublja.	
* smanjenje utovara kod podešavanja programa  SpeedPerfect  ** maks. Broj okretaja centrifuge ovisno o modelu i programu	



Vrijednosti potrošnje

Tabela vrijednosti potrošnje

(okvirni podaci)

Program	Punjenje	Potrošnja energije*	Potrošnje vode*	Trajanje programa*
Cottons (Pamuk) 20 °C	6,5 kg	0,25 kWh	76 l	2 3/4 h
Cottons (Pamuk) 40 °C	6,5 kg	0,98 kWh	76 l	3 h
Cottons (Pamuk) 60 °C	6,5 kg	1,22 kWh	76 l	3 h
Cottons (Pamuk) 90 °C	6,5 kg	2,10 kWh	88 l	2 3/4 h
Easy-Care (Lako za njegu) 40 °C	3 kg	0,72 kWh	62 l	2 h
Mix (Miješano rublje) 40 °C	4 kg	0,59 kWh	45 l	1 1/4 h
Delicate/Silk (Fino/Svila) 30 °C	2 kg	0,21 kWh	36 l	3/4 h
Wool (Vuna) 30 °C	2 kg	0,25 kWh	35 l	3/4 h

Program	okvirni podaci o preostaloj vlazi**		
	WLT24 ... max 1200 okr/min	WLT20 ... max 1000 okr/min	WLT16 ... max 800 okr/min
Cottons (Pamuk)	58 %	68 %	80 %
Easy-Care (Lako za njegu)	40 %	40 %	40 %
Delicate/Silk (fino/svila)	30 %	30 %	30 %
Wool (vuna)	45 %	45 %	45 %
* Vrijednosti mogu odstupati od navedenih vrijednosti ovisno o tlaku vode, tvrdoći vode, ulaznoj temperaturi vode, temperaturi prostorije, vrsti rublja, njegovoj količini i zaprljanosti, korištenom sredstvu za pranje, oscilacijama napona u električnoj mreži i odabranim dodatnim funkcijama.			
** Podaci o preostaloj vlazi na temelju ograničenja broja okretaja centrifuge i maksimalnom punjenju ovim programima.			

Program	Punjenje	Godišnja potrošnja energije	Godišnja potrošnja vode
Cottons (Pamuk) 40/60 °C +  EcoPerfect* 	6,5 kg	119 kWh	8800 l
* Postavka programa za ispitivanje i oznaku energije prema direktivi 2010/30/EU s hladnom vodom (15 °C).			

Najefikasniji program za pamučne tkanine

Sljedeći su programi (standardni programi, označeni simbolom ) prikladni za čišćenje normalno uprljane pamučne tkanine i najučinkovitiji su u odnosu na kombiniranu potrošnju energije i vode.

Standardni programi za pamuk prema odredbi (EU) br. 1015/2010	Punjenje	Okvirno trajanje programa
Program Cottons (Pamuk)  + tipka  EcoPerfect* 	6,5 kg	5 1/2 h
Program Cottons (Pamuk)  + tipka  EcoPerfect* 	3,25 kg	4 1/2 h
Program Cottons (Pamuk)  + tipka  EcoPerfect* 	3,25 kg	4 1/2 h
Postavka programa za ispitivanja i oznaku energije prema smjernici 2010/30/EU s hladnom vodom (15 °C). Informacija o temperaturi programa orijentira se prema temperaturi koja se nalazi na etiketi za njegu na tkanini. Stvarna temperatura za pranje može se razlikovati od navedene temperature programa zbog uštede energije.		

WLT24440BY

9001079276 (9703)

