

Overview of programmes

Programme/Type of laundry/Instructions	Settings
Name of the programme Brief explanation of the programme and for which fabrics it is suitable.	Max. load; temperature can be selected (* = cold) Spin speed can be selected**; ---- = Rinse Hold Additional programme settings that can be selected
 Cottons: Hard-wearing textiles, heat-resistant textiles made of cotton or linen	max. 6,5 kg/4 kg*; * - 90 °C ----, 0 - 1200** rpm  Speed Eco $\equiv$  Perfect [®] , 
 Easy-Care: Fabrics made from synthetic or blended fabrics	max. 3 kg; * - 60 °C ----, 0 - 1200** rpm  Speed Eco $\equiv$  Perfect [®] , 
 Wool: Hand- or machine-washable fabrics that are made of wool or contain wool; particularly gentle washing programme to prevent shrinkage of laundry, with longer programme breaks (fabrics rest in the water)	max. 2 kg; * - 40 °C ----, 0 - 800 rpm -
Notes - Wool is of animal origin, e.g. angora, alpaca, llama, sheep. - Use a detergent that is suitable for machine-washing wool.	
 SuperQuick 15'/30': Extra-short programme of approx. 30 minutes, suitable for small amounts of lightly soiled washing	max. 3,5 kg/2 kg*; * - 40 °C ----, 0 - 1200** rpm  SpeedPerfect $\equiv$  Perfect [®]
Note: Shorter programme length (approx. 15 mins) if  SpeedPerfect $\equiv$ programme setting is selected	
 Mix: Mixed load consisting of textiles made of cotton and synthetics	max. 4 kg; * - 40 °C ----, 0 - 1200** rpm  Speed Eco $\equiv$  Perfect [®] , 
 Night wash: Especially quiet programme for washing during the night; suitable for cotton, linen, synthetic and blended fabrics	max. 4 kg; * - 40 °C ----, 0 - 1200** rpm  Speed Eco $\equiv$  Perfect [®] , 
Note: Final buzzer deactivated	
* reduced load at  SpeedPerfect $\equiv$ programme setting ** max. spin speed, depending on the model	

Programme/Type of laundry/Instructions	Settings
 Rinse: Extra rinse with spin	-;- ----, 0 - 1200** rpm 
 Spin/: Extra spin with selectable speed	-;-
 Empty: Draining of the rinsing water	0 - 1200** rpm
Note: If only draining is required, set the spin speed to - 0 -.	-
 AllergyPlus: Hard-wearing fabrics made of cotton or linen	max. 5,5 kg/3,5 kg*; * - 60 °C
Note: Particularly suited to washing items that need to be hygienically clean and especially kind to sensitive skin thanks to the longer wash cycle at a defined temperature, higher water level and longer rinse cycle.	----, 0 - 1200** rpm  Speed Eco  Perfect   
 Shirt/Blouses: Drip-dry shirts made of cotton, linen, synthetic fibres or blended fabrics	max. 2 kg; * - 60 °C
Note: Use the Delicate/Silk programme to wash shirts/blouses made of silk.	----, 0 - 800 rpm  Speed Eco  Perfect   
 Dark wash: Dark fabrics made of cotton and dark, easy-care fabrics	max. 2 kg; * - 40 °C
	----, 0 - 1200** rpm  Speed Eco  Perfect   
 Sportswear: Sportswear and leisurewear made from microfibre fabrics	max. 2 kg; * - 40 °C
Notes	----, 0 - 800 rpm  Speed Eco  Perfect   
 Down: Machine-washable fabrics filled with down, such as pillows and duvets; also suitable for items filled with synthetic fibres	max. 1 kg; * - 60 °C
Note: Wash large items separately. Use a detergent designed for delicates and follow the instructions on the items' care labels. Use detergent sparingly.	----, 0 - 1200** rpm  Speed Eco  Perfect  
 Delicate/Silk: For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarves)	max. 2 kg; * - 40 °C
Note: Use detergent intended for machine-washing delicates and/or silk.	----, 0 - 800 rpm  Speed Eco  Perfect   
* reduced load at  SpeedPerfect  programme setting	
** max. spin speed, depending on the model	

Programme/Type of laundry/Instructions	Settings
 Drum clean: Programme for cleaning and caring for the drum and the outer tub, e.g. before running the first wash cycle, if washing frequently at a low temperature (40 °C or lower) or if an odour has developed after a prolonged period of non-use.	max. 0 kg; 90 °C
	1200** rpm
	-
Notes	
■ Run the programme without laundry. ■ Use washing powder or a detergent containing bleach. To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergents designed for woollens or delicates.	
* reduced load at  SpeedPerfect  programme setting	
** max. spin speed, depending on the model	



Consumption rates

Consumption values table

(approximate values)

Programme	Load	Energy consumption*	Water consumption*	Programme duration*
Cottons 20 °C	6.5 kg	0.25 kWh	76 litres	2 3/4 h
Cottons 40 °C	6.5 kg	0.98 kWh	76 litres	3 h
Cottons 60 °C	6.5 kg	1.22 kWh	76 litres	3 h
Cottons 90 °C	6.5 kg	2.10 kWh	88 litres	2 3/4 h
Easy-Care 40 °C	3 kg	0.72 kWh	62 litres	2 h
Mix 40 °C	4 kg	0.59 kWh	45 litres	1 1/4 h
Delicate/Silk 30 °C	2 kg	0.21 kWh	36 litres	3/4 h
Wool 30 °C	2 kg	0.25 kWh	35 litres	3/4 h

Programme	Approximate information on the residual moisture**		
	WLT24 ... Max. 1200 rpm	WLT20 ... Max. 1000 rpm	WLT16 ... Max. 800 rpm
Cottons	58%	68%	80%
Easy-Care	40%	40%	40%
Delicate/Silk	30%	30%	30%
Wool	45%	45%	45%
* The actual values may deviate from the stated values depending on the following factors: water pressure and hardness, inlet temperature, room temperature, type, amount and soiling of laundry, type and amount of detergent used, fluctuation of power supply and additional functions selected.			
** Information on residual moisture based on programme-dependent spin-speed limit and maximum loads.			

Programme	Load	Annual energy consumption	Annual water consumption
Cottons 40/60 °C +  EcoPerfect* 	6.5 kg	119 kWh	8800 litres
* Programme setting for testing and energy labelling in accordance with Directive 2010/30/EU with cold water (15 °C).			

Efficiency test programmes for cotton fabrics

The following programmes (standard programmes, indicated by ) are suitable for cleaning normally soiled cotton fabrics and are the most efficient with respect to combined energy and water consumption.

Standard programmes for cottons according to (EU) Reg- ulation No. 1015/2010	Load	Approximate pro- gramme duration
Cottons programme  + button  EcoPerfect* 	6.5 kg	5 1/2 h
Cottons programme  + button  EcoPerfect* 	3.25 kg	4 1/2 h
Cottons programme  + button  EcoPerfect* 	3.25 kg	4 1/2 h
Programme setting for testing and energy labelling in accordance with Directive 2010/30/EU with cold water (15 °C). The programme temperature information is based on the temperature stated on the care label for the fabrics. The actual washing temperature may deviate from the stated programme temperature for energy-saving reasons.		

WLT24440BY

9001079284 (9611)

