

Overview of programmes

Programme/type of laundry/information	Settings
Name of the programme: Brief explanation of the programme and for which textiles it is suitable.	max. load; temperature spin speed*
	additional settings that can be selected
 Cottons: Hard-wearing textiles, heat-resistant textiles made of cotton or linen	7 kg/4** kg; - - (cold) - 90 °C - -- (Rinse Stop), 0 - 1400* rpm  Less Ironing, Water Plus/Rinse Plus
 Easy Care: Textiles made of synthetic materials or blended fabrics	4 kg; - - (cold) - 60 °C - -- (Rinse Stop), 0 - 1200* rpm  Less Ironing, Water Plus/Rinse Plus
  Wool: Hand or machine-washable wool or rich-wool textiles. Especially gentle wash programme to prevent shrinkage, longer programme pauses (textiles rest in wash liquor).	max. 2 kg; - - (cold) - 40 °C - -- (Rinse Stop), 0 - 800 rpm -
Notes	
■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep. ■ Use a detergent that is suitable for machine-washing wool.	
  Super 15'30': Extra short programme of approx. 15/30 minutes, suitable for small items of lightly soiled laundry	2/3.5 kg; - - (cold) - 40 °C - -- (Rinse Stop), 0 - 1200* rpm 
Note: When selecting the Speed setting, the programme  Super 15' is run.	
 Mix: Mixed load of cottons and synthetic fabrics	4 kg; - - (cold) - 40 °C - -- (Rinse Stop), 0 - 1400* rpm  Less Ironing, Water Plus/Rinse Plus
 Night Wash: Especially quiet programme for washing during the night; suitable for cotton, linen, synthetic and blended fabrics	4 kg; - - (cold) - 40 °C - -- (Rinse Stop), 0 - 1400* rpm  Less Ironing, Water Plus/Rinse Plus
* the maximum spin speed depends on the programme and model	
** reduced load for the Speed setting	

Programme/type of laundry/information	Settings
Name of the programme: Brief explanation of the programme and for which textiles it is suitable.	max. load; temperature spin speed*
	additional settings that can be selected
 Rinse: Extra rinse with selectable spin speed	-; - - - (Rinse Stop), 0 - 1400* rpm Less Ironing, Water Plus/Rinse Plus
 Spin/Drain: Extra spin with selectable spin speed. Only to be emptied, set Spin speed to 0.	-; - - - (Rinse Stop), 0 - 1400* rpm Less Ironing
 Power Wash: Extra short programme of approx. 60 minutes; suitable for small items of lightly soiled laundry	4 kg; - - (cold) - 60 °C - - (Rinse Stop), 0 - 1400* rpm Less Ironing, Water Plus/Rinse Plus
 Delicates/Silk: For delicate, washable textiles, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarf)	2 kg; - - (cold) - 40 °C - - (Rinse Stop), 0 - 800 rpm =   , Less Ironing, Water Plus/Rinse Plus
 Down: Machine-washable fabrics stuffed with down, such as pillows and duvets; also suitable for items stuffed with synthetic fibres	1.5 kg; - - (cold) - 60 °C - - (Rinse Stop), 0 - 1200* rpm =   , Water Plus/Rinse Plus
 Sportswear: Sportswear and leisure wear made from microfibre fabrics	2 kg; - - (cold) - 40 °C - - (Rinse Stop), 0 - 800 rpm =   , Less Ironing, Water Plus/Rinse Plus
Notes	
<ul style="list-style-type: none"> ■ Laundry must not be treated with fabric softener. ■ Before washing, clean the detergent drawer thoroughly (all compartments) to remove fabric-softener residue. 	
 Dark Wash: Dark textiles made of cotton and dark easy-care textiles.	3.5 kg; - - (cold) - 40 °C
Note: Wash textiles inside out.	- - (Rinse Stop), 0 - 1200* rpm =   , Less Ironing, Water Plus/Rinse Plus

* the maximum spin speed depends on the programme and model

** reduced load for the **Speed** setting

Programme/type of laundry/information	Settings
Name of the programme: Brief explanation of the programme and for which textiles it is suitable.	max. load; temperature
	spin speed*
	additional settings that can be selected
 Shirts: Non-iron shirts or blouses made of cotton, linen, synthetic fibres or blended fabrics	2 kg; - - (cold) - 60 °C
	- -- (Rinse Stop), 0 - 800 rpm
	=⌚⌚, Less Ironing, Water Plus/Rinse Plus
Notes	
■ Shirts/blouses are only given a short spin on the Less Ironing setting. Hang them up to dry while still dripping wet. → Self-smoothing effect	
■ Use the  Delicates/Silk programme to wash shirts/blouses made of silk/delicate fabrics.	
 Allergy +: Hard-wearing fabrics made of cotton or linen	6.5 kg; - - (cold) - 60 °C
Note: Particularly suited to washing items that need to be hygienically clean and especially kind to sensitive skin thanks to the longer wash cycle at a defined temperature, higher water level and longer spin cycle.	- -- (Rinse Stop), 0 - 1400* rpm
	=⌚⌚, Less Ironing, Water Plus/Rinse Plus
* the maximum spin speed depends on the programme and model	
** reduced load for the Speed setting	



Consumption values table

Programme	Load	Energy consumption*	Water consumption*	Programme duration*
Cottons 20 °C	7 kg	0.29 kWh	76 l	2 1/2 h
Cottons 40 °C	7 kg	1.01 kWh	76 l	3 h
Cottons 60 °C	7 kg	1.20 kWh	76 l	2 1/2 h
Cottons 90 °C	7 kg	2.25 kWh	87 l	2 1/2 h
Easy-Care 40 °C	4 kg	0.79 kWh	69 l	2 h
Mix 40 °C	4 kg	0.63 kWh	46 l	1 1/4 h
Delicates/Silk 30 °C	2 kg	0.22 kWh	38 l	3/4 h
Wool 30 °C	2 kg	0.19 kWh	44 l	3/4 h

Programme	Load	Energy consumption*	Water consumption*	Programme duration*
Cottons + ☺ EcoPerfect 60 °C**	7 kg	0.91 kWh	47 l	4 1/4 h

* Values determined acc. EN60456:2005.
 ** Observed values may deviate from the indicated values due to influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in power supply and selected additional functions.
 ** Programme setting with maximum spin speed for testing according to EN60456:2005 and energy labelling according to Directive 95/12/EG with cold water (15°C).

Notes

- This supplementary sheet is included with your operating and installation instructions. Retain all documentation for subsequent use.
- Much more important information can be found in your operating and installation instructions.

WAN24250IL

9001160246 (9511)

