























































## Overview of programmes

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
<p><b>Name of programme</b></p> <p>Short explanation of the programme or the fabric for which it is suitable.</p>	<p>Max. load;</p> <p>* Reduced load for SpeedPerfect  function</p> <p>Temperature that can be selected</p> <p>Spin speed that can be selected;</p> <p>** Max. spin speed, depending on the model</p> <p>Possible programme settings</p>
<p> <b>Cottons</b></p> <p>Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen</p> <p><b>Note:</b> The SpeedPerfect  setting is suitable as a short programme for lightly soiled laundry.</p>	<p>Max. 7 kg/4* kg</p> <p>cold - 40 - 90 °C</p> <p>--- ... 1200** rpm</p> <p> , , </p>
<p> <b>Synthetics</b></p> <p>Fabrics made from synthetic or blended fabrics</p>	<p>Max. 4 kg</p> <p>cold - 40 - 60 °C</p> <p>--- ... 1200** rpm</p> <p> , , </p>
<p> <b>Daily Wash</b></p> <p>A mixed load of fabrics made of cotton and synthetic fabrics</p>	<p>Max. 3.5 kg</p> <p>cold - 40 °C</p> <p>--- ... 1200** rpm</p> <p> , , </p>
<p> <b>Delicates/Silk</b></p> <p>For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarves)</p> <p><b>Note:</b> Use a detergent which is suitable for machine washing delicates or silk.</p>	<p>Max. 2 kg</p> <p>Cold - 40 °C</p> <p>--- ... 600... 800** rpm</p> <p> , , </p>
<p>* Reduced load for the  <b>Speed</b> setting</p> <p>** Maximum spin speed depends on the program and model</p>	

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
<p> <b>Wool</b></p> <p>Hand or machine-washable fabrics made of wool or that contain wool; particularly gentle wash programme to prevent shrinkage of laundry, with longer programme breaks (fabrics rest in the detergent solution)</p> <p><b>Notes</b></p> <ul style="list-style-type: none"> <li>■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep.</li> <li>■ Use a detergent which is suitable for machine washing wool.</li> </ul>	<p>Max. 2 kg</p> <p>Cold - 40 °C</p> <p>--- ... 800**rpm</p> <p>-</p>
<p> <b>Drum Clean</b></p> <p>Programme for cleaning and caring for the drum and the outer tub, e.g. before the 1st wash cycle, if an odour has formed after a prolonged absence</p> <p><b>Notes</b></p> <ul style="list-style-type: none"> <li>■ Run programme without laundry.</li> <li>■ Use only detergents for front-loading washing machines. Do not use additional cleaning agents.</li> </ul>	<p>-</p> <p>90 °C</p> <p>800**rpm</p> <p>-</p>
<p> <b>Rinse</b></p> <p>Extra rinse with spin</p>	<p>-</p> <p>-</p> <p>--- ... 800 ... 1200** rpm</p> <p></p>
<p> <b>Spin/Drain</b></p> <p>Extra spin with speed that can be selected</p> <p>If only the drain cycle is required, set the spin speed to ---.</p>	<p>-</p> <p>-</p> <p>--- ... 800 ... 1200** rpm</p> <p>-</p>
<p><b>Super 15/30 min</b> </p> <p>Extra-short programme of approx. 15 minutes, suitable for small items of lightly soiled laundry</p> <p><b>Note:</b> Longer programme duration (approx. 30 minutes) for deactivated SpeedPerfect  setting</p>	<p>Max. 2 kg/3.5* kg</p> <p>Cold</p> <p>--- ... 800 ... 1200** rpm</p> <p> </p>
<p><b>Refresh</b> </p> <p>Fabrics made from cotton or synthetics</p> <p>Short programme suitable for removing dust and sand from washing, e.g. after rainfall; washing warmer after the last rinse cycle, this may reduce the subsequent drying process.</p>	<p>Max. 2 kg</p> <p>30 - 40 °C</p> <p>--- ... 1200** rpm</p> <p>-</p>
<p>* Reduced load for the  <b>Speed</b> setting</p> <p>** Maximum spin speed depends on the program and model</p>	

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
<p><b>Gentle Wash</b> </p> <p>Programme suitable for saris made of washable textiles such as cotton and synthetics; Creasing is reduced.</p> <p><b>Note:</b> Wash a maximum of 2 saris per wash cycle (including blouse and petticoat). Glued adornments or embroidery may detach and are not recommended to be washed.</p>	<p>Max. 1 kg</p> <p>cold - 30 - 40 °C</p> <p>--- ... 600** rpm</p> <p>    </p>
<p><b>Kidswear</b> </p> <p>Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen</p>	<p>Max. 7 kg/4* kg</p> <p>cold - 40 °C</p> <p>--- ... 1200** rpm</p> <p>  </p>
<p><b>Allergy Plus</b> </p> <p>Hard-wearing textiles made of cotton or linen</p> <p><b>Note:</b> Especially suitable for increased hygienic demands or particularly sensitive skin on account of prolonged washing at a defined temperature, with a higher water level and longer rinsing time</p>	<p>Max. 6.5 kg/4* kg</p> <p>cold - 40 - 60 °C</p> <p>--- ... 800 ... 1200** rpm</p> <p>    </p>
<p><b>Jeans</b> </p> <p>Dark fabrics made of cotton and dark easy-care fabrics Turn laundry inside-out before washing.</p>	<p>Max. 3 kg</p> <p>cold - 40 °C</p> <p>--- ... 800 ... 1200** rpm</p> <p>    </p>
<p><b>Sportswear</b> </p> <p>For fabrics made of microfibres for sports and leisure</p> <p><b>Notes</b></p> <ul style="list-style-type: none"> <li>■ The laundry must not be treated with fabric softener.</li> <li>■ Before washing, clean the detergent drawer thoroughly (all compartments) to remove fabric softener residue.</li> </ul>	<p>Max. 2 kg</p> <p>cold - 30 - 40 °C</p> <p>--- ... 800** rpm</p> <p>    </p>
<p>* Reduced load for the  <b>Speed</b> setting</p> <p>** Maximum spin speed depends on the program and model</p>	



## Consumption rates

### Consumption values table

Programme	Load	Energy consumption*	Water*	Programme duration*
Cottons 20 °C	7 kg	0.21 kWh	68 l	2 h
Cottons 40 °C	7 kg	0.75 kWh	69 l	2 h
Cottons 60 °C	7 kg	1.26 kWh	68 l	2 1/4 h
Cottons 90 °C	7 kg	2.19 kWh	79 l	3 h
Synthetics 40 °C	4 kg	0.71 kWh	51 l	2 h
Daily Wash 40 °C	3.5 kg	0.46 kWh	44 l	1 1/4 h
Delicate/Silk 30 °C	2 kg	0.17 kWh	34 l	3/4 h
Wool 30 °C	2 kg	0.16 kWh	42 l	3/4 h

\* Observed values may deviate from the indicated values due to influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in power supply and selected additional functions.

**WAK24269IN**

**9001282098 (9612)**

