










































Overview of programmes

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
<p>Name of programme</p> <p>Short explanation of the programme or the fabric for which it is suitable.</p>	<p>Max. load;</p> <p>* Reduced load for Speed+  function</p> <p>Temperature that can be selected</p> <p>Spin speed that can be selected;</p> <p>** Max. spin speed, depending on the model</p> <p>Possible programme settings</p>
<p> Cottons</p> <p>Super Clean</p> <p>Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen</p> <p>Note: The Speed+  @setting is suitable as a short programme for lightly soiled laundry.</p>	<p>Max. 6.5 kg/4* kg</p> <p>cold - 40 - 60 °C</p> <p>1000**rpm</p> <p>  </p>
<p> Synthetics</p> <p>Fabrics made from synthetic or blended fabrics</p>	<p>Max. 4 kg</p> <p>30 °C</p> <p>1000** rpm</p> <p>  </p>
<p> Daily Wash</p> <p>A mixed load of fabrics made of cotton and synthetic fabrics</p>	<p>Max. 3.5 kg</p> <p>30 °C</p> <p>1000** rpm</p> <p>  </p>
<p> Delicate/Silk</p> <p>For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarves)</p> <p>Note: Use a detergent which is suitable for machine washing delicates or silk.</p>	<p>Max. 2 kg</p> <p>30 °C</p> <p>- - - ... 600 ... 800** rpm</p> <p>  </p>
<p>** maximum spin speed depends on the program and model</p> <p>* reduced load for the  Speed setting</p>	

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
 Wool Hand or machine-washable fabrics made of wool or that contain wool; particularly gentle wash programme to prevent shrinkage of laundry, with longer programme breaks (fabrics rest in the detergent solution)	Max. 2 kg cold - - - ... 800 rpm** -
Notes <ul style="list-style-type: none"> ■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep. ■ Use a detergent which is suitable for machine washing wool. 	
 Spin/Drain Extra spin with speed that can be selected If only the drain cycle is required, set the spin speed to - - -.	- - - - - ... 800 ... 1000** rpm -
Super 15/30 min  Extra-short programme of approx. 15 minutes, suitable for small items of lightly soiled laundry Note: Longer programme duration (approx. 30 minutes) for deactivated SpeedPerfect  setting	Max. 2 kg/3.5 kg - - - - ... 800 ... 1000** rpm 
Refresh  Fabrics made from cotton or synthetics Short programme suitable for removing dust and sand from washing, e.g. after rainfall; washing warmer after the last rinse cycle, this may reduce the subsequent drying process.	Max. 2 kg 40 °C 1000** rpm -
Gentle Wash  Programme suitable for saris made of washable textiles such as cotton and synthetics; Creasing is reduced. Note: Wash a maximum of 2 saris per wash cycle (including blouse and petticoat). Glued adornments or embroidery may detach and are not recommended to be washed.	Max. 1 kg 30 °C - - - ... 600** rpm  , 
AllergyPlus  Hard-wearing textiles made of cotton or linen Note: Especially suitable for increased hygienic demands or particularly sensitive skin on account of prolonged washing at a defined temperature, with a higher water level and longer rinsing time	Max. 6.5 kg/4* kg 60 °C - - - ... 800 ... 1000** rpm  , 
** maximum spin speed depends on the program and model * reduced load for the  Speed setting	

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
Kidswear  Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen	Max. 6.5 kg/4* kg 40 °C - - - ... 1000** rpm ≡   , 
Drum Clean  Programme for cleaning and caring for the drum and the outer tub, e.g. before the 1st wash cycle, if an odour has formed after a prolonged absence or if washing frequently at a low washing temperature (40 °C and lower)	- 90 °C 800** rpm -
Notes <ul style="list-style-type: none"> ■ Run programme without laundry. ■ Use only detergents for front-loading washing machines. Do not use additional cleaning agents. 	- - - - - ... 800 ... 1000** rpm 
Rinse  Extra rinse with spin	- - - - - ... 800 ... 1000** rpm 
** maximum spin speed depends on the program and model * reduced load for the ≡  Speed setting	



Consumption rates

Consumption values table

Programme	Load	Energy consumption*	Water*	Programme duration*
Cottons cold	6.5 kg	0.21 kWh	68 l	2 h
Cottons 40 °C	6.5 kg	0.75 kWh	69 l	2 h
Super Clean 60 °C	6.5 kg	0.99 kWh	47 l	3 1/4 h
Synthetics 30 °C	4 kg	0.71 kWh	51 l	2 h
Daily Wash 30 °C	3.5 kg	0.46 kWh	44 l	1 1/4 h
Delicate/Silk 30 °C	2 kg	0.17 kWh	34 l	3/4 h
Wool cold	2 kg	0.16 kWh	42 l	3/4 h

* Observed values may deviate from the indicated values due to influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in power supply and selected additional functions.

WAK20166IN

9001287644 (9701)

