


Overview of programmes

Program/type of laundry/information	Settings
Name of the program : Brief explanation of the program and for which textiles it is suitable.	max. load, temperature (☼ = cold) Spin speed* additional settings that can be selected
Cottons  : Hard-wearing textiles, heat-resistant textiles made of cotton or linen Notes <ul style="list-style-type: none"> ■ For the Eco setting, the wash temperature is lower than the selected temperature. If you would like to set a particular wash temperature, use the program without the Eco setting or, if necessary, set a higher temperature. ■ The Speed setting is suitable as a short program for lightly soiled laundry. 	9 kg/5** kg; ☼ - 90 °C ----, 0 - 1400* rpm Speed Eco ≡   , Reduced Ironing, Aqua Plus
Easy-Care : Textiles made of synthetic materials or blended fabrics	4 kg; ☼ - 60 °C ----, 0 - 1200 rpm Speed Eco ≡   Reduced Ironing, Aqua Plus
Wool : Hand or machine-washable wool or rich-wool textiles. Especially gentle wash program to prevent shrinkage, longer program pauses (textiles rest in wash liquor). Notes <ul style="list-style-type: none"> ■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep. ■ Use a detergent that is suitable for machine-washing wool. 	max. 2 kg; ☼ - 40 °C ----, 0 - 800 rpm -
SuperQuick 15'/30' : Extra short program of approx. 15/30 minutes, suitable for small items of lightly soiled laundry Note : When selecting the Speed setting, the program SuperQuick 15' is run.	2/3.5 kg; ☼ - 40 °C 0 - 1200 rpm Speed ≡ 
Mixed Load : Mixed load of cottons and synthetic fabrics	4 kg; ☼ - 40 °C ----, 0 - 1400* rpm Speed Eco ≡   , Reduced Ironing, Aqua Plus
* max. The maximum spin speed depends on the program and model ** reduced load for the Speed setting	

Program/type of laundry/information	Settings
<p>Night Wash: Especially quiet program for washing during the night; suitable for cotton, linen, synthetic and blended fabrics</p> <p>Note: Final buzzer deactivated.</p>	<p>4 kg; - 40 °C</p> <p>---, 0 - 1200 rpm</p> <p>Speed Eco , Reduced Ironing, Aqua Plus</p>
<p>Rinse: Extra rinse with selectable spin speed</p>	<p>-; -</p> <p>---, 0 - 1400** rpm</p> <p>Reduced Ironing</p>
<p>Spin/Drain: Extra spin with selectable spin speed. Only to be emptied, set spin speed to 0.</p> <p>Note: The display of the Ready-in time is only updated once the program is restarted.</p>	<p>-; -</p> <p>---, 0 - 1400** rpm</p> <p>Reduced Ironing</p>
<p>Drum Clean: Program for cleaning and caring for the drum and the outer tub, e.g. before running the first wash cycle, if washing frequently at a low temperature (40 °C or lower) or if an odour has developed after a prolonged period of non-use.</p> <p>Notes</p> <ul style="list-style-type: none"> ■ Run the drum-care program without any laundry. ■ Use washing powder or a detergent containing bleach. To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergents designed for woollens or delicates. 	<p>0 kg; 90 °C</p> <p>1200 rpm</p> <p>-</p>
<p>Delicates/Silk: For delicate, washable textiles, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarf)</p> <p>Note: Use a detergent suitable for machine-washing delicates or silk.</p>	<p>2 kg; - 40 °C</p> <p>---, 0 - 800 rpm</p> <p>Speed Eco , Reduced Ironing, Aqua Plus</p>
<p>Down: Machine-washable items stuffed with synthetic fibres, such as pillows, quilts and bedspreads; also suitable for items stuffed with down</p> <p>Note: Wash large items separately. Use a detergent designed for delicates and follow the instructions on the item's care label. Use detergent sparingly.</p>	<p>2 kg; - 60 °C</p> <p>---, 0 - 1200 rpm</p> <p>Speed Eco Aqua Plus</p>
<p>Sportswear: Sportswear and leisure wear made from microfibre fabrics</p> <p>Notes</p> <ul style="list-style-type: none"> ■ Laundry must not be treated with fabric softener. ■ Before washing, clean the detergent drawer thoroughly (all compartments) to remove fabric-softener residue. 	<p>2 kg; - 40 °C</p> <p>---, 0 - 800 rpm</p> <p>Speed Eco , Reduced Ironing, Aqua Plus</p>
<p>* max. The maximum spin speed depends on the program and model</p> <p>** reduced load for the Speed setting</p>	

Program/type of laundry/information	Settings
Dark Wash: Dark textiles made of cotton and dark easy-care textiles. Wash textiles inside out.	3.5 kg; - 40 °C ---, 0 - 1200 rpm Speed Eco , Reduced Ironing, Aqua Plus
Shirts: Non-iron shirts or blouses made of cotton, linen, synthetic fibres or blended fabrics Notes <ul style="list-style-type: none"> ■ Shirts/blouses are only given a short spin on the Easy-Iron (depend on model) setting. Hang them up to dry while still dripping wet. -> Self-smoothing effect ■ Use the Delicate/Silk program to wash shirts/blouses made of silk/delicate fabrics. 	2 kg; - 60 °C ---, 0 - 800 rpm Speed Eco Reduced Ironing, Aqua Plus
Allergy+: Hard-wearing fabrics made of cotton or linen Note: Particularly suited to washing items that need to be hygienically clean and especially kind to sensitive skin thanks to the longer wash cycle at a defined temperature, higher water level and longer spin cycle.	7.5 kg/5** kg; - 60 °C ---, 0 - 1400* rpm Speed Eco , Reduced Ironing, Aqua Plus
* max. The maximum spin speed depends on the program and model ** reduced load for the Speed setting	



Consumption values table

Energy and water consumption, program duration and residual moisture for the main wash program

(approximate values)

Program	Load	Energy consumption*	Water consumption*	Program duration*
Cottons 20 °C	9 kg	0,25 kWh	90 l	2 ¾ h
Cottons 40 °C	9 kg	1,10 kWh	90 l	3 h
Cottons Eco** <60°C	9 kg	0,92 kWh	57 l	4 ¾ h
Cottons Eco** <60°C	4,5 kg	0,60 kWh	46 l	4 ½ h
Cottons Eco** <40°C	4,5 kg	0,42 kWh	46 l	4 ½ h
Cottons 60 °C	9 kg	1,16 kWh	90 l	2 ¾ h
Cottons 90 °C	9 kg	2,14, kWh	100 l	2 ¾ h
Easy-Care 40 °C	4 kg	0,71 kWh	64 l	2 h
Mix 40 °C	4 kg	0,60 kWh	45 l	1 ¼ h
Delicates/Silk 30 °C	2 kg	0,19 kWh	37 l	¾ h
Wool 30 °C	2 kg	0,19 kWh	41 l	¾ h

Program	Approximate information on the residual moisture***		
	WAT28... max. 1400 rpm	WAT24... max. 1200 rpm	WAT20... max. 1000 rpm
Cottons	48 %	53 %	62 %
Easy-Care	40 %	40 %	40 %
Delicates/Silk	30 %	30 %	30 %
Wool	45 %	45 %	45 %

* The values may deviate from the indicated values depending on water pressure, water hardness, water inlet temperature, ambient temperature, type of laundry, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions.

** Program setting for testing and energy labelling in accordance with Directive 2010/30/EU with cold water (15 °C). The specification of the program temperature is based on the temperature stated on the care label in the textiles. The actual washing temperature may deviate from the stated program temperature for energy-saving reasons

*** Information on residual moisture based on program-dependent spin-speed limit and maximum loads.

WAT2840SGB

9001352479 (9711)

