

Overview of programmes

Programme/type of laundry/information	Settings
Programme name	Max. load
Brief explanation of the programme and the items for which it is suitable.	Temperature; spin speed**
	Additional programme settings
	Automatic dosing (i-Dos) (De)selectable ✓, not selectable -
 Cottons	Max. 9.0 kg/5.0* kg
Hard-wearing items and heat-resistant items made of cotton or linen	* - 90 °C; ⌀ - 1400** rpm
Note: Suitable as a short programme for lightly soiled laundry when Speed setting selected.	Eco, Speed,  ,  ,  , 
	○ ✓, * ✓
Cottons Eco 	Max. 9.0 kg
Hard-wearing items and heat-resistant items made of cotton or linen;	* - 90 °C; ⌀ - 1400** rpm
energy-optimised washing that works by reducing the temperature while achieving a comparable washing result to the Cottons programme.	 ,  ,  , 
Note: The washing temperature is lower than the selected temperature. If you want to achieve a higher water temperature, use the Cottons programme with a higher temperature as required.	○ ✓, * ✓
 Synthetics	Max. 4.0 kg
Items made of synthetic or blended fabrics	* - 60 °C; ⌀ - 1200** rpm
	Eco, Speed,  ,  ,  , 
	○ ✓, * ✓
 Delicates/Silk	Max. 2.0 kg
For delicate, washable items, e.g. made of silk, satin, synthetic or blended fabrics (e.g. silk blouses, silk scarves)	* - 40 °C; ⌀ - 800 rpm
Note: Use a detergent that is suitable for machine-washing delicate fabrics or silk.	Eco, Speed,  ,  ,  , 
	○ ✓, * ✓
* Reduced load with the Speed setting	
** Max. spin speed depends on the model	

Programme/type of laundry/information	Settings
 Wool Hand- or machine-washable items that are made of wool or contain wool; particularly gentle wash programme to prevent laundry from shrinking, with longer pauses in the programme (during which the items rest in the water)	Max. 2.0 kg ❄ - 40 °C; ⌚ - 800 rpm  ⦿ -, ⦿ ✓
Notes ■ Wool is of animal origin, e.g. angora, alpaca, llama, sheep. ■ Use a detergent that is suitable for machine-washing wool.	
 Quick Wash Mixed load of cottons and synthetic fabrics	Max. 4.0 kg ❄ - 40 °C; ⌚ - 1400** rpm Eco, Speed,  ,  ,  ,  ⦿ ✓, ⦿ ✓
 further programs Allows additional programmes to be selected via the Home Connect app (see the user and set-up instructions for more information)	Depending on the selected programme
 Automatic Intensive More intensive treatment of the laundry; the degree of soiling and the type of fabric are automatically detected and the washing sequence and intelligent dosing are adjusted accordingly.	Max. 6.0 kg ❄ - 60 °C; ⌚ - 1400** rpm  ⦿ ✓, ⦿ ✓
 Allergy Plus Hard-wearing items made of cotton or linen Note: Particularly suitable for strict hygiene requirements or particularly sensitive skin thanks to the extended wash cycle at a defined temperature, higher water level and extended rinse cycle.	Max. 6.5 kg ❄ - 60 °C; ⌚ - 1400** rpm Eco, Speed,  ,  ,  ,  ⦿ ✓, ⦿ ✓
 Curtains 3.5 kg heavy curtains or 25-30 m² lightweight drapes Notes ■ Shorter rinse and final spin cycles, ■ Use a detergent that is suitable for machine-washing curtains. ■ The  setting is activated by default. If you do not require a pre-wash cycle, deactivate the setting.	Max. 3.5 kg ❄ - 40 °C; ⌚ - 800 rpm Eco, Speed,  ,  ,  ⦿ ✓, ⦿ ✓
* Reduced load with the Speed setting ** Max. spin speed depends on the model	

Programme/type of laundry/information	Settings
Duvet Machine-washable items stuffed with synthetic fibres, such as pillows, quilts and bedspreads; also suitable for items stuffed with down Note: Wash large items separately. Use a detergent intended for delicates and follow the instructions on the item's care label. Use detergent sparingly.	Max. 2.5 kg (down max. 2.0 kg) ❄ - 60 °C; ⌚ - 1200** rpm Eco, Speed, 🧺, 🪣 ⬇ -, ⚙ -
Super Quick 15/30 min Extra-short programme lasting approx. 15/30 minutes, suitable for small items of lightly soiled laundry Note: The Super Quick 15' programme is run when the Speed setting is selected.	Max. 2.0/3.5 kg ❄ - 40 °C; ⌚ - 1200** rpm Speed, 🪣 ⬇ ✓, ⚙ ✓
Drum clean 🧼 Programme for cleaning and caring for the drum and the outer tub, e.g. before running the first wash cycle, if washing frequently at a low temperature (40 °C or lower) or if an odour has developed after an extended period of non-use. The 🧼 indicator (drum care reminder function) will flash if you have not used any programmes at a temperature of 60 °C or higher for an extended period.	0.0 kg 90 °C; 1200** rpm - ⬇ -, ⚙ -
Notes ■ Run the programme without laundry. ■ Use standard washing powder or a detergent that contains bleach. To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergents intended for woollens or delicates.	
Rinse / Spin / Drain 🧺/⌚/🪣 Combined extra programme for rinsing and spinning the laundry, and draining the rinsing water Note: The 🧺 setting is activated by default for this programme.	- -; ⌚ - 1400** rpm 🧺, 🧺, 🪣 ⬇ -, ⚙ ✓
If you only want to spin the laundry: Deactivate the 🧺 setting and, if required, adjust the spin speed. If you only want to drain water: Deactivate the 🧺 setting and select the ⌚ setting.	
* Reduced load with the Speed setting ** Max. spin speed depends on the model	



Consumption values table

Energy and water consumption, programme duration and residual moisture for the main washing programme (approximate information)

Programme	Load size	Energy consumption*	Water consumption*	Programme duration*
Cottons 20 °C	9 kg	0,25 kWh	90 l	2 ¾ h
Cottons 40 °C	9 kg	1,10 kWh	90 l	3 h
Cottons Eco** <60°C	9 kg	0,92 kWh	57 l	4 ¾ h
Cottons Eco** <60°C	4,5 kg	0,60 kWh	46 l	4 ¾ h
Cottons Eco** <40°C	4,5 kg	0,42 kWh	46 l	4 ¾ h
Cottons 60 °C	9 kg	1,16 kWh	90 l	2 ¾ h
Cottons 90 °C	9 kg	2,14 kWh	100 l	2 ¾ h
Synthetics 40 °C	4 kg	0,71 kWh	64 l	2 h
Quick Wash 40 °C	4 kg	0,60 kWh	45 l	1 ¼ h
Delicates / Silk 30 °C	2 kg	0,19 kWh	37 l	¾ h
Wool 30 °C	2 kg	0,19 kWh	41 l	¾ h

Programme	Approximate information on the residual moisture***		
	WAT28 ... Max. 1400 rpm	WAT24 ... Max. 1200 rpm	WAT20 ... Max. 1000 rpm
Cottons	48 %	53 %	62 %
Synthetics	40 %	40 %	40 %
Delicates / Silk	30 %	30 %	30 %
Wool	45 %	45 %	45 %

* The values may deviate from the indicated values depending on water pressure, water hardness, water inlet temperature, ambient temperature, type of laundry, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions.

** Programme setting for testing and energy labelling in accordance with directive 2010/30/EU with cold water (15 °C). The specification of the programme temperature is based on the temperature stated on the care label in the textiles. The actual washing temperature may deviate from the stated programme temperature for energy-saving reasons; the washing performance corresponds to the selected temperature.

*** Information on residual moisture based on program-dependent spin-speed limit and maximum loads. The programme used for the evaluation of the captioned model under the SG Mandatory Water Efficiency Labelling Scheme (MWELS) is Cotton 60 °C.

WAT286H9SG

9001360143 (9802)

