














































Overview of programmes

Program/type of laundry/information	Settings
<p>Name of the program: Brief explanation of the program and for which textiles it is suitable.</p>	<p>max. load; temperature (* = cold)</p> <p>spin speed*</p> <p>programme additional settings that can be selected</p> <p>Softener</p>
<p> Cottons Hard-wearing textiles, heat-resistant textiles made of cotton or linen.</p>	<p>6.2 kg/4.0** kg; * - 90 °C</p> <p>---, 400 - 1200 rpm</p> <p> Speed,  Eco,  Soak,  Rinse Plus</p> <p>Optional</p>
<p> Sensitive Program special designed for allergic people and advanced hygiene, suitable for hard-wearing textiles made of cotton or linen.</p>	<p>5.5 kg/3.5** kg; * - 60 °C</p> <p>---, 400 - 1200 rpm</p> <p> Speed,  Eco,  Soak,  Rinse Plus</p> <p>Optional</p>
<p> Synthetics Textiles made of synthetic materials or blended fabrics.</p>	<p>3.0 kg; * - 60 °C</p> <p>---, 0 - 1200 rpm</p> <p> Speed,  Eco,  Soak,  Rinse Plus</p> <p>Optional</p>
<p> Mix Load Mixed load of cottons and synthetic fabrics.</p>	<p>4.0 kg; * - 40 °C</p> <p>---, 0 - 1200 rpm</p> <p> Speed,  Eco,  Soak,  Rinse Plus</p> <p>Optional</p>
<p> Delicates/Silk For delicate, washable textiles, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarf).</p> <p>Note: Use a detergent suitable for appliance-washing delicates or silk.</p>	<p>2.0 kg; * - 40 °C</p> <p>---, 0 - 800 rpm</p> <p> Speed,  Eco,  Soak,  Rinse Plus</p> <p>Optional</p>
<p>* maximum spin speed depends on the programme and model</p> <p>** reduced load for the  Speed setting</p>	

Program/type of laundry/information	Settings
Wool  <p>Hand or appliance-washable wool or rich-wool textiles. Especially gentle wash program to prevent shrinkage, longer program pauses (textiles rest in wash liquor).</p> <p>Notes</p> <ul style="list-style-type: none"> Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep. Use a detergent that is suitable for appliance-washing wool. 	2.0 kg; * - 40 °C ----, 0 - 800 rpm - Optional
Spin  <p>Extra spin with selectable spin speed. Only to be emptied, set spin speed to 0.</p>	- 0 - 1200 rpm - Not possible
Rinse  <p>Extra rinse with selectable spin speed.</p>	- ----, 0 - 1200 rpm  Rinse Plus Optional
Drum Clean  <p>Special program for drum hygiene or fluff removal. 90°C = antibacterial program, use no detergent. 40°C = antibacterial program, special drum cleaning detergent can be used. * (cold) = fluff rinsing program, to remove fluff accumulated in the tub.</p> <p>Note: Run programme without laundry.</p>	0.0 kg; *, 40 °C, 90 °C 1200 rpm - Not possible
Allergy Plus  <p>Washing program together with disinfectant, for cotton and synthetic fibres.</p>	4.0 kg; * - 40 °C ----, 0 - 1200 rpm  Speed,  Eco,  Soak,  Rinse Plus Optional
Soft Toys  <p>For appliance washable plush toy (details pls. refer to washing indication label on the item). If there are some small parts made of paper in the toys, they are not suitable to be washed.</p>	1.5 kg; * - 40 °C ----, 0 - 1200 rpm  Speed,  Eco,  Soak,  Rinse Plus Optional
* maximum spin speed depends on the programme and model ** reduced load for the  Speed setting	

Program/type of laundry/information	Settings
Jeans  Dark textiles made of cotton and dark easy-care textiles. Wash textiles inside out.	2.0 kg; * - 40 °C ----, 0 - 1200 rpm ≡⏻ Speed, Ⓞ Eco, 🪥 Soak, 🏰 Rinse Plus Optional
Bedsheets  Machine-washable textiles filled with down (e.g. jackets, pillows, blankets)	2.0kg; * - 60 °C ----, 0 - 1200 rpm ≡⏻ Speed, Ⓞ Eco, 🏰 Rinse Plus Not possible
Sportswear  Washing followed by water proofing of weatherproof and outdoor clothing with membrane coating and water-resistant textiles	1.0 kg; * - 40 °C 0 - 800 rpm ≡⏻ Speed, Ⓞ Eco, 🏰 Rinse Plus Not possible
Super 45/30/15 min ⏱ Super 15 min programme, for less soiling and low load capacity, e.g., daily changing laundry or new laundry. Super 30 min programme, for less soiling cotton or linen laundry. Super 45 min programme, for less soiling cotton or linen laundry. Note: The ≡⏻ Speed setting is suitable as a short program for lightly soiled laundry.	3.5 kg/2.0** kg; * - 40 °C ----, 0 - 1200 rpm ≡⏻ Speed, Ⓞ Eco Optional
* maximum spin speed depends on the programme and model ** reduced load for the ≡⏻ Speed setting	

en Supplementary sheet for the installation and operating instructions

WLK24268IN

9001370264 (9802)

