

Overview of programmes

Programme/type of laundry/information Name of the programme: Brief explanation of the programme and for which textiles it is suitable.	Settings
	max. load; temperature
	spin speed*
additional settings that can be selected	
Cotone (Cotton): Hard-wearing textiles, heat-resistant textiles made of cotton or linen Note: The  Speed setting is suitable as a short programme for lightly soiled laundry.	8 kg/5** kg; * (cold) - 90 °C - -- (Rinse Stop), 0 - 1400* rpm   , Extra acqua e risciacquo (Water Plus/Rinse Plus), Prelavaggio (Prewash)
 Cotone (Cotton) Eco: Hard-wearing fabrics, heat-resistant textiles made of cotton or linen Energy-optimised washing by reducing the temperature while achieving a comparable washing result for the Cotone (Cotton) programme. Note: The washing temperature is lower than the selected temperature. If you want to achieve a higher water temperature, use the Cotone (Cotton) programme with a higher temperature as required.	8 kg; * (cold) - 90 °C - -- (Rinse Stop), 0 - 1400* rpm Extra acqua e risciacquo (Water Plus/Rinse Plus), Prelavaggio (Prewash)
Sintetici (Easy-Care): Textiles made of synthetic materials or blended fabrics	4 kg; * (cold) - 60 °C - -- (Rinse Stop), 0 - 1200* rpm   , Extra acqua e risciacquo (Water Plus/Rinse Plus), Prelavaggio (Prewash)
 Lana (Wool): Hand or machine-washable wool or rich-wool textiles. Especially gentle wash programme to prevent shrinkage, longer programme pauses (textiles rest in wash liquor). Notes ■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep. ■ Use a detergent that is suitable for machine-washing wool.	2 kg; * (cold) - 40 °C - -- (Rinse Stop), 0 - 800 rpm -
Rapido (Super) 15/30 min.: Extra short programme of approx. 15/30 minutes, suitable for small items of lightly soiled laundry Note: When selecting the  Speed setting, the programme Rapido (Super) 15 min. is run.	2/3.5 kg; * (cold) - 40 °C - -- (Rinse Stop), 0 - 1200* rpm 
Mix: Mixed load of cottons and synthetic fabrics	4 kg; * (cold) - 40 °C - -- (Rinse Stop), 0 - 1400* rpm   , Extra acqua e risciacquo (Water Plus/Rinse Plus), Prelavaggio (Prewash)
* the maximum spin speed depends on the programme and model ** reduced load for the Speed setting *** depending on the model	

Programme/type of laundry/information	Settings
Name of the programme: Brief explanation of the programme and for which textiles it is suitable.	max. load; temperature
	spin speed*
	additional settings that can be selected
Night Wash: Especially quiet programme for washing during the night; suitable for cotton, linen, synthetic and blended fabrics Note: Final buzzer deactivated.	4 kg; ❄ (cold) - 40 °C - -- (Rinse Stop), 0 - 1400* rpm ≡🌀🌀, Extra acqua e risciacquo (Water Plus/Rinse Plus), Prelavaggio (Prewash)
Risciacquo/Centrifuga/Scarico acqua (Rinse/Spin/Drain): Combined extra programme for rinsing and spinning the laundry, and draining the rinsing water Notes ■ The Extra acqua e risciacquo (Water Plus/Rinse Plus) setting is preset by default. ■ Only to be rinsed, set the Spin speed to 0. ■ Only to be spun, deactivate Extra acqua e risciacquo (Water Plus/Rinse Plus) and, if required, adjust the spin speed. ■ Only to be emptied, set the Spin speed to 0 and deactivate Extra acqua e risciacquo (Water Plus/Rinse Plus).	-; - - -- (Rinse Stop), 0 - 1400* rpm Extra acqua e risciacquo (Water Plus/Rinse Plus)
Pulizia cestello (Drum Care): Programme for cleaning and caring for the drum and the outer tub, e.g. before running the first wash cycle, if washing frequently at a low temperature (40 °C or lower) or if an odour has developed after a prolonged period of non-use. The Pulizia cestello (Drum Clean) indicator lamp 🌀 flashes when you have not used a programme of 60 °C or higher for a long time. Notes ■ Run the drum-care programme without any laundry. ■ Use washing powder or a detergent containing bleach. To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergents designed for woollens or delicates.	0 kg; 90 °C 1200* rpm -
Delicati/Seta (Delicate/Silk): For delicate, washable textiles, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarf) Note: Use a detergent suitable for machine-washing delicates or silk.	2 kg; ❄ (cold) - 40 °C - -- (Rinse Stop), 0 - 800 rpm ≡🌀🌀, Extra acqua e risciacquo (Water Plus/Rinse Plus), Prelavaggio (Prewash)
* the maximum spin speed depends on the programme and model ** reduced load for the Speed setting *** depending on the model	

Programme/type of laundry/information Name of the programme: Brief explanation of the programme and for which textiles it is suitable.	Settings max. load; temperature spin speed* additional settings that can be selected
Trapunte (Quilts): Machine-washable items stuffed with synthetic fibres, such as pillows, quilts and bedspreads; also suitable for items stuffed with down Note: Wash large items separately. Use a detergent designed for delicates and follow the instructions on the item's care label. Use detergent sparingly. Laundry must not be treated with fabric softener.	2 kg (Down 1.5 kg); * (cold) - 60 °C - -- (Rinse Stop), 0 - 1200* rpm ≡   , Extra acqua e risciacquo (Water Plus/Rinse Plus)
Sport/Fitness: Sportswear and leisure wear made from microfibre fabrics Notes ■ Laundry must not be treated with fabric softener. ■ Before washing, clean the detergent drawer thoroughly (all compartments) to remove fabric-softener residue.	2 kg; * (cold) - 40 °C - -- (Rinse Stop), 0 - 800 rpm ≡   , Extra acqua e risciacquo (Water Plus/Rinse Plus), Prelavaggio (Prewash)
Jeans: Dark textiles made of cotton and dark easy-care textiles. Note: Wash textiles inside out.	3.5 kg; * (cold) - 40 °C - -- (Rinse Stop), 0 - 1200* rpm ≡   , Extra acqua e risciacquo (Water Plus/Rinse Plus), Prelavaggio (Prewash)
Camicie (Shirts/Business): Non-iron shirts or blouses made of cotton, linen, synthetic fibres or blended fabrics Notes ■ Shirts/blouses are only given a short spin on the Stirofacile (Less Ironing)*** setting. Hang them up to dry while still dripping wet. → Self-smoothing effect ■ Use the Delicati/Seta (Delicates/Silk) programme to wash shirts/blouses made of silk/delicate fabrics.	2 kg; * (cold) - 60 °C - -- (Rinse Stop), 0 - 800 rpm ≡   , Extra acqua e risciacquo (Water Plus/Rinse Plus), Prelavaggio (Prewash)
AllergyPlus: Hard-wearing fabrics made of cotton or linen Note: Particularly suited to washing items that need to be hygienically clean and especially kind to sensitive skin thanks to the longer wash cycle at a defined temperature, higher water level and longer spin cycle.	6.5 kg; * (cold) - 60 °C - -- (Rinse Stop), 0 - 1400* rpm ≡   , Extra acqua e risciacquo (Water Plus/Rinse Plus), Prelavaggio (Prewash)
* the maximum spin speed depends on the programme and model ** reduced load for the Speed setting *** depending on the model	



Consumption values

(approximate values)

Programme	Load	Energy consumption*	Water consumption*	Programme duration*	Approximate residual moisture values*/***
	in kg	in kWh	in l	in hours	in %
Cotton 20 °C	8	0,29	78	2 ½	58
Cotton 40 °C	8	1,01	78	3	58
Cotton 60 °C	8	1,20	78	2 ½	58
 Cotton Eco +  **	8	0,94	55	3 ½	53
 Cotton Eco +  **	4	0,78	42	3 ½	53
 Cotton Eco +  **	4	0,56	42	3 ½	53
Cotton 90 °C	8	2,25	89	2 ½	58
Easy-Care 40 °C	4	0,79	69	2	40
Mix 40 °C	4	0,63	46	1 ¼	60
Delicates/Silk 30 °C	2	0,22	38	¾	30
Wool 30 °C	2	0,19	44	¾	45

Values in accordance with the applicable version of EN60456

* The observed values may deviate from the indicated values depending on water pressure, water hardness, water inlet temperature, ambient temperature, type, amount and soiling of laundry, the detergent used, fluctuations in the mains voltage and which additional functions are selected.

** Programme setting at maximum speed for testing and energy labelling in accordance with Directive 2010/30/EU with cold water (15 °C).

These programmes are suitable for cleaning normally soiled cotton items and are the most efficient in terms of combined energy and water consumption.

The stated programme temperature is based on the temperature indicated on the care label for the laundry. The actual washing temperature may differ from the stated programme temperature for energy-saving reasons; the washing performance meets legal requirements.

*** The stated residual moisture is based on the maximum spin speed and load of each individual programme.

Notes

- This supplementary sheet is included with your operating and installation instructions. Retain all documentation for subsequent use.
- Lots of other important information can be found in your operating and installation instructions.

WAN24268II

9001451204 (9904)

