



Pregled programa

Program/vrsta rublja/napomene	Postavke
Naziv programa :Kratko pojašnjenje programa, odnosno za koju vrstu tkanine je primjeren.	maks. utovar; temperatura (☼ = hladno) Broj okretaja centrifuge* dodatne Postavke programa
👤 Cottons (Pamuk): Otporne tkanine, pamučne ili lanene tkanine za iskuhavanje Napomene - Kod postavke Eco temperatura pranja je niža od odabrane temperature. Kod posebne želje za postizanjem temperature sapunice koristite program bez postavki Eco po potrebi s višom temperaturom. - Kod postavke Speed primjereno kao kratki program za blago zaprljano rublje.	9 kg/5** kg; ☼ - 90 °C ----, 0 - 1200* okr/min Speed Eco = ☹ ☹ ☹ ☹ ☹ predpranje, ⬇ voda+ 🏠
👤 Easy-Care (Lako za njegu): tekstil izradjen od sintetike ili miješanih materijala	4 kg; ☼ - 60 °C ----, 0 - 1200 okr/min Speed Eco = ☹ ☹ ☹ ☹ ☹ predpranje, ⬇ voda+ 🏠
👤 Wool (Vuna) tkanine za ručno ili strojno pranje od vune ili s dijelom vune u sastavu; izričito nježan program pranja kako bi se izbjeglo skupljanje rublja, dulje programske stanke (tkanine miruju u lužini) Napomene - Vuna je životinjskog podrijetla, npr. angora, alpaka, lama, ovca. - Koristite deterdžent za strojno pranje primjeren za vunu.	maks. 2 kg; ☼ - 40 °C ----, 0 - 800 okr/min -
👤 SuperQuick 15'/30' : ekstra kratki program oko 15/30 minuta primjeren za blago zaprljanu malu količinu odjeće Napomena: Kod postava Speed se provodi program SuperQuick 15' .	2/3,5 kg; ☼ - 40 °C 400 - 1200 okr/min Speed = ☹
👤 Mix : miješani utovar koji se sastoji od pamuka i sintetike	4 kg; ☼ - 40 °C ----, 0 - 1200* okr/min Speed Eco = ☹ ☹ ☹ ☹ ☹ predpranje, ⬇ voda+ 🏠
* maks. broj okretaja centrifuge ovisno o programu i modelu ** smanjeno punjenje kod postavke Speed	

Program/vrsta rublja/napomene	Postavke
 Zavjese : (Zavjese) 3,5 kg teških zavjesa ili 25 – 30 m ² lakih zastora Napomene ■ smanjenje ispiranja i završno centrifugiranje, ■ Za pranje u perilici rublja koristite deterdžent za pranje zavjesa. ■ Tvornički je tipka Vorwäsche unaprijed podešena. Kada ne želite predpranje, deaktivirajte tipku.	3,5 kg;  - 40 °C ---, 0 - 800 okr/min Speed Eco =    voda+ 
 Rinse (Ispiranje): ekstra ispiranje s biranjem broja okretaja centrifuge	-; - ---, 0 - 1200** okr/min -
 Spin/  Empty : (Zavrtiti / Prazan) Ekstra centrifugiranje s biranjem broja okretaja centrifuge. Samo treba ispumpati, broj okretaja centrifuge postavite na 0. Napomena: Prikaz Gotovo u vremenu tek sen ažurira nakon pokretanja programa.	-; - ---, 0 - 1200** okr/min -
 Drum Clean (Bubanj čist): Programm za čišćenje i održavanje bubnja i spremnika za sapunicu, npr. prije 1. pranja kod učestalog pranja na niskim temperaturama pranja (40 °C i niže) ili kod stvaranja neugodnih mirisa nakon duže odsutnosti. Napomene ■ Pokrenite program za održavanje bubnja bez umetanja rublja. ■ Za to koristite deterdžent u prašku. ili deterdžent koji sadrži izbjeljivač. Kako biste spriječili stvaranje pijene, koristite samo polovicu količine sredstva za pranje koju je preporučio proizvođač deterdženta. Ne upotrebljavajte sredstvo za pranje vune ili finog rublja.	0 kg; 90 °C 1200 okr/min -
 Delicate/Silk (Osjetljivo / Svila): za osjetljive, perive tkanine, npr. svila, saten, sintetika ili mješani materijal (npr. svilene bluze, svileni šalovi) Napomena: Koristite deterdžent za strojno pranje primjeren za osjetljivo rublje ili svilu.	2 kg;  - 40 °C ---, 0 - 800 okr/min Speed Eco =    predpranje,  voda+ 
 Duvet : (Popluni): tkanine punjene sa sintetičkim vlaknima koje možete prati u perilici, jastuci, prekrivači, pokrivači; primjereno i za punjenja s perjem Napomena: Velike komade prati posebno. Koristite sredstvo za fino pranje - molimo obratite pozornost na oznaku za održavanje. Sredstvo za pranje dozirajte štedljivo.	2 kg;  - 60 °C ---, 0 - 1200 okr/min Speed Eco =    predpranje,  voda+ 
 Sportswear (Sportska): tekstil od mikrovlakana za sport i rekreaciju Napomene ■ Rublje se ne smije tretirati omekšivačem. ■ Prije pranja temeljito očistite ladicu za deterdžent (sve odjeljke) od ostataka omekšivača.	2 kg;  - 40 °C ---, 0 - 800 okr/min Speed Eco =    predpranje,  voda+ 
* maks. broj okretaja centrifuge ovisno o programu i modelu ** smanjeno punjenje kod postavke Speed	

Program/vrsta rublja/napomene	Postavke
 Dark wash (Tamno pranje): tamna pamučna tkanina i tamna tkanina koja je laka za njegu; tekstil prati na način da perete unutarnju stranu	3,5 kg;  - 40 °C ---, 0 - 1200 okr/min Speed Eco =    , predpranje,  voda+ 
 Shirt/Blouses (Shirt / Bluze): košulje/bluze koje ne treba glačati od pamuka, lana, sintetike ili miješanoga sastava	2 kg;  - 60 °C ---, 0 - 800 okr/min Speed Eco =    , predpranje,  voda+ 
Napomene ■ Kod postavke Knitterschutz se košulje/bluze samo kratko centrifugiraju, za vješanje dok su još vlažne. —> Efekt samozaglađivanja ■ Svilene košulje/bluze /osjetljivi materijali prati u programu Delicate/Silk .	
 AllergyPlus : otporne tkanine od pamuka ili lana	7,5 kg/5** kg;  - 60 °C ---, 0 - 1200* okr/min Speed Eco =    , predpranje,  voda+ 
Napomena: Posebno pogodan kod povećanih higijenskih zahtjeva ili posebno osjetljive kože na temelju produženog pranja na definiranoj temperaturi, višoj razini vode i dužeg ispiranja.	
* maks. broj okretaja centrifuge ovisno o programu i modelu ** smanjeno punjenje kod postavke Speed	



Vrijednosti potrošnje

Potrošnja energije i vode, trajanje programa i preostala vlaga glavnih programa pranja

(okvirni podaci)

Program	Punjenje	Potrošnja energije*	Potrošnje vode*	Trajanje programa*
Pamuk 20 °C	9 kg	0,25 kWh	90 l	2 ¾ h
Pamuk 40 °C	9 kg	1,10 kWh	90 l	3 h
Pamuk Eco** <60°C	9 kg	0,92 kWh	57 l	4 ¾ h
Pamuk Eco** <60°C	4,5 kg	0,60 kWh	46 l	4 ¾ h
Pamuk Eco** <60°C	4,5 kg	0,42 kWh	46 l	4 ¾ h
Pamuk 60 °C	9 kg	1,06 kWh	90 l	2 ¾ h
Pamuk 90 °C	9 kg	2,14 kWh	100 l	2 ¾ h
Lako za njegu 40 °C	4 kg	0,71 kWh	64 l	2 h
Brzo/miješano 40 °C	4 kg	0,60 kWh	45 l	1 ¼ h
Fino/Svila 30 °C	2 kg	0,19 kWh	37 l	¾ h
Vuna 30 °C	2 kg	0,19 kWh	41 l	¾ h

Program	okvirni podaci o preostaloj vlazi***		
	WAT28...	WAT24...	WAT20...
	maks. 1400 okr/min	maks. 1200 okr/min	maks. 1000 okr/min
Pamuk	48 %	53 %	62 %
Lako za njegu	40 %	40 %	40 %
Fino/Svila	30 %	30 %	30 %
Vuna	45 %	45 %	45 %

* Vrijednosti odstupaju od navedenih vrijednosti ovisno o tlaku vode, tvrdoći vode, ulaznoj temperaturi vode, temperaturi prostorije, vrsti rublja, njegovoj količini i zaprljanosti, korištenom sredstvu za pranje, oscilacijama napona u električnoj mreži i odabranim dodatnim funkcijama.

** Postavka programa za ispitivanje i oznaku energije prema smjernici 2010/30/EU s hladnom vodom (15 °C). Informacija o temperaturi programa orijentira se prema temperaturi koja se nalazi na etiketi za njegu na tkanini. Stvarna temperatura za pranje može se razlikovati od navedene temperature programa zbog uštede energije.

*** Podaci o preostaloj vlazi na temelju ograničenja broja okretaja centrifuge i maksimalnom punjenju ovisnima o programu.

WAT24461BY

9001469645 (9906)

