

Overview of programmes

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
Name of programme Short explanation of the programme or the fabric for which it is suitable.	Max. load; * Reduced load for SpeedPerfect  function Temperature that can be selected Spin speed that can be selected; ** Max. spin speed, depending on the model Possible programme settings
 Cottons Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen Note: The SpeedPerfect  setting is suitable as a short programme for lightly soiled laundry.	Max. 7 kg/4* kg cold - 40 - 90 °C - - - ... 400-1200** rpm  ,  , 
 Synthetics Programme for cleaning synthetic or blended fabric-made laundry	Max. 4 kg cold - 40 - 60 °C - - - ... 400-1200** rpm  ,  , 
 Mix Load Items made from cotton, linen, or synthetic or blended fabrics.	Max. 3.5 kg cold - 40 °C - - - ... 400-1200** rpm  ,  , 
 Delicates/Silk For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarves) Note: Use a detergent which is suitable for machine washing delicates or silk.	Max. 2 kg Cold - 40 °C - - - ... 400... 800** rpm  ,  , 
* Reduced load for the  Speed setting ** Maximum spin speed depends on the program and mode *** depending on the model	

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
 Wool Hand or machine-washable fabrics made of wool or that contain wool; particularly gentle wash programme to prevent shrinkage of laundry, with longer programme breaks (fabrics rest in the detergent solution)	Max. 2 kg Cold - 40 °C - - - ... 400 - 800** rpm -
Notes ■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep. ■ Use a detergent which is suitable for machine washing wool.	
 Drum Descale Programme for cleaning and caring for the drum and the inner tub, Descaling helps to remove lime scale build up due to hard water	- Cold - -
Notes ■ Run programme without laundry. ■ Use only Bosch descaler for front-loading washing machines. Do not use any other additional cleaning agents or mix the descaler with detergent.	
 Rinse Extra rinse with spin	- - - - - ... 400 ... 1200** rpm 
 Spin/Drain  Extra spin with speed that can be selected If only the drain cycle is required, set the spin speed to - - -.	- - - - - ... 400 ... 1200** rpm -
Super 15/30 min  Programme for cleaning lightly soiled small amounts of laundry in an very short time Note: Longer programme duration (approx. 30 minutes) for deactivated SpeedPerfect  setting	Max. 2 kg/3.5* kg Cold - 40 °C - - - ... 800 ... 1200** rpm 
60°Cottons Label  Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen Note: The actual washing temperature may differ from the stated programme temperature for energy-saving reasons; the washing performance corresponds to the selected temperature.	Max. 7*** kg 60 °C - - - ... 400 - 1200** rpm  ***
* Reduced load for the  Speed setting ** Maximum spin speed depends on the program and mode *** depending on the model	

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
Lingerie  For cleaning delicate underwear made of velvet, silk, satin, lycra or lace.	Max. 1 kg cold - 30 - 40 °C - - - ... 400 - 600** rpm ≡  ,  , 
Kidswear  Hard-wearing textiles made of cotton or linen or blended fabrics. Suitable for childrens clothing.	Max. 7 kg/4* kg cold - 40 °C - - - ... 400 - 1200** rpm ≡  , 
Allergy Plus  Hard-wearing textiles made of cotton or linen Note: Especially suitable for increased hygienic demands or particularly sensitive skin on account of prolonged washing at a defined temperature, with a higher water level and longer rinsing time	Max. 6.5 kg/4* kg cold - 40 - 60 °C - - - ... 400 ... 1200** rpm ≡  ,  , 
Shirts  Dark fabrics made of cotton and dark easy-care fabrics Turn laundry inside-out before washing.	Max. 2 kg cold - 60 °C - - - ... 400 - 800** rpm ≡  ,  , 
Sportswear  Sportswear and leisurewear made from synthetic or microfibre fabrics or fleece.	Max. 2 kg cold - 30 - 40 °C - - - ... 400 - 800** rpm ≡  ,  , 
* Reduced load for the  Speed setting ** Maximum spin speed depends on the program and mode *** depending on the model	



Consumption rates

Consumption values table

Programme	Load	Energy consumption*	Water*	Programme duration*
Cottons 20 °C	7** kg	0.21 kWh	68 l	2 h
Cottons 40 °C	7** kg	0.75 kWh	69 l	2 h
Cottons 60°C Label	7** kg	0.45 kWh	50 l	2 1/4 h
Cottons 90 °C	7** kg	2.19 kWh	79 l	3 h
Synthetics 40 °C	4 kg	0.71 kWh	51 l	2 h
Daily Wash/Mix Load** 40 °C	3.5 kg	0.46 kWh	44 l	1 1/4 h
Delicates/Silk 30 °C	2 kg	0.17 kWh	34 l	3/4 h
Wool 30 °C	2 kg	0.16 kWh	42 l	3/4 h

* Observed values may deviate from the indicated values due to influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in power supply and selected additional functions.

** Programme names and max Load depends on the model.

WAK2426SIN

9001482020 (9909)

