







































Overview of programmes

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
<p>Name of programme</p> <p>Short explanation of the programme or the fabric for which it is suitable.</p>	<p>Max. load;</p> <p>*Reduced load for SpeedPerfect  function</p> <p>Temperature that can be selected</p> <p>Spin speed that can be selected;</p> <p>**Max. spin speed, depending on the model</p> <p>Possible programme settings</p>
<p>Cottons </p> <p>Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen</p> <p>Note: The SpeedPerfect  setting is suitable as a short programme for lightly soiled laundry.</p>	<p>Max. 7 kg/4* kg</p> <p>cold - 40 - 60 °C</p> <p>--- ... 400 - 1000** rpm</p> <p>, </p>
<p>Cottons Label </p> <p>Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen</p> <p>Note: The actual washing temperature may differ from the stated programme temperature for energy-saving reasons; the washing performance corresponds to the selected temperature.</p>	<p>Max. 7*** kg</p> <p>60 °C</p> <p>--- ... 400 - 1000** rpm</p> <p>***</p>
<p>Sportswear </p> <p>Sportswear and leisurewear made from synthetic or microfibre fabrics or fleece.</p>	<p>Max. 2 kg</p> <p>30 °C</p> <p>--- ... 400 - 800** rpm</p> <p>, </p>
<p>Synthetics </p> <p>Programme for cleaning synthetic or blended fabric-made laundry</p>	<p>Max. 4 kg</p> <p>30 °C</p> <p>--- ... 400 - 1000** rpm</p> <p>, </p>
<p>Mix Load </p> <p>Items made from cotton, linen, or synthetic or blended fabrics.</p>	<p>Max. 3.5 kg</p> <p>30 °C</p> <p>--- ... 400. - 1000** rpm</p> <p>, </p>
<p>* reduced load for the  Speed setting</p> <p>** maximum spin speed depends on the program and model</p> <p>*** depending on the model</p>	

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
<p>Drum Descale </p> <p>Programme for cleaning and caring for the drum and the inner tub, Descaling helps to remove lime scale build up due to hard water</p> <p>Notes</p> <ul style="list-style-type: none"> ■ Run programme without laundry. ■ Use only Bosch descaler for front-loading washing machines. Do not use any other additional cleaning agents or mix the descaler with detergent. 	<p>-</p> <p>Cold</p> <p>1000**rpm</p> <p>-</p>
<p>Spin/Drain </p> <p>Extra spin with speed that can be selected</p> <p>If only the drain cycle is required, set the spin speed to - - - .</p>	<p>-</p> <p>-</p> <p>- - - ... 400... 1000** rpm</p> <p>-</p>
<p>Super 15/30 min </p> <p>Extra-short programme of approx. 15 minutes, suitable for small items of lightly soiled laundry</p> <p>Note: Longer programme duration (approx. 30 minutes) for deactivated SpeedPerfect  setting</p>	<p>Max. 2 kg/3.5* kg</p> <p>-</p> <p>- - - ... 400 ... 1000** rpm</p> <p></p>
<p>Monsoon </p> <p>Items made from cotton or synthetic or blended fabrics. Quick washing programme suitable for freshening up laundry that has been soaked in the rain. By reheating the water during the final rinse cycle, the appliance is able to more effectively eliminate water from the laundry during the spin cycle.</p>	<p>Max. 2 kg</p> <p>40 °C</p> <p>- - - ... 400 - 1000** rpm</p> <p>-</p>
<p>Lingerie </p> <p>For cleaning delicate underwear made of velvet,silk,satin,lycara or lace.</p>	<p>Max. 1 kg</p> <p>Cold</p> <p>- - - ...400 - 600** rpm</p> <p>, </p>
<p>Kidswear </p> <p>Hard-wearing textiles made of cotton or linen or blended fabrics.Suitable for childrens clothing.</p>	<p>Max. 7 kg/4* kg</p> <p>40 °C</p> <p>- - - ... 400 ... 1000** rpm</p> <p>, </p>
<p>* reduced load for the  Speed setting</p> <p>** maximum spin speed depends on the program and model</p> <p>*** depending on the model</p>	

Programme/type of laundry/information	Settings/Presettings of the programmes are highlighted in bold
 Delicates/Silk For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarves) Note: Use a detergent which is suitable for machine washing delicates or silk.	Max. 2 kg 30 °C - - - ... 400 - 800** rpm  , 
 Wool  Hand or machine-washable fabrics made of wool or that contain wool; particularly gentle wash programme to prevent shrinkage of laundry, with longer programme breaks (fabrics rest in the detergent solution) Notes <ul style="list-style-type: none"> ■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep. ■ Use a detergent which is suitable for machine washing wool. 	2 Kg Cold - - - ... 400 - 800** rpm -
 Rinse Extra rinse with spin	- - - - - ... 400 - 1000** rpm 
* reduced load for the  Speed setting ** maximum spin speed depends on the program and model *** depending on the model	



Consumption rates

Consumption values table

Programme	Load	Energy consumption*	Water*	Programme duration*
Cottons cold	7 kg	0.21 kWh	68 l	2 h
Cottons 40 °C	7 kg	0.75 kWh	69 l	2 h
Cottons 60 °C Label	7 kg	0.45 kWh	50 l	2 3/4 h
Synthetics 30 °C	4 kg	0.71 kWh	51 l	2 h
Daily Wash/Mix Load** 30 °C	3.5 kg	0.46 kWh	44 l	1 1/4 h
Delicates/Silk 30 °C	2 kg	0.17 kWh	34 l	3/4 h
cold Wool	2 kg	0.16 kWh	42 l	3/4 h
* Observed values may deviate from the indicated values due to influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in power supply and selected additional functions.				
** Programme names depending on the model				

WAK20164IN

9001494255 (9911)

