





























## Overview of programmes

Program/type of laundry/information	Settings
<b>Name of the program:</b> Brief explanation of the program and for which textiles it is suitable.	max. load, temperature (☀ = cold) Spin speed* additional settings that can be selected
<b>Cottons</b>  : hard-wearing textiles, heat-resistant textiles made of cotton or linen <b>Note:</b> The SpeedPerfect  setting is suitable as a short programme for lightly soiled laundry.	8 kg/5** kg; ☀ - 90 °C ----, 400 - 1400* rpm   ,  , 
<b>60° Cottons Label</b>  : hard-wearing textiles, heat-resistant textiles made of cotton or linen <b>Note:</b> The actual washing temperature may differ from the stated programme temperature for energy-saving reasons; the washing performance corresponds to the selected temperature.	8*** kg; ☀*** ----, 400 - 1400* rpm  ,  ,  ***
<b>Synthetics</b>  : Programme for cleaning synthetic or blended fabric-made laundry	4 kg; ☀ - 60 °C ----, 0 - 1200* rpm   ,  , 
<b>Mix Load</b>  : Items made from cotton, linen, or synthetic or blended fabrics.	4 kg; ☀ - 40 °C ----, 0 - 1400* rpm   ,  , 
<b>Delicates/Silk</b>  : for delicate, washable textiles, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarf) <b>Note:</b> Use a detergent suitable for machine-washing delicates or silk.	2 kg; ☀ - 40 °C ----, 0 - 800 rpm   ,  , 
 <b>Wool</b>  : hand or machine-washable wool or rich-wool textiles. Especially gentle wash program to prevent shrinkage, longer program pauses (textiles rest in wash liquor).	2 kg; ☀ - 40 °C ----, 0 - 800 rpm -
<b>Notes</b> <ul style="list-style-type: none"> <li>■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep.</li> <li>■ Use a detergent that is suitable for machine-washing wool.</li> </ul>	
* maximum spin speed depends on the program and model ** reduced load for the  <b>Speed</b> setting *** depending on the model	

Program/type of laundry/information	Settings
<b>Drum Descale</b>  : Programme for cleaning and caring for the drum and the inner tub, Descaling helps to remove lime scale build up due to hard water	 (Cold) 1200* rpm
<b>Notes</b> <ul style="list-style-type: none"> <li>■ Run programme without laundry.</li> <li>■ Use only Bosch descaler for front-loading washing machines. Do not use any other additional cleaning agents or mix the descaler with detergent</li> </ul>	-
 <b>Spin/Drain</b>  : Extra spin with selectable spin speed. Only to be emptied, set spin speed to 0.	-; - 0 - 1400* rpm
<b>Note:</b> The display of the Ready-in time is only updated once the program is restarted.	-
 <b>Quick 15/30 min</b> : extra short program of approx. 30 minutes, suitable for small items of lightly soiled laundry	2/3.5 kg;  - 40 °C ----, 0 - 1200* rpm
<b>Note:</b> When selecting the  <b>Speed</b> setting, the program <b>Super 15</b> is run.	
 <b>Allergy Plus</b> : hard-wearing fabrics made of cotton or linen	6.5 kg;  - 60 °C
<b>Note:</b> Particularly suited to washing items that need to be hygienically clean and especially kind to sensitive skin thanks to the longer wash cycle at a defined temperature, higher water level and longer spin cycle.	----, 400 - 1400* rpm   ,  , 
 <b>Lingerie</b> : For cleaning delicate underwear made of velvet, silk, satin, lycara or lace.	1 kg;  - 40 °C ----, 0 - 600 rpm   , 
 <b>Jeans/Dark Wash</b> : Dark textiles made of cotton and dark easy-care textiles. Wash textiles inside out	3.5 kg;  - 40 °C ----, 0 - 1200* rpm   , 
 <b>Sportswear</b> : Sportswear and leisurewear made from synthetic or microfibre fabrics or fleece.	2 kg;  - 40 °C ---, 0 - 800* rpm   ,  , 
 <b>Shirts</b> : Non-iron shirts or blouses made of cotton, linen, synthetic fibres or blended fabrics	2 kg;  - 60 °C ----, 0 - 800* rpm
<b>Note:</b> Use the <b>Delicates/Silk</b> program to wash shirts/blouses made of silk/delicate fabrics.	  ,  , 
 <b>Rinse</b> : extra rinse with selectable spin speed	-; - ----, 0 - 1400* rpm 
* maximum spin speed depends on the program and model ** reduced load for the  <b>Speed</b> setting *** depending on the model	



## Consumption values table

Programme	Load	Energy consumption*	Water*	Programme duration*
Cottons 20 °C	8 kg	0,25 kWh	84 l	2 1/2 h
Cottons 40 °C	8 kg	1,01 kWh	86 l	3 h
Cottons 60 °C Label	8 kg	0,64 kWh	64 l	3 1/2 h
Cottons 90 °C	8 kg	1,90 kWh	94 l	2 1/2 h
Synthetics 40 °C	4 kg	0,79 kWh	65 l	2 h
Daily Wash/Mix Load**40 °C	4 kg	0,58 kWh	44 l	1 1/4 h
Delicates/Silk 30 °C	2 kg	0,20 kWh	36 l	3/4 h
Wool 30 °C	2 kg	0,17 kWh	41 l	3/4 h
* Observed values may deviate from the indicated values due to influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in power supply and selected additional functions.				
** Programme names depending on the model				

**en** Supplementary sheet for the installation and operating instructions

**WAT2846WIN WAT2846SIN WAT24464IN WAT24463IN**

**9001496028 (0003)**

